

Structural Engineering Library

Version 5.8

by Michael D. Brooks, S.E., P.E.

*A product of
ENERCALC, INC.*

ENERCALC

©1983-2003 ENERCALC Engineering Software

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Publisher

ENERCALC, INC. □

Managing Editor

Michael D. Brooks, S.E., P.E.

ENERCALC Engineering Software

Post Office Box 188
Corona del Mar, CA 92625

(949) 645-0151

(800) 424-2252

Fax: (949) 645-3881

Technical Services: (949) 645-0441

Sales: info@enercalc.com

Tech Support : support@enercalc.com

Web : www.enercalc.com

Vesion 5.8 User's Reference

December 2003

Newport Beach, CA

Table of Contents

Foreword	1
Part I Welcome	5
Part II Structural Analysis Modules	8
1 Single Span Beam Analysis.....	9
2 Beam on Elastic Foundation.....	22
3 Rigid Diaphragm Torsional Analysis.....	35
4 Section Properties.....	46
5 Pole Formula.....	53
6 Pile Group Load Distribution.....	61
7 Multi-Story Wind Load Analysis.....	68
8 Multi-Story Seismic Load Analysis.....	77
9 Multi-Story Column Load Analysis.....	85
Part III Wood Design Modules	92
1 Multi Span Timber Beam.....	93
2 Timber Beam & Joist Design.....	107
3 General Timber Beam.....	117
4 Series of Cantilevered Beams.....	134
5 Timber Column.....	153
6 Plywood Shear Wall.....	165
7 Horizontal Plywood Diaphragm.....	180
8 High-Load Plywood Diaphragm.....	193
9 Timber Ledger.....	206
10 Bolt Group in Timber Member.....	215
Part IV Steel Design Modules	224
1 Multi-Span Steel Beam.....	225
2 Single Span Steel Beam.....	242
3 Steel Beam w/Torsion.....	260
4 Steel Column.....	279
5 Composite Steel Beam.....	295
6 Base Plate.....	321
7 Bolt Group.....	332

Foreword

This software system was designed and developed to give the practicing Structural Engineer a tool to rapidly perform structural analysis and design of building components.

The design philosophy has remained the same for the last 20 years.....provide software that is a "fill-in'the-blanks" tool with instant recalculation and review of the results.

We thank the thousands of engineers who have purchased ENERCALC software over the last two decades helping this software develop to where it is today.

Part



1 Welcome

Welcome To The Structural Engineering Library

You've chosen one of the most respected Structural Engineering software packages available today. In continuous development since 1983 , Version 5.8 is the culmination of years of development and refinement from suggestions of engineers worldwide.

This document provides detailed documentation for all the modules contained in Vesion 5.8 of the Structural Engineering Library.

Please refer to Volume I for general information including licensing, installation, usage instructions, and a sample session.

Part



2 Structural Analysis Modules

The programs in this section provides mostly analysis capabilities. Design in a particular material is not provided.

Single Span Beam Analysis

Single Span Beam Analysis analyzes single span beams with cantilevers and a variety of end restraints. Up to 30 point, moment, and uniform/trapezoidal loads can be applied. Reactions, shears, moments, deflections, and graphic diagrams are given.

Beam on Elastic Foundation

Beam on Elastic Foundation provides all of Hetenyi's and Roark's work in one fast program. A beam may have any combination of free, guided, pinned, fixed, and semi-infinite supports. Up to 23 point, moment, and uniform/trapezoidal loads may be applied. Shear, moment, deflection, rotations and graphic diagrams given.

Torsional Analysis of Rigid Diaphragms

Torsional Analysis of Rigid Diaphragms can calculate the center of rigidity, torsional moments, minimum eccentricities, and give resultant force to attached walls oriented at any angle. A stiffness approach is used to generate matrices which are solved for forces. End fixity combination and elastic modulus can be varied for each wall and all cases of eccentricity are considered.

General Section Properties

General Section Properties can determine area, neutral axes, inertia, fiber distances, section modulus, and radii of gyration for sections combining up to 11 bar/pipe shapes and 3 rolled steel sections.

Pole Footing Design

Pole Footing Design determines required embedment depths for shaft type footings with shear and moment applied at ground surface, with or without lateral surface restraint.

Pile Group Load Distribution

Pile Group Load Distribution distributes a single vertical load to a maximum of ten piles using direct distribution and skew bending theory.

Multi-Story Seismic Force Distribution

Multi-Story Seismic Force Distribution gives story shears and moments on a multi-story structure by vertically distributing base shear on the structure using '94 UBC code.

Multi-Story Wind Force Distribution

Multi-Story Wind Force Distribution gives story shears and moments on a multi-story structure by vertically distributing '88 UBC wind loads and modification factors.

Multi-Story Column Load Summary

Multi-Story Column Load Summary provides a tabular format for accumulating area loads on multi-story columns. Loads may be varied per floor and reduction factors considered.

2.1 Single Span Beam Analysis

Overview

This program provides analysis of single span beams with a variety of loading and support conditions. Maximum moments, shears, reactions, and deflections are given. The basic ability of this program is also contained in the various beam design programs in the steel, concrete, and timber divisions. This program performs a more detailed analysis and offers more loading options than most of the design programs.

A single span beam with optional cantilevers can be analyzed, and the end supports can be modified to give almost any configuration.....simple supports, propped cantilever, fixed at both ends, pure cantilever, or double cantilever.

Loads that can be applied are extensive. Uniform, partial length, trapezoidal, concentrated, and moment type load can be entered. For partial length and trapezoidal loads, entry is very simple by just entering the start and end magnitudes and locations. The program uses the locations to determine how the load is applied to center and cantilever spans.

NOTE! All load locations are in reference to the LEFT support. Distances are positive toward the right support, and negative over the left cantilever. The program also provides a QUERY section, allowing you to enter locations along the span where you would like to investigate the conditions.

ENERCALC c:\ECSS\EXAMPLES.ECW - Single Span Beam Analysis

Single Span Beam Analysis

Tools & Settings ? Help Print Cancel Save

General | Uniform | Point | Trapezoidal | Moments | Query

Results | Sketch | Diagrams | Printing

Description: **Double Cantilevered Beam**

Center Span 40.000 ft

Left Cantilever 10.000 ft

Right Cantilever 12.000 ft

End Fixity

Pin-Pin Fix-Pin Fix-Fix

Pin-Fix Fix-Free

Moment of Inertia 8,352.000 in⁴

Elastic Modulus 29,000.0 ksi

Maximum Moment 324.38 k-ft at 20.00 ft

Maximum Shear 30.901 k at Left Support

Maximum Deflection -0.2930 in at 20.25 ft

Left Reaction 51.361 k

Right Reaction 49.099 k

Moments...

Max. +@ Center 324.38 k-ft at 20.00 ft

Max. - @ Center -137.97 k-ft at 0.00 ft

@ Left End Support -137.97 k-ft

@ Right End Support -137.60 k-ft

Shears...

@ Left 30.90 k

@ Right 30.70 k

Maximum 30.90 k

Reactions...

@ Left 51.36 k

@ Right 49.10 k

Deflections...

@ Center -0.293 in at 20.25 ft

@ Left Cant. 0.149 in at -10.00 ft


@ Right Cant. 0.180 in at 52.00 ft

Assumptions and Limitations

- The program calculates all values by dividing the beam up into 500 sections and performing moment-area integration for deflections. Calculated values generally will be within 1/5000th of the actual number.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow. The example is for a double-cantilevered beam with loads applied to center span and cantilever. Because this program does not do automatic calculations for multiple locations of live load only one set of results are given. Here is a basic sketch of the geometry and loading:



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General	Uniform	Point	Trapezoidal	Moments	Query
Description		Double Cantilevered Beam			
Center Span		40.000	ft		
Left Cantilever		10.000	ft		
Right Cantilever		12.000	ft		
End Fixity					
<input checked="" type="radio"/> Pin-Pin <input type="radio"/> Fix-Pin <input type="radio"/> Fix-Fix <input type="radio"/> Pin-Fix <input type="radio"/> Fix-Free					
Moment of Inertia		8,352.000	in ⁴		
Elastic Modulus		29,000.0	ksi		

Center Span, Left Cantilever, Right Cantilever

Enter the span lengths for center span and cantilevers. When an end fixity is specified as Fixed, any entry for cantilever length or loads that extend past the fixed support will be ignored. Distributed loads that extend past the fixed support will simply be truncated.

End Fixity

This entry enable you to specify the end fixity combination for the beam. The order of the words is refers to the left-right ends of the beam.

- "Pin" means that the beam end is free to rotate but fixed against X or Y (horizontal or vertical) movement.
- "Free" means that the end is completely free to move in all directions....basically a cantilever end.
- "Fixed" is like "Pin" but rotation is also prevented.....just as if the beam end were buried in stone.

Inertia & Elastic Modulus

Entry of both these items is required to for the program to calculate deflections. If one or both of these entries is zero deflections will be "0.0".

Uniform Tab

This tab provides entries for you to apply full-length uniform loads to the center span and cantilevers. Positive values act with the force of gravity and deflect a beam downward resulting in compression on the top fiber.

General	Uniform	Point	Trapezoidal	Moments	Query
Center Uniform Loads...					
# 1	<input type="text" value="0.400"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
# 2	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
# 3	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
# 4	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
LEFT Cant Uniform Loads...			RIGHT Cant Uniform Loads...		
# 1	<input type="text" value="0.400"/>	<input type="text"/>	# 1	<input type="text" value="0.400"/>	<input type="text"/>
# 2	<input type="text"/>	<input type="text"/>	# 2	<input type="text"/>	<input type="text"/>
# 3	<input type="text"/>	<input type="text"/>	# 3	<input type="text"/>	<input type="text"/>
# 4	<input type="text"/>	<input type="text"/>	# 4	<input type="text"/>	<input type="text"/>

Point Tab

This tab provides entries so you can enter up to 14 point loads. The "Location" is the distance from the left support to the location of the point load. If the "Location" value is negative then it is on the left cantilever. If the value exceeds the center span length then it is on the right cantilever. Cases where negative Locations are entered with no left cantilever or a "Fixed" left support are ignored. Similar behavior happens for Location values that are longer than the Center Span distance. Positive values act with the force of gravity and deflect a beam downward resulting in compression on the top fiber.

	Magnitude k	Location ft
#1	9.600	-10.000
#2	4.110	-2.000
#3	25.000	20.000
#4	12.000	26.000
#5	6.000	44.000
#6	6.000	52.000
#7		0.000
#8		0.000
#9		0.000
#10		0.000
#11		0.000
#12		0.000
#13		0.000
#14		0.000

--> All load locations measured from LEFT support

Trapezoidal Tab

Up to 8 full or partial length uniform loads with varying start & end magnitudes can be specified on this tab. The "Left/Start" magnitude refers to the left hand side of the load. Magnitudes can be positive or negative values at both or either ends. The "Location" is the distance from the left support to the location of the Startpoint or Endpoint of the load. If the "Location" value is negative then it is on the left cantilever. If the value exceeds the center span length then it is on the right cantilever. Cases where negative Locations are entered with no left cantilever or a "Fixed" left support are ignored. Similar behavior happens for Location values that are longer than the Center Span distance. Positive values act with the force of gravity and deflect a beam downward resulting in compression on the top fiber.

General	Uniform	Point	Trapezoidal	Moments	Query
Magnitude....	#1	#2	#3		
at Left/Start	0.275	0.200		k/ft	
at Right/End	0.275	0.200	0.310	k/ft	
X-Left	-10.000	44.000	0.000	ft	
X-Right	20.000	52.000	20.000	ft	
Magnitude....	#4	#5	#6		
at Left/Start				k/ft	
at Right/End				k/ft	
X-Left	0.000	0.000	0.000	ft	
X-Right	0.000	0.000	0.000	ft	
Magnitude....	#7	#8			
at Left/Start			k/ft		
at Right/End			k/ft		
X-Left	0.000	0.000	ft		
X-Right	0.000	0.000	ft		

-> All load locations measured from LEFT support

Moment Tab

This tab provides entries so you can enter up to 8 moments. The "Location" is the distance from the left support to the location of the point load. If the "Location" value is negative then it is on the left cantilever. If the value exceeds the center span length then it is on the right cantilever. Cases where negative Locations are entered with no left cantilever or a "Fixed" left support are ignored. Similar behavior happens for Location values that are longer than the Center Span distance. Positive values act with the force of gravity and deflect a beam downward resulting in compression on the top fiber.

General	Uniform	Point	Trapezoidal	Moments	Query
Center Span....					
Distance	<input type="text" value="20.000"/>	ft			
Moment		324.38	k-ft		
Shear		-10.70	k		
Deflection		-0.29290	in		
Left Cantilever....					
Distance	<input type="text" value="0.000"/>	ft			
Moment		0.00	k-ft		
Shear		0.00	k		
Deflection		0.00000	in		
Right Cantilever...					
Distance	<input type="text" value="40.000"/>	ft			
Moment		-137.60	k-ft		
Shear		-30.70	k		
Deflection		0.00000	in		

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This tab contains the resulting calculated values for the beam analysis.

Results	Sketch	Diagrams	Printing
Maximum Moment	324.38	k-ft	at 20.00 ft
Maximum Shear	30.901	k	at Left Support
Maximum Deflection	-0.2930	in	at 20.25 ft
Left Reaction	51.361	k	
Right Reaction	49.099	k	
Moments...			
Max. + @ Center	324.38	k-ft	at 20.00 ft
Max. - @ Center	-137.97	k-ft	at 0.00 ft
@ Left End Support	-137.97	k-ft	
@ Right End Support	-137.60	k-ft	
Shears...			
@ Left	30.90	k	
@ Right	30.70	k	
Maximum	30.90	k	
Reactions...			
@ Left	51.36	k	
@ Right	49.10	k	
Deflections...			
@ Center	-0.293	in	at 20.25 ft
@ Left Cant.	0.149	in	at -10.00 ft
@ Right Cant	0.180	in	at 52.00 ft

Maximum Moment & Location

The maximum moments at location is shown with it's location measured from the left support. This is an absolute value maximum with the sign intact. The actual span lengths increments used to determine the accuracy depend upon the center span and cantilever lengths. A beam with no cantilevers will be divided up into 500 increments. When cantilevers are used, each span is divided into a portion of the 500 increments according to its percentage of the total beam length. This is the maximum positive moment (compression at top of beam) between the supports. The entire length of the beam is scanned, and if compression occurs over a support due to a cantilever this will be included also.

Moments....Max.+, Max. -, Left & Right End Support

These values are the maximum and minimum values for the center span and the actual moment at the end support. M The entire length of the beam is scanned, and if compression occurs over a support due to a cantilever this will be included also.

Shears

These values are the maximum shear at each support. This value is determined by checking two items:

- At ends without cantilevers or with fixed ends, the end shear equals the support reaction.

- At ends with cantilevers, the end shear is calculated by determining the total of all loads acting on the cantilever, or by the reaction less loads acting on the cantilever).

Reactions


These are the calculated vertical reactions at each support from the given loads.

Maximum Deflections

When both moment of inertia and elastic modulus are non-zero, this area displays the beam deflections for center and cantilever spans (as applicable). All 250 span locations are checked for maximum deflection and both the location and deflection are given.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown.



Diagrams Tab

This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.



Graphic Diagram		Data Table		
Location (ft)	Moment (kip-feet)	Shear (kips)	lection	
0.0000	0.0000	-9.6000	0.1488	
0.1242	-1.2053	-9.6844	0.1471	
0.2485	-2.4211	-9.7687	0.1454	
0.3727	-3.6475	-9.8531	0.1437	
0.4970	-4.8844	-9.9375	0.1420	
0.6212	-6.1318	-10.0219	0.1403	
0.7455	-7.3898	-10.1062	0.1386	
0.8697	-8.6584	-10.1906	0.1369	
0.9940	-9.9375	-10.2750	0.1352	
1.1182	-11.2271	-10.3594	0.1334	
1.2425	-12.5273	-10.4437	0.1317	
1.3667	-13.8381	-10.5281	0.1300	
1.4910	-15.1594	-10.6125	0.1283	
1.6152	-16.4912	-10.6969	0.1266	
1.7395	-17.8336	-10.7812	0.1249	
1.8637	-19.1865	-10.8656	0.1231	
1.9880	-20.5500	-10.9500	0.1214	
2.1122	-21.9240	-11.0344	0.1197	
2.2365	-23.3086	-11.1187	0.1180	
2.3607	-24.7037	-11.2031	0.1162	
2.4850	-26.1094	-11.2875	0.1145	
2.6092	-27.5256	-11.3719	0.1127	
2.7335	-28.9522	-11.4562	0.1110	

Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results | Sketch | Diagrams | Printing

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Uniform Loads	<input checked="" type="checkbox"/>
Point Loads	<input checked="" type="checkbox"/>
Trapezoidal Loads	<input checked="" type="checkbox"/>
Moments	<input checked="" type="checkbox"/>
Query Values	<input checked="" type="checkbox"/>
Summary	<input checked="" type="checkbox"/>

Note: When all are selected, the software will still omit unused sections

[Sample Printout](#)

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949-645-0151
www.enercalc.com

Title : ENERCALC Example Problems Job # 97-000001
Dsgnr: MDB Date: 9:50PM, 22 OCT 03
Description : Collection of example problems

Scope : All programs in the Structural Engineering Library

Rev: 680000 User: KW-0003189, Ver 5.8.0, 10-Sep-2003 (c)1989-2003 ENERCALC Engineering Software
Single Span Beam Analysis Page 1
c:\eob\examples_e.obr\Analysis_Calcs

Description Double Cantilevered Beam

General Information

Center Span	40.00 ft	Moment of Inertia	8,352,000 in ⁴
Left Cantilever	10.00 ft	Elastic Modulus	29,000 ksi
Right Cantilever	12.00 ft	Beam End Fixity	Pin-Pin

Uniform Loads

On Center Span...	On Left Cantilever...	On Right Cantilever...
# 1	# 1	# 1
0.400 k/ft	0.400 k/ft	0.400 k/ft

Point Loads

Magnitude	9.600 k	4.110 k	25.000 k	12.000 k	6.000 k
Location	-10.000 ft	-2.000 ft	20.000 ft	26.000 ft	44.000 ft
Magnitude	6.000 k	k	k	k	k
Location	52.000 ft	ft	ft	ft	ft

Trapezoidal Loads

Magnitude @ Left	0.275 k/ft	0.200 k/ft	k/ft	k/ft
Magnitude @ Right	0.275 k/ft	0.200 k/ft	0.310 k/ft	k/ft
Dist. To Left Side	-10.000 ft	44.000 ft	ft	ft
Dist. To Right Side	20.000 ft	52.000 ft	20.000 ft	ft

Query Values

Center Location	20.000 ft	Left Cant	0.000 ft	Right Cant	40.000 ft
Moment	324.38 k-ft		0.00 k-ft		-137.60 k-ft
Shear	-10.70 k		0.00 k		-30.70 k
Deflection	-0.29290 in		0.00000 in		0.00000 in

Summary

Moments...		Shears...		Reactions...	
Max + @ Center	324.38 k-ft at 20.00 ft	@ Left	30.90 k	@ Left	51.36 k
Max - @ Center	-137.97 k-ft at 0.00 ft	@ Right	30.70 k	@ Right	49.10 k
@ Left Cant	-137.97 k-ft	Maximum	30.90 k		
@ Right Cant	-137.60 k-ft	Deflections...			
Maximum -	324.38 k-ft	@ Center	-0.293 in at 20.25 ft		
		@ Left Cant.	0.149 in at -10.00 ft		
		@ Right Cant	0.180 in at 52.00 ft		

2.2 Beam on Elastic Foundation

This program provides analysis of solid beams continuously supported by an elastic material. Typical applications are for concrete beams supporting uniform and concentrated building loads, transferring the loads to the underlying soil.

This program is based upon the elastic beam formulas presented in **Formulas for Stress and Strain**, 5th Ed., by Raymond J. Roark and Warren C. Young (Article 7.5 and

Table 7 & 8) and **Beams on Elastic Foundation** by M. Hetenyi, University of Michigan Press, 1946.

NOTE! THIS PROGRAM ASSUMES ELASTIC BEAM IS ALWAYS IN COMPRESSION. No provision is made when the beam has upward deflection. In this instance the beam is actually "pulling" the soil upward instead ignoring the soil/beam interaction. This is so because of the nature of the equations used.

The established formulas have been formulated into computer code that is used by this program, which can analyze beams considering:

- Left end free, guided, pinned, or free.
- Right end free, guided, pinned, free, or infinite.
- Up to 7 uniform loads, 11 concentrated loads, and 5 applied moments.

Beam on Elastic Foundation

Tools & Settings | ? Help | Print | Cancel | Save

General | Uniform Loads | Point Loads | Moments | Results | Sketch | Diagrams | Printing

Description: Beam with Fixed & Pinned ends

Beam Span: 24.500 ft
 Depth: 18.000 in
 Width: 36.000 in

Left End Fixity: Free Pinned Guided Fixed
 Right End Fixity: Free Pinned Guided Fixed

Elastic Modulus: 3,122.0 ksi
 Subgrade Modulus: 231.000 pci
 I Gross: 17,496.00 in⁴
 Beta*Length: 4.106

Load Factoring...
 Dead Loads: 1.400
 Live Loads: 1.700
 Short Term Loads: 1.550
 Overall Factor: 0.830

Current Load Combination:
 Dead Loads Only
 Dead & Live Loads
 Dead & Short Term Loads
 Dead, Live, & Short Term Loads

Rotation Factor Set To 1.0 ?
 Deflections Factor Set To 1.0 ?
 Soil Pressure Set To 1.0 ?

Results:

Shear:
 Maximum: 31.47 k at 0.000 ft
 Minimum: -11.86 k at 16.071 ft

Moment:
 Maximum: 46.17 k-ft at 8.722 ft
 Minimum: -101.79 k-ft at 0.000 ft

Rotation:
 Maximum: 0.00038 rad at 18.228 ft
 Minimum: -0.00054 rad at 4.806 ft

Deflection:
 Maximum: 0.000 in at 0.000 ft
 Minimum: -0.046 in at 11.270 ft

Soil Press:
 Maximum: 1,330.3 psf at 11.270 ft
 Minimum: 0.0 psf at 0.000 ft

Values @ Beam Ends...

Reaction, Left	31.47 ft	Rotation @ Left	0.00000 rad
Reaction, Right	-2.58 ft	Rotation @ Right	0.00031 rad
M @ Left	-101.79 k-ft	Defl. @ Left	0.000 in
M @ Right	0.00 k-ft	Defl. @ Rt	0.000 in

Assumptions and Limitations


The flexibility of the beam in relation to the spring constant of the soil is limited. In the program you will see the item "**Beta * Length**". The value Beta is a measure of the beams flexibility and is equal to:

$$(\text{Width} * \text{Subgrade Modulus} / (4 * EI)) ^{1/4}$$

According to the reference text when the value $\text{Beta} * \text{Length} > 6.0$ the beam is so flexible that the behavior changes. In this case the program displays a message and no results are given.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab collects all the analysis information except loading.

General	Uniform Loads	Point Loads	Moments
Description Beam with Fixed & Pinned ends			
Beam Span	24.500 ft		
Depth	18.000 in		
Width	36.000 in		
Left End Fixity		Right End Fixity	
<input type="radio"/> Free <input type="radio"/> Pinned <input type="radio"/> Guided <input checked="" type="radio"/> Fixed		<input type="radio"/> Free <input checked="" type="radio"/> Pinned <input type="radio"/> Guided <input type="radio"/> Fixed	
Elastic Modulus	3,122.0 ksi		
Subgrade Modulus	231.000 pci		
I Gross	17,496.00 in ⁴		
Beta*Length	4.106		
Load Factoring...			
Dead Loads	1.400	Current Load Combination	
Live Loads	1.700	<input type="radio"/> Dead Loads Only <input type="radio"/> Dead & Live Loads <input type="radio"/> Dead & Short Term Loads <input checked="" type="radio"/> Dead, Live, & Short Term Loads	
Short Term Loads	1.550		
Overall Factor	0.830		
Rotation Factor Set To 1.0 ?	<input type="checkbox"/>		
Deflections Factor Set To 1.0 ?	<input type="checkbox"/>		
Soil Pressure Set To 1.0 ?	<input checked="" type="checkbox"/>		

Beam Span

Enter the length of the beam between end supports.

Depth & Width

Enter the beam depth and width to be used for calculation of moment of inertia.

End Fixities

Free : Indicates the beam end has no vertical, horizontal, or rotational restraint.

Guided : Indicates the beam end has horizontal restraint, but is not allowed to rotate or move horizontally.

Pinned : Indicates the beam end is free to rotate, but cannot translate vertically or horizontally.

Fixed : Indicates the beam end is fully restrained against vertical and horizontal translation and cannot rotate.

Elastic Modulus

Elastic modulus of the beam's material. Steel is 29,000 ksi; concrete is $57,000 * \sqrt{f'c}$

Subgrade Modulus

The compressive modulus (commonly called the K-Value) of the supporting material. A Soil Engineer, based upon field testing of the soil typically supplies this value. The units for this number are pounds per square inch per inch of deflection, or just an ordinary spring constant.

I-Gross

Calculated using $\text{Width} * \text{Depth}^3 / 12$ for rectangular sections

Beta * Length

Beta is a measure of the difference in flexural stiffness between the beam and foundation. $\text{beta} = (\text{Beam Width} * \text{Subgrade Modulus}) / (4.0 * E * I)^{.25}$. See the major section "Assumptions & Limitations" for more information.

Load Combinations

These entries define load factors to be applied to the loads entered on the next three tabs. You can use these to build ACI type factored load combinations for the analysis run. There is one load factor for Dead, Live and Short Term loads. The "Overall" factor is applied to the summation of the three.

The "Current Load Combination" selection tells the program which loads to use. In our example you can see that "**Dead, Live & Short Term Loads**" has been selected. This means that all loads of all types will have the factors applied to them and then the overall factor applied. In this example the final load applied to the beam is:

$$(1.40 * DL + 1.70 * LL * 1.55 * ST) * 0.83$$

Uniform Loads Tab

This load is a uniform intensity load applied from SLoc (start distance) to ELoc (end distance). The values for dead, live, and short-term loads are combined according to Load Combination. If ELoc is specified greater than Span (except for an Infinite right support), then the excess distance is ignored.

	<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	<u>Location</u>
	k	k	k	ft
#1	12.000			8.750
#2	10.000			16.000
#3				0.000
#4				0.000
#5				0.000
#6				0.000
#7				0.000
#8				0.000
#9				0.000
#10				0.000
#11				0.000

Point Loads Tab

Up to 11 point loads can be applied to the beam, with the dead, live, and short-term components combined according to Load Combination. If the ELoc distance is specified greater than Span (except for Infinite right supports), the load is ignored.

	General	Uniform Loads	Point Loads	Moments
		<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>
#1		<input type="text" value="3.825"/> k/ft	<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft
	Start X	<input type="text" value="0.000"/> ft	End X	<input type="text" value="15.000"/> ft
#2		<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft
	Start X	<input type="text" value="0.000"/> ft	End X	<input type="text" value="0.000"/> ft
#3		<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft
	Start X	<input type="text" value="0.000"/> ft	End X	<input type="text" value="0.000"/> ft
#4		<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft
	Start X	<input type="text" value="0.000"/> ft	End X	<input type="text" value="0.000"/> ft
#5		<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft
	Start X	<input type="text" value="0.000"/> ft	End X	<input type="text" value="0.000"/> ft
#6		<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft
	Start X	<input type="text" value="0.000"/> ft	End X	<input type="text" value="0.000"/> ft
#7		<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft	<input type="text" value=""/> k/ft
	Start X	<input type="text" value="0.000"/> ft	End X	<input type="text" value="0.000"/> ft

Moments Tab

The user may apply up to 5 concentrated moments at any location on the beam. The sign convention follows the right hand rule, where a positive moment applies a torque to the beam in a counter-clockwise direction.

	General	Uniform Loads	Point Loads	Moments
	<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	<u>Location</u>
	k-ft	k-ft	k-ft	ft
#1	<input type="text" value="1.000"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="4.000"/>
#2	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="0.000"/>
#3	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="0.000"/>
#4	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="0.000"/>
#5	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="0.000"/>

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Results	Sketch	Diagrams	Printing
Shear:			
Maximum	31.47 k	at	0.000 ft
Minimum	-11.86 k	at	16.071 ft
Moment			
Maximum	46.17 k-ft	at	8.722 ft
Minimum	-101.79 k-ft	at	0.000 ft
Rotation Rotations Calc'd using Factored Loads			
Maximum	0.00038 rad	at	18.228 ft
Minimum	-0.00054 rad	at	4.606 ft
Deflection Deflections Calc'd using Factored Loads			
Maximum	0.000 in	at	0.000 ft
Minimum	-0.046 in	at	11.270 ft
Soil Press Soil Pressure Calc'd using Unfactored Loads			
Maximum	1,330.3 psf	at	11.270 ft
Minimum	0.0 psf	at	0.000 ft
Values @ Beam Ends...			
Reaction,Left	31.47 ft	Rotation @ Left	0.00000 rad
Reaction,Right	-2.58 ft	Rotation @ Right	0.00031 rad
M @ Left	-101.79 k-ft	Defl. @ Left	0.000 in
M @ Right	0.00 k-ft	Defl. @ Rt	0.000 in

Shear (Reactions)

Maximum positive and negative shears and the locations where they occur are given by checking the span at 250th points.

Moments

Maximum positive and negative moments and the locations where they occur are given by checking the span at 250th points.

Rotation

Maximum positive and negative rotations and the locations where they occur are given by checking the span at 250th points.

Deflection

Maximum positive and negative deflections and the locations where they occur are given by checking the span at 250th points.

Soil Pressure

Using the deflection values given above and multiplying by the subgrade modulus gives the soil pressures. The basis of the calculation is (Spring Force * Distance) = Force. Maximum positive and


negative soil pressures and the locations where they occur are given by checking the span at 250th points.

Values @ Beam Ends

- Reactions Ra and Rb (left and right supports) are given for ends which have Pinned and Fixed support restraints.
- Rotations at Left and Right (left and right ends supports) are given for ends which have Free, Pinned, and Infinite support restraints.
- Moments Ma and Mb (left and right ends supports) are given for ends which have Guided and Fixed support restraints.
- Deflections Da and Db (left and right ends supports) are given for ends which have Free and Guided support restraints.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Diagrams Tab

This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.



Graphic Diagram		Data Table	
Location	Moment	Shear	arDeflec
0.0000	-101.7451	31.5283	0.0000
0.0984	-98.6767	31.0928	-0.0000
0.1968	-95.6509	30.6576	-0.0001
0.2952	-92.6678	30.2229	-0.0001
0.3936	-89.7272	29.7892	-0.0002
0.4920	-86.8290	29.3565	-0.0004
0.5904	-83.9732	28.9253	-0.0005
0.6888	-81.1596	28.4957	-0.0007
0.7871	-78.3880	28.0680	-0.0009
0.8855	-75.6582	27.6424	-0.0011
0.9839	-72.9700	27.2192	-0.0014
1.0823	-70.3232	26.7986	-0.0017
1.1807	-67.7174	26.3808	-0.0020
1.2791	-65.1524	25.9660	-0.0023
1.3775	-62.6280	25.5544	-0.0026
1.4759	-60.1437	25.1462	-0.0030
1.5743	-57.6992	24.7415	-0.0034
1.6727	-55.2942	24.3406	-0.0037
1.7711	-52.9283	23.9436	-0.0042
1.8695	-50.6011	23.5507	-0.0046
1.9679	-48.3122	23.1621	-0.0050
2.0663	-46.0612	22.7778	-0.0055
2.1647	-43.8476	22.3980	-0.0059

Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results	Sketch	Diagrams	Printing
Please select printout sections to be printed...			
General Information			<input checked="" type="checkbox"/>
Uniform Loads			<input checked="" type="checkbox"/>
Point Loads			<input checked="" type="checkbox"/>
Moments			<input checked="" type="checkbox"/>
Summary			<input checked="" type="checkbox"/>
Note: When all are selected, the software will still omit unused sections			

Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems Job # 97-00001
 Dsgnr: MDB Date: 9:47PM, 22 OCT 03
 Description : Collection of example problems
 Scope : All programs in the Structural Engineering Library

Rev. 560000 User: KW-0603186 Ver 5.8.0, 10-Sep-2003 Page 1
 (c)1983-2003 ENERCALC Engineering Software c:\ec55\examp\ples.scw\Analysis Calc

Description Beam with Fixed & Pinned ends

General Information

Beam Span	24.500 ft	Elastic Modulus	3,122.0 ksi	Load Factor	1.400
Depth	18.00 in	Subgrade Modulus	231.00 pci	Dead Loads	1.400
Width	36.00 in	I Gross	17,496.00 in4	Live Loads	1.700
Left End Fixity	Fixed	Beta	4.106	Short Term Loads	1.550
Right End Fixity	Pinned			Overall Factor	0.830
Load Combination	DL+LL+ST			Deflections Calc'd using Factored Loads	
				Rotations Calc'd using Factored Loads	
				Soil Pressure Calc'd using Unfactored Loads	

Uniform Loads

#1 Dead Load	3.825 k/ft	Live	k/ft	Short Term	k/ft
Start X	0.000 ft	End X	15.000 ft		

Point Loads

	Dead Load	Live Load	Short Term Load	Location
#1	12.00 k	k	k	8.750 ft
#2	10.00 k	k	k	16.000 ft

Moments

	Dead Load	Live Load	Short Term Load	Location
#1	1.00 k-ft	k-ft	k-ft	4.000 ft

Summary

Max Shear	31.47 k	at	0.000 ft	Defl:a	0.000 in	R:a	31.47 k
Min Shear	-11.86 k	at	16.071 ft	Defl:b	0.000 in	R:b	-2.58 k
Max Moment	46.17 k-ft	at	8.722 ft	Max Defl	0.00 in	at	0.000 ft
Min Moment	-101.79 k-ft	at	0.000 ft	Min Defl	-0.05 in	at	11.270 ft
Max Rotation	0.00038 rad	at	18.228 ft	Max SP	1,330.33 psf	at	11.270 ft
Min Rotation	-0.00054 rad	at	4.606 ft	Min SP	0.00 psf	at	0.000 ft
				Theta:a	0.00000 rad		
				Theta:b	0.00031 rad		

Rotations Calc'd using Factored Loads
 Deflections Calc'd using Factored Loads
 Soil Pressure Calc'd using Unfactored Loads

2.3 Rigid Diaphragm Torsional Analysis

This program provides horizontal force distribution analysis for a rigid diaphragm laterally supported by up to 60 walls. X and Y axis forces may be applied to a center of mass location, and that force distributed to all walls after the rotational stiffness analysis has been completed.

All lateral forces are distributed to each wall on the basis of relative rigidities and wall locations. Lateral shear forces, induced torsional forces, and minimum eccentricity are considered after determining the location of the center of rigidity. The user may enter dimensions for walls of homogeneous materials for use in calculating relative stiffness's.

The program provides analysis for one level only. For structures where walls are

symmetrically placed on many levels, a calculation may be performed for each level and results added to determine shears and overturning moments for each wall. When determining center of mass (where the lateral force is applied) on successively lower levels when walls are NOT all in line, a new center of mass position should be calculated based upon wall forces acting from the diaphragm from the level above and combined with the force at that level.

Label	Eccentricity		Direct Shears		Torsional Shears		Max Shear Along L k
	X ft	Y ft	Len k	Thk k	Len k	Thk k	
1	0.00	27.35	-23.30	0.00	-9.34	-0.00	-32.635
2	31.39	0.00	71.16	-0.00	13.17	0.00	84.329
3	0.00	27.35	-25.64	0.00	4.29	-0.00	-25.643
4	31.39	0.00	-52.88	-52.88	-5.33	-7.07	-58.209
5	0.00	27.35	-57.20	0.00	9.57	0.00	-57.205
6	0.00	27.35	-25.64	0.00	-2.56	-0.00	-28.202
7	11.39	0.00	-61.50	61.50	3.96	-2.37	-61.501
8	11.39	0.00	-49.44	-49.44	4.73	1.60	-49.439

Basic Usage

- The most important step for successful use of this program is to properly enter the X and Y location of the center of rigidity of each wall and the wall angle.
- For rectangular walls, the center of the wall's rigidity will be at the centroid of the section.
- The wall angle is measured with respect to the centerline of the length measurement (long dimension). 0deg and 180deg defines the wall's angle as parallel to the X-axis. 90deg and 270deg defines the wall as being parallel to the Y-axis. The angle increases positively in a counterclockwise direction.
- You will also note that the wall table allows up to 60 walls to be entered. When you have less than 60 (which will be typical), make sure all information for each unused

row is zero, which signals the program that no wall is being used on that row.

- Lateral shears are typically the force at the diaphragm level due to wind or seismic forces at that level. Distance to Center of Mass specifies the X/Y location where the lateral shears act. If lateral forces must be added to the diaphragm from the level above or below, you must combine all forces to calculate an adjusted mass application point. Maximum Dimensions are used to calculate the minimum additional eccentricity that will be added and subtracted from the calculated eccentricity to calculate governing forces to each wall.
- Wall Thickness, Length, Height dimensions of each wall providing lateral support to the diaphragm are required, and together with the elastic modulus entry fully define the relative stiffness of the wall.
- The Elastic Modulus does not have to be an exact number if all the walls are of identical construction. The most typical use is to enter 1" here.
- X & Y Distances for each wall design the center of plan-view stiffness of each wall. This location will be used when combining all wall stiffness's and calculating the overall center of rigidity for all walls acting as a system.
- Enter the inclination angle of each wall along its length axis. Enter all angles as positive.
- Enter the fixity condition that will best describe the wall's top and bottom rotational restraint. FP (Fix/Pin) indicates that one end is free to rotate while the other is fixed, while FF (Fix/Fix) indicates that both ends cannot rotate and results in double curvature.

Unique Features

This program uses a numerical approach to determine center of rigidity location and to distribute lateral forces to each wall. Because walls may be located at any angle, a rigorous stiffness analysis is made calculating each wall's stiffness about both axes and combining the stiffness's of all the walls to determine a center of rigidity location.

Assumptions & Limitations


Because this program performs a very complex stiffness matrix analysis for all walls, the traditional method of listing separate components of direct and torsional shears is not applicable. Also, the program internally adds and subtracts the additional accidental eccentricity (based on both maximum dimensions) about each axis to calculate maximum force to each wall. The results in one final force value being displayed for each wall.

Coordinate System

Please note that a STRICT X-Y coordinate system should be used to ensure that the analysis is properly carried out. When setting up an X-Y coordinate axis, please follow the standard Cartesian model with the diaphragm located such that X increases to the right and Y increases up. Unless another method is necessary, this will perform very well (but the program can handle variations).

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow. Here is the sketch showing the angular orientation of the walls. Please see the table of wall input values for the exact locations.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General Wall Data	
Description	Example Problem, 8 Wall System, One Wall Angled
Loading...	
Y-Y Axis Shear	187.000 k
X-X Axis Shear	187.000 k
Load Application	<input type="radio"/> Forces Act Together <input checked="" type="radio"/> Forces Act Separately
Analysis Data...	
Min. X Axis Shear Eccentricity	5.00 %
Min. Y Axis Shear Eccentricity	5.00 %
X Axis Center of Mass	118.50 ft
Y Axis Center of Mass	71.50 ft
Max X Dimension	200.00 ft
Max Y Dimension	180.00 ft

Loading : XX Shear, YY Shear

Calculate the total lateral force to be applied at the center of mass of the diaphragm. We have provided individual entries for each direction, to allow for different lateral forces in each direction. For multi-story buildings in seismic and/or high wind areas, the building code specifies a non-linear distribution of base shear force (for multiple levels) which should be considered. You can use the Multi Story Seismic Force Distribution and Multi Story Wind Force Distribution programs to help you with this analysis.

Load Application

Forces Act Separately : The maximum applied shear value will be the maximum force from each shear force acting separately along each axis.

Forces Act Together : Both XX and YY axis shear forces will be applied to the diaphragm simultaneously to calculate the maximum forces to each wall.

Minimum Applied Shear Eccentricity

This specifies the minimum accidental (additional) eccentricity that should always be used for determining torsional forces on the diaphragm. Entering 5" specifies 5% minimum accidental eccentricity for a direction. For a 100' maximum dimension this would result in a 5'-0" minimum eccentricity between center of mass and center of rigidity.

Distance to Center of Mass

Enter the X and Y distance from the datum point to where the Shear Force is applied. The center of rigidity (+/-5% accidental eccentricity) is compared with this location to determine overall diaphragm

torsions.

Maximum Dimensions

This value represents the diaphragm's maximum dimension along the X and Y-axis, and is used to determine the minimum eccentricity of the applied shears by multiplying it by the "**Minimum Applied Shear Eccentricity**".

Wall Data Tab

This tab is used as the main data entry location for all wall data. The entry items at the bottom of the screen let you edit the highlighted item in the list directly. To Add a wall you must use the **+** **Add** button.

Label	Thickness in	Length ft	Height ft	Wall C.G. Location		Angle deg	Fixity	E (relative)
				X ft	Y ft			
1	0.22	25.00	17.50	167.50	179.66	0.0	Fix-Fix	3.122
2	0.22	35.00	17.50	199.66	162.50	90.0	Fix-Fix	3.122
3	0.22	20.00	13.00	190.00	0.33	0.0	Fix-Fix	3.122
4	0.22	30.00	13.00	155.00	45.00	135.0	Fix-Fix	3.122
5	0.22	40.00	13.00	90.00	0.33	0.0	Fix-Fix	3.122
6	0.22	20.00	13.00	105.00	84.66	0.0	Fix-Fix	3.122
7	0.22	28.28	13.00	10.00	75.00	45.0	Fix-Fix	3.122
8	0.22	28.28	13.00	10.00	10.00	135.0	Fix-Fix	3.122

Thickness	<input type="text" value="0.222"/>	in	X c.g. location	<input type="text" value="167.500"/>	ft
Length	<input type="text" value="25.000"/>	ft	Y c.g. location	<input type="text" value="179.660"/>	ft
Height	<input type="text" value="17.500"/>	ft	Angle	<input type="text" value="0.00"/>	deg
Fixity	<input checked="" type="radio"/> Fixed-Fixed <input type="radio"/> Fixed-Pinned				
E	<input type="text" value="3.122"/>				

Add, Change Delete Buttons

These buttons control the table of values for all the walls. Each button works on the wall line currently highlighted. When pressing Add or Change a window is displayed very similar to the one shown below. Using this window you can specify the information for the wall.

Since the program considers each wall to be of one material with uniform properties throughout you simply need to specify the Thickness, Height, Width, and Elastic Modulus to specify the stiffness of the wall.

The "Length" dimension is used by the program as the axis to report shear along the wall. Although the program calculates shear both along and perpendicular to the wall (width direction) the length is assumed to be what you are interested in and the final shear results are given along that direction.

Wall ID Number : 1

Thickness 0.222 in

Length 25.000 ft

Height 17.500 ft

X Distance to C.G. 167.500 ft

Y Distance to C.G. 179.660 ft

Wall Angle : CCW ... 0.00 degrees

Elastic Modulus 3.1

Wall End Fixity

Fixed-Fixed

Fixed-Pinned

Ok

Cancel

Thickness

This is the thickness of the wall and should be the smaller plan view cross sectional dimension of the wall.

Length

This is the length of the wall and should be the larger plan view cross sectional dimension of the wall. This is the length which would normally be considered to be stiffer and brace the diaphragm against lateral forces. Each wall's thickness (and length) is used to calculate the moment of inertia about each axis, depending on how the Fixity item is specified (see below). This dimension is perpendicular to the axis used to measure the wall angle.

NOTE..... Before examining components of each wall's stiffness about each axis, for calculation of the wall stiffness matrices, deflection constants are calculated using IMAJOR and IMINOR. The typical deflection equation:

$$P/E[h^3/(inertia *value) + 2.64h/A]$$

will set value = 12 for Fixed/Fixed walls and 3 for Fixed/Pinned walls.

Height

This is the height of the wall from the next lower datum point. Because the program does not "know" that there is any consistent reference elevation on the floor below you are free to enter a different height.

X Distance to C.G., Y Distance to C.G.

This is the distance from the center of resistance of the wall from your datum point. The center of resistance is the dimensional plan view center of the wall.

Wall Angle CCW

This is the rotation of the wall's **length** axis. It is measured in degrees rotated counter-clockwise from the "X" axis which is assumed to be horizontal to the model. For example, a 12" thick x 5'-0" long wall (in plan view) that is rotated 90 degrees is oriented up & down and is parallel with the "Y" axis.

Elastic Modulus

This is the elastic modulus of the wall. You can modify this value to "play" with a wall's stiffness that will result in a linear effect on the walls stiffness.

Wall End Fixity

Select **Fixed-Fixed** when the wall's top and bottom end rotations are completely restrained by boundary elements (such as by walls above, large footing, etc.). When one end of the wall is free to rotate select **Fixed-Pinned**. This entry will modify the calculation of each wall's rigidity (1/deflection).

Modeling hints

You can use this program to model all types of shear resisting elements. Note that Thickness and Elastic modulus have a direct linear effect on the wall stiffness. The length and height values have a non-linear effect (see stiffness equations to follow).

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This tab shows the major calculated values for the system of walls entered.

Results	Wall Forces	Sketch
Summary...		
X Dist. to Center of Rigidity		97.114 ft
Y Dist. to Center of Rigidity		53.154 ft
X Accidental Eccentricity		10.000 ft
Y Accidental Eccentricity		9.000 ft
Torsional Moments from Y-Y Shear		
Xcm + (Min%*MaxX) - Xcr	31.386 ft	= 5,869.14 k-ft
Xcm - (Min%*MaxX) - Xcr	11.386 ft	= 2,129.14 k-ft
Torsional Moments from X-X Shear		
Ycm + (Min%*MaxY) - Ycr	27.346 ft	= 5,113.63 k-ft
Ycm - (Min%*MaxY) - Ycr	9.346 ft	= 1,747.63 k-ft

Distance to Center of Rigidity

This is the calculated distance from the datum (0,0) point to the center of translational rigidity of the system of walls.

The center of rigidity is calculated by:

- Forming a stiffness matrix for each wall. This matrix models each wall's stiffness about its length and

- thickness axis.
- Solve each matrix for wall rigidities
- Solve simultaneous equations for X and Y locations of center of rigidity.

Accidental Eccentricity

This value is the entered maximum X and Y dimensions multiplied by the minimum eccentricity value/100 =(CR-CM)+ Accidental

Using the calculated center of rigidity and accidental torsion values that cause maximum wall loads, these are the eccentricities used to calculate X-X and Y-Y axis torsions.

Torsional Moments from Y-Y Shear

Using the specified Y-Y applied shear force and applying it at an eccentricity equal to :

Center of Mass - Minimum Eccentricity - Distance to Center of Rigidity)

the applied torsional moments on the diaphragm are calculated. These torsional moments are then used to determine the force along the length axis of the wall needed to resist it using the calculated stiffness's of all walls in the system.

Wall Forces Tab

This is a summary of information table that shows wall number, eccentricity of wall's resisting center to diaphragm's center of rigidity, and the direction and torsional shear components calculated for the wall.

These components are then analyzed in all of their combinations to see which combination gives the maximum force parallel to the "length" of the wall.

Results Wall Forces Sketch								
Label	Eccentricity		Direct Shears		Torsional Shears		Max Shear	
	X ft	Y ft	Len k	Thk k	Len k	Thk k	Along L k	
1	0.00	27.35	-23.30	0.00	-9.34	-0.00	-32.635	
2	31.39	0.00	71.16	-0.00	13.17	0.00	84.329	
3	0.00	27.35	-25.64	0.00	4.29	-0.00	-25.643	
4	31.39	0.00	-52.88	-52.88	-5.33	-7.07	-58.209	
5	0.00	27.35	-57.20	0.00	9.57	0.00	-57.205	
6	0.00	27.35	-25.64	0.00	-2.56	-0.00	-28.202	
7	11.39	0.00	-61.50	61.50	3.96	-2.37	-61.501	
8	11.39	0.00	-49.44	-49.44	4.73	1.60	-49.439	

Eccentricity

This is the distance from the walls geometric center (entered as input as "Wall C.G. Location") to the calculated "Center of Rigidity" of the system of walls you have entered.

Direct Shears & Torsional Shears

Max. Shear Along Length

Considering the center of rigidity for the entire system of walls, the maximum force to each wall is calculated by:

- Using the individual wall stiffness values to calculate a polar moment of inertia.
- Using the applied shear force in each direction and wall stiffness's, to solve for the X and Y deflections of the overall diaphragm system.

- Calculating two torsional moments for the X and Y shear force, and determining which will yield the greatest force to each wall.
- Using those torsions and the polar moment of inertia to calculate diaphragm rotations.
- Solving the forces in each wall that would be necessary to produce the wall deflection consistent with diaphragm rotation at the wall's location.


Because of the stiffness matrix approach for determining rigidities and deflections, the actual number of forces calculated for each wall is 32....one for each axis (2), one for each applied load (2), and two for each accidental eccentricity (8). This equals $2 * 2 * 8 = 32$ forces for each wall.

For each wall, the force applied to the wall in each direction is summarized as direct and torsional shear, with the governing eccentricity of the applied load that created the torsional shears shown.

The table is difficult to understand when loads are applied along both axis at once, so we recommend only applying a load along one axis for each run and printout.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper. The buttons at the bottom of the tab control the display of additional information.



Sample Printout

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949-645-0151
www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
Dsgnr: MDB Date: 9:28PM, 22 OCT 03
Description: Collection of example problems
Scope: All programs in the Structural Engineering Library

Rev: 980000
User: KW-0003186, Ver 5.6.0, 10-Sep-2003
(c)1983-2003 ENERCALC Engineering Software

Rigid Diaphragm Torsional Analysis

Page 1

c:\e05\examples.edm\Analysis Calc0

Description Example Problem, 8 Wall System, One Wall Angled

General Information

Y-Y Axis Shear	187.00 k	Min. X Axis Ecc	5.00 %	X Axis Center of Mass	118.50 ft
X-X Axis Shear	187.00k	Min. Y Axis Ecc	5.00 %	Y Axis Center of Mass	71.50 ft
...Shears are applied on each axis separately					
				Max X Dimension	200.00ft
				Max Y Dimension	180.00ft

Wall Data

Label	Thickness in	Length ft	Height ft	Wall Xcg ft	Wall Ycg ft	Wall Angle deg CCW	Wall End Fixity	E
1	0.222	25.000	17.500	167.500	179.660	0.0	Fix-Fix	3.1
2	0.222	35.000	17.500	199.660	162.500	90.0	Fix-Fix	3.1
3	0.222	20.000	13.000	190.000	0.333	0.0	Fix-Fix	3.1
4	0.222	30.000	13.000	155.000	45.000	135.0	Fix-Fix	3.1
5	0.222	40.000	13.000	90.000	0.333	0.0	Fix-Fix	3.1
6	0.222	20.000	13.000	105.000	84.660	0.0	Fix-Fix	3.1
7	0.222	28.280	13.000	10.000	75.000	45.0	Fix-Fix	3.1
8	0.222	28.280	13.000	10.000	10.000	135.0	Fix-Fix	3.1

Calculated Wall Forces

Label	Load Location for Maximum Forces		Direct Shears K		Torsional Shears K		Final Max. Wall Shear k
	X ft	Y	Length	Thick	Length	Thick	
1	0.000	27.346	-23.298	0.000	-9.338	-0.000	-32.635
2	31.386	0.000	71.157	-0.000	13.172	0.000	84.329
3	0.000	27.346	-25.643	0.000	4.291	-0.000	-25.643
4	31.386	0.000	-52.882	-52.883	-5.327	-7.074	-58.209
5	0.000	27.346	-57.205	0.000	9.573	0.000	-57.205
6	0.000	27.346	-25.643	0.000	-2.560	-0.000	-28.202
7	11.386	0.000	-61.501	61.502	3.958	-2.371	-61.501
8	11.386	0.000	-49.439	-49.440	4.732	1.597	-49.439

Summary

X Distance to Center of Rigidity	97.114 ft	Controlling Eccentricities & Forces from Applied Y-Y Shear
Y Distance to Center of Rigidity	53.154 ft	Xcm + (Min%*MaxX) - X-cr = 31.386 ft Torsion = 5,869.14 k-ft
		Xcm - (Min%*MaxX) - X-cr = 11.386 ft Torsion = 2,129.14 k-ft
X Accidental Eccentricity	10.000 ft	Controlling Eccentricities & Forces from Applied X-X Shear
Y Accidental Eccentricity	9.000 ft	Ycm + (Min%*MaxY) - Y-cr = 27.346 ft Torsion = 5,113.63 k-ft
		Ycm - (Min%*MaxY) - Y-cr = 9.346 ft Torsion = 1,747.63 k-ft

2.4 Section Properties

This program determines section properties for built up sections with rectangles, hollow circles, solid circles, and standard AISC steel sections.

AISC sections can be recalled from the database files and included in the built-up section. W and C sections from the 6th, 7th, 8th, and 9th edition handbooks are available. They can be rotated 90 deg, 180 deg, or 270270 deg desired

Calculated section property values are area, moments of inertia, center of gravity location, extreme fiber distances, section moduli, and radius of gyration.

Built-Up Section Property

Tools & Settings | ? Help | Print | Cancel | Save

General | Results | Sketch

Description: I Beam w/ various shapes attached

#1 #2 #3 #4 #5 #6 #7 #8 #9 #10

Type: Rect

Height: 0.7500 in Width: 10.0000 in

Xcg: 0.0000 in Ycg: -10.8700 in

Section #1 Section #2 Section #3 Section #4 Section #5

Section: W21x62

Rotation Angle: Counter-Clockwise 0 deg

Section Centroid Location from Datum:

Xcg: 0.0000 in Ycg: 0.0000 in

Section Properties

Depth	20.9900 in	Ixx	1,330.0000 in ⁴
Width	8.2400 in	Iyy	57.5000 in ⁴
Area	18.3000 in ²	Xbar	4.1200 in
		Ybar	10.4950 in

Calculated Properties...

Total Area	59.7908 in ²
X cg Distance from Datum	0.0000 in
Y cg Distance from Datum	-3.9958 in
Edge Distances from CG...	
+X	8.0000 in
-X	-8.0000 in
+Y	14.7728 in
-Y	-15.8174 in
Ixx	4,980.2937 in ⁴
Iyy	372.9328 in ⁴
rxx	9.1288 in
ryy	2.4975 in
S left	82.1555 in ³
S right	82.1555 in ³
S top	337.1300 in ³
S bottom	314.8622 in ³

Basic Usage

Before starting data entry, be sure you have set up an X/Y coordinate system to consistently reference all component locations.

For each rectangular shape, enter the height, width, and center of area from the datum.

Circular sections are entered by specifying the outside radius and thickness. The radius is measured from the center to the outside of the circular shape. Set thickness to zero for solid sections, or non-zero for hollow pipes.

For AISC sections, this distance will locate the section's centroid position. The program knows the centroid location of AISC members with respect to their own extreme fiber locations. However, you need to enter the location of the shape's actual centroid in relation to the other rectangular and/or circular shapes. Be careful, as this can be tricky when entering channels, angles, and tee sections that are rotated.

This program will allow entry of solid circular or pipe sections. When a solid circular section is to be used, the user simply enters 0" for thickness of the circular shape.

A unique feature allows the user to specify whether the X and Y axes of AISC sections should be turned +/-90 degrees.

Assumptions & Limitations

The program operates on a simple calculation procedure:

- Calculate the moment of inertia of each shape,
- Calculate the neutral axis of the group of shapes, and


- Calculate the moment of inertia of the group using $I + A \cdot D^2$ equations.

More complex analysis such as polar moment of inertia, plastic moduli, and buckling constants are beyond the scope of the program.

To calculate the section modulus, the program checks for the most distant portion of any shape from the calculated neutral axis on all four sides. The appropriate X-X or Y-Y moment of inertia is then divided by this distance (fiber distance) to get the section modulus for each of the four sides.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab provides all the data entry locations. It is divided into two areas: (1) to define rectangular and circular shapes and (2) To add AISC rolled sections.

General										
Description		I Beam w/ various shapes attached								
#1	#2	#3	#4	#5	#6	#7	#8	#9	#10	
Type		Rect								
Height	0.7500 in			Width	10.0000 in					
Xcg	0.0000 in			Ycg	-10.8700 in					
Section #1		Section #2		Section #3		Section #4		Section #5		
Section		W21x62								
Rotation Angle : Counter-Clockwise										0 deg
Section Centroid Location from Datum :										
Xcg	0.0000 in			Ycg	0.0000 in					
Section Properties										
Depth	20.9900 in			Ixx	1,330.0000 in ⁴					
Width	8.2400 in			Iyy	57.5000 in ⁴					
Area	18.3000 in ²			Xbar	4.1200 in					
				Ybar	10.4950 in					

General Shapes

This area contains small tabs #1 thru #10 which each are used to define a rectangular or circular item. The screen image above shows data entry for a rectangular section. By changing the drop-down box to "**Circular**" you would see the entry prompts below:

General										
#1	#2	#3	#4	#5	#6	#7	#8	#9	#10	
Type		Circ								
Radius	2.7840 in			Thick	0.5210 in					
Xcg	0.0000 in			Ycg	-17.0290 in					

Each shape input provides for the size of the item and the X & Y distance from a datum point where the CENTER OF GRAVITY of the section is located.

Also note that for "Circular" section types you can enter the inside diameter thus allowing solid circles and hollow pipes.

Rectangles

Enter the dimensions of square or rectangular shapes to be included in the analysis on each line. Also, enter the location of the center of gravity of this shape with respect to a datum point you have chosen. Distances from the datum can be positive or negative.

Circular Sections

Enter the dimensions of solid circular or hollow pipe shapes to be included in the analysis in this location. Also, enter the location of the center of gravity of this shape with respect to a datum point you have chosen. Distances from the datum can be positive or negative. The Radius entry means the outside radius.

To specify a solid circular section, set the entry for Thickness equal to zero. This will signal the program that the circular section is solid. For any other circular shape that has a hollow circular core, enter the wall thickness (not the inner diameter).

Distance to C.G.

This distance locates the center of area of each shape with respect to a datum. Locations may be positive or negative.

AISC Rolled Shapes

In the lower area of the tab you see five smaller tabs that provide data entry locations for up to five rolled AISC sections. To specify a section to be used either type in the section name in the entry area and press the [Tab] key -or- use the [Section] button to use the built in steel section database.

Angle 0/90 deg.

This entry allows you to orient the section at 0, 90, or -90 degrees. 0 degrees specifies the typical orientation with the Y-Y axis vertical. 90 degrees rotates the section counterclockwise 90 degrees. -90 degrees will rotate the section clockwise 90 degrees (to allow channels to be oriented open end down).

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results	Sketch
Calculated Properties...	
Total Area	59.7908 in ²
X cg Distance from Datum	0.0000 in
Y cg Distance from Datum	-3.9956 in
Edge Distances from CG...	
+X	6.0000 in
-X	-6.0000 in
+Y	14.7726 in
-Y	-15.8174 in
I _{xx}	4,980.2937 in ⁴
I _{yy}	372.9328 in ⁴
r _{xx}	9.1266 in
r _{yy}	2.4975 in
S left	62.1555 in ³
S right	62.1555 in ³
S top	337.1300 in ³
S bottom	314.8622 in ³

Total Area

The total area of all defined shapes, including the area of any AISC sections which have been included in the analysis.

X Distance to Center of Gravity

Using the locations of the center of gravity of each entered shape and AISC section data, static moments are taken about each X and Y datum and the center of gravity distance from the datum is determined.

Edge Distance from C.G.

This is the distance from the Center of Gravity (more properly the center of area) of the composite section to the most extreme fiber in each direction.

Inertia : I_{xx} & I_{yy}

The overall moment of inertia of the composite section is determined by applying the following equation to all the defined shapes:

$$I - xx + (A * dy^2) \text{ and } I - yy + (A * dx^2)$$

where d = Distance from the shape's C.G. to the overall C.G. of the composite section.

Radius of Gyration

The radius of gyration of the composite section is determined using the typical equation: $(I_{xx} / A)^{1/2}$ and $(I_{yy} / A)^{1/2}$


Section Modulus : S

These values are the calculated section moduli of the composite section. The values are determined by dividing I_{xx} or I_{yy} by the fiber distances above, below, right, and left of the center of gravity of the

section.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems **Job #** 97-00001
Dsgnr: MDB **Date:** 9:54PM, 22 OCT 03
Description : Collection of example problems

Scope : All programs in the Structural Engineering Library

Rev: 580000
 User: KW-0603186, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

Built-Up Section Properties

Page 1
 c:\ec55\examples.ecw\Analysis Calc

Description I Beam w/ various shapes attached

General Information

Type...					X cg	Y cg
#1 Rectangular	Height	0.7500 in	Width	10.0000 in	0.0000 in	-10.8700 in
#2 Rectangular	Height	3.0000 in	Width	1.0000 in	0.0000 in	-12.7450 in
#3 Circular	Radius	2.7840 in	Thick	0.5210 in	0.0000 in	-17.0290 in

Steel Shapes

#1:	Name	W21x62	Angle	0 deg	Depth	20.9900 in	Ixx	1,330.0000 in4
	Location of Centroid from Datum				Width	8.2400 in	Iyy	57.5000 in4
	Xcg	0.000 in	Ycg	0.000 in	Area	18.3000 in2	Xbar	4.120 in
							Ybar	10.495 in
#2:	Name	C12x20.7	Angle	-90 deg	Depth	12.0000 in	Ixx	128.1000 in4
	Location of Centroid from Datum				Width	2.9400 in	Iyy	3.8800 in4
	Xcg	0.000 in	Ycg	10.079 in	Area	6.0300 in2	Xbar	0.698 in
							Ybar	6.000 in
#3:	Name	L8x8x1-1/8	Angle	0 deg	Depth	12.0000 in	Ixx	98.0000 in4
	Location of Centroid from Datum				Width	8.0000 in	Iyy	98.0000 in4
	Xcg	0.000 in	Ycg	-2.350 in	Area	16.7000 in2	Xbar	2.410 in
							Ybar	2.410 in

Summary

Total Area	59.7908 in2	Ixx	4,980.294 in4	r xx	9.1266 in
X cg Dist.	0.0000 in	Iyy	372.933 in4	r yy	2.4975 in
Y cg Dist.	3.9956 in	Edge Distances from CG...			
		+X	6.0000 in	S left	62.1555 in3
		-X	-6.0000 in	S right	62.1555 in3
		+Y	14.7726 in	S top	337.1300 in3
		-Y	-15.8174 in	S bottom	314.8622 in3

2.5 Pole Formula

This program determines actual soil pressures and required depths for footings primarily supporting lateral loads. Such footings are commonly called Flagpole footings. Since applied top moment generates lateral soil pressures that usually govern the design, these footings typically have a depth/width ratio of 2:1 and greater.

Cases with and without lateral restraint at the ground surface are allowed. Evaluation of actual and allowable pressures is in accordance with 1994 U.B.C. Section 1806.7.

ENERCALC c:\EC55\EXAMPLES.EC.W - Pole Embedment in Soil

Pole Embedment in Soil

Tools & Settings Help Print Cancel Save

General

Description: Circular pole with Point & Uniform Loads

Allow Passive: 250.0 pcf

Max Passive: 1,500.0 psf

Load duration factor: 1.330

Pole Shape: Rectangular Circular

Diameter: 24.000 in

Surface Restraint: No Yes

Applied Loads... (Distances are above ground surface)

Point Load: 7,000.00 lbs
distance from base: 8.000 ft

Distributed Load: 350.00 #/ft
distance to top: 11.000 ft
distance to bottom: 3.000 ft

'97 UBC 2907g2, 2003 IBC 1805.7.2, 2003 NFPA 5000 36.4.3

Results Sketch

Results...

Moments @ Surface...

Point load	58,000.00 ft-#
Distributed load	19,800.00 ft-#
Total Moment	75,800.00 ft-#
Total Lateral	9,800.00 lbs

Without Surface Restraint...

Required Depth	13.875 ft
Press @ 1/3 Embed...	
Actual	1,328.88 psf
Allowable	1,330.00 psf

Code Ref:

- 1997 UBC section 2907g2
- 2003 IBC 1805.7.2
- 2003 NFPA 5000 36.4.3

Unique Features


- This program allows you to design up to five pole footings on one calculation sheet.
- You can enter a point lateral load, partial length distributed lateral load, or both, to apply shear and moment at the top of the footing.
- This program is a straight application of the Uniform Building Code formula referenced above.

Assumptions & Limitations

- Allowable passive pressure is assumed to increase linearly with depth, up to the specified maximum.
- When surface restraint is specified, the restraint is assumed to be rigid and able to resist lateral reactions.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab contains all the data entry items for this calculation.

General	
Description	Circular pole with Point & Uniform Loads
Allow Passive	250.0 pcf
Max Passive	1,500.0 psf
Load duration factor	1.330
Pole Shape	
<input type="radio"/> Rectangular <input checked="" type="radio"/> Circular	
Diameter	24.000 in
Surface Restraint	
<input checked="" type="radio"/> No <input type="radio"/> Yes	
Applied Loads... <i>(Distances are above ground surface)</i>	
Point Load	7,000.00 lbs
distance from base	8.000 ft
Distributed Load	350.00 #/ft
distance to top	11.000 ft
distance to bottom	3.000 ft
'97 UBC 2907g2, 2003 IBC 1805.7.2, 2003 NFPA 5000 36.4.3	

Allowable Passive Pressure

The allowable lateral force the soil can withstand. This value will be increased per foot of vertical embedment depth. For example, at 4'-0" below the surface allowable lateral pressure entry of 150 psf/ft would be able to resist $150 * 4 = 600$ psf.

- **Regardless of maximum value entered in the next entry the allowable pressure will not be raised when the depth of embedment is below 12'-0".**

Max Passive

Maximum allowable passive pressure regardless of depth, and load duration factor to be used to increase the allowable pressures. Per code

Load Duration Factor

The load duration factor will be applied to the allowable lateral passive pressures. This number will then be used as the allowable pressures used to determine footing embedment.

Pole Shape

Use this section to specify whether the pole is round or square. If the pole is specified as square, the dimension entered is multiplied by 1.41 to arrive at an equivalent width dimension for calculations.

Pole Diameter / Pole Width

Enter the width or diameter of the footing, and specify whether a round or rectangular footing is used. Width is measured perpendicular to force direction.

Pole Restraint

Specify whether the footing is free at the ground surface or restrained and cannot rotate. A Restrained footing indicates that a concrete slab or other rigid element only allows rotation of the top of the footing without translation. When specifying a restrained footing, you must assure yourself that the final force required to be restrained at the top can be provided.

When ground surface restraint is present, the lateral pressure value that will govern the design will be at the base of embedment.

The program will iterate (solving the indeterminate equations) until the minimum embedment depth is determined.

Applied Loads

Point and Distributed Loads. Two types of loads may be entered; concentrated load applied at some point above the ground, or a partial length uniform lateral load. The program will combine both loading's and use the resultant moment and shear force at the ground surface.

Results Tab

Results	
Results...	
Moments @ Surface...	
Point load	56,000.00 ft-#
Distributed load	19,600.00 ft-#
Total Moment	75,600.00 ft-#
Total Lateral	9,800.00 lbs
Without Surface Restraint...	
Required Depth	13.875 ft
Press @ 1/3 Embed...	
Actual	1,328.68 psf
Allowable	1,330.00 psf
Code Ref:	
1997 UBC section 2907g2	
2003 IBC 1805.7.2	
2003 NFPA 5000 36.4.3	
With Surface Restraint...	
Req'd Depth	9.000 ft
Pressure @ Base...	
Actual	1,995
Allowable	1,330
Surface Restraint Force	

Moments @ Surface

This moment results from applying both point and concentrated loads to the pole (above soil) at their respective distances above the soil surface

Total Moment**Total Lateral Load**

This force is simply the sum of point and distributed lateral loads applied to the pole.

Without Surface Restraint

Required Depth : Based on the 1988 UBC 1806.7 formulas shown on the next page, the minimum required embedment depth is calculated to satisfy allowable soil pressures.

For poles not restrained at surface:

$$\begin{aligned} \text{Depth} &= A/2 * [1 + (1 + (4.36*h/A))^{1/2}] \\ A &= 2.34 P / (S1 * b) \\ P &= \text{Applied lateral force, lbs} \\ S1 &= \text{Allowable Lateral passive pressure at 1/3 embedment * LDF} \\ b &= \text{Diameter or width of footing or pole} \\ h &= \text{Height of point of load application} \end{aligned}$$

Actual @ 1/3 Embedment : This is the location of maximum lateral pressure for non-restrained footings. Considering the applied loads, pole footing dimensions, and calculated length of embedment, the actual lateral pressure at 1/3 of embedment depth is given here. It is calculated using a modified version of the formula used to calculate depth of embedment.

Allow. @ 1/3 Embedment : The allowable passive pressure (after application of the load duration factor) is multiplied by 1/3 the pole embedment, compared with the limiting value, and the smaller value used. This number is then multiplied by the load duration factor to get the final allowable pressure at 1/3 embedment.

With Surface Restraint

Required Depth : Based on the formulas to follow, the minimum required embedment depth is calculated to satisfy allowable soil pressures. Per U.B.C Section 1806.7 :

$$\begin{aligned} \text{Depth} &= (4.25 * P * h / (S3 * b))^{1/2} \\ P &= \text{Applied lateral force, lbs} \\ h &= \text{Height of point of load application, ft.} \\ b &= \text{Diameter or width of footing or pole, ft.} \\ S3 &= \text{Allowable lateral bearing pressure at base of embedment} \end{aligned}$$


Allow. @Base of Embedment : This represents the maximum allowable pressure at the base of embedment, and is given only for poles with lateral restraint at the ground surface. It equals the maximum allowable passive pressure multiplied by the load duration factor.

Actual @ Base of Embedment : The allowable passive pressure (after application of the load duration factor) is multiplied by the footing depth, compared with the limiting soil pressure value, and the smaller value used. This number is then multiplied by the load duration factor to get the final allowable pressure at the base.

Surface Restraint Force : When surface restraint has been specified, the lateral force acting at the surface is given. The user should verify that this force can be resisted.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Sample Printout

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949-645-0151
www.enercalc.com

Title : ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 10:49PM, 22 OCT 03
Description : Collection of example problems
Scope : All programs in the Structural Engineering Library

Rev: 580000
 User: KW0601, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

Pole Embedment in Soil

Page 1
 c:\ec55\examples.ecw\Analysis Calc3

Description Circular pole with Point & Uniform Loads

General Information Code Ref: 1997 UBC section 2907g2, 2003 IBC 1805.7.2, 2003 NFPA 5000 36.4.3

Allow Passive	250.00 pcf	Applied Loads...	
Max Passive	1,500.00 psf	Point Load	7,000.00 lbs
Load duration factor	1.330	distance from base	8.000 ft
Pole is Circular		Distributed Load	350.00 #/ft
Diameter	24.000 in	distance to top	11.000 ft
No Surface Restraint		distance to bottom	3.000 ft

Summary			
Moments @ Surface...			
Point load	56,000.00 ft-#	Total Moment	75,600.00 ft-#
Distributed load	19,600.00	Total Lateral	9,800.00 lbs
Without Surface Restraint...			
Required Depth	13.875 ft		
Press @ 1/3 Embed...			
Actual	1,328.68 psf		
Allowable	1,330.00 psf		

2.6 Pile Group Load Distribution

This program distributes a concentrated load applied on a rigid pile cap to a group of piles. Force distribution is performed assuming a rigid pile cap and that all piles having equal vertical load resistance.

Distribution of loads to each pile due to the effect of load eccentricity is determined using a skew bending analysis. This considers simultaneous action about both X and Y axes. The program is also an efficient method for determining loads on a pile group in the as driven arrangement.

ENERCALC c:\EC55\EXAMPLES.EC5W - Pile Group Analysis

Pile Group Analysis

Tools & Settings ? Help Print Cancel Save

General

Description: Seven pile system w/ X & Y load eccentricity

Total Applied Load: 262.90 k

X Distance to Load: 16.000 ft

Y Distance to Load: 10.500 ft

Pile Locations...

	X Location	Y Location
1	7.00	4.00
2	3.00	8.00
3	7.00	12.00
4	3.00	16.00
5	37.00	3.00
6	32.00	8.50
7	37.00	16.00
8	0.00	0.00
9	0.00	0.00
10	0.00	0.00

Results

C.G. Distance from Datum		Moments...	
X	18.00 ft	XX Axis	225.34 k-ft
Y	9.64 ft	YY Axis	-525.80 k-ft

Load Distance from C.G. of Piles		Moments of Inertia	
X	-2.000 ft	Y-Y Axis	1,610.00 ft ⁴
Y	0.857 ft	XX Axis	166.36 ft ⁴
		XY Axis	56.00 ft ⁴
		XY ²	3,136.00 ft ⁴


Pile Forces...	Forces from Rotation		Pile Reaction	
	Load / # Piles	Y-Y Axis		XX Axis
1:	37.56	4.16	-8.36 k	33.35 k
2:	37.56	5.67	-2.43 k	40.79 k
3:	37.56	4.16	3.49 k	45.21 k
4:	37.56	5.67	9.42 k	52.65 k
5:	37.56	-7.18	-9.84 k	20.53 k
6:	37.56	-5.29	-1.69 k	30.57 k
7:	37.56	-7.18	9.42 k	39.79 k
8:	0.00	0.00	0.00 k	0.00 k
9:	0.00	0.00	0.00 k	0.00 k
10:	0.00	0.00	0.00 k	0.00 k
				262.90 k

Basic Usage

- Define the coordinate system, locating the applied vertical load and piles locations. For ease of use, it's wise to set up the system so all offset distances from the datum are positive.
- Enter Load and Location for vertical loads only. Enter X and Y distances from the datum to center of applied load.
- Enter Pile X and Y locations from the datum to the center of each pile.
- Note: Only the first pile may be specified at location (0,0). For pile # 2 -> #10, at least one distance must be non-zero. The first (0,0) location encountered in rows #2 -> #10 will signal that the previous line was the last pile in the group.
- Assumptions & Limitations
- The pile cap is assumed rigid and the distribution is performed by calculating the properties of the pile group.
- The program doesn't calculate punching shear or other such detailed items for a pile cap.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General

Description Seven pile system w/ X & Y load eccentricity

Total Applied Load k

X Distance to Load ft

Y Distance to Load ft

Pile Locations....

	X Location	Y Location
1	<input type="text" value="7.00"/> ft	<input type="text" value="4.00"/> ft
2	<input type="text" value="3.00"/> ft	<input type="text" value="8.00"/> ft
3	<input type="text" value="7.00"/> ft	<input type="text" value="12.00"/> ft
4	<input type="text" value="3.00"/> ft	<input type="text" value="16.00"/> ft
5	<input type="text" value="37.00"/> ft	<input type="text" value="3.00"/> ft
6	<input type="text" value="32.00"/> ft	<input type="text" value="8.50"/> ft
7	<input type="text" value="37.00"/> ft	<input type="text" value="16.00"/> ft
8	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft
9	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft
10	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft

Total Axial Load

Enter the total Vertical load to be distributed to the piles in the pile group using the coordinate system you have defined. This indicates the distance from the datum (0,0) point to the point of load application. Note! Only vertical loads are allowed; no lateral shears.

X & Y Distance to Load

Distance from "Datum" point to where the load is applied.

Pile Locations

Distance from "Datum" to the pile.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Results				
C.G. Distance from Datum		Moments...		
X	18.00 ft	X-X Axis	225.34 k-ft	
Y	9.64 ft	Y-Y Axis	-525.80 k-ft	
Load Distance from C.G. of Piles		Moments of Inertia		
X	-2.000 ft	Y-Y Axis	1,610.00 ft ⁴	
Y	0.857 ft	X-X Axis	166.36 ft ⁴	
		X-Y Axis	56.00 ft ⁴	
		XY ²	3,136.00 ft ⁸	
Pile Forces....				
		Forces from Rotation		
	<u>Load / # Piles</u>	<u>Y-Y Axis</u>	<u>X-X Axis</u>	<u>Pile Reaction</u>
1:	37.56	4.16	-8.36 k	33.35 k
2:	37.56	5.67	-2.43k	40.79 k
3:	37.56	4.16	3.49k	45.21 k
4:	37.56	5.67	9.42k	52.65 k
5:	37.56	-7.18	-9.84k	20.53 k
6:	37.56	-5.29	-1.69k	30.57 k
7:	37.56	-7.18	9.42k	39.79 k
8:	0.00	0.00	0.00k	0.00 k
9:	0.00	0.00	0.00k	0.00 k
10:	0.00	0.00	0.00k	0.00 k
				262.90 k

Center of Gravity

Using a simple center of gravity calculation assuming each pile is of equal resistance, the neutral axis of the pile group about both axes is determined.

Load Ecc. from CG

After the center of gravity of the pile group is located, the eccentricity of the applied load to the C.G. is calculated and will be used to determine the X-X and Y-Y axis moments on the pile group.

Group Inertia About Axis Ixx and Iyy are calculated by using:

$$I = \text{SUM} (A * d^2)$$

where...

$$d = \text{Distance of each pile from the center of gravity}$$

X-X & Y-Y moments

Using the applied load and eccentricity from the pile group center of gravity, the X-X and Y-Y axis

moments on the pile group are calculated. This will be used in the equations detailed below to determine the loads to each pile.

Summary Of Pile Loads

Pile Number : Reference number for your convenience.

Coordinates : According to the user-defined coordinate system, enter the X and Y distances of each individual pile from datum (0,0).

Load/# Piles : This equals the total applied load divided by the number of piles.

Force from Rotation : Represents the force applied to each pile as a result of the induced moment about the X and Y axes.

The X-X axis bending load is calculated as:

$$\frac{[M_x * I_y - M_y * I_{xy}]Y}{I_y * I_x - I_{xy}^2} + \frac{[M_y * I_x - M_x * I_{xy}]X}{I_y * I_x - I_{xy}^2}$$

The Y-Y axis bending load is calculated as:


$$\frac{[M_y * I_x - M_x * I_{xy}]Y}{I_x * I_y - I_{xy}^2} + \frac{[M_x * I_y - M_y * I_{xy}]X}{I_x * I_y - I_{xy}^2}$$

Pile Reaction

The total pile reaction is equal to the sum of the previous calculated forces.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 11:06PM, 22 OCT 03
 Description : Collection of example problems
 Scope : All programs in the Structural Engineering Library

Rev: 680000
 User: KKW-0600001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

File Group Analysis

Page 1

c:\ec56\examples.ecw\Analysis Calc5

Description Seven pile system w/ X & Y load eccentricity

General Information

Total Applied Load	262.90 k	X Distance to Load	16.000 ft
		Y Distance to Load	10.500 ft

Input & Results

	X Location	Y Location ft	Load / # Piles	Forces from Rotation k		Pile Reaction
				Y-Y Axis	X-X Axis	
1:	7.000	4.000	37.56	4.16	-8.36	33.35
2:	3.000	8.000	37.56	5.67	-2.43	40.79
3:	7.000	12.000	37.56	4.16	3.49	45.21
4:	3.000	16.000	37.56	5.67	9.42	52.65
5:	37.000	3.000	37.56	-7.18	-9.84	20.53
6:	32.000	8.500	37.56	-5.29	-1.69	30.57
7:	37.000	16.000	37.56	-7.18	9.42	39.79
				Total		262.90 k


Summary

Xcg from Datum	18.00 ft	Y-Y Axis Inertia	1,610.00 ft ⁴	Moments...	
Ycg from Datum	9.64 ft	X-X Axis Inertia	166.36 ft ⁴	X-X Axis	225.34 k-ft
X Load Dist from CG	-2.000 ft	X-Y Axis Inertia	56.00 ft ⁴	Y-Y Axis	-525.80 k-ft
Y Load Dist from CG	0.857 ft	XY ² Inertia	3,136.00 ft ⁸		

2.7 Multi-Story Wind Load Analysis

This program calculates the wind pressures on a structure where the wind force will vary with height. Analysis is performed per 1994 UBC Section 16 Division II, Section 1613 -> 1618, which uses C_e , C_q , q_s , and I to calculate wind pressures at different heights on a structure.

The user can enter floor to floor heights for the program to use in calculating the wind pressures, and enter tributary widths for the calculation of total story shears at each level.



Basic Usage


This program performs a simple tabular summary of wind pressures, and basic usage consists of entering the wind pressure criteria, selecting the number of stories, and entering the floor to floor heights and exposed widths.

Basic usage follows these steps :

- Study your particular wind pressure area and design criteria, and enter the Height, Exposure, and Gust factors, Pressure Coefficient, Basic Wind Speed, and Importance Factor. The Wind Stagnation Pressure will be automatically read from an internal table after the first calculation is performed.
- Enter the distance the building wall extends above the top framing level in the entry Parapet Height. The load at the top level will be calculated as this height plus tributary force on 1/2 the distance to the level below.
- Continue to enter the Level Height and Exposed Width for each level that is above grade. Exposed width is used directly to calculate the tributary wind force at that level.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General		Force Table	
Description		Example Problem.	
Exposure		C	▼
<i>See '97 UBC Definition, Pg 2-9</i>			
Cq : Pressure Coefficient		1.4	▼
<i>See '97 UBC Table 16-H, Pg2-33</i>			
Importance Factor		1	▼
<i>See '97 UBC Table 16-J, Pg2-35</i>			
Basic Wind Speed		95.00	▲▼
<i>See '97 UBC Wind Speed Map, Pg 2-38</i>			
Qs : Wind Stagnation Pressure		23.200 psf	
Parapet Height		5.00	▲▼ ft

Exposure

Enter the type of exposure the structure will be exposed to per section 1994 UBC section 1614. Exposure B is for terrain that has buildings, forest, or surface irregularities 20 feet or more in height, covering at least 20 percent of the area within one mile of the structure. Exposure C is for terrain that is generally open, extending ½ mile or more from the site in any full quadrant. Exposure D is for wind speeds in excess of 80mph (129 km/h) and has terrain that is flat and unobstructed facing large bodies of water. Please see the UBC for more in-depth descriptions.

Cq = Pressure Coefficient

This factor, which varies from 0.5 to 3.0, can be obtained from UBC Table 16-H. It pertains to the general composition of the structure that the wind load will be applied to.

I:Importance Factor

Enter the "I" factor from UBC Table 16-J.

Basic Wind Speed

From UBC section 1616 and 1994 UBC Figure 16-1.

Qs = Wind Stagnation Pressure

This value is read directly from UBC Table 16-F, which is stored internally. Based directly on the user defined Basic Wind Speed.

Force Table Tab

This table is the actual analysis of the wind forces on the structure. The calculated Design Pressure for each level height will be applied over the Exposed Width to yield the total lateral force per level. This lateral force will be added down the height of the structure, level by level, to calculate the Story Shear. Similarly, the lateral force will be multiplied by the appropriate lever arms to give the Story Moments .

General Force Table

Level	Height (ft)	Exposed Width (ft)
5	65.00	45.00
4	52.00	45.00
3	39.00	45.00
2	26.00	45.00
1	13.00	45.00

Delete
 Change
 Add

Level

This is the story label for the level. It will be numbered automatically from the highest floor downward. The table is automatically sorted in order of highest to lowest "Height".

Height

The user should enter the height of each level above the base for the analysis. This height will be used to recall the various Exposure Coefficients from the internally stored UBC Table 16-H.

Exposed Width

Enter the width of the structure to which the Design Pressure should be applied, for calculating the shear force per level.

Add, Change, Delete Buttons

These buttons control your modifications to the table of story information. Pressing Add or Change displays another window where you can specify the floor information. Here is what it looks like :

Level ID Number :

Level Height (above Base) ft

Exposed Width ft

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This table provides a table of the calculated values for each floor level.

Level	Ce	Cq	Pressure (psf)	Lateral F (k)	Story V (k)	Story M (k-ft)
5	1.455	1.400	47.26	24.456	10.633	
4	1.382	1.400	44.89	26.226	35.089	456.162
3	1.302	1.400	42.29	24.666	61.315	1,253.257
2	1.198	1.400	38.91	22.653	85.981	2,371.015
1	1.060	1.400	34.43	20.327	108.635	3,783.268

Lateral @ Base Level = 10.070 k

Total Base Shear = 128.399 k

Base Moment = 4,768.613 k-ft

Level

This is the story label for the level. It will be numbered automatically from the highest floor downward. The table is automatically sorted in order of highest to lowest "Height".

Ce

Based upon the Level Height above the base and the Height/Gust/Exposure factors the user has entered, this value is read from the internally stored UBC Table 16-H.

Cq

This value is automatically inserted from the previous input.

Design Pressure

For each level, the design pressure is determined by calculating UBC Formula 18-1 for the values entered. This design pressure is then applied to the Exposed Width to calculate the lateral force being applied at each level.

Lateral Force

This is the product of the Design Pressure * Exposed Width * Height Between Floors above & below, and is the force applied to each level for calculating Story Shear and Story Moment.

Story Shear

The Story Shear at each level is calculated by adding the Lateral Forces at and above the current level.

Story Moment


The Story Moment at each level is the summation of all the lateral forces above the current level times their moment arms.

Base Totals

This are the total shear and overturning moment at the base of the structure.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Design Pressure List

This tab shows the calculated wind pressure for the entire height of the structure you have entered. The total height is divided into 400 increments and the pressures given. To calculate the total force per level the individual pressures are totalled for 1/2 the level height above and below.

Results | Sketch | Design Pressure List

This list shows the pressure gradient used on the multi-story model. 400 pressure points are calculated from base to the top of the parapet. Tributary pressures at each level are calculated by taking this pressure * width * incremental height for the tributary height above and below the level height.

Height above Base (ft)	Pressure (psf)
70.000	48.07
69.825	48.04
69.649	48.01
69.474	47.98
69.298	47.96
69.123	47.93
68.947	47.90
68.772	47.87
68.596	47.84
68.421	47.81
68.246	47.79
68.070	47.76
67.895	47.73
67.719	47.70
67.544	47.67
67.368	47.64
67.193	47.61
67.018	47.59
66.842	47.56
66.667	47.53
66.491	47.50
66.316	47.47
66.140	47.44
65.965	47.42
65.789	47.39

Sample Printout

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949-645-0151
www.enercalc.com

Title : ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 8:07PM, 23 OCT 03
Description : Collection of example problems
Scope : All programs in the Structural Engineering Library

Rev: 580000 User: KW-0600001, Ver 5.8.0, 10-Sep-2003 (c)1983-2003 ENERCALC Engineering Software **Multi-Story Wind Forces** Page 1
 c:\ec5\examples.ecw\Analysis Calcs

Description Example Problem,

General Information Calculations per 1997 UBC

Exposure	C	Gs : Wind Stagnation Pressure	23.200 psf
Cq : Pressure Coefficient	1.40		
Basic Wind Speed	95.0 mph	Parapet Height	5.000 ft
Importance Factor	1.00		

Load Information for Each Level

Level	Level Height ft	Exposed Width ft	Ce	Cq	Design Pressure psf	Lateral Force k	Story Shear k	Story Moment k-ft
5	65.000	45.000	1.455	1.400	47.258	24.456	10.633	0.000
4	52.000	45.000	1.382	1.400	44.887	26.953	35.089	456.162
3	39.000	45.000	1.302	1.400	42.289	25.499	62.042	1,262.708
2	26.000	45.000	1.198	1.400	38.911	23.751	87.541	2,400.742
1	13.000	45.000	1.060	1.400	34.429	21.452	111.292	3,847.538

Shear at Base Level = 10.070 k

Total Base Wnd Shear = 132.181 k
Total Base Wind Moment = 4,882.056 k-ft

2.8 Multi-Story Seismic Load Analysis

This program provides analysis of lateral seismic forces on multi-story buildings according to the 1994 UBC lateral force formulas 28-1, 28-6, 28-8 and the diaphragm force formula 31-1. Also included is a section that will assist the user in determining the overall seismic factor. By entering building dimensions and the number of stories, the basic building period is determined using the UBC formulas for basic building periods. From this value, and user defined Z, I, S, Hn, and Ct factors, C/RW limits are checked and overall seismic factor determined.

Force distribution factors for each level is determined using formula 28-7, and the base shear applied to each level for the evaluation of story shears and overturning moments. Also, these forces are used along with formula 31-1 to determine the required diaphragm forces at each level. Any number of stories may be specified, and the additional top force FT is applied when required.

ENERCALC c:\EC55\EXAMPLES.ECIV - Multi-Story Seismic Forces

Multi-Story Seismic Forces

Tools & Settings Help Print Cancel Save

General 1997 UBC Calculations Building Forces Diaphragm Forces

Determine Procedure Type... Total Number of Stories Construction Type **UBC 1630.2.3 Simplified Static Force Procedure**

Ground Floor Area ft² Occupancy Category Seismic Importance Factor $I = 1.25$

Determine N_a & N_v ... Distance From Known Source Seismic Source Type Seismic Coefficients $N_a = 1.50$ $N_v = 2.00$

Soil Profile Type *UBC table 16-J* Seismic Coefficients $C_a = 0.66$ $C_v = 1.28$

Structural System... Shear wall-frame interact: Concrete

Overstrength & Global Ductility Coefficient $R = 5.500$ Seismic Force Amplification Factor $\Omega = 2.800$ Structure Height Limit ft

Max Element Story Shear Ratio r_{max} p : Reliability Factor = $2 - 20/(r_{max} * \sqrt{A_b})$

Calculated Values : UBC 1630.2.1 Static Procedure
 Seismic Dead Load (Calculated From Story Shear V)
 Table on "Building Forces" Tab $W = 335.0$ k
 Calculated Base Shear $V = C_v I W / (R T) = 121.6$ k
 Min. Base Shear $V = 0.11 C_a I W = 30.4$ k
 Zone 4: Min. Base Shear $V = 0.8 Z N_v I R / W = 48.7$ k
 Base Shear Max Limit $V = 2.5 C_a I W / R = 125.6$ k
V:Design Base Shear 86.9 k
Ft: Top Force 4.873 k

Calculated Values : UBC 1630.1.1 Earthquake Loads
Not Used Here But For Your Reference
 $E_h = V$:Design Base Shear 86.9 k
 Horiz Seismic Factor E_h / W 0.259
 Vertical Seismic Factor E_v / D 0.413
 $E_h * p$ 115.8 k
 $E_m = \Omega * E_h$ 243.3 k

Divide Factor by 1.4 For Use in Allowable Stress Design ?

Basic Usage

This program is used in areas where seismic forces on multi-story buildings will have considerable effect on the design of the lateral resisting system.

Enter the values for Z , I , R_w , S , and C based upon your building. The value for C can be calculated in two ways.....either entering the actual building period -or- the simplified UBC method of height and C_t factor.

From the entered values the program calculates the overall seismic factor to be used. This is applied to the story weight W_i entered by you.

The multi-story force analysis is based on filling out a table, one line for each story. You need to start at the BOTTOM of the table, working upward for each story.


Assumptions & Limitations

The analysis is based upon the 1994 UBC static force formulas, and as such, determine lateral forces according to the static model approach.

The seismic factor cannot be varied at each level to account for varying dynamic properties that the user may wish to use to perform alternative studies.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab allows you to select which code method to use to calculate your seismic factor and also other common values regarding the seismic zone and building.

General	1994 UBC Calculations	Building Forces	Diaphragm Forces
Description			
Example Problem.			
Select Governing Code			
<input checked="" type="radio"/> 1994 & Earlier UBC <input type="radio"/> 1997 UBC			
Seismic Zone	UBC Figure 16-2	4	
Seismic Zone Factor : Z =		0.40	
Building Period Calculation...			
<input type="radio"/> Enter Period <input checked="" type="radio"/> Enter Height & Ct			
Hn to Top Level		65.000	ft
Ct : Construction Type Factor		0.035	
Building period		0.801	sec

Select Governing Building Code

Select the radio button for the code calculation method you wish to use.

Seismic Zone

Factor Enter the seismic factor which is based on the seismic risk map area (found in UBC Table 23-I).

Seismic Zone Factor

sd

Building Period

The building period can be specified by either:

- Entering the number of stories and CT factor that applies to the type of construction, and allowing the program to calculate the value using standard UBC equations, or.
- Entering a building period which you have determined

UBC Calculations Tab

This tab provides data entry and calculated values according to 1994 UBC criteria. Please see that code for further explanations of the values.

General	1994 UBC	Building Forces	Diaphragm Forces	
S: Site Response Factor	<input type="text" value="1"/>		Final Calculated Values Seismic Dead Load (Calculated From Story Table on "Building Forces" Tab) N = 335.0 k Horiz Seismic Factor = 0.052 V:Design Base Shear = 17.3 k Ft: Top Force = 0.972 k	
Rw: Coefficient	<input type="text" value="8.000"/>			
Importance Factor	<input type="text" value="1"/>			
C: Coefficient	<input type="text" value="1.449"/>			

UBC Calculations Tab

This tab provides data entry and calculated values according to 1997 UBC criteria. Please see that code for further explanations of the values.

General	1997 UBC	Building Forces	Diaphragm Forces	
Determine Procedure Type... Total Number of Stories <input type="text" value="8"/> Construction Type <input type="text" value="Light-Frame"/> UBC 1630.2.3 Simplified Static Force Procedure				Calculated Values : UBC 1630.2.1 Static Procedure Seismic Dead Load (Calculated From Story Shear V) Table on "Building Forces" Tab W = 335.0 k Calculated Base Shear V=Cv I W / (RT)= 121.6 k Min.Base Shear V = 0.11 Ca I W = 30.4 k Zone 4: Min.Base Shear V=0.8 Z Nv I R / W= 48.7 k Base Shear Max Limit V = 2.5 Ca I W / R = 125.6 k V:Design Base Shear 86.9 k Ft: Top Force 4.873 k
Ground Floor Area <input type="text" value="2,000.0"/> ft2 Occupancy Category <input type="text" value="1.25: Specified"/> Seismic Importance Factor I = 1.25				
Determine Na & Nv... Distance From Known Source <input type="text" value="<=2km"/> Seismic Source Type <input type="text" value="A: Faults Capable of Large Quakes & High Seis"/> Seismic Coefficients Na = 1.50 Nv = 2.00				Calculated Values : UBC 1630.1.1 Earthquake Loads <i>Not Used Here But For Your Reference</i> Eh = V:Design Base Shear 86.9 k Horiz Seismic Factor Eh / W 0.259 Vertical Seismic Factor Ev / D 0.413 Eh * p 115.8 k Em = Omega * Eh 243.3 k
Soil Profile Type UBC table 16-J <input type="text" value="SD"/> Seismic Coefficients Ca = 0.66 Cv = 1.28				
Structural System... <input type="text" value="Shear wall-frame interact: Concrete"/> Shear wall-frame interact Concrete Overstrength & Global Ductility Coefficient R = 5.500 Seismic Force Amplification Factor Omega = 2.800 Structure Height Limit 0.0 ft				<input checked="" type="checkbox"/> Divide Factor by 1.4 For Use in Allowable Stress Design
Max Element Story Shear Ratio r _{max} <input type="text" value="0.67"/> p: Reliability Factor = 2 - 20/(r _{max} *sqrt(A _b)) 1.3325				

Building Forces Tab

This table performs the distribution of total base shear to the various floors, based upon UBC formula 28-5, 28-6, and 28-7. The resulting distribution of forces will resemble a triangular distribution with the maximum intensity at the top of the building.

General 1997 UBC Building Forces Diaphragm Forces								
Level	Weight (k)	Ht (ft)	Wi * Hi (k-ft)	Ft (k)	Fx (k)	Lat Force (k)	Story Shear (k)	Story Mom (k-ft)
5	35.00	65.00	2,275.0	4.87	15.51	20.39		
4	75.00	52.00	3,900.0		26.60	26.60	20.39	265.04
3	75.00	39.00	2,925.0		19.95	19.95	46.98	875.84
2	75.00	26.00	1,950.0		13.30	13.30	66.93	1,745.96
1	75.00	13.00	975.0		6.65	6.65	80.23	2,788.97

Sum Wi = 335.00 k Total Base Shear = 86.88 k
 Sum Wi * Hi = 12,025.0 k-ft Base Moment = 3,918.4 k-ft

- Delete Level Change Level + Add Level

Level #

This is the level # above the base. Base shear and overturning moment are given as the Base Totals shown at the bottom of the table. These level numbers are modified during the program's self-modifying process while adjusting to the requested number of levels.

Weight Wi

Enter the weight of each level of the structure in this area. This weight will be multiplied by the overall seismic factor ZIC/RW for the calculation if Fx.

Height Hi

Enter the height of each level above the base. This represents the vertical distances between each floor mass Wi.

Wi * Hi

This is an intermediate calculation for Fx.

Ft : Top Force

The added top force is calculated only if the building period is greater than 0.7 seconds. This added top force is equal to 0.07 times the calculated period times the total base shear, and is applied to the uppermost level of the structure if applicable, this is the top force Ft applied at the top level.

Fx

After all the factors in the equation for Fx are ready, the lateral force to each level of the structure Fx is calculated using formula 28-7 of the UBC. This force is applied to each level for calculation of story

shears and overturning moments.

Lateral Force

This is simply a restatement of F_x with F_t added if applicable.

Story Shear

Using the calculated forces at each level, story shear gives the total shear acting at each level, and is the summation of the lateral forces at each level at and above the current level.

Story Moment

Using the calculated Story Shears at each level, story moment gives the total moment acting at each level, and is the summation of the lateral forces times moment arms for all levels at and above the current level.

Base Totals


This item lists the total base shear and overturning moment at the bottom of the structure.


Diaphragm Force Distribution Tab


This table performs an analysis of the forces to be carried by the floor diaphragm, using UBC formula 12-11.

Level	Weight (k)	Ht (ft)	$W_i * H_i$ (k-ft)	F_t (k)	F_x (k)	Lat Force (k)	Story She (k)	Story Mom (k-ft)
5	35.00	65.00	2,275.0	4.87	15.51	20.39		
4	75.00	52.00	3,900.0		26.60	26.60	20.39	265.04
3	75.00	39.00	2,925.0		19.95	19.95	46.98	875.84
2	75.00	26.00	1,950.0		13.30	13.30	66.93	1,745.96
1	75.00	13.00	975.0		6.65	6.65	80.23	2,788.97

Sum W_i =	335.00 k	Total Base Shear =	86.88 k
Sum $W_i * H_i$ =	12,025.0 k-ft	Base Moment =	3,918.4 k-ft


Delete Level


Change Level


Add Level

W_{px}

This is the weight of the floor system at each level, and is the same as W_i which the user entered in

the previous table. This value is automatically transferred down from the earlier input cells.

Lat. Force


This is the force that the diaphragm at each level must be designed to adequately carry, and is the result of UBC formula 28-9. To arrive at the final F_{px} , the F_p is calculated at each level and compared with the maximum value of $0.75ZI$ times W_i at each level, and the minimum of the two is used.

Diaphragm F_{px}

This is the calculated force that must be applied at each level, and is equal to the Lateral Force value calculated in the preceding table.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown.



Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 8:21PM, 23 OCT 03
Description: Collection of example problems
Scope: All programs in the Structural Engineering Library

Rev: 90000
 User: K:\0800001_Ver 5.0.0_10-Sep-2003
 ©1983-2003 ENERCALC Engineering Software **Multi-Story Seismic Forces** Page 1
 c:\eef5\examples.acw:Analysis Calc

Description Example Problem,

General Information Calculations are designed to 1997 UBC Requirements

<p>Seismic Zone 4</p> <p>UBC 1630.2.3 Simplified Static Force Procedure</p> <p>Ground Floor Area 2,000.0 ft²</p> <p>Occupancy Category 1.25: Specified</p> <p>Seismic Importance Factor I = 1.25</p> <p>Determine Na & Nv...</p> <p>Site Distance From Known Source <=2km</p> <p>Seismic Source Type... A : Faults Capable of Large Quakes & High Seismic Activity Seismic Coefficients Na = 1.50 Nv = 2.00</p> <p>Soil Profile Type SD</p> <p>Seismic Coefficients Ca = 0.66 Cv = 1.28</p> <p>Structural System...</p> <p>Shear wall-frame interact: Concrete Concrete</p> <p>Overstrength & Global Ductility Coefficient R = 5.500 Seismic Force Amplification Factor Omega = 2.800 Structure Height Limit 0.0 ft</p>	<p>Building period 0.801 sec</p> <p>Hn to Top Level 65.00 ft</p> <p>Ct: Construction Type Factor 0.035</p> <p>Max Element Story Shear Ratio ρ_{max} 0.67</p> <p>p: Reliability Factor = $2 - 20/(r \cdot \max(\sqrt{A_b}))$ 1.3325</p> <p>Calculated Values : UBC 1630.2.1</p> <p>Seismic Dead Load (Calculated From Story Table on "Building Forces" Tab) W = 335.0 k</p> <p>Calculated Base Shear V = Cv I W / (RT) = 121.6 k</p> <p>Min. Base Shear V = 0.11 Ca I W = 30.4 k</p> <p>Zone 4: Min. Base Shear V = 0.8 Z Nv I R / W = 48.7 k</p> <p>Base Shear Max Limit V = 2.5 Ca I W / R = 125.6 k</p> <p>Final Calculated Values</p> <p>Horiz Seismic Factor Eh / W = 0.259</p> <p>Vertical Seismic Factor Ev / D = 0.413</p> <p>V : Design Base Shear 86.9 k</p> <p>Ft : Top Force 4.873 k</p> <p>Eh * p 115.8 k</p> <p>Em - Omega * Eh 243.3 k</p>
---	--

Note! Seismic Factor Has Been Divided by 1.4 to give allowable stress values to coincide with 1994 UBC.

Building Seismic Forces

Level	Weight Wi k	Height Hi ft	Wi * Hi k-ft	Ft k	Fx Force @ Level k	Lateral Force k	Story Shear k	Story Moment k-ft
5	35.00	65.00	2,275.0	4.873	15.515	20.388		
4	75.00	52.00	3,900.0		26.597	26.597	20.388	265.040
3	75.00	39.00	2,925.0		19.948	19.948	46.985	875.841
2	75.00	26.00	1,950.0		13.299	13.299	66.932	1,745.963
1	75.00	13.00	975.0		6.649	6.649	80.231	2,788.965
Total Base Shear							86.880 k	
Base Overturning Moment								3,918.408 k-ft

Diaphragm Forces

Level	Weight Wpk k	Lateral Force @ this Level k	Summation of Lateral Forces Above k	Summation of Level Weights k	Min Req'd Force @ Level k	Calculated Force @ Level k	Max Req'd Force @ Level k	Diaphragm Force : Fpx k
5	35.00	15.51	15.51	35.000	14.438	15.515	28.875	15.515
4	75.00	26.60	42.11	110.000	30.938	28.713	61.875	30.938
3	75.00	19.95	62.06	185.000	30.938	25.159	61.875	30.938
2	75.00	13.30	75.36	260.000	30.938	21.738	61.875	30.938
1	75.00	6.65	82.01	335.000	30.938	18.360	61.875	30.938

2.9 Multi-Story Column Load Analysis

This program assists the designer in determining the individual and accumulated loads

per level on a multi-story load-bearing member. This program will prove to be a tremendous help in keeping track of loads when many levels are used and different tributary widths and loading criteria are present.

The program also has the ability to determine live load reductions per 1994 UBC section 1606 Formulas 6-1 and 6-2. The user may input the "r" factor at each level according to UBC Table 16-C (for roofs).

Loading options for each level include Tributary Area, Dead Load, Reducible Live Load, and Non-Reducible Live Load. Reducible live loads are automatically reduced by the calculated reduction factor, and all three loads are combined at each level and summed down the height of the column.

Multi-Story Column Loads

Tools & Settings | ? Help | Print | Cancel | Save

General & Floor Data

Description: 5 Story Building

+ Add | Change | - Delete

Level	Dead Load (psf)	Live Load (psf)	Floor Area (ft ²)	Basic 'r' Reduction Factor
		on-Reducible Reducible		
6	15.00	0.000 50.000	1200.00	0.080
5	25.00	20.000 75.000	1200.00	0.080
4	25.00	20.000 66.000	2100.00	0.080
3	25.00	20.000 66.000	1200.00	0.080
2	25.00	20.000 66.000	1200.00	0.080
1	25.00	20.000 75.000	1200.00	0.080

Results

<<... All Loads These Columns in k ...>>

Level	Total D.L.	'R'	Reduced LL (psf)	Total LL Reduced	Total LL Non-Red.	Total DL+LL	Sum @ Floor Level
6	18.00	0.700	34.99	41.98	0.00	59.98	59.982
5	30.00	0.692	51.90	62.28	24.00	116.28	176.262
4	52.50	0.682	44.98	94.46	42.00	138.96	365.218
3	30.00	0.682	44.98	53.97	24.00	107.97	473.193
2	30.00	0.682	44.98	53.97	24.00	107.97	581.168
1	30.00	0.692	51.90	62.28	24.00	116.28	697.448
Totals :							
190.500k				368.948	138.000	697.448k	

Basic Usage

Enter the Unit Dead, Live, and Non-Reducible Live loads acting at each level. Also, enter the tributary area that the unit loads apply to, and the r-value you choose from UBC Table 16-C. Only the reducible live load will be modified according to the UBC equations. Be sure to work from the top of the table downward.

Example

The data entry for this example is shown in the screen captures that accompany the Data

Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General & Floor Data Tab

This is the main input tab for entering data that describes all the levels in your column. The list is arranged with the highest levels at the top of the list. Notice the two buttons below the table : [Move Level Up] & [Move Level Down]. These two buttons move the levels you have entered up and down in the table.

The screenshot shows the 'General & Floor Data' window. At the top, the title is 'General & Floor Data'. Below it is a 'Description' field containing '5 Story Building'. There are three buttons: '+ Add', 'Change', and '- Delete'. Below these is a table with the following data:

Level	Dead Load	Live Load (psf)		Floor Area (ft ²)	Basic 'r' Reduction Factor
	(psf)	on-Reducible	Reducible		
6	15.00	0.000	50.000	1200.00	0.080
5	25.00	20.000	75.000	1200.00	0.080
4	25.00	20.000	66.000	2100.00	0.080
3	25.00	20.000	66.000	1200.00	0.080
2	25.00	20.000	66.000	1200.00	0.080
1	25.00	20.000	75.000	1200.00	0.080

At the bottom of the window, there are two buttons: '▲ Move Level Up' and '▼ Move Level Down'. There are also navigation icons (back, forward, search) at the bottom left.

Add, Change, Delete Buttons

These buttons control your modifications to the table of story information. Pressing Add or Change displays another window where you can specify the floor information. Here is what it looks like :

The screenshot shows a dialog box for editing floor information. The 'Floor ID Number' is set to 4. The 'Dead Load' is 25.00 psf, 'Non-Reducible Live Load' is 20.00 psf, and 'Reducible Live Load' is 66.00 psf. The 'Floor Area' is 2,100.0 ft² and the 'Reduction Factor' is 0.08. There are 'Ok' and 'Cancel' buttons on the right side of the dialog.

Unit Dead Load

Enter the basic dead load to be included in the summary. This load may vary from level to level.

Non-Reducible Live Load

Enter the live load that IS NOT reducible based on tributary area.

Reducible Live Load

Enter the live load that IS reducible based on tributary area.

Floor Area

This represents the tributary area that will be used to determine the actual dead and live load acting on the column at a particular level. This area may vary from level to level.

Reduction Factor

UBC Section 2306 Reductions : The reductions used in the program to automatically determine the live load reduction based upon tributary area are based on UBC section 2306. Formulas 6-1 and 6-2 are used to determine the maximum live load reduction. The user should indicate in the space provided whether the 60 % maximum reduction rule should be used for the loads added when two or more levels receive loads.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This tab displays a table of the resulting calculated values for each floor level. The order of the floors displayed is the same as for the input table.

Results

<< --- All Loads These Columns in k --- >>

Lvl	Total D.L.	"R"	Reduced LL (psf)	Total LL Reduced	Total L.L. Non-Red.	Total DL+LL	Sum @ Floor Level
6	18.00	0.700	34.99	41.98	0.00	59.98	59.982
5	30.00	0.692	51.90	62.28	24.00	116.28	176.262
4	52.50	0.682	44.98	94.46	42.00	188.96	365.218
3	30.00	0.682	44.98	53.97	24.00	107.97	473.193
2	30.00	0.682	44.98	53.97	24.00	107.97	581.168
1	30.00	0.692	51.90	62.28	24.00	116.28	697.448
Totals :							
	190.500k			368.948	138.000	697.448k	

Level #

This level number is automatically entered when the program modifies the table for the chosen number of stories.

Total Dead Load

Total DL Per Level Equals Unit Dead Load * Tributary Area.

" R " : Maximum Reduction Factor

The maximum reduction factor is calculated from UBC Section 2306, formula 6-1 and 6-2, and according to the "r" factor entered by the user

Reduced Unit Live Load

This equals the Reducible Live Load * Reduction Factor, and will be used in tabulating the total load to each level. Total Reduced LL Per Level Equals Reduced Unit Live Load * Tributary Area.

Total LL Non-Reducible

Total Non- -Reducible LL Per Level Equals Reduced Unit Live Load * Tributary Area.

Total DL+LL Per Level

This is the summation of Dead, Live, and reducible Live load at each level.

Sum @ Floor Level

Summation Of Dead +Live Loads This represents the accumulation of loads along the length of the column.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.

Sample Printout

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949-645-0151
www.enercalc.com

Title : ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 9:05PM, 23 OCT 03
Description : Collection of example problems

Scope : All programs in the Structural Engineering Library

Rev: 590000
 User: KW-0600001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

Multi-Story Column Loads

Page 1

c:\ec55\examples.ecw\Analysis Calcs

Description 5 Story Building

Load Information for Each Level

Floor Level	Dead Load psf	Non-Reducible Live Load psf	Reducible Live Load	Tributary Floor Area ft2	Basic 'r' Reduction Factor
6	15.000	0.000	50.000	1,200.00	0.080
5	25.000	20.000	75.000	1,200.00	0.080
4	25.000	20.000	66.000	2,100.00	0.080
3	25.000	20.000	66.000	1,200.00	0.080
2	25.000	20.000	66.000	1,200.00	0.080
1	25.000	20.000	75.000	1,200.00	0.080

Calculated Loads & Summary

Floor Level	Total Dead Load k	Reduction Factor	Reduced Live Load psf	Total Reduced Live Load k	Total Non-Reduced Live Load k	Total Load Dead + Live k	Sum @ Floor Level k
6	18.000	0.700	34.985	41.982	0.000	60.0	60.0
5	30.000	0.692	51.900	62.280	24.000	116.3	176.3
4	52.500	0.682	44.979	94.456	42.000	189.0	365.2
3	30.000	0.682	44.979	53.975	24.000	108.0	473.2
2	30.000	0.682	44.979	53.975	24.000	108.0	581.2
1	30.000	0.692	51.900	62.280	24.000	116.3	697.4
Total DL	190.50 k		Totals :	368.95	138.00	697.45 k	

Part



3 Wood Design Modules

The programs in this section provide analysis and design for structural elements made of wood.

Code References

Program modules for WOOD design are designed to be in conformance with ANSI / AF & PA National Design Specification (NDS) dated 30 November 2001. All analysis and design is done using allowable stress design.

Timber Beam & Joist Design

Lets you quickly design single span members with cantilevers. Designed specifically for simple roof/ceiling/floor framing, up to 8 beams can be designed per calc sheet. Full stress and deflection analysis & design is provided.

Multi-Span Timber Beam

Multi-Span Timber Beam allows design of up to eight spans on one calculation sheet. Two modes are available; each span can be considered as simply supported with optional cantilevers or all can be continuous with cantilevers and varying end fixities. Dead and live point, moment, and uniform/trapezoidal loads can be applied in any combination. Alternate span live loading is easily defined. Full AITC stress checks are performed (including long beams), and reactions, shears , moments, deflections, and stresses are given.

General Timber Beam

Heavy Timber Beam allows users very detailed design ability, offering up to 23 dead and live point, moment, and uniform/trapezoidal loads. Fixed, pinned, and free end restraints and cantilevers are available. All possible dead and live loading's are considered for calculation of maximum shears, moments, deflections, and combined stresses. Full AITC stress analysis is performed considering shear/depth reductions and duration of load factors.

Series of Cantilevered Beams

Series of Cantilevered Beams is perfect for design of simple span & cantilevered roof and floor systems typically used in warehouse type structures. The need to optimize cantilever lengths and evaluate deflections and cambers for these systems is completely provided. The program places live loads at different locations to determine maximum reactions, shears, moments, and dead and live load deflections. Cantilever bracing, load duration, and laminations are considered when performing stress checks.

Timber Column Design

Timber Column Design analyzes rectangular and circular timber columns subjected to axial loads, eccentricities, haunch loads, and lateral moments. Allowable bending and

axial stress are calculated considering unbraced lengths and interaction formulas.

Plywood Shear Wall & Footing

Plywood Shear Wall Footing greatly simplifies designing typical plywood shear walls. By using diaphragm shears, drag forces, and vertical stabilizing loads, a complete wall and footing design will be given. Nailing, wall stability, and footing designs are provided.

Plywood Diaphragm Design

Plywood Diaphragm Design provides fast design of rectangular plywood diaphragms, and follows '94 UBC table 25-J-1 for blocked and unblocked diaphragms. The program can be used for either wind or seismic conditions. Boundary loads and diaphragm weight are used to calculate chord forces and boundary shears, while internal tables generate nailing schedules.

High-Load Plywood Diaphragm

Plywood Diaphragm Design provides fast design of rectangular plywood diaphragms, and follows ICBO Report #1952 for 23/32"; plywood diaphragms. The program can be used for either wind or seismic conditions. Boundary loads and diaphragm weight are used to calculate chord forces and boundary shears, while internal tables generate nailing schedules.

Wood Ledger Design

Wood Ledger Design combines vertical and lateral loads applied to ledgers to calculate maximum shears & moments. Flexible bolting is allowed with maximum loads compared to Hankinson formula allowable's. Perfect for ledgers supporting roof or floor diaphragms.

Bolt Groups in Timber Members

Bolt Groups in Timber Members provides an analysis of steel bolts and side plates transmitting axial loads. Considers reductions for bolt spacing, quantity, plate size, force direction, and more.

3.1 Multi Span Timber Beam

This program provides design and analysis of simple span or continuous timber beams. This compact program can let you design wood beams in production line form, letting you rapidly complete many designs simultaneously. The program can handle up to eight spans at once. The end fixities of each can easily be modified to model many types of beams, including (but not limited to):

- Simple span beams with cantilevers at one or both ends.
- Single span beams with fixed and/or free ends.
- Continuous beams with up to nine supports.
- Continuous beams with one or both ends fixed or cantilevered.
- This flexibility is provided using a Yes/No prompt All Spans Simple Support.
- Answering NO tells the program that beams that have pinned ends at the

same support are connected and continuous over that support.

- Answering YES tells the program that each data entry column represents a single beam that is unaffected by the beam on either side of it.

Each span can be loaded with dead and live uniform, a partial length uniform, partial length trapezoidal, and concentrated loads. To further aid your design, you can easily omit live load on any span to perform alternate span load analysis

The screenshot shows the ENERCALC Multi-Span Timber Beam Design software interface. The window title is "ENERCALC c:\EC55\EXAMPLES.ECW - Multi-Span Timber Beam Design". The interface is divided into several sections:

- General:** Span Description, Span (15.00 ft), Unbraced Length (0.000 ft), Left Fixity (Pinned), Right Fixity (Pinned), Wood Section (5.125x16.5), Beam Width (5.125 in), Beam Depth (16.500 in), Beam Type (Sawn, GluLam, Manuf or So. Pine).
- Loads...:** Apply Live Load This Span? (checkbox), Dead Load (144.0 #/ft), Live Load (260.0 #/ft), Uniform, Partial, Trapezoidal (@ Left, @ Right), Point Load #1-4, Moment.
- Results:** Beam is OK, Moments & Stresses (Max. Moment @ Mid-Span: 48.6 in-k @ 7.50 ft, Max @ Left End: 0.0 in-k, Max @ Right End: 0.0 in-k), Shears & Reactions (Shear @ Support: 1.080 k @ Left, 1.080 k @ Right, Reactions: Dead 1.080 k, Live 0.000 k, Total 1.080 k), Query.... (Query Location: 0.000 ft, Query Shear: 1.080 k, Query Moment: 0.000 in-k, Query Deflection: 0.0000 in, Cf: 1.000, Rb: 0.000, Le: 0.000 ft).
- Tools & Settings:** Help, Design, Print, Cancel, Save.

Unique Features

- Full NDS code checks are made considering length effects on allowable bending stresses.
- A simple flag can be set on any span to ignore all live loads on that span, making alternate span loading analysis easy.
- Very flexible loadings may be applied to each span, including three uniform/partial/trapezoidal loads.
- The program can perform automatic member depth selection using stress and deflection criteria. All that is required is for you to specify the allowable stresses and desired beam width.

Assumptions And Limitations

User must enter ACTUAL (not nominal) beam width and depth for analysis. The program calculates the required depth, and the user can then enter the beam depth to be used for an exact analysis of stresses.

The following span condition is not permitted:

Automatic Member Design

This program automatically selects member depth requirements for single or multiple span beams. By pressing Design you will access the design window. This screen allows you to:

- Specify dead, live, and dead+live load Span/Deflection ratio limits.
- Specify overstress limits for bending and shear forces.
- Specify a minimum dimension to increment beam depths when determining a required depth.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab contains entries for values that will be used for ALL the beams in the multi-span system.

General	# 1	# 2	# 3	# 4	# 5	# 6	# 7	# 8
Description 3-Span System, 2 Load Patterns								
Operating Mode <input checked="" type="radio"/> All Spans Considered as Individual Beams <input type="radio"/> Spans Considered Continuous Over Supports								
Stress								
Fb : Base Allowable	1,550.0						psi	
Fv : Allowable	85.0						psi	
E : Elastic Modulus	1,800.0						ksi	
Load Duration Factor	1.250							
Repetitive Member							<input type="checkbox"/>	

Operating Mode

This item plays a critical role in governing the calculation procedure for the entire program.

- **Spans Considered Continuous Over Support** : When two beams share the same support , and the support fixity for both beams at that support is Pinned, then the two beams are tied together to form one continuous beam over that support.
- **All Spans Considered as Individual Beams** : When two beams share the same support , they are always considered as two separate beams and the stresses and rotations in one never affect the other.

Within each beam span information tab there is a setting for end fixity. Here is how those end fixities are described according to the selection for this item:

When "**All Spans Considered as Individual Beams**" is chosen:


- Free will indicate that the end is completely free of the support and adjacent beam.
- Pinned will affect the beam according to the end fixity of the adjacent beam. If the adjacent beam end is Fixed or Free, then the beam will be pinned and not affected by the adjacent beam. If the adjacent beam is pinned, the two beams are locked together, forming one beam continuous over the support.
- Fixed will attach the beam end to a rigid boundary element, allowing no rotation or vertical movement, and not linked to the adjacent beam.

When "**Spans Considered Continuous Over Support**" is chosen :

- Free will indicate that the end is completely free of the support, allowing translation and rotation.
- Pinned will allow the beam end to rotate but not translate.
- Fixed will attach the beam end to a rigid boundary element, allowing no rotation or vertical movement.

[Stress] button & entry

This allows you to use the built-in NDS & Manufactured lumber allowable stress database to retrieve allowable stresses. When you press the button you will see this selection window. Please see the section earlier in this User's Manual that give information and usage for the databases.



Fb-Basic Allow.

Enter allowable bending stress. This value will be multiplied by LDF , Cf, and reduced per unbraced length (as applicable) to determine Fb-Modified Allowable.

Fv-Basic Allow.

Enter the basic allowable shear stress. This value will be multiplied by LDF to get Fv-Allowable.

E

Enter the elastic modulus for the beam being investigated.

Load Duration Factor

Load duration factor for each span will be applied to the final allowable stresses (as applicable per code considering beam slenderness). This factor will be applied to the allowable bending and shear stresses to increase/decrease the beam's capacity based upon the nature of the applied load.

Repetitive Member Flag

Check this box if the multi-span beam can be considered to be a repetitive member according to NDS definitions.

Typical Span Tab : #1 to #8

Each tab that shows #1 through #8 specifies information for one of the beams of the multi-span beam. Tab #1 is the left-most beam and you work to the right to define additional adjacent spans.

General	# 1	# 2	# 3	# 4	# 5	# 6	# 7	# 8
Span Description	<input type="text"/>							
Span	<input type="text" value="15.00"/>						ft	
Unbraced Length	<input type="text" value="0.000"/>						ft	
Left Fixity	<input type="text" value="Pinned"/>							
Right Fixity	<input type="text" value="Pinned"/>							
Wood Section	<input type="text" value="5.125x16.5"/>							
Beam Width	<input type="text" value="5.125"/>						in	
Beam Depth	<input type="text" value="16.500"/>						in	
Beam Type	<input type="radio"/> Sawn <input checked="" type="radio"/> GluLam <input type="radio"/> Manuf or So. Pine							
Loads...	Apply Live Load This Span ? <input type="checkbox"/>							
	<u>Dead Load</u>		<u>Live Load</u>					
Uniform	<input type="text" value="144.0"/>		<input type="text" value="260.0"/>		#/ft			
Partial	<input type="text"/>		<input type="text"/>		Start		<input type="text" value="0.00"/>	
					End		<input type="text" value="15.00"/>	
Trapezoidal								
@ Left	<input type="text"/>		<input type="text"/>		Start		<input type="text" value="0.00"/>	
@ Right	<input type="text"/>		<input type="text"/>		End		<input type="text" value="15.00"/>	
	<u>Location</u>							
Point Load #1	<input type="text"/>		<input type="text"/>		lbs		at <input type="text" value="0.000"/>	
Point Load #2	<input type="text"/>		<input type="text"/>		lbs		at <input type="text" value="0.000"/>	
Point Load #3	<input type="text"/>		<input type="text"/>		lbs		at <input type="text" value="0.000"/>	
Point Load #4	<input type="text"/>		<input type="text"/>		lbs		at <input type="text" value="0.000"/>	
Moment	<input type="text"/>		<input type="text"/>		ft-#		at <input type="text" value="0.000"/>	

Span Description

Enter a brief description of this span. Leaving it blank is fine.

Span

This equals the span distance of a beam segment.

Le:Unbraced Length

If the span will have the compression edge laterally unbraced for some distance, enter the distance here. This length will be used to determine whether the beam falls into the short, intermediate, or long beam classification for determination of allowable bending stress.

For continuous beams, remember that the true meaning of this value is distance between points of contra flexure, and most likely will NOT be the distance between supports.

This entry is the unsupported compression edge length, corrected for span type per AITC/UBC code. Use the following table as a guide.

Type of Beam Span and Nature of Load	Value of Effective Length, Le
--------------------------------------	-------------------------------

Single Span beam, load concentrated at center	1.61 Lu
Single Span beam, uniformly distributed load	1.92 Lu
Single Span beam, equal end moments	1.84 Lu
Cantilever beam, point load at unsupported end	1.69 Lu
Cantilever beam, uniform load w/ point load at end	1.69 Lu
Single Span beam, any other load	1.92 Lu

Left Fixity, Right Fixity

Specifies how the ends of the beam will be restrained.

[Wood Section] button and entry

Use this button to display the database of wood sections. The database provides selections for sawn, glued-laminated, and manufactured lumber. Please refer to the previous chapter describing using database in the Structural Engineering Library. Pressing **[Wood Section]** will display the following selection window:

Wood Section Database

Select Types to Display

Sawn **Glued-Laminated** **PowerBeam**

TJ: Parallam **TJ: Timber Strand** **VersaLam**

TJ: MicroLam **LP: Gang-Lam LVL** **Custom**

Specify Depth Range

Low: in

High: in

Type	Name	Width	Depth	Area	Ix	Sx	Iy	Sy	Ix/Area	Sx/Area
		in	in	in ²	in ⁴	in ³	in ⁴	in ³	in ³	in ³
Sawn	2x3	3.750	1.500	2.500	1.953	1.563	0.703	0.938	0.521	0.4167
Sawn	2-2x3	7.500	3.000	2.500	3.910	3.130	5.630	3.750	0.521	0.4173
Sawn	3-2x3	11.250	4.500	2.500	5.860	4.690	18.980	8.440	0.521	0.4169
Sawn	2x4	5.250	1.500	3.500	5.359	3.063	0.984	1.313	1.021	0.5833
Sawn	3x4	8.750	2.500	3.500	8.932	5.104	4.557	3.646	1.021	0.5833
Sawn	2-2x4	10.500	3.000	3.500	10.720	6.130	7.880	5.250	1.021	0.5838
Sawn	4x4	12.250	3.500	3.500	12.505	7.146	12.505	7.146	1.021	0.5833
Sawn	3-2x4	15.750	4.500	3.500	16.080	9.190	26.580	11.810	1.021	0.5835
Sawn	2x6	8.250	1.500	5.500	20.797	7.563	1.547	2.063	2.521	0.9167
Sawn	3x6	13.750	2.500	5.500	34.661	12.604	7.161	5.729	2.521	0.9167
Sawn	2-2x6	16.500	3.000	5.500	41.590	15.130	12.380	8.250	2.521	0.9170
Sawn	4x6	19.250	3.500	5.500	48.526	17.646	19.651	11.229	2.521	0.9167
Sawn	3-2x6	24.750	4.500	5.500	62.390	22.690	41.770	18.560	2.521	0.9168
Sawn	6x6	30.250	5.500	5.500	76.255	27.729	76.255	27.729	2.521	0.9167
Sawn	2x8	10.875	1.500	7.250	47.635	13.141	2.039	2.719	4.380	1.2083
Sawn	3x8	18.125	2.500	7.250	79.391	21.901	9.440	7.552	4.380	1.2083
Sawn	2-2x8	21.750	3.000	7.250	95.270	26.280	16.310	10.880	4.380	1.2083
Sawn	4x8	25.375	3.500	7.250	111.148	30.661	25.904	14.802	4.380	1.2083
Sawn	3-2x8	32.630	4.500	7.250	142.900	39.420	55.050	24.470	4.379	1.2081
Sawn	6x8	41.250	5.500	7.500	193.359	51.563	103.984	37.813	4.687	1.2500

Sort Order: [A-Z] [Z-A] [None]

Beam Width

Beam width is defined by the user, and will be used to determine section properties for stresses and deflections. This value can be modified at any time during the analysis process. The width is also used as the basis for the Selection procedure to determine required beam depth. The width must be ACTUAL (not nominal) width.

Beam Depth

Enter the actual depth of the beam, which in turn will be used to determine depth factor (Cf), actual bending stress, shear stress, and deflections. This value can be modified at any time to refine your

designs. You can also leave this entry zero, and press [F7] to display the selection window. From there the program automatically designs the depth of the member.

Beam Type

This selection controls how the Size of Volume factor is calculated. If "Sawn" is selection "Cf" is calculated. If "GluLam" is selected then "Cv" is calculated. If "Manufactured or So. Pine" selected then NO factor (Cf or Cv) is calculated.

Apply Live Load This Span?

This entry controls whether or not the live load entered for the span will be used or ignored. A YES/NO entry here gives you a simple way to try various live load alternates to determine maximum moments and shears on multi-span beams.

Applied Loads

Uniform

Uniform dead and live load applied to the entire length of the center span. You should be aware that beam weight is not considered in the program, therefore this input should include allowance for beam weight. These values may be positive or negative.

Partial Length Distributed

Uniform dead and live load applied over a full or partial length of the center span. X-Left indicates the distance from the left support to the beginning of the load, and X-Right is the distance from the left support to the right end of the load. These values may be positive or negative.

Trapezoidal Distributed

Uniform or varying dead and live load applied over a full or partial length of the center span. DL/LL @ Left indicates the dead or live load magnitude at the X-Left distance location. DL/LL @ Right indicates the dead or live load magnitude at the X-Right distance location. These values may be positive, negative, or both. X-Left indicates the distance from the left support to the beginning of the load, and X-Right is the distance from the left support to the right end of the load.

Point Load

Concentrated dead and live load applied to the beam.

Moment

Dead and live moment applied to the beam.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This tab gives ALL the calculated values for the span tab selected.

Results Sketch Diagrams Printing			
Beam is OK			
Moments & Stresses			
Max. Moment @ Mid-Span	48.6 in-k	@	7.50 ft
Max @ Left End	0.0 in-k		
Max @ Right End	0.0 in-k		
	<u>Actual</u>		<u>Allowable</u>
Bending Stress	209.0 psi		1,937.5 psi
Shear Stress	15.8 psi		106.3 psi
Max. Deflection	-0.047 in	@	7.50 ft
Shears & Reactions			
	<u>@ Left</u>		<u>@ Right</u>
Shear @ Support	1.080 k		1.080 k
Reactions...	Dead	1.080 k	1.080 k
	Live	0.000 k	0.000 k
	Total	1.080 k	1.080 k
Query.....			
Query Location		0.000	ft
Query Shear		1.080	k
Query Moment		0.000	in-k
Query Deflection		0.0000	in
Cf		1.000	
Rb		0.000	
Le		0.000	ft

Moments & Stresses

These are the maximum values to use for design for this span. The "Mid-Span" moment can occur anywhere between the two end supports. It is possible that this number is right next to the support.

Max. Moment @ Mid-Span

To determine maximum moments, the following technique is used:

- Fixed end moments are calculated for each span. When LL Flag is set to NO, no live loads are applied to that span.
- A 16 pass moment distribution is performed on the entire eight span system.
- The resulting end moments are then applied to each beam end and the resulting moments, shears, and deflections for the span are calculated. Each beam is divided into 250 increments for this process.

Max @ Left End & Right End

Maximum values for the calculated moments at the ends (or over the supports when a cantilever is present).

Bending Stress : Actual & Allowable

Allowable bending stress calculated considering C_f , load duration factor, and from the evaluation of allowable bending stress, due to the unbraced length. Actual bending stress is the maximum of positive or negative moment, divided by section modulus of the beam at that span location. Continuous beams will have this value equal to the maximum stress between the supports.

Shear Stress

Allowable stress is calculated load duration factor applied to F_v (see below). Actual shear stress is the maximum unit shear stress at the end of the beam. To determine net shear at the beam end, all loads within a distance d away from the end of the member are subtracted from the end shear. This value is multiplied by 1.5 and divided by beam width times beam depth. When the beam is continuous over a support, shear on BOTH SIDES of the support is evaluated.

Max. Deflection

Using the applied loads, support fixities, and moment distribution results, the resulting deflection curve at 250 points along the beam is searched for the maximum deflection and location. This is the maximum deflection, considering both upward and downward displacements. Negative sign is downward deflection.

Shear @ Left & Right Supports

The calculates shears at each support are given. This value is the maximum shear after checking both sides of the support.

Reactions @ Left & Right Supports

Reactions are calculated using dead load and the live load as selected to be applied for each span.

Query Values

In this area you can enter a distance location along the span, measured from the left support, and have the shear, moment, and deflection at that location calculated.

C_f or C_v

This item displays the size factor "C_f" for sawn members or the volume factor "C_v" for glued-laminated members.

R_b


This value is calculated from the compression edge slenderness of the beam and applied as a factor to the allowable stress.

L_e

This is the effective length used in the calculation of R_b.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Diagrams Tab

This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.



Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results | Sketch | Diagrams | Printing |

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Timber Member Information	<input checked="" type="checkbox"/>
Loads	<input checked="" type="checkbox"/>
Moment	<input checked="" type="checkbox"/>
Results	<input checked="" type="checkbox"/>
Reactions & Deflection	<input checked="" type="checkbox"/>
Query Values	<input checked="" type="checkbox"/>
Notes	<input type="checkbox"/>

Note: When all are selected, the software will still omit unused sections

Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Desgn: MDB Date: 9:21PM, 23 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 99000
 Use: ENERCALC Engineering Software
 Ver 5.8.0, 10-Sep-2003
 ©1983-2003 ENERCALC Engineering Software

Multi-Span Timber Beam

Page 1

ch:\c86\example\zow\Theater Calc

Description 3-Span System, 2 Load Patterns

General Information

Code Ref: 1997 NDS, 2003 IBC, 2003 NFPA 5000. Base allowables are user defined

All Spans Considered as Individual Beams	Fb: Basic Allow	1,550.0 psi	Elastic Modulus	1,800.0 lbs
	Fv: Basic Allow	85.0 psi	Load Duration Factor	1.250

Timber Member Information

Description	Span	15.00	21.00	8.00	15.00	15.00
Timber Section		5.125x16.5	5.125x16.5	5.125x16.5	5.125x16.5	5.125x16.5
Beam Width	in	5.125	5.125	5.125	5.125	5.125
Beam Depth	in	16.500	16.500	16.500	16.500	16.500
End Fixity		Pn - Pn	Pn - Pn	Pn - Pn	Pn - Pn	Pn - Pn
Le: Unbraced Length	ft	0.00	0.00	8.00	15.00	15.00
Member Type		GLULam	GLULam	GLULam	GLULam	GLULam

Loads

Live Load Used This Span ?	No	No	No	Yes	No
Dead Load	#/ft	144.00	144.00	144.00	144.00
Live Load	#/ft	260.00	260.00	260.00	260.00
Dead Load	#/ft				275.00
Live Load	#/ft				191.00
Start	ft				3.000
End	ft	15.000	15.000	8.000	15.000
Dead Load @ Left	#/ft				
Dead Load @ Right	#/ft				
Live Load @ Left	#/ft			321.00	
Live Load @ Right	#/ft				
Start	ft				
End	ft	15.000	15.000	8.000	15.000
Point #1 Dead Load	lbs				1,200.00
Live Load	lbs				1,500.00
@ X	ft				6.000

Results

Mmax @ Cnt	in-l	48.6	95.3	0.0	247.5	72.1
@ X =	ft	7.50	10.50	0.00	6.00	5.90
Max @ Left End	in-l	0.0	0.0	0.0	0.0	0.0
Max @ Right End	in-l	0.0	0.0	0.0	0.0	-122.1
f _b : Actual	psi	209.0	409.6	0.0	1,064.5	525.1
Fb: Allowable	psi	1,937.5	1,876.8	0.0	1,882.7	1,882.7
		Bending OK	Bending OK	Bending OK	Bending OK	Bending OK
Shear @ Left	l	1.08	1.51	0.00	4.65	1.64
Shear @ Right	l	1.08	1.51	0.00	4.11	3.00
f _v : Actual	psi	15.8	23.6	0.0	73.2	49.6
Fv: Allowable	psi	106.3	106.3	0.0	106.3	106.3
		Shear OK	Shear OK	Shear OK	Shear OK	Shear OK

Reactions & Deflection

DL @ Left	l	1.08	1.51	0.00	1.80	1.64
LL @ Left	l	0.00	0.00	0.00	2.85	0.00
Total @ Left	l	1.08	1.51	0.00	4.65	1.64
DL @ Right	l	1.08	1.51	0.00	1.56	3.00
LL @ Right	l	0.00	0.00	0.00	2.55	0.00
Total @ Right	l	1.08	1.51	0.00	4.11	3.00
Max. Deflection	in	-0.047	-0.182	0.000	-0.223	-0.051
@ X =	ft	7.50	10.50	0.00	7.30	6.40

Query Values

Location	ft	0.00	0.00	0.00	0.00	0.00
Moment	in-l	0.0	0.0	0.0	0.0	0.0
Shear	l	1.1	1.5	0.0	4.6	1.6
Deflection	in	0.0000	0.0000	0.0000	0.0000	0.0000

3.2 Timber Beam & Joist Design

This program provides design and analysis of up to seven simple beams on one calculation page. We've designed it primarily for rapid design of joists, rafters, and headers, and other wood members with simple loadings.

As you view the worksheet, you will notice seven side-by-side columns, each of which represents a single beam. In each of those columns, you can enter beam size data, allowable stresses, span lengths, and loads and view calculated output consists of stresses, reactions, shears, and deflections, and span/deflection ratios.

The program automatically applies live loads to the center span, cantilever span, and the entire span when calculating maximum moments, shears, reactions and deflections. This eliminates the need for you to change loadings to find all the maximum conditions.

ENERCALC c:\EC55\EXAMPLES\ECW - Timber Beam & Joist Design

Timber Beam & Joist Design

Tools & Settings | ? Help | Design | Print | Cancel | Save

General | Span 1 | Span 2 | Span 3 | Span 4 | Span 5 | Span 6 | Span 7 | Results | Sketch | Diagrams | Notes | Printing

Description []

Wood Section TJ MicroLam : 1.75x

Width 1.750 in

Depth 9.250 in

Type: Sawn GluLam Manuf. or So. Pine

Stress

Fb - Basic 1,450.0 psi

Fv - Basic 95.0 psi

Elastic Modulus 1,700.0 ksi

Load Duration Factor 1.000

Center Span Cantilever Repetitive Member?

Center Span = 8.500 ft

Le : Eff. unbraced Length 0.000 ft

Dead Load Live Load

Uniform: 29.3 #/ft 66.7 #/ft

Partial: #/ft #/ft

Start = 0.00 ft End = 0.00 ft

Point Ld #1: lbs at 0.00 ft

Point Ld #2: lbs at 0.00 ft

Point Ld #3: lbs at 0.00 ft

Point Ld #4: lbs at 0.00 ft

Results

Beam is OK

Deflection OK

Moments..

Mmax @ Center 10.40 in-k at 4.250 ft

M @ Rt Support 0.00 in-k

Stress Ratio 0.328

Bending.. fb 416.9 psi Fb 1,450.0 psi

Shear.. fv 31.15 psi Fv 95.00 psi

Reactions...

Left : DL 124.7 LL 283.3 Max 408.0 lbs

Right : DL 124.7 LL 283.3 Max 408.0 lbs

Defl. Ratio Limit = 356.0

Center Span Deflections...

DL	-0.018 in	@	4.25 ft	L/Defl Ratio	5,809
LL	-0.040 in	@	4.25 ft	L/Defl Ratio	2,556
DL+LL	-0.057 in	@	4.25 ft	L/Defl Ratio	1,775

Cantilever End Deflections...

DL	0.000 in	L/Defl Ratio	0
DL+LL	0.000 in	L/Defl Ratio	0
Cf	1.000		
Rb	0.000		
Le	0.000 ft		

Unique Features

- The user has the ability to quickly design up to seven beams or joists in this one program.
- Live loads are automatically skip-loaded when cantilevers are present to get maximum moments, shears, reactions, and deflections.
- The program checks depth factor and unsupported lengths to calculate allowable

bending stresses.

- The actual shear stress is calculated at a distance d from each support.

Assumptions & Limitations

- You must enter the actual beam depth and width.
- Beam ends can't be fixed nor can purely cantilever beams be analyzed. For this condition use either the Heavy Timber Beam or Multi-Span Timber Beam programs.
- Beam weight is not automatically added to entered loads.

Example


The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab contains only the input for a general description. Because this program designs individual beams on each tab all the entry information is contained on that particular tab.



Beam Tabs : #1 through #7

On each of these tabs you can design a complete beam. Each beam is simply span with an optional cantilever.

General		Span 1	Span 2	Span 3	Span 4	Span 5	Span 6	Span 7		
Description										
Wood Section		TJ MicroLam : 1.75x								
Width		1.750	in							
Depth		9.250	in							
Type :	<input type="radio"/> Sawn	<input type="radio"/> GluLam	<input checked="" type="radio"/> Manuf. or So. Pine							
Stress										
Fb - Basic		1,450.0	psi							
Fv - Basic		95.0	psi							
Elastic Modulus		1,700.0	ksi							
Load Duration Factor		1.000								
Center Span		Cantilever		Repetitive Member ?				<input checked="" type="checkbox"/>		
Center Span =		8.500 ft								
Le : Eff. unbraced Length		0.000 ft								
		<u>Dead Load</u>		<u>Live Load</u>						
Uniform		29.3	66.7		#/ft					
Partial					#/ft					
		Start =		0.00		ft		End =	0.00	ft
Point Ld #1					lbs		at	0.00	ft	
Point Ld #2					lbs		at	0.00	ft	
Point Ld #3					lbs		at	0.00	ft	
Point Ld #4					lbs		at	0.00	ft	

[Wood Section] button and entry

Use this button to display the database of wood sections. The database provides selections for sawn, glued-laminated, and manufactured lumber. Please refer to the previous chapter describing using database in the Structural Engineering Library. Pressing **[Wood Section]** will display the following selection window:

Wood Section Database

Select Types to Display

Specify Depth Range Low: in High: in

Type	Name	Width	Depth	Area	Ix	Sx	Iy	Sy	Ix/Area	Sx/Area		
		in	in	in ²	in ⁴	in ³	in ⁴	in ³	in ⁴ /Area	in ³ /Area		
Sawn	2x3			3.750	1.500	2.500	1.953	1.563	0.703	0.938	0.521	0.4167
Sawn	2-2x3			7.500	3.000	2.500	3.910	3.130	5.630	3.750	0.521	0.4173
Sawn	3-2x3			11.250	4.500	2.500	5.860	4.690	18.980	8.440	0.521	0.4169
Sawn	2x4			5.250	1.500	3.500	5.359	3.063	0.984	1.313	1.021	0.5833
Sawn	3x4			8.750	2.500	3.500	8.932	5.104	4.557	3.646	1.021	0.5833
Sawn	2-2x4			10.500	3.000	3.500	10.720	6.130	7.880	5.250	1.021	0.5838
Sawn	4x4			12.250	3.500	3.500	12.505	7.146	12.505	7.146	1.021	0.5833
Sawn	3-2x4			15.750	4.500	3.500	16.080	9.190	26.580	11.810	1.021	0.5835
Sawn	2x6			8.250	1.500	5.500	20.797	7.563	1.547	2.063	2.521	0.9167
Sawn	3x6			13.750	2.500	5.500	34.661	12.604	7.161	5.729	2.521	0.9167
Sawn	2-2x6			16.500	3.000	5.500	41.590	15.130	12.380	8.250	2.521	0.9170
Sawn	4x6			19.250	3.500	5.500	48.526	17.646	19.651	11.229	2.521	0.9167
Sawn	3-2x6			24.750	4.500	5.500	62.390	22.690	41.770	18.560	2.521	0.9168
Sawn	6x6			30.250	5.500	5.500	76.255	27.729	76.255	27.729	2.521	0.9167
Sawn	2x8			10.875	1.500	7.250	47.635	13.141	2.039	2.719	4.380	1.2083
Sawn	3x8			18.125	2.500	7.250	79.391	21.901	9.440	7.552	4.380	1.2083
Sawn	2-2x8			21.750	3.000	7.250	95.270	26.280	16.310	10.880	4.380	1.2083
Sawn	4x8			25.375	3.500	7.250	111.148	30.661	25.904	14.802	4.380	1.2083
Sawn	3-2x8			32.630	4.500	7.250	142.900	39.420	55.050	24.470	4.379	1.2081
Sawn	6x8			41.250	5.500	7.500	193.359	51.563	103.984	37.813	4.687	1.2500

Width & Depth

Enter the exact dimensions of the beam section being used. You can quickly change this entry to optimize your design. Also, the automatic member sizing will place a depth here.

Beam Type

This selection controls how the Size of Volume factor is calculated. If "Sawn" is selection "Cf" is calculated. If "GluLam" is selected then "Cv" is calculated. If "Manufactured or So. Pine" selected then NO factor (Cf or Cv) is calculated.

[Stress] button & entry

This allows you to use the built-in NDS & Manufactured lumber allowable stress database to retrieve allowable stresses. When you press the button you will see this selection window. Please see the section earlier in this User's Manual that give information and usage for the databases.

Wood Stress Database

Species... Size Classes to Show

Using 1997 UBC/NDS Stress Values

2"->4" Thick, 2" & Wider 5" x 5" & Larger Glued-Laminated
Beams & Stringers Posts & Timbers Manufactured

All stresses in PSI

<- Sort Order

Species	Grade	Class	Fb	Ft	Fv	Fc - Perp	Fc - P l	Elastic	Grading Agency
			Bending	Tension	Shear	Comp.	Comp.	Modulus	
Douglas Fir - Larch	Select structural	2-4	1,450	1,000	95	625	1,700	1,900,000	WCLIB WWPA
Douglas Fir - Larch	Dense Select Str	BS	1,900	1,100	85	730	1,300	1,700,000	WCLIB
Douglas Fir - Larch	No.1 & Better	2-4	1,150	775	95	625	1,550	1,800,000	WCLIB WWPA
Douglas Fir - Larch	Select structural	BS	1,600	950	85	625	1,100	1,600,000	WCLIB
Douglas Fir - Larch	Dense No.1	BS	1,550	775	85	730	1,100	1,700,000	WCLIB
Douglas Fir - Larch	No.1	2-4	1,000	675	95	625	1,500	1,700,000	WCLIB WWPA
Douglas Fir - Larch	No.2	2-4	875	575	95	625	1,350	1,600,000	WCLIB WWPA
Douglas Fir - Larch	No.1	BS	1,350	675	85	625	925	1,600,000	WCLIB
Douglas Fir - Larch	No.2	BS	875	425	85	625	600	1,300,000	WCLIB
Douglas Fir - Larch	No.3	2-4	500	325	95	625	775	1,400,000	WCLIB WWPA
Douglas Fir - Larch	Stud	2-4	675	450	95	625	850	1,400,000	WCLIB WWPA
Douglas Fir - Larch	Construction	2-4	1,000	650	95	625	1,650	1,500,000	WCLIB WWPA
Douglas Fir - Larch	Standard	2-4	550	375	95	625	1,400	1,400,000	WCLIB WWPA
Douglas Fir - Larch	Utility	2-4	275	175	95	625	900	1,300,000	WCLIB WWPA
Douglas Fir - Larch	Dense select Str	BS	1,850	1,110	85	730	1,300	1,700,000	WWPA
Douglas Fir - Larch	Select structural	BS	1,600	950	85	625	1,100	1,600,000	WWPA
Douglas Fir - Larch	Dense No.1	BS	1,550	775	85	730	1,100	1,700,000	WWPA
Douglas Fir - Larch	No.1	BS	1,350	675	85	625	925	1,600,000	WWPA
Douglas Fir - Larch	Dense No.2	BS	1,000	500	85	730	700	1,400,000	WWPA
Douglas Fir - Larch	No.2	BS	875	425	85	625	600	1,300,000	WWPA

Select Insert Change Delete Cancel

Fb:Basic

Enter the basic code-allowable bending stress here. Do not multiply it by any factors (load duration, depth, and slenderness). The program will calculate all appropriate factors, apply them to this value, and display the final Fb:Allowable value in the RESULTS section.

Fv: Basic

As for Fb:Allow described above, enter the basic code allowable shear stress.

Elastic Modulus

The elastic modulus should be entered in KSI, i.e. 1,700 ksi. This value is used to calculate deflections and allowable stress factors for long slender beams.

Load Duration Factor

This factor will modify the allowable bending and shear stresses. Since this value is applied to allowable values, your STRESS RATIO values should always be less than one.

Center Span TAB

This tab allows you to enter span length, unbraced length, and loads applied to the main span of the wood beam.

Center Span Length

Enter the length of the main beam span.

Le: Unbraced Length

Enter the unbraced length of the compression edge of the beam that is to be used for calculation of allowable bending stress based on possible failure of the beam by lateral-torsional buckling.

Uniform Loads

You can enter dead and live loads applied to the full length of the center span. This load has uniform intensity for the entire beam length.

Partial Load

Loads Here you can enter a uniform intensity dead and live load over all or just part of the beam's center span. X-Left is the starting point of the load with respect to the left support. X-Right is the ending point. Leaving both X-Left and X-Right zero will apply the load to the entire center span.

Point Loads

Up to four dead and live concentrated load can be applied to the center span. X-Dist. is the load's location from the left support.

Cantilever Span TAB

This tab allows you to an optional cantilever along with it's unbraced length and the applied loads.

Cantilever Length

Enter the length of the main beam span.

Le: Unbraced Length

Enter the unbraced length of the compression edge of the beam that is to be used for calculation of allowable bending stress based on possible failure of the beam by lateral-torsional buckling.

Uniform Loads

You can enter dead and live loads applied to the full length of the center span. This load has uniform intensity for the entire beam length.

Span Point Loads

Two dead and live concentrated load can be applied to the center span. X-Dist. is the load's location from the left support.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Results	Sketch	Diagrams	Notes	Printing
Beam is OK				
Deflection OK				
Moments..				
Mmax @ Center		10.40 in-k	at	4.250 ft
M @ Rt Support		0.00 in-k		
Stress Ratio		0.328		
Bending..	fb	416.9 psi	Fb	1,450.0 psi
Shear..	fv	31.15 psi	Fv	95.00 psi
Reactions...				
Left :	DL	124.7 LL	283.3 Max	408.0 lbs
Right :	DL	124.7 LL	283.3 Max	408.0 lbs
Defl. Ratio Limit =	<input type="text" value="356.0"/>			
Center Span Deflections...				
DL	-0.018 in	@	4.25 ft	L/Defl Ratio 5,809
LL	-0.040 in	@	4.25 ft	L/Defl Ratio 2,556
DL+LL	-0.057 in	@	4.25 ft	L/Defl Ratio 1,775
Cantilever End Deflections...				
DL	0.000 in			L/Defl Ratio 0
DL+LL	0.000 in			L/Defl Ratio 0
Cf	1.000			
Rb	0.000			
Le	0.000 ft			

M:max @ Center Span

This is the maximum moment within the center span. When a cantilever is present, any live loads are skip loaded to determine maximum moment.

Moment @ Right Support

This is the moment at the right support due only to the full dead and live load being applied to the cantilever.

Stress Ratio

Overall maximum actual / allowable stress ratio for the beam

Bending Stresses

Fb: Allow : Final allowable bending stress after calculating all modifications due to load duration, depth factors, and reductions for long unbraced compression edges.

Fb: Actual : Actual maximum bending stress along the full length of the beam.

Shear Stresses

Fv: Allow : Final allowable shear stress after applying the load duration factor.

Fv: Actual : Actual maximum shear stress at either end of the beam.

Reactions


Dead and live load support reactions. Live load reaction is the maximum reaction resulting from skip-loading when a cantilever is used.

Deflections

These are all the maximum dead and live load deflections and their distance from supports. Live load deflections result from Skip loading when a cantilever is present. The Length/Deflection ratios are multiplied by 2 for cantilevers, to adjust them to equivalent simple span deflection ratios.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Diagrams Tab

This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.



Notes Tab

This tab contains some general notes about the usage of the results of this program.

Results	Sketch	Diagrams	Notes	Printing
<p>General Notes...</p> <ul style="list-style-type: none"> • Calculations are designed to 1997 NDS and 1997 UBC Guideline • Section databases have been updated as of 2-Apr-1999 • Allowable stress databases have been updated to 1997 NDS & 1997 UBC values on 2-Apr-1999 • To determine Cf values for sawn sections, the program looks for the identifying words in the "Select", "No.1", "Standard" and similar typical words are used to determine Cf category • "Unbraced length" is multiplied by the following values to calculate "Le" <ul style="list-style-type: none"> When beam depth $\leq 7"$, $Le = 2.06 * Lu$ When $7" < \text{beam depth} \leq 14.3"$, $Le = 1.62 * Lu + 3d$ When beam depth $> 14.3"$, $Le = 1.84 * Lu$ 				

Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results	Sketch	Diagrams	Notes	Printing														
<p>Please select printout sections to be printed...</p> <table> <tr> <td>General Information</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Center Span Data</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Cantilever Span Data</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Results</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Reactions</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Deflections</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Notes</td> <td><input type="checkbox"/></td> </tr> </table> <p>Note: When all are selected, the software will still omit unused sections</p>					General Information	<input checked="" type="checkbox"/>	Center Span Data	<input checked="" type="checkbox"/>	Cantilever Span Data	<input checked="" type="checkbox"/>	Results	<input checked="" type="checkbox"/>	Reactions	<input checked="" type="checkbox"/>	Deflections	<input checked="" type="checkbox"/>	Notes	<input type="checkbox"/>
General Information	<input checked="" type="checkbox"/>																	
Center Span Data	<input checked="" type="checkbox"/>																	
Cantilever Span Data	<input checked="" type="checkbox"/>																	
Results	<input checked="" type="checkbox"/>																	
Reactions	<input checked="" type="checkbox"/>																	
Deflections	<input checked="" type="checkbox"/>																	
Notes	<input type="checkbox"/>																	

Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job #97-000001
 Design: MDB Date: 8:54AM, 25 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 990000
 Use: ENERCALC Example Problems, Ver 6.0.0, 10-Sep-2003
 ©1983-2003 ENERCALC Engineering Software
Timber Beam & Joist Page 1
 c:\e066\examples\enr\Timber Calc

Description 3 Beams

Timber Member Information Code Ref 1997 NDS, 2003 IBC, 2003 NFPA 5000. Base allowables are user defined.

Timber Section	Timber Size	1.75	3.50	5.125
Beam Width	in	1.750	3.500	5.125
Beam Depth	in	9.250	11.250	19.500
L: Unbraced Length	ft	0.00	0.00	22.00
Timber Grade				
Fb - Basic Allow	psi	1,450.0	1,300.0	2,200.0
Fv - Basic Allow	psi	95.0	85.0	165.0
Elastic Modulus	ksi	1,700.0	1,600.0	1,800.0
Load Duration Factor		1.000	1.000	1.000
Member Type		Manuf/Pine	Sawn	Sawn
Repetitive Status		Repetitive	No	No

Center Span Data

	1	2	3	
Span	ft	8.50	16.00	22.00
Dead Load	#/ft	29.33	104.00	335.00
Live Load	#/ft	66.67	96.00	560.00

Cantilever Span

	1	2	3
Span	ft		5.00
Uniform Dead Load	#/ft		12.00
Uniform Live Load	#/ft		32.00
Point #1 DL	lbs		572.00
LL	lbs		877.00
@ X	ft		5.000

Results Ratio = 0.3279 0.8660 1.1486

Mmax @ Center	in-k	10.40	59.80	649.77
@ X =	ft	4.25	7.04	11.00
Mmax @ Cantilever	in-k	0.00	-93.54	0.00
fb : Actual	psi	416.9	1,267.0	2,000.5
Fb : Allowable	psi	1,450.0	1,430.0	1,741.7
		Bending OK	Bending OK	OverStress
fv : Actual	psi	31.2	72.7	126.5
Fv : Allowable	psi	95.0	85.0	165.0
		Shear OK	Shear OK	Shear OK

Reactions

@ Left End DL	lbs	124.67	643.87	3,685.00
LL	lbs	283.33	768.00	6,160.00
Max. DL+LL	lbs	408.00	1,411.87	9,845.00
@ Right End DL	lbs	124.67	1,652.12	3,685.00
LL	lbs	283.33	2,104.06	6,160.00
Max. DL+LL	lbs	408.00	3,756.19	9,845.00

Deflections Ratio OK Deflection OK Deflection OK

Center DL Def	in	-0.016	-0.108	-0.310
L/Def Ratio		5,809.3	1,772.4	852.3
Center LL Def	in	-0.040	-0.213	-0.518
L/Def Ratio		2,556.1	901.2	509.9
Center Total Def	in	-0.057	-0.320	-0.828
Location	ft	4.250	7.616	11.000
L/Def Ratio		1,775.1	600.7	319.0
Cantilever DL Def	in		-0.043	
Cantilever LL Def	in		-0.219	
Total Cant. Def	in		-0.262	
L/Def Ratio			458.5	

3.3 General Timber Beam

This program provides design and analysis for wood beams with optional cantilevers at

one or both ends. A variety of loads and end fixities can be used to model most span conditions. This program is ideally suited for design and analysis of glued-laminated beams.

This program is provided as an alternative to the Multi-Span program. It gives more detailed analysis capabilities, allows more loads to be applied, gives cambers and bearing stresses, and allows the user to query the program for values at any beam location.

The program divides the beam into 250 span increments and determines maximum shear, moment, deflection, and stress at each location.

You can apply up to seven full and partial length distributed dead and live loads, up to eight point dead and live loads, and up to eight dead and live bending moments. These loads are easily specified by entering the magnitude and location with reference to the left support.

The beam can have either end fixed or pinned in various combinations. From the user defined loading condition, allowable stresses, and end fixities, the program calculates maximum and minimum shears, moments, and deflections.

The user has options to specify automatic calculation of beam weights, reduction of end shears by loads within a distance d from a support, enter unbraced lengths to govern allowable stresses, and set a lamination thickness to be used for automatic member sizing of laminated beams.

ENERCALC c:\ECSS\EXAMPLES.ECW - General Timber Beam Design

General Timber Beam Design

Tools & Settings | ? Help | Design | Print | Cancel | Save

General | Uniform & Trapezoidal | Point & Moment Loads | Summary | Sketch | Diagrams | Printing | Notes

Description: Example Problem #2, Double Cantilevered Beam

Center Span: 48.000 ft Lu: 0.000 ft
 Left Cantilever: 8.500 ft Lu: 8.500 ft
 Right Cantilever: 6.500 ft Lu: 6.500 ft

Wood Section: 5.125x36.0
 Beam Width: 5.125 in
 Beam Depth: 36.000 in

End Finity: Pin-Pin Pin-Fix
 Fix-Fix Fix-Pin Fix-Free

Sawn GluLam
 Manuf. or So. Pine

Wood Species: Douglas Fir, 24F -V8

Fb: Base Allowable: 2,400.0 psi
 Fv: Allowable: 190.0 psi
 Fc-Perp: Allowable: 560.0 psi
 Elastic Modulus: 1,800.0 ksi

Repetitive Member?:
 Load Duration Factor: 1.250
 Calc shear at "depth" from support?:

Results | Stress Calcs | Deflections | Query

Beam Design OK

Max Stress Ratio 0.723 : 1

Maximum Moment 153.3 k-ft **Stress** 1,661.3 psi
 Allowable: 212.1 k-ft 2,299.2 psi

Maximum Shear * 1.5 26.8 k 145.4
 Allowable: 43.8 k 237.5 psi

Max Mid-Span Deflection -1.693 in
 Length / Deflection Ratio 340.2 : 1

Moment Details...
 Max. Pos Mom: 153.28 k-ft at 24.377 ft
 Max. Neg Mom: 38.76 k-ft at 0.000 ft
 Max @ Left Support: -73.17 k-ft
 Max @ Right Support: -68.76 k-ft

Shears...
 Max @ Left Support: 16.49 k
 Max @ Right Support: 17.89 k

Reactions...
 @ Left Support: Dead Load: 14.804 k Max: 27.854 k
 @ Right Support: Dead Load: 15.151 k Max: 31.809 k

Basic Usage

- Beam Data defines the size and allowable stress for the beam to be analyzed or designed. Width must always be entered, but Depth can either be entered to analyze a beam or can be automatically selected.
- Lamination Thickness is used by the selection routine as the minimum increment the beam depth should be adjusted to.
- Allowable Stresses will be modified according to load duration factor, size factor, and beam slenderness (as applicable).
- Beam Density is only used when the Use Beam Wt entry is set to YES.
- Design Data modifies the allowable values and modifies how stresses are calculated. Load Duration Factor is applied to all allowable stresses. Use Beam Weight is a YES/NO flag that will automatically add a uniform load to the beam to account for its own weight. Reduce Shear By d is also a YES/NO flag that, when set to Yes, will deduct all loads within a distance Beam Depth from each support when calculating shears.
- End Conditions define how the beam ends are attached to their supports. If cantilever information is entered for a side of the beam that has been specified as fixed, that information (including loads) is ignored.
- This program provides plenty of load capability for loading any part of the beam. All Dist. values position the load with respect to the left support. To apply a load to the left cantilever, enter the distances as negative.
- Summary gives stress results for the beam analysis. Maximum Moments are given

for the center span and cantilevers (and their locations). Allowable and Actual Stresses are also given for the worst case conditions. Reactions and Deflections are given for dead load only and total load cases.

- Live load is ALWAYS skip loaded to determine the maximum moment in the center span.

Automatic Beam Sizing

Using the **[Design]** button you can display a screen that will enable you to set design parameters and examine a database of wood members for selection of those that satisfy your criteria.

The screenshot shows a dialog box titled "Design Beam". It contains a "Section Type" group box with four radio buttons: "Sawn" (selected), "Glued-Laminated", "TJ : Parallam", and "TJ : TimberStrand". Below this is "Custom (User Defined)". To the right, there are two numeric input fields: "Maximum Stress Ratio" set to "1.00" and "Minimum Total Deflection Ratio" set to "240.0". At the bottom, there are two buttons: "Cancel" with a red "X" icon and "Go" with a magnifying glass icon.


- Specify maximum deflection ratios for dead and total loads.
- Specify overstress limits for bending and shear forces.
- Use "Go" to start the database search. The beam width and lamination thickness already present in the calcsheet will be used to determine a depth considering bending and shear stresses and deflections.

Assumptions & Limitations

Live loads are automatically placed in various combinations of center, left, and right cantilever spans to determine maximum moments, shears, deflections, and reactions.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab provides data entry for all input except loads.

General		Uniform & Trapezoidal		Point & Moment Loads	
Description Example Problem #2, Double Cantilevered Beam					
Center Span	48.000	ft	Lu	0.000	ft
Left Cantilever	8.500	ft	Lu	8.500	ft
Right Cantilever	6.500	ft	Lu	6.500	ft
Wood Section 5.125x36.0		End Fixity			
Beam Width	5.125	in	<input checked="" type="radio"/> Pin-Pin <input type="radio"/> Pin-Fix <input type="radio"/> Fix-Fix <input type="radio"/> Fix-Pin <input type="radio"/> Fix-Free		
Beam Depth	36.000	in			
<input type="radio"/> Sawn <input checked="" type="radio"/> GluLam <input type="radio"/> Manuf. or So. Pine					
Wood Species Douglas Fir, 24F - V8					
Fb : Base Allowable	2,400.0	psi			
Fv : Allowable	190.0	psi			
Fc-Perp : Allowable	560.0	psi			
Elastic Modulus	1,800.0	ksi			
Repetitive Member ?			<input type="checkbox"/>		
Load Duration Factor	1.250				
Calc shear at "depth" from support ?			<input type="checkbox"/>		

Center Span

Span distance between the left and right supports for the beam.

Left & Right Cantilever

Specifies the length of the cantilevers, if applicable.

Lu : Unbraced Lengths

These lengths define the length of unbraced compression edge (L_e) for use in calculating allowable bending stresses based on beam slenderness.

For cantilevers, you should always consider whether knee braces or other equivalent means of lateral support are provided to stabilize the compression edge.

End Fixity

This Fixity Code is used to specify the end conditions of your beam.

- Pinned-Pinned allows cantilevers at either end, and only rotation of the beam-ends are allowed.
- Fixed-Pinned & Pinned-Fixed allow one end to rotate and have a cantilever, while the other end is rigidly attached to a boundary element (allowing no rotation). If loads are specified with locations past the fixed support, they are ignored.

- Fixed-Fixed attaches both beam ends to rigid boundary elements. All information for cantilevers and load locations outside the center span are ignored.

[Wood Section] button and entry

Use this button to display the database of wood sections. The database provides selections for sawn, glued-laminated, and manufactured lumber. Please refer to the previous chapter describing using database in the Structural Engineering Library. Pressing [Wood Section] will display the following selection window:

Wood Section Database

Select Types to Display

Specify Depth Range Low: in High: in

Sawn Glued-Laminated PowerBeam

TJ: Parallam TJ: Timber Strand VersaLam

TJ: MicroLam LP: Gang-Lam LVL Custom

Type	Name	Width	Depth	Area	Ix	Sx	Iy	Sy	Ix/Area	Sx/Area
		in	in	in ²	in ⁴	in ³	in ⁴	in ³	in ³	in ³
Sawn	2x3	3.750	1.500	2.500	1.953	1.563	0.703	0.938	0.521	0.4167
Sawn	2-2x3	7.500	3.000	2.500	3.910	3.130	5.630	3.750	0.521	0.4173
Sawn	3-2x3	11.250	4.500	2.500	5.860	4.690	18.980	8.440	0.521	0.4169
Sawn	2x4	5.250	1.500	3.500	5.359	3.063	0.984	1.313	1.021	0.5833
Sawn	3x4	8.750	2.500	3.500	8.932	5.104	4.557	3.646	1.021	0.5833
Sawn	2-2x4	10.500	3.000	3.500	10.720	6.130	7.880	5.250	1.021	0.5838
Sawn	4x4	12.250	3.500	3.500	12.505	7.146	12.505	7.146	1.021	0.5833
Sawn	3-2x4	15.750	4.500	3.500	16.080	9.190	26.580	11.810	1.021	0.5835
Sawn	2x6	8.250	1.500	5.500	20.797	7.563	1.547	2.063	2.521	0.9167
Sawn	3x6	13.750	2.500	5.500	34.661	12.604	7.161	5.729	2.521	0.9167
Sawn	2-2x6	16.500	3.000	5.500	41.590	15.130	12.380	8.250	2.521	0.9170
Sawn	4x6	19.250	3.500	5.500	48.526	17.646	19.651	11.229	2.521	0.9167
Sawn	3-2x6	24.750	4.500	5.500	62.390	22.690	41.770	18.560	2.521	0.9168
Sawn	6x6	30.250	5.500	5.500	76.255	27.729	76.255	27.729	2.521	0.9167
Sawn	2x8	10.875	1.500	7.250	47.635	13.141	2.039	2.719	4.380	1.2083
Sawn	3x8	18.125	2.500	7.250	79.391	21.901	9.440	7.552	4.380	1.2083
Sawn	2-2x8	21.750	3.000	7.250	95.270	26.280	16.310	10.880	4.380	1.2083
Sawn	4x8	25.375	3.500	7.250	111.148	30.661	25.904	14.802	4.380	1.2083
Sawn	3-2x8	32.630	4.500	7.250	142.900	39.420	55.050	24.470	4.379	1.2081
Sawn	6x8	41.250	5.500	7.500	193.359	51.563	103.984	37.813	4.687	1.2500

Sort Order

Select

+

Insert

△

Change

-

Delete

✕

Cancel

Depth & Width

Enter the beam width & depth you wish to use, or select the beam from the database (see above).

Beam Type

This selection controls how the Size of Volume factor is calculated. If "Sawn" is selection "Cf" is calculated. If "GluLam" is selected then "Cv" is calculated. If "Manufactured or So. Pine" selected then NO factor (Cf or Cv) is calculated.

Wood Species : [Stress] button & entry

This allows you to use the built-in NDS & Manufactured lumber allowable stress database to retrieve allowable stresses. When you press the button you will see this selection window. Please see the section earlier in this User's Manual that give information and usage for the databases.

Wood Stress Database

Species...

Size Classes to Show: 2"->4" Thick, 2" & Wider 5" x 5" & Larger Glued-Laminated
 Beams & Stringers Posts & Timbers Manufactured

Using 1997 UBC/NDS Stress Values

All stresses in PSI

<- Sort Order

Species	Grade	Class	F _b	F _t	F _v	F _{c-Perp}	F _{c-Prll}	Elastic	Grading Agency
			Bending	Tension	Shear	Comp.	Comp.	Modulus	
Douglas Fir	16F-E6	GLB	1,600	1,000	165	650	1,600	1,600,000	
Douglas Fir	20F-E6	GLB	2,000	1,150	165	650	1,650	1,700,000	
Douglas Fir	22F-E5	GLB	2,200	1,100	165	650	1,650	1,700,000	
Douglas Fir	24F-E10	GLB	2,400	1,300	165	650	1,750	1,900,000	
Douglas Fir	24F-E12	GLB	2,400	1,200	155	650	1,600	1,900,000	
Douglas Fir	24F-E13	GLB	2,400	1,250	165	650	1,700	1,800,000	
Douglas Fir	24F-E18	GLB	2,400	950	190	650	1,600	1,800,000	
Douglas Fir	24F-V8	GLB	2,400	1,100	190	560	1,650	1,800,000	
E-Rated Southern Pine	20F-E3	GLB	2,000	1,150	200	650	1,700	1,700,000	
E-Rated Southern Pine	22F-E3	GLB	2,200	1,150	200	650	1,650	1,700,000	
E-Rated Southern Pine	24F-E4	GLB	2,400	1,250	200	650	1,750	1,800,000	
Hem Fir	16F-E7	GLB	1,600	850	155	500	1,150	1,400,000	
Hem Fir	20F-E7	GLB	2,000	1,050	155	500	1,550	1,600,000	
Hem Fir	22F-E6	GLB	2,200	1,050	155	500	1,500	1,700,000	
Hem Fir	24F-E11	GLB	2,400	1,150	155	500	1,550	1,800,000	
Hem Fir	24F-E16	GLB	2,400	850	155	500	1,400	1,700,000	
Hem Fir	24F-E19	GLB	2,400	950	155	500	1,200	1,800,000	
Hem Fir / Softwood	24F-E17	GLB	2,400	750	140	500	1,250	1,800,000	
Southern Pine	16F-V5	GLB	1,600	1,000	200	560	1,550	1,400,000	
Southern Pine	20F-V5	GLB	2,000	1,050	200	560	1,550	1,600,000	

Buttons: Select, Insert, Change, Delete, Cancel

F_b-Bending : Base Allowable

Basic allowable bending stress to be used for design and analysis. This stress will be modified based by slenderness, size factor, and load duration factor.

F_v-Shear

Allowable shear stress to be used in design. This allowable will be modified by the load duration factor.

F_c-Bearing

Allowable bearing stress perpendicular to the grain.

Elastic Modulus

Enter the modulus of elasticity to be used in determining deflections and calculation of F_b for laterally unbraced beams.

Repetitive Member Flag

Check this box if the multi-span beam can be considered to be a repetitive member according to NDS definitions.

Load Duration Factor

Load duration factor to be applied to allowable bending and shear stresses. Application of this factor is in accordance with NDS.

Lamination Thickness

You can specify a lamination thickness to be used to determine the minimum required depth increment. The program determines the minimum number of laminations of this thickness that are needed, and rounds up a full lamination. Leave this value set to zero for exact depth calculations.

Calc Shear at "depth" from Support ?

This YES/NO flag allows you to disable the automatic subtraction of all loads within a distance Beam Depth from a support (when determining design shears).

Uniform & Trapezoidal Loads Tab

General	Uniform & Trapezoidal	Point & Moment Loads
Uniform Loads Over Full Span		
<input checked="" type="checkbox"/> Auto Calc Beam Weight ?	Wood Density	<input type="text" value="0.00"/> #/ft
	Dead Load	Live Load
Center Span	<input type="text" value="360.0"/> #/ft	<input type="text" value="288.0"/> #/ft
Left Cantilever	<input type="text" value="360.0"/> #/ft	<input type="text" value="288.0"/> #/ft
Right Cantilever	<input type="text" value="360.0"/> #/ft	<input type="text" value="288.0"/> #/ft
Trapezoidal Loads		
	#1	#2
DL @ Left	<input type="text"/> #/ft	<input type="text"/> #/ft
DL @ Right	<input type="text"/> #/ft	<input type="text"/> #/ft
LL @ Left	<input type="text" value="25.0"/> #/ft	<input type="text"/> #/ft
LL @ Right	<input type="text" value="500.0"/> #/ft	<input type="text"/> #/ft
Start Location	<input type="text" value="37.250"/> ft	<input type="text" value="0.000"/> ft
End Location	<input type="text" value="54.500"/> ft	<input type="text" value="0.000"/> ft
	#3	#4
DL @ Left	<input type="text"/> #/ft	<input type="text"/> #/ft
DL @ Right	<input type="text"/> #/ft	<input type="text"/> #/ft
LL @ Left	<input type="text"/> #/ft	<input type="text"/> #/ft
LL @ Right	<input type="text"/> #/ft	<input type="text"/> #/ft
Start Location	<input type="text" value="0.000"/> ft	<input type="text" value="0.000"/> ft
End Location	<input type="text" value="0.000"/> ft	<input type="text" value="0.000"/> ft

Uniform Loads Over Full Span

Auto Calc Beam Weight

Check this box to have the program calculate the beam weight and apply it as a uniform loads on the center and cantilever spans.

Wood Density

Enter the density of the beam. It will only be used if the **Auto Calc Beam Weight** box is checked.

Center Span Dead & Live Loads

Enter the uniform dead and live loads acting on the center span of the beam. These entries allow you to apply one uniform dead and live load to the center span.

Left & Right Cantilever Dead & Live Loads

Enter the uniform dead and live loads acting on either of the cantilevers. The loads are applied to the entire cantilever length.

Trapezoidal Loads

This section allows you to enter loads that can have different end magnitudes and can start and end at any location along the beam.

--->>> Note! Entering ONLY the "Left" value and leaving the "Right" load and BOTH Start and End location blank will make the load a uniform full length loads.

Load @ Left & Right

These entries define the magnitudes of the ends of the loads. The load magnitude is then linearly interpolated between the starting and ending points. These values may be positive or negative to indicate downward or upward force direction.

Left & Right Locations

The starting and ending extents of the loads are entered here. These values are entered as the distance from the LEFT support. For loads on the left cantilever enter a negative value. For loads on the right cantilever the location must be greater than the "Center Span" length.

Point & Moment Loads Tab

	#1	#2	#3	#4	
Dead	3,030.0	4,245.0			lbs
Live	2,824.0	2,796.0			lbs
Dist.	-8.500	54.500	0.000	0.000	ft
	#5	#6	#7		
Dead					lbs
Live					lbs
Dist.	0.000	0.000	0.000		ft

	#1	#2	#3	
Dead				in-#
Live				in-#
Dist.	0.000	0.000	0.000	ft
	#4	#5	#6	
Dead				in-#
Live				in-#
Dist.	0.000	0.000	0.000	ft
	#7			
Dead				in-#
Live				in-#
Dist.	0.000			ft

Point Loads

Dead & Live Loads

This entry allows you to apply up to eight concentrated dead and live loads to any portion of the entire beam; center span or cantilevers.

Distance

All distances are referenced from the left support.

Moment Loads

Dead & Live Moment

This entry allows you to apply up to eight moments dead and live loads to any portion of the entire beam.....center span or cantilevers.

Distance

All distances are referenced from the left support.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Summary / Results Tab

Max. Stress Ratio

Considering all placement options for live loads and examining the maximum moment at all locations of the beam, this is the maximum stress ratio calculated by dividing that moment by the beam's S_{xx} section modulus times the allowable bending stress.

Maximum Moment & Stress

This is the maximum moment used in the "Max. Stress Ratio" calculation and the resulting stress in the beam. Also given is the allowable moment and stress.

Maximum Shear * 1.5

Considering all placement options for live loads and examining the maximum shear at all locations of the beam, this is the maximum value multiplied by the code required 1.5 to arrive at a design shear. Also given are the actual and allowable stresses

Max Mid-Span Deflection

Considering all placement options for live loads and examining the maximum deflection across the center span of the beam, this the maximum value. Also given is the Length / Deflection ratio

Moment Details

More details about the maximum values for positive and negative moments and support moments are given.

Shears

This is the maximum shear calculated at both ends. Live load is automatically placed in all possible location combinations to determine the maximum shear value on each side of the supports. (This shear is not modified for loads within d distance from end of beam nor multiplied by typical 1.5 shear factor. Please see Design Shear for those adjusted numbers).

Reactions

For both left and right support, the dead and total load reactions are given. When cantilevers are present, live load is omitted from the cantilever at the opposite end from the support. Live load is automatically placed in all possible location combinations to determine the maximum shear value on each side of the supports.

Summary / Stress Calcs Tab

Bending Analysis

Le

Unbraced length used for allowable bending stress calculation of "Cl" factor.

Cv

This item will display as "Cv" for glued laminated beams when the volume factor applies and as "Cf" for sawn or manufactured members when the size factor applies.

Rb

Slenderness ratio for the beam.

Cl

Reduction factor that will be applied to the F_b : Basic Allowable to reduce the allowable bending stress based on unbraced compression edge lengths.

Sxx & Area

Section properties for the beam being analyzed.

Max. Moment, Sxx Required, Fb:Allowable @ Span

This is a summary of important bending analysis values at the three critical locations in the beam.

Shear Analysis**Design Shear**

By dividing the entire beam into 250 increments, the maximum shears are determined by applying live loads on various portions of the beam to create maximum effects on either side of the supports and mid-span. Then all loads within a distance equal to the beam depth from the end of beam are subtracted, and the result multiplied by 1.5.

Area Required

Required shear area of beam calculated by Design Shear / FV:Allowable.

Fv:Allowable

Fv is equal to the allowable shear stress times load duration factor.

Bearing @ Supports

Maximum reactions at each support are divided by allowable bearing stress, and beam width to determine the required length of bearing.

Summary / Deflections Tab**Dead Load & Total Load Values**

Dead load deflections represent the calculated deflections when the entered dead load (and beam self weight if chosen) is applied to the entire span.

Total load deflections represent the MAXIMUM deflections at each location on the beam.

Deflection, Location & Length/Defl Ratio

This area gives the deflection value, the location from the LEFT support (negative for left cantilever), and Span Length / Deflection Ration.

Note: negative deflections are downward

Note: For cantilevers the deflection ratio is calculated as $(2.0 * \text{Cant. Length}) / (\text{Deflection at end})$.

Because code deflection ratio limits are suggested for simple span beams with two supports a cantilever represents just 1/2 of the equivalent span.

Camber

This is 1.5 times the dead load deflections

Summary / Query Tab**Locations**

Enter the location measures from the left support for where you would like the detailed value calculated.

Use "LL" at xxxxxx for Query


This selection instructs the program how to apply the live load for this query value.

Calculated Values

Gives the calculated moment, shear, and deflection for the location specified.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.




Diagrams Tab

This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.




Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".



Notes Tab

This tab contains some general notes about the usage of the results of this program.



Sample Printout

Page 1

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 9:36AM, 25 OCT 03
Description: Collection of example problems
Scope: All programs in the Structural Engineering Library

Rev: 680000
 User: KW-0600001, Ver 8.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

General Timber Beam

Page 1
 c:\ec03\examples\ew\Timber Calc

Description Example Problem #2, Double Cantilevered Beam

General Information Code Ref: 1997 NDS, 2003 IBC, 2003 NFPA 5000. Base allowables are user defined

Section Name		Center Span	48.00 ft	Lu	0.00 ft
Beam Width	5.125 in	Left Cantilever	8.50 ft	Lu	8.50 ft
Beam Depth	40.500 in	Right Cantilever	6.50 ft	Lu	6.50 ft
Member Type					
Load Dur. Factor	1.250	Fb Base Allow	2,400.0 psi		
Beam End Fixity	Pin-Pin	Fv Allow	165.0 psi		
		Fc Allow	385.0 psi		
		E	1,800.0 ksi		

Full Length Uniform Loads

Center	DL	360.00 #/ft	LL	288.00 #/ft
Left Cantilever	DL	360.00 #/ft	LL	288.00 #/ft
Right Cantilever	DL	360.00 #/ft	LL	288.00 #/ft

Trapezoidal Loads

#1 DL @ Left	#/ft	LL @ Left	25.00 #/ft	Start Loc	37.250 ft
DL @ Right	#/ft	LL @ Right	500.00 #/ft	End Loc	54.500 ft

Point Loads

Dead Load	3,030.0 lbs	4,245.0 lbs	lbs	lbs	lbs	lbs	lbs
Live Load	2,824.0 lbs	2,796.0 lbs	lbs	lbs	lbs	lbs	lbs
...distance	-8.500 ft	54.500 ft	0.000 ft	0.000 ft	0.000 ft	0.000 ft	0.000 ft

Summary **Overstressed in Bending !**

Span= 48.00ft, Left Cant= 8.50ft, Right Cant= 6.50ft, Beam Width = 5.125in x Depth = 40.5in, Ends are Pin-Pin							
Max Stress Ratio	0.000 : 1			Maximum Shear * 1.5	26.8 k		
Maximum Moment	153.3 k-ft			Allowable	42.8 k		
Max. Positive Moment	153.26 k-ft	at	24.377 ft	Shear:	@ Left	16.49 k	
Max. Negative Moment	-38.76 k-ft	at	0.000 ft		@ Right	17.89 k	
Max @ Left Support	-73.17 k-ft			Camber:	@ Left	0.274 in	
Max @ Right Support	-68.76 k-ft				@ Center	0.722 in	
Max. M allow	0.00				@ Right	0.225 in	
				Reactions...			
Fb	1,312.64 psi	Fv	129.27 psi	Left DL	14.80 k	Max	27.85 k
Fb	0.00 psi	Fv	206.25 psi	Right DL	15.15 k	Max	31.81 k

Deflections

Center Span...	Dead Load	Total Load	Left Cantilever...	Dead Load	Total Load
Deflection	-0.482 in	-1.189 in	Deflection	0.183 in	0.568 in
...Location	24.126 ft	24.126 ft	...Length/Defl	1,117.3	359.3
...Length/Defl	1,196.0	484.36			
Camber (using 1.5 * D.L. Defl) ...			Right Cantilever...		
@ Center	0.722 in		Deflection	0.150 in	0.451 in
@ Left	0.274 in		...Length/Defl	1,039.9	345.7
@ Right	0.225 in				

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 9:36AM, 25 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 580000 User: KAW-0000001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software
General Timber Beam Page 2
 c:\e05\examples\cor:\timber Calc

Description Example Problem #2, Double Cantilevered Beam


Stress Calcs

Bending Analysis					
Ck	19.865	Le	17.503 ft	Sxx	1,401.047 in ³
	0.000	Rb	18.000	CI	0.000
				Area	207.563 in ²
			<u>Max Moment</u>	<u>Sxx Req'd</u>	<u>Allowable fb</u>
@ Center			153.26 k-ft	0.00 in ³	0.00 psi
@ Left Support			73.17 k-ft	0.00 in ³	0.00 psi
@ Right Support			68.76 k-ft	0.00 in ³	0.00 psi
Shear Analysis					
		@ Left Support		@ Right Support	
Design Shear		24.74 k		26.83 k	
Area Required		119.941 in ²		130.094 in ²	
Fv Allowable		206.25 psi		206.25 psi	
Bearing @ Supports					
Max. Left Reaction		27.85 k		Bearing Length Req'd	14.117 in
Max. Right Reaction		31.81 k		Bearing Length Req'd	16.121 in

Query Values

M, V, & D @ Specified Locations	Moment	Shear	Deflection	
@ Center Span Location =	12.50 ft	74.12 k-ft	7.65 k	-0.6033 in
@ Right Cant. Location =	33.00 ft	95.59 k-ft	-5.54 k	0.3027 in
@ Left Cant. Location =	-8.00 ft	-1.53 k-ft	-6.02 k	-0.7089 in

Sketch & Diagram



3.4 Series of Cantilevered Beams

This program analyzes and designs a series of statically determinate simple span and cantilevered beams. This type of framing arrangement is typically used in warehouse type

structures where long runs of cantilevered and simple span beams provide an economical framing system. The economy of this type of framing system can be improved when the positive and negative moments are nearly equal in magnitude, thereby fully utilizing the beam.

Live load is automatically applied to various span combinations to give maximum reactions, shears, moments, and deflections. Using the column layout of the calcsheet, you can model a variety of different framing systems. The following span combinations can be used to model a line of beams having up to eight beams:

- Single Cantilever Simple Span Single Cantilever
- Simple Span Double Cantilever Simple Span
- Simple Span Simple Span Simple Span

On each span, you can apply one uniform load, one partial length uniform load, and four point loads, each having dead and live components.

NOTE!! When entering loads in the various calcsheet columns, keep in mind that the load is applied to beams and cantilevers located between the supports, NOT JUST TO THE BEAM REFERRED TO IN THE COLUMN TITLE. This enables you to simply specify the point load locations, and the program will determine if it applies to the simple span beam or the adjacent cantilevers.

The program also offers some general design options:

- Automatic live load alternate span placement.
- For laminated beams; specification of lamination thickness for automatic design.
- Consideration of load duration factors for live and/or snow loads.
- The program also offers two unique abilities:
- Automatic Cantilever Balancing. This feature automatically adjusts cantilever lengths to balance the positive and negative moments.
- Automatic Beam Depth Determination using the calculated moments and shears.

ENERCALC c:\ECSS\EXAMPLES.ECW - Cantilevered Beam System

Cantilevered Beam System

Tools & Settings | Optimize Cantilevers | Help | Design | Print | Cancel | Save

General | Right Cant | Key #1 | Double #1 | Key #2 | Double #2 | Key #3 | Results | Sketch | Notes | Printing

Column Spacing: 40.000 ft

Left Cantilever: 6.881 ft

Right Cantilever: 9.762 ft

Unbraced Length: 0.000 ft

Wood Section: 5.0x34.5

Beam Width: 5.000 in

Beam Depth: 34.500 in

Beam Type: Sawn GluLam Manuf or So. Pine

Loads:

Load Type	Dead Load	Live Load	Location
Uniform	96.0 #/ft	128.0 #/ft	
Partial			Start: 0.00 ft, End: 0.00 ft
Point Ld #1	6,720.0 lbs	5,760.0 lbs	16.00 ft
Point Ld #2			0.00 ft
Point Ld #3			0.00 ft
Point Ld #4			0.00 ft
Point Ld #5			0.00 ft
Point Ld #6			0.00 ft
Point Ld #7			0.00 ft

Results: **Beam is OK**

Moments...

Max @ Left End	-108.5 k-ft
Max. Moment @ Mid-Span	108.0 k-ft
Max @ Right End	-108.2 k-ft

Bending Stress...

Fb : Actual	1,312.4 psi
Fb : Allowable	2,537.1 psi

Shear Stress...

Maximum Shear	15,894 lbs
Fv : Actual	138.2 psi
Fv : Allowable	237.5 psi

Deflections...

	Dead Load	Total Load
Left Cantilever	-0.109 in	-0.586 in
Center Span	-0.047 in	-0.692 in
Right Cantilever	-0.217 in	-0.907 in

Maximum Reactions...

	@Left	@Right
Maximum Reaction	29,879 lbs	22,962 lbs
Cf	0.846	
Rb	0.000	
Le	0.000 ft	

Basic Usage

- If this will be a design calculation, enter the lamination thickness that should be used when automatically calculating required beam depths.
- Since this system of beams can have numerous arrangements of live load, set Skip Load Live to YES indicate if you wish the program to perform the extra calculations to place live loads in all possible locations for maximum values. Indicate the load duration factor for the type of loads you will be applying, and indicate if cantilever bracing should be assumed. If no bracing is used, all cantilevers will go through code checking with the unbraced length equal to 2*Cant. Span.
- Enter the column spacing for the system of beams. All beams must be in line with one another, and up to eleven spans can be used. For more spans, try to look for symmetry and model accordingly. Then take a first trial estimate of the various cantilever lengths for the beams.
- Although depth isn't required if you will be doing an automatic design, you must enter a beam width for each span. If you choose the auto design capability, the program will determine the depth (considering lamination increments) for you.
- Use the Beam Design Data section to specify the material properties for the timber beam.
- Up to nine loads can be applied between each column. The two uniform load entries allow a full length and partial length load to be applied. The partial length load can be used to apply a different load to the simple span beam than to the adjacent cantilevers. Point loads can be applied anywhere between the supports; the

program uses the X-Dist. values to apply the load to the cantilever or simple beam.

Unique Features

With this program you can either analyze or optimize the design of a series of simple span and cantilever beams.


- By specifying a cantilever at only one end of a double cantilever beam, you can simulate a Single Cant. - Simple Span - Single Cant. condition.
- The program automatically checks the location of the point loads specified in Simple Span columns, and determines if they rest on the cantilever or simple span beam.
- The maximum shear and reactions are calculated by skip loading.

When the program flag "Skip Load Live" is set to YES, the live load is placed on spans as follows:

- For all Simple Span Beams , full live load is always placed on the entire span.
- For maximum Cantilever moments, live load is applied to the cantilever and adjacent simple span beam.
- The following placements apply to cantilevered beams for calculating moments between supports and maximum end shears and reactions:
- For Maximum Moment t, live load is not applied to cantilevers or simple span beams between adjacent columns. Live load is applied to the portion of the beam between supports.
- For Maximum Left Shear , live load is applied to the left cantilever and the simple span beam is supported by the left cantilever. This value is then compared to the maximum left reaction (see below) minus this value.
- For Maximum Left Reaction , live load is applied between supports, left cantilever, and simple span beam supported by the left cantilever. No live load is applied to the right cantilever or simple span beam supported by the right cantilever.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.




Automatic Cantilever Length Optimization

Using the [Optimize Cantilevers] button in the toolbar at the top of the screen you can have the program automatically calculate the proper cantilever lengths to make the center span "Positive" moments approximately equal to the "Negative" moments at the end supports. The program performs a cyclical modification of the cantilever lengths and examines the resulting end moments and center span moments.

This type of optimization is essential when designing these types of beam system

because the greatest economy of member sizes is achieved.




Automatic Member Selection

Using the [Design] button you can display a screen that will enable you to set design parameters and examine a database of wood members for selection of those that satisfy your criteria. This screen allows you to:

- Specify maximum deflection ratios for dead and total loads.
- Specify overstress limits for bending and shear forces.
- Use "Go" to start the database search. The beam width and lamination thickness already present in the calcsheet will be used to determine a depth considering bending and shear stresses and deflections.

Here's the screen....



Wood Section Database

On all the tabs labeled "Right", "Key", "Double", and "Left" you are provided with a button to select a wood section from the internal wood member database.

[Wood Section] button and entry

Use this button to display the database of wood sections. The database provides selections for sawn, glued-laminated, and manufactured lumber. Please refer to the previous chapter describing using database in the Structural Engineering Library. Pressing **[Wood Section]** will display the following selection window:

Wood Section Database

Select Types to Display

Specify Depth Range Low: in High: in

Type	Name	Width	Depth	Area	Ix	Sx	Iy	Sy	Ix/Area	Sx/Area
		in	in	in ²	in ⁴	in ³	in ⁴	in ³	in ³	in ³
Sawn	2x3	3.750	1.500	2.500	1.953	1.563	0.703	0.938	0.521	0.4167
Sawn	2-2x3	7.500	3.000	2.500	3.910	3.130	5.630	3.750	0.521	0.4173
Sawn	3-2x3	11.250	4.500	2.500	5.860	4.690	18.980	8.440	0.521	0.4169
Sawn	2x4	5.250	1.500	3.500	5.359	3.063	0.984	1.313	1.021	0.5833
Sawn	3x4	8.750	2.500	3.500	8.932	5.104	4.557	3.646	1.021	0.5833
Sawn	2-2x4	10.500	3.000	3.500	10.720	6.130	7.880	5.250	1.021	0.5838
Sawn	4x4	12.250	3.500	3.500	12.505	7.146	12.505	7.146	1.021	0.5833
Sawn	3-2x4	15.750	4.500	3.500	16.080	9.190	26.580	11.810	1.021	0.5835
Sawn	2x6	8.250	1.500	5.500	20.797	7.563	1.547	2.063	2.521	0.9167
Sawn	3x6	13.750	2.500	5.500	34.661	12.604	7.161	5.729	2.521	0.9167
Sawn	2-2x6	16.500	3.000	5.500	41.590	15.130	12.380	8.250	2.521	0.9170
Sawn	4x6	19.250	3.500	5.500	48.526	17.646	19.651	11.229	2.521	0.9167
Sawn	3-2x6	24.750	4.500	5.500	62.390	22.690	41.770	18.560	2.521	0.9168
Sawn	6x6	30.250	5.500	5.500	76.255	27.729	76.255	27.729	2.521	0.9167
Sawn	2x8	10.875	1.500	7.250	47.635	13.141	2.039	2.719	4.380	1.2083
Sawn	3x8	18.125	2.500	7.250	79.391	21.901	9.440	7.552	4.380	1.2083
Sawn	2-2x8	21.750	3.000	7.250	95.270	26.280	16.310	10.880	4.380	1.2083
Sawn	4x8	25.375	3.500	7.250	111.148	30.661	25.904	14.802	4.380	1.2083
Sawn	3-2x8	32.630	4.500	7.250	142.900	39.420	55.050	24.470	4.379	1.2081
Sawn	6x8	41.250	5.500	7.500	193.359	51.563	103.984	37.813	4.687	1.2500

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General	Right Cant	Key #1	Double #1	Key #2	Double #2	Key #3
Description Four Bay System : 2 Simple, 1 Rt Cant, 1 Double Cant						
Stress		Douglas Fir, 24F - V8				
Fb : Base Allowable	<input style="width: 100%;" type="text" value="2,400.0"/>		psi			
Fv : Allowable	<input style="width: 100%;" type="text" value="190.0"/>		psi			
E : Elastic Modulus	<input style="width: 100%;" type="text" value="1,800.0"/>		\$\$\$\$\$\$\$			
Load Duration Factor	<input style="width: 100%;" type="text" value="1.250"/>					
Lamination Thickness	<input style="width: 100%;" type="text" value="1.500"/>		in			
Should Live Load Be "Skip" Loaded			<input checked="" type="checkbox"/>			
Are Cantilevers Braced ?			<input checked="" type="checkbox"/>			

Wood Species : [Stress] button & entry

This allows you to use the built-in NDS & Manufactured lumber allowable stress database to retrieve allowable stresses. When you press the button you will see this selection window. Please see the section earlier in this User's Manual that give information and usage for the databases.

Wood Stress Database

Species...

Size Classes to Show: 2"->4" Thick, 2" & Wider 5" x 5" & Larger Glued-Laminated
 Beams & Stringers Posts & Timbers Manufactured

Using 1997 UBC/NDS Stress Values

All stresses in PSI

<- Sort Order

Species	Grade	Class	F _b	F _t	F _v	F _c - Perp	F _c - P _{rl}	Elastic Modulus	Grading Agency
			Bending	Tension	Shear	Comp.	Comp.		
Douglas Fir	16F - E6	GLB	1,600	1,000	165	650	1,600	1,600,000	
Douglas Fir	20F - E6	GLB	2,000	1,150	165	650	1,650	1,700,000	
Douglas Fir	22F - E5	GLB	2,200	1,100	165	650	1,650	1,700,000	
Douglas Fir	24F - E10	GLB	2,400	1,300	165	650	1,750	1,900,000	
Douglas Fir	24F - E12	GLB	2,400	1,200	155	650	1,600	1,900,000	
Douglas Fir	24F - E13	GLB	2,400	1,250	165	650	1,700	1,800,000	
Douglas Fir	24F - E18	GLB	2,400	950	190	650	1,600	1,800,000	
Douglas Fir	24F - V8	GLB	2,400	1,100	190	560	1,650	1,800,000	
E-Rated Southern Pine	20F - E3	GLB	2,000	1,150	200	650	1,700	1,700,000	
E-Rated Southern Pine	22F - E3	GLB	2,200	1,150	200	650	1,650	1,700,000	
E-Rated Southern Pine	24F - E4	GLB	2,400	1,250	200	650	1,750	1,800,000	
Hem Fir	16F - E7	GLB	1,600	850	155	500	1,150	1,400,000	
Hem Fir	20F - E7	GLB	2,000	1,050	155	500	1,550	1,600,000	
Hem Fir	22F - E6	GLB	2,200	1,050	155	500	1,500	1,700,000	
Hem Fir	24F - E11	GLB	2,400	1,150	155	500	1,550	1,800,000	
Hem Fir	24F - E16	GLB	2,400	850	155	500	1,400	1,700,000	
Hem Fir	24F - E19	GLB	2,400	950	155	500	1,200	1,800,000	
Hem Fir / Softwood	24F - E17	GLB	2,400	750	140	500	1,250	1,800,000	
Southern Pine	16F - V5	GLB	1,600	1,000	200	560	1,550	1,400,000	
Southern Pine	20F - V5	GLB	2,000	1,050	200	560	1,550	1,600,000	

Buttons: Select, Insert, Change, Delete, Cancel

F_b : Base Allowable

Basic allowable bending stress to be used for design and analysis. This stress will be modified based by slenderness, size factor, and load duration factor.

F_v-Shear

Allowable shear stress to be used in design. This allowable will be modified by the load duration factor.

Elastic Modulus

Enter the modulus of elasticity to be used in determining deflections and calculation of F_b for laterally unbraced beams.

Load Duration Factor

Load duration factor to be applied to allowable bending and shear stresses. Application of this factor is in accordance with NDS.

Lamination Thickness

Should Live Load be "Skip" Loaded

Use this checkbox specifies whether the program's analysis should place the live load in different locations to determine maximum values. If unchecked dead and live load will always be placed on each span.

Are Cantilevers Braced

This checkbox specifies whether the program should consider all cantilevers to have an unbraced length equal to zero. This allows full stresses to be used for design and analysis. If CHECKED either the cantilever's span/thickness ratio is very low, or cantilever braces are being used. If NOT CHECKED an unbraced length equal to 2*Cant. Length is used to determine allowable stresses based on lateral buckling of the compression face.

Using the Beam Data Entry Tabs "Right", "Key", "Double", "Left"

At the top you will see the following tabs:

Right Cant----Key #1----Double #1----Key #2----

Each span condition is represented by the tab. All information for that beam is specified in that column. For example, if we want to analyze a beam with a cantilever off the right end, and that cantilever supports the left end of a simple span beam we would use the two left-most columns, labeled :

Right Cant----Key #1

Use any column on the calcsheet to model your system of cantilevered beams.

On each tab you will see an entry called "Column Spacing". Think of the program as setting up column bays that support the system of beams. Because you will be modifying cantilever lengths it is far easier to enter the column locations and let the program recalculate key beam lengths automatically.

Also, when you enter partial length loads and point loads in the "Key Beam" tabs this program will automatically figure out whether the load is on the cantilevered portion or simple span portion of the beam system between those support.

Right Cant Tab

This tab is used to enter the information for the left-most beam in your cantilevered beam system.

- It is named "Right Cant" because the beam ONLY has a cantilever to the right. The left end is bearing on a wall or other end support.
- You do not need to use this tab if the left side of your cantilever system is a simple-span beam that bears on a support at the left and hangs on a cantilever on the right. In that case do not use this tab by setting the span to "0.0" and the "Key #1" tab is the left-most tab used in the calculation.

General		Right Cant	Key #1	Double #1	Key #2	Double #2	Key #3
Column Spacing	<input type="text" value="40.250"/> ft						
Right Cantilever	<input type="text" value="7.588"/> ft						
Unbraced Length	<input type="text" value="0.000"/> ft						
Wood Section	<input type="text" value="5.125x37.5"/>						
Beam Width	<input type="text" value="5.125"/> in						
Beam Depth	<input type="text" value="37.500"/> in						
Beam Type	<input type="radio"/> Sawn <input checked="" type="radio"/> GluLam <input type="radio"/> Manuf or So. Pine						
Loads..	<u>Dead Load</u>	<u>Live Load</u>					<u>Location</u>
Uniform	<input type="text" value="96.0"/> #/ft	<input type="text" value="128.0"/> #/ft					
Partial	<input type="text" value=""/> #/ft	<input type="text" value=""/> #/ft	Start	<input type="text" value="0.00"/> ft		End	<input type="text" value="0.00"/> ft
Point Ld #1	<input type="text" value="6,720.0"/> lbs	<input type="text" value="5,760.0"/> lbs			<input type="text" value="24.00"/> ft		
Point Ld #2	<input type="text" value=""/> lbs	<input type="text" value=""/> lbs			<input type="text" value="0.00"/> ft		
Point Ld #3	<input type="text" value=""/> lbs	<input type="text" value=""/> lbs			<input type="text" value="0.00"/> ft		
Point Ld #4	<input type="text" value=""/> lbs	<input type="text" value=""/> lbs			<input type="text" value="0.00"/> ft		
Point Ld #5	<input type="text" value=""/> lbs	<input type="text" value=""/> lbs			<input type="text" value="0.00"/> ft		
Point Ld #6	<input type="text" value=""/> lbs	<input type="text" value=""/> lbs			<input type="text" value="0.00"/> ft		
Point Ld #7	<input type="text" value=""/> lbs	<input type="text" value=""/> lbs			<input type="text" value="0.00"/> ft		

Column Spacing

This is the distance between the supports for this beam.

Right Cantilever

This is the cantilever length for this beam that extends past the right support. LOADS THAT WILL BE APPLIED TO THIS CANTILEVER ARE SPECIFIED ON THE "Key #1" TAB. This is because the program operates on a column-to-column format. You specify the loads between columns and the program automatically figures out which member (cantilever portion or simple "key" beam) that the load actually is applied to based upon the loads' location.

Unbraced Length

Enter the unbraced length of the compression side of the beam that should be used to calculate R_b and the resulting allowable stress reduction factor "Cl".

Wood Section

See the information given previously on using the built-in wood section database.

You do not need to use the database ! You can enter any beam name in this entry and type in

the beam Width & Depth. When you use the wood section database it merely fills in the beam name, depth, and width for you.

Beam Depth & Width

The actual beam Width and Depth to be used for calculation of section properties used in this design/analysis.

Uniform & Partial Length Loads

Uniform loads apply to the beam between the supports. Any loads that need to be applied to the cantilever must be entered on the adjacent tab.

Partial Length loads allow you to enter a starting and ending location as a distance from the left support. Values less than zero and greater than "Column Spacing" are not valid and will be automatically corrected for you.

Point Loads

Enter any point loads applied to the beam here. The "Location" is the distance from the left support. Values less than zero and greater than "Column Spacing" are not valid and will be automatically corrected for you.

Key Tabs

The data entry on this tab is essentially the same as the "Right Cant" tab except that no entry for cantilevers is available. Instead the actual span of the beam is shown. The "Actual Span" is calculated by subtracting the cantilevers specified on the adjacent tabs from the "Column Spacing" specified here.

Also, the loads that you specify here are applied to any beam portion that is in this "Column Spacing" area. Referring to the image below, this means the right cantilever specified on the "Right Cant" tab and the left cantilever specified on the "Double #1" tab.

General	Right Cant	Key #1	Double #1	Key #2	Double #2	Key #3
Column Spacing						
Actual Span						25.53 ft
Unbraced Length						0.000 ft
Timber Section						5.125x19.5
Beam Width						5.125 in
Beam Depth						19.500 in
Beam Type						<input type="radio"/> Sawn <input checked="" type="radio"/> GluLam <input type="radio"/> Manuf or So. Pine
Loads..						
	<u>Dead Load</u>	<u>Live Load</u>				
Uniform	96.0 #/ft	128.0 #/ft				
Partial						
			Start			0.00 ft
			End			0.00 ft
Point Ld #1	6,720.0 lbs	5,760.0 lbs				8.00 ft
Point Ld #2	6,720.0 lbs	5,760.0 lbs				32.00 ft
Point Ld #3						0.00 ft
Point Ld #4						0.00 ft
Point Ld #5						0.00 ft
Point Ld #6						0.00 ft
Point Ld #7						0.00 ft

Double Tabs

The data entry on this tab is essentially the same as the "Right Cant" tab except entries for cantilevers off both ends of the beam are now available.

General	Right Cant	Key #1	Double #1	Key #2	Double #2	Key #3
Column Spacing						
						40.000 ft
Left Cantilever						6.881 ft
Right Cantilever						9.762 ft
Unbraced Length						0.000 ft
Timber Section		5.0x34.5				
Beam Width						5.000 in
Beam Depth						34.500 in
Beam Type	<input type="radio"/> Sawn <input checked="" type="radio"/> GluLam <input type="radio"/> Manuf or So. Pine					
Loads..	<u>Dead Load</u>		<u>Live Load</u>			
Uniform	96.0 #/ft	128.0 #/ft				
Partial			Start	0.00 ft	End	0.00 ft
Point Ld #1	6,720.0 lbs	5,760.0 lbs		16.00 ft		
Point Ld #2				0.00 ft		
Point Ld #3				0.00 ft		
Point Ld #4				0.00 ft		
Point Ld #5				0.00 ft		
Point Ld #6				0.00 ft		
Point Ld #7				0.00 ft		

Uniform & Partial Length Loads

Uniform loads apply to the beam between the supports. Any loads that need to be applied to the cantilever must be entered on the adjacent tab.

Partial Length loads allow you to enter a starting and ending location as a distance from the left support. Values less than zero and greater than "Column Spacing" are not valid and will be automatically corrected for you.

Point Loads

Enter any point loads applied to the beam here. The "Location" is the distance from the left support. Values less than zero and greater than "Column Spacing" are not valid and will be automatically corrected for you.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information

on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This tab shows all of the calculated values for the beam tab selected on the left.

Results	Sketch	Notes	Printing
Beam is OK			
Moments...			
Max @ Left End	-108.5	k-ft
Max. Moment @ Mid-Span	108.0	k-ft
Max @ Right End	-108.2	k-ft
Bending Stress...			
fb : Actual	1,312.4	psi
Fb : Allowable	2,537.1	psi
Shear Stress...			
Maximum Shear	15,894	lbs
fv : Actual	138.2	psi
Fv : Allowable	237.5	psi
Deflections...			
		<u>Dead Load</u>	<u>Total Load</u>
Left Cantilever	-0.109 in	-0.566 in
Center Span	-0.047 in	-0.692 in
Right Cantilever	-0.217 in	-0.907 in
Maximum Reactions...			
		<u>@ Left</u>	<u>@ Right</u>
Maximum Reaction	29,879 lbs	22,962 lbs
Cf	0.846	
Rb	0.000	
Le	0.000 ft	

Moments

This is the maximum moments between end supports and at the cantilevers (if present).

- For simple span beams on the "Key #?" tabs this moment is caused by dead and live loading. For cantilevered beams when the Skip Load flag is set to YES, the live load on the adjacent simple span beams and cantilevers is Skip Loaded to determine maximum moments.
-
- For beams with left cantilevers (which are the "Double Cant" tabs and the "Left Cant" tab to the far right in the tab set) the moment at the beam's left support is induced by applying full dead and live load to the left cantilever AND the simple span beam it is supporting.
-
- For beams with right cantilevers (which are the "Double Cant" tabs and the "Right Cant" tab to the

far left in the tab set) the moment at the beam's right support is induced by applying full dead and live load to the right cantilever and to the simple span beam it is supporting.

F'b-Allow

Using the basic Fb entered under DESIGN DATA, the actual allowable bending stress is calculated considering Load Duration Factor, Size Factor, and reductions considering lateral buckling failure (caused by long unbraced lengths).

fb-Actual

Maximum moment divided by section modulus.

Maximum Shear

For cantilevered beams, this is the maximum shear over the support. For calculation of the maximum shear, the greater of:

- A total of all forces acting on the cantilever
- The maximum reaction minus the total of all forces acting on the cantilever.
- For simple span beams it is simply the maximum end reaction.

fv-Actual

After calculations have determined the maximum shear magnitude at supports, all loads within a distance Beam Depth from the support (on the governing side of the beam) are subtracted, the result is divided by the beam's area, and then multiplied by 1.5 to arrive at this true shear stress.

Fv-Allow

Basic Fv entered under the DESIGN DATA section is multiplied by the load duration factor.

Center Deflection

Center Dead Load Deflection results from applying all dead loads to the beam and all contributing cantilevers and beams which the cantilevers support. Center Maximum Deflection depends upon the state of the Skip Load flag. If skip loading is not used, dead and live loads are applied to all beams. If skip loading IS used, the live load is applied to the beam only between supports..... no cantilevers or beams they support are loaded with live load.

Cantilever Deflections

Maximum cantilever deflections (regardless of Skip Load flag) are calculated by applying dead and live load to the cantilever and adjacent simple span beam. No live load is applied to the beam between supports, BUT the opposite cantilever IS loaded with live load.

Maximum Reactions

These are calculated as follows:

- For the left support t this value is calculated by applying full dead and live load to all portions of the beam between supports and the simple span beam to the left, and NOT APPLYING LIVE LOAD to the right cantilever or the simple span beam immediately to its right.
- For the right support this value is calculated by applying full dead and live load to all portions of the beam between supports and simple span beam to the right, and NOT APPLYING LIVE LOAD to the left cantilever or the simple span beam immediately to its left.
- For the simple span beams, all loads are applied to the beam.

Cv

This item will display as "Cv" for glued laminated beams when the volume factor applies and as "Cf" for sawn or manufactured members when the size factor applies.

Rb

Slenderness ratio for the beam.

Le : Unbraced Length

This unbraced length entry ONLY APPLIES TO THE SIMPLE BEAM AND CENTER SPAN OF CANTILEVERED BEAMS. It is independent of the Are Cants. Braced general entry. This value helps the

stress checking function to determine if the beam is short, intermediate, or long for purposes of allowable stress determination.


This entry is the unsupported compression edge length, corrected for span type per AITC/UBC code.

Use the following table as a guide.

Type of Beam Span and Nature of Load	Value of Effective Length, L_e Single
Span beam, load concentrated at center	1.61 L_u
Single Span beam, uniformly distributed load	1.92 L_u
Single Span beam, equal end moments	1.84 L_u
Cantilever beam, point load at unsupported end	1.69 L_u
Cantilever beam, uniform load w/ point load at end	1.69 L_u
Single Span beam, any other load	1.92 L_u

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Notes Tab

This tab contains some general notes about the usage of the results of this program.

Results | Sketch | Notes | **Printing**

General Notes...

- Calculations are designed to 1997 NDS and 1997 UBC Guideline
- Section databases have been updated as of 2-Apr-1999
- Allowable stress databases have been updated to 1997 NDS & 1997 UBC values on 2-Apr-1999
- To determine Cf values for sawn sections, the program looks for the identifying words in the ' "Select", "No.1", "Standard" and similar typical words are used to determine Cf category
- "Unbraced length" is multiplied by the following values to calculate "Le"
 - When beam depth ≤ 7 " , $Le = 2.06 * Lu$
 - When $7 < \text{beam depth} \leq 14.3$ " , $Le = 1.62 * Lu + 3d$
 - When beam depth > 14.3 " , $Le = 1.84 * Lu$

Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results | Sketch | Notes | **Printing**

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Column Bay & Beam Data	<input checked="" type="checkbox"/>
Calculated Moments	<input checked="" type="checkbox"/>
All Loads	<input checked="" type="checkbox"/>
Uniform Loads	<input checked="" type="checkbox"/>
Point Loads	<input checked="" type="checkbox"/>
Stresses	<input checked="" type="checkbox"/>
Reactions	<input checked="" type="checkbox"/>
Deflections	<input checked="" type="checkbox"/>
Notes	<input type="checkbox"/>

Note: When all are selected, the software will still omit unused sections

Sample Printout Page 1

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949.645.0151
www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
Dsgnr: MDB Date: 11:49AM, 25 OCT 03
Description: Collection of example problems
Scope: All programs in the Structural Engineering Library

Rev: 080000
User: KW-0900001, Ver 5.8.0, 10-Sep-2003
(c)1983-2003 ENERCALC Engineering Software

Timber Cantilevered Beam System

Page 1

c:\ec65\examples\ewr\Timber Calcs

Description Four Bay System : 2 Simple, 1 Rt Cant, 1 Double Cant]

General Information Code Ref: 1997 NDS, 2003 IBC, 2003 NFPA 5000. Base allowables are user defined

Fb : Base Allow	2,400.0 psi	Fv : Base Allow	1,900.0 ksi	Live loads placed for maximum values
Fv : Base Allow	155.0 psi	Load Duration Factor	1.250	Cantilevers assumed braced for Fb calcs

Column Bay & Beam Data

Column Spacing	ft	40.25	40.00	40.00	40.00
... Actual Span	ft	----	26.50	----	34.00
Left Cantilever	ft	----	----	6.00	----
Right Cantilever	ft	7.500	----	6.00	----
Beam Width	in	1.500	5.125	5.125	5.125
Beam Depth	in	7.250	28.500	28.500	28.500
Member Type		Sawn	GluLam	GluLam	GluLam

Moments

Mmax @ Center	k-ft	125.4	36.4	122.2	137.5
Max @ Left End	k-ft	----	----	-92.5	----
Max @ Right End	k-ft	-127.5	----	-62.1	----

Loads

Dead Load	#/ft	96.0	96.0	96.0	96.0
Live Load	#/ft	128.0	128.0	128.0	128.0
Point #1	DL	lbs	6,720.0	6,720.0	6,720.0
	LL	lbs	5,760.0	5,760.0	5,760.0
	@ X	ft	24.00	8.00	16.00
Point #2	DL	lbs	6,720.0		
	LL	lbs	5,760.0		
	@ X	ft	32.00		

Stresses

Fb : Allowable	psi	3,600.0	0.0	0.0	0.0
Fb : Actual	psi	116,393.5	629.2	2,113.2	2,378.2
		Overstress	Overstress	Overstress	Overstress
Max. Shear	lbs	17,705.0	16,154.3	15,558.6	10,414.9
Fv : Allowable	psi	193.8	193.8	193.8	193.8
Fv : Actual	psi	2,442.1	165.9	159.8	107.0
		Overstress	Shear OK	Shear OK	Shear OK

Reactions

Max. Left Reaction	lbs	7,919.2	16,154.3	29,602.9	9,680.8
Max. Right Reaction	lbs	32,950.2	14,741.5	20,864.5	10,414.9

Deflections

Center DL	in	###.###	-0.124	-0.358	-0.657
... Maximum	in	###.###	-0.258	-1.419	-1.294
Left Cant. DL	in	----	----	0.009	----
... Maximum	in	----	----	-0.489	----
Right Cant DL	in	-11.742	----	0.041	----
... Maximum	in	###.###	----	-0.391	----

0.000

Sample Printout Page 2

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949.645.0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 11:49AM, 25 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 280000
 User: KW0600001, Ver 6.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software


Timber Cantilevered Beam System

Page 2

c:\ec58\examples\ew\Timber\Calcs

Description Four Bay System : 2 Simple, 1 Rt Cant, 1 Double Cant]

Sketch & Diagram



3.5 Timber Column

This program analyzes timber columns subjected to a combination of axial load (with optional eccentricities), side bracket load, and applied transverse moment. Either rectangular or round columns may be analyzed.

In order to properly consider the effects of column slenderness and unbraced compression edge effects, the user enters the unbraced lengths for each axis of axial instability, and enters a separate unbraced length for determining the allowable bending stress about the X axis.

ENERCALC c:\ECSS\EXAMPLES.ECIV - Timber Column Design

Timber Column Design

Tools & Settings Help Design Print Cancel Save

General Loads

Description: Column Subjected to Additional Side Load

Total Column Height: 10.500 ft

Le X-X for Axial: 11.750 ft

Le Y-Y for Axial: 8.500 ft

Lu XX for Bending (Unbraced Length): 10.500 ft

Column Shape: Rectangular Circular

Wood Section: 8x8

Column Depth: 7.50 in

Width: 7.50 in

Sawn So. Pine GluLam Manufactured

Stress: Fc: Parallel: 1,250.0 psi; Fb: 1,750.0 psi; E: 1,800.0 ksi; Load Duration Factor: 1.000

Results Sketch Notes Printing

Column OK

	DL+LL	DL+LL+ST	DL+ST
Fc : Compression	164.44	226.67	172.44 psi
Fc : Allowable	944.34	944.34	944.34 psi
Fbx : Flexural	871.11	1,244.44	956.43 psi
Fbx : Allowable	1,750.00	1,750.00	1,750.00 psi
Interaction Value	0.5284 : 1.0	0.8286 : 1.0	0.6136 : 1.0

Fc : X-X: 944.34 psi; Fc : Y-Y: 1,112.89 psi; Fc : Allowable: 944.34 psi; Fc:Allow * Load Duration Factor: 944.34 psi (Note: This values is not a simple multiplication, see NDS code); Fbx: 1,750.00 psi; Fbx * Load Duration Factor: 1,750.00 psi

For Bending Stress Calcs.... Max k Lu / d: 50.0000; Actual K Lu / d: 25.4627; Min. Allow k Lu / d: 11.0000; Cf Bending: 1.0000; Rb : (Le d / b^2) ^ 5: 5.5599

For Axial Stress Calcs.... Cf: Axial: 1.0000; Axial X-X k Lu / d: 18.800; Axial Y-Y k Lu / d: 13.800

Basic Usage

- Column Dimensions & Lengths. Use the Depth, Width, and Actual/Nominal entries for rectangular columns, or Column Diameter for circular columns (which is always considered the actual diameter). The X-X and Y-Y axial unbraced lengths are used to determine allowable axial stress considering buckling effects. X-X Bending unbraced length is used to determine allowable bending stress considering length effects.
- Allowable Stresses. Enter the allowable basic compressive stress for the column Parallel to Grain, and allowable bending stress about the X-X (width) axis. These basic allowable stresses will be modified by the Load Duration Factor, size factor, axial slenderness, and bending slenderness to give the net allowable stress values.
- Applied Loads. Axial Load can be applied at an optional eccentricity to the column centerline (creating an X-X moment at the top of the column). Transverse moment will be considered a maximum moment midspan between the ends. Side load is applied at a Dist. from CL, creating a concentrated moment between the ends. All column loads are combined and the incremental points along the column evaluated for combined axial and bending to give the final results.

Unique Features

Axial load & eccentricity, side bracket load, and applied transverse moment may be applied to the column for analysis

- Either a rectangular or round column may be analyzed.

General		Loads	
Description		Column Subjected to Additional Side Load	
Total Column Height		10.500	ft
Le X-X for Axial		11.750	ft
Le Y-Y for Axial		8.500	ft
Lu XX for Bending (Unbraced Length)		10.500	ft
Column Shape			
		<input checked="" type="radio"/> Rectangular	<input type="radio"/> Circular
Wood Section		8x8	
Column Depth		7.50	in
Width		7.50	in
<input checked="" type="radio"/> Sawn		<input type="radio"/> So. Pine	<input type="radio"/> GluLam
		<input type="radio"/> Manufactured	
Stress			
Fc:Parallel		1,250.0	psi
Fb		1,750.0	psi
E		1,800.0	ksi
Load Duration Factor		1.000	

Total Column Height

When you wish to analyze a circular column, the diameter is entered here. Please note that any entry in this location (except zero) will overwrite the depth/width dimensions, and the analysis will continue for the circular column.

Le XX for Axial

Unbraced length used to calculate compression slenderness. This is the distance between elements that support the column from failing by deflecting along the "X-X" axis which is along the column's "width" dimension.

Le YY for Axial

Unbraced length used to calculate compression slenderness. This is the distance between elements that support the column from failing by deflecting along the "Y-Y" axis which is along the column's "width" dimension.

Lu XX for Bending (Unbraced Length)

This entry specifies the unbraced length to be used for calculating allowable bending stress in the

column. This is the distance between lateral supports that brace the beam from failure due to movement of the compression edge along the column's "X-X" axis (which is the width direction), and are the $k \cdot L_u$ values used to determine column slenderness.

[Wood Section] button and entry

Use this button to display the database of wood sections. The database provides selections for sawn, glued-laminated, and manufactured lumber. Please refer to the previous chapter describing using database in the Structural Engineering Library. Pressing **[Wood Section]** will display the following selection window:

Wood Section Database

Select Types to Display

Specify Depth Range Low: 2.00 in High: 12.00 in

Type	Name	Width	Depth	Area	Ix	Sx	Iy	Sy	Ix/Area	Sx/Area
		in	in	in ²	in ⁴	in ³	in ⁴	in ³	in ³	in ³
Sawn	2x3	3.750	1.500	2.500	1.953	1.563	0.703	0.938	0.521	0.4167
Sawn	2-2x3	7.500	3.000	2.500	3.910	3.130	5.630	3.750	0.521	0.4173
Sawn	3-2x3	11.250	4.500	2.500	5.860	4.690	18.980	8.440	0.521	0.4169
Sawn	2x4	5.250	1.500	3.500	5.359	3.063	0.984	1.313	1.021	0.5833
Sawn	3x4	8.750	2.500	3.500	8.932	5.104	4.557	3.646	1.021	0.5833
Sawn	2-2x4	10.500	3.000	3.500	10.720	6.130	7.880	5.250	1.021	0.5838
Sawn	4x4	12.250	3.500	3.500	12.505	7.146	12.505	7.146	1.021	0.5833
Sawn	3-2x4	15.750	4.500	3.500	16.080	9.190	26.580	11.810	1.021	0.5835
Sawn	2x6	8.250	1.500	5.500	20.797	7.563	1.547	2.063	2.521	0.9167
Sawn	3x6	13.750	2.500	5.500	34.661	12.604	7.161	5.729	2.521	0.9167
Sawn	2-2x6	16.500	3.000	5.500	41.590	15.130	12.380	8.250	2.521	0.9170
Sawn	4x6	19.250	3.500	5.500	48.526	17.646	19.651	11.229	2.521	0.9167
Sawn	3-2x6	24.750	4.500	5.500	62.390	22.690	41.770	18.560	2.521	0.9168
Sawn	6x6	30.250	5.500	5.500	76.255	27.729	76.255	27.729	2.521	0.9167
Sawn	2x8	10.875	1.500	7.250	47.635	13.141	2.039	2.719	4.380	1.2083
Sawn	3x8	18.125	2.500	7.250	79.391	21.901	9.440	7.552	4.380	1.2083
Sawn	2-2x8	21.750	3.000	7.250	95.270	26.280	16.310	10.880	4.380	1.2083
Sawn	4x8	25.375	3.500	7.250	111.148	30.661	25.904	14.802	4.380	1.2083
Sawn	3-2x8	32.630	4.500	7.250	142.900	39.420	55.050	24.470	4.379	1.2081
Sawn	6x8	41.250	5.500	7.500	193.359	51.563	103.984	37.813	4.687	1.2500

Depth & Width

Enter the beam width & depth you wish to use, or select the beam from the database (see above).

Column Type

This selection controls how the Size of Volume factor is calculated. If "Sawn" is selection "Cf" is calculated. If "GluLam" is selected then "Cv" is calculated. If "Manufactured or So. Pine" selected then NO factor (Cf or Cv) is calculated.

Wood Species : [Stress] button & entry

This allows you to use the built-in NDS & Manufactured lumber allowable stress database to retrieve allowable stresses. When you press the button you will see this selection window. Please see the section earlier in this User's Manual that give information and usage for the databases.

Wood Stress Database

Species... --All Species--

Size Classes to Show: 2"->4" Thick, 2" & Wider | 5" x 5" & Larger | Glued-Laminated

Using 1997 UBC/NDS Stress Values

Beams & Stringers | Posts & Timbers | Manufactured

All stresses in PSI

<- Sort Order

Species	Grade	Class	F _b	F _t	F _v	F _c - Perp	F _c - P _{rl}	Elastic Modulus	Grading Agency
			Bending	Tension	Shear	Comp.	Comp.		
Douglas Fir	16F - E6	GLB	1,600	1,000	165	650	1,600	1,600,000	
Douglas Fir	20F - E6	GLB	2,000	1,150	165	650	1,650	1,700,000	
Douglas Fir	22F - E5	GLB	2,200	1,100	165	650	1,650	1,700,000	
Douglas Fir	24F - E10	GLB	2,400	1,300	165	650	1,750	1,900,000	
Douglas Fir	24F - E12	GLB	2,400	1,200	155	650	1,600	1,900,000	
Douglas Fir	24F - E13	GLB	2,400	1,250	165	650	1,700	1,800,000	
Douglas Fir	24F - E18	GLB	2,400	950	190	650	1,600	1,800,000	
Douglas Fir	24F - V8	GLB	2,400	1,100	190	560	1,650	1,800,000	
E-Rated Southern Pine	20F - E3	GLB	2,000	1,150	200	650	1,700	1,700,000	
E-Rated Southern Pine	22F - E3	GLB	2,200	1,150	200	650	1,650	1,700,000	
E-Rated Southern Pine	24F - E4	GLB	2,400	1,250	200	650	1,750	1,800,000	
Hem Fir	16F - E7	GLB	1,600	850	155	500	1,150	1,400,000	
Hem Fir	20F - E7	GLB	2,000	1,050	155	500	1,550	1,600,000	
Hem Fir	22F - E6	GLB	2,200	1,050	155	500	1,500	1,700,000	
Hem Fir	24F - E11	GLB	2,400	1,150	155	500	1,550	1,800,000	
Hem Fir	24F - E16	GLB	2,400	850	155	500	1,400	1,700,000	
Hem Fir	24F - E19	GLB	2,400	950	155	500	1,200	1,800,000	
Hem Fir / Softwood	24F - E17	GLB	2,400	750	140	500	1,250	1,800,000	
Southern Pine	16F - V5	GLB	1,600	1,000	200	560	1,550	1,400,000	
Southern Pine	20F - V5	GLB	2,000	1,050	200	560	1,550	1,600,000	

Select

+

Insert

Change

-

Delete

Cancel

F_c:Parallel

Allowable compressive stress parallel to the grain, when length effects do not apply.

F_b:Bending

Allowable bending stress in the column when bracing effects do not apply ($L_e = 0$).

E : Elastic Modulus

Elastic modulus of wood column used.

Load Duration Factor

Short term stress increase factor to be applied to allowable stresses.

Loads Tab

	Dead Load	Live Load	Short Term Load	
Axial Load	5,000.0	2,500.0	3,500.0	lbs
Eccentricity	7.50			in
Applied Moment				in-#
Eccentric Side Load	1,200.0	550.0		lbs
....Side Load Eccentricity	5.000	5.000	0.000	in
Side Load Dist. above Base	8.000	8.000	0.000	ft
Equivalent Load @ Mid-Height	108.84	49.89	0.00	lbs
Side Load Moment	3,428.57	1,571.43	0.00	in-#
Max. Design Moment	40,928.57	20,321.43	26,250.00	in-#

Axial Load

This defines the axial load applied to the top of the column. It can be applied, optionally, at the eccentricity defined below.

Eccentricity

Eccentricity of the axial load defined above. This eccentricity is in reference to the X-axis only, and may be entered as positive or negative.

Applied Transverse Moment

This is a user-defined moment applied to the column between supports. This represents a magnitude only, and is added to the other moments calculated.

Eccentric Side Load

Enter the vertical load applied eccentrically to the column between top and bottom ends. Based upon the distance and height entries to follow, this load is transformed into an equivalent lateral point load on the column to determine the moment it induces.

Side Load Eccentricity (Distance from column Centerline)

This defines the distance from column centerline to the point of side load application.

For axial load, positive ecc. = positive moment.

For side load, positive ecc. = positive moment

All positive moments will be added to obtain Max. Design Moment .

Equivalent Load @Mid-height

This load is determined from the following formula :

$P' = \text{Ecc.} * L' * P / L$ $2 L = \text{Total column height}$

Applied laterally at mid-height of the column to determine the moment induced from the side bracket load. This moment = $P' * L / 4$.

Side Load Moment This moment = $P'L/4$

Maximum Design Moment

From the previously entered loads, moments and eccentricities, a final maximum moment is determined to be used for analysis.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Results	Sketch	Notes	Printing
Column OK			
	<u>DL+LL</u>	<u>DL+LL+ST</u>	<u>DL+ST</u>
fc : Compression	164.44	226.67	172.44 psi
Fc : Allowable	944.34	944.34	944.34 psi
fbx : Flexural	871.11	1,244.44	955.43 psi
F'bx : Allowable	1,750.00	1,750.00	1,750.00 psi
Interaction Value	0.5284 : 1.0	0.8286 : 1.0	0.6136 : 1.0
Fc : X-X			944.34 psi
Fc : Y-Y			1,112.89 psi
F'c : Allowable			944.34 psi
F'c:Allow * Load Duration Factor <i>(Note: This values is not a simple multiplication..see NDS code)</i>			944.34 psi
F'bx			1,750.00 psi
F'bx * Load Duration Factor			1,750.00 psi
For Bending Stress Calcs....			
Max k Lu / d			50.0000
Actual K Lu / d			25.4627
Min. Allow k Lu / d			11.0000
Cf:Bending			1.0000
Rb : (Le d / b^2) ^.5			5.5599
For Axial Stress Calcs....			
Cf : Axial			1.0000
Axial X-X k Lu / d			18.800
Axial Y-Y k Lu / d			13.600

fc : Compression

Equals the total axial and side load divided by the column area. Remember, when Nominal is chosen, the true net column dimensions are used.

Fc : Allow Axial Compression Stress

The allowable axial stress as defined in the items to follow, multiplied by the load duration factor.

fbx : Actual Flexural

Equals the Maximum Design Moment divided by the actual section modulus of the column specified. This equals the total bending moment divided by the column's X-X section modulus.

F'bx : Allowable Bending

The allowable bending stress as defined in the items to follow, multiplied by the load duration factor.

Interaction Value

This is the typical interaction equation used for timber column design. It is defined in the

NDS code, and other codes and references. This is the final calculation of all values in the interaction equation to determine the final state of combined stresses.

For Bending Stress Calculations

Max k Lu/d

Allowable k Lu/d For Rectangular Columns = 50
For Circular Columns = 43.

"K" represents the minimum value of Lu/d at which the column can be expected to perform as a Euler column. This is taken as :

- Rectangular Columns: $0.671 * [E / (FC * LDF)]^{1/2}$
- Circular Columns: $0.582 * [E / (FC * LDF)]^{1/2}$

k Lu/d

This equals : $L_e / \text{Column Depth}$

Min. Allow K Lu/d

This represents the value of k Lu / d at which the effects of slenderness must be considered. This is :

- Rectangular Columns: 11
- Circular Columns: 9

C-f : Bending

Defines the stress reduction factor to be applied when the column depth exceeds 12" and bending stresses are present.

Rb : $(L_e d / b^2)^{.5}$

This is the slenderness factor based upon the defined effective length "Le". It is used to determine the adjusted allowable bending stress based upon column slenderness under beam action (Compression face stability)

For Axial Stress Calculations

Axial ($L_{e-x} * k * / \text{Column Depth}$)


This is the actual slenderness of the column that will be used to calculate allowable Fa values when the column is checked about out-of-plane buckling movement about the columns X-X axis (which is parallel to the width of the section)

Axial ($L_{e-yy} * k * / \text{Column Width}$)

This is the actual slenderness of the column that will be used to calculate allowable Fa values when the column is checked about out-of-plane buckling movement about the columns X-X axis (which is parallel to the width of the section)


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.




Notes Tab

This tab contains some general notes about the usage of the results of this program.



Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".



Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 1:55PM, 25 OCT 03
 Description : Collection of example problems
 Scope : All programs in the Structural Engineering Library

Rev: 590000 User: 199-0800001, Ver: 8.6.0, 10 Sep 2003
 (c)1983-2003 ENERCALC Engineering Software **Timber Column Design** Page 1
 c:\ec55\examples.eoc\Timber Calcs

Description Column Subjected to Additional Side Load

General Information Code Ref: 1997 NDS, 2003 IBC, 2003 NFPA 5000. Base allowables are user defined.

Wood Section	6x8	Total Column Height	11.75 ft	Le XX for Axial	11.75 ft
Rectangular Column		Load Duration Factor	1.00	Le YY for Axial	8.50 ft
Column Depth	7.50 in	Fc	1,250.00 psi	Lu XX for Bending	10.50 ft
Width	5.50 in	Fb	1,750.00 psi		
Sawn		E - Elastic Modulus	1,800 ksi		

Loads

	Dead Load	Live Load	Short Term Load
Axial Load	5,000.00 lbs	0.00 lbs	0.00 lbs
Eccentricity	0.000 in		
Eccentric Side Load	5,000.00 lbs	0.00 lbs	0.00 lbs
... Side Load Eccentricity	5.00 in	0.00 in	0.00 in
... Side Load Dist. above Base	8.00 ft	0.00 ft	0.00 ft
Equivalent Load @ Mid-Height	453.51 lbs	0.00 lbs	0.00 lbs
Side Load Moment	14,285.71 in-#	0.00 in-#	0.00 in-#
Max. Design Moment	14,285.71 in-#	0.00 in-#	0.00 in-#

Summary

Column OK

Using: 6x8, Width= 5.50in, Depth= 7.50in, Total Column Ht= 10.50ft

	DL + LL	DL + LL + ST	DL + ST
fc : Compression	242.42 psi	242.42 psi	242.42 psi
Fc : Allowable	944.34 psi	944.34 psi	944.34 psi
fbx : Flexural	277.06 psi	277.06 psi	277.06 psi
F'bx : Allowable	1,737.40 psi	1,737.40 psi	1,737.40 psi
Interaction Value	0.1939	0.2554	0.2554

Stress Details

Fc : X-X	944.34 psi	For Bending Stress Calcs...	
Fc : Y-Y	954.26 psi	Max k*Lu / d	50.00
Fc : Allowable	944.34 psi	Actual k*Lu/d	25.45
Fc Allow * Load Dur Factor	944.34 psi	Min. Allow k*Lu / d	11.00
Fbx	1,737.40 psi	Cf Bending	1.000
Fbx * Load Duration Factor	1,737.40 psi	Rb : (Le d / b^2) ^ .5	7.582
		For Axial Stress Calcs...	
		Cf : Axial	1.000
		Axial X-X k Lu / d	18.80
		Axial Y-Y k Lu / d	18.55

3.6 Plywood Shear Wall

This program provides complete design and analysis of shear walls constructed of plywood sheathing over wood studs. Plywood can be applied to one or both sides, and you can specify up to five applied lateral loads and five vertical loads to the wall.

Applied lateral loads can be from uniform forces (diaphragm connection) or concentrated loads (collector load transfer). Additionally, a concentrated moment can be applied to the wall, allowing you to transfer moments from upper level wall sections to the current wall.

Vertical loads can be applied as uniform or concentrated, and will act to stabilize the wall for overturning. You can use the concentrated load entries to apply end uplift/compression forces from a wall above to the current section.

Values which can be specified for the wall construction are; plywood thickness, plywood grade, nail size, number of sides applied, stud spacing, sill thickness, and seismic factor. All of these values will be used to determine allowable shear capacity and nail spacing of the wall sheathing, sill bolting requirements, and wall uplift provisions.

Also provided by this program is the ability to design a supporting footing. The footing length, width, and thickness can be modified to achieve acceptable soil pressures, shearing stresses, overturning stability, and bending reinforcement requirements.

ENERCALC c:\EC55\EXAMPLES.EC5W - Plywood Shear Wall & Footing

Plywood Shear Wall & Footing

Tools & Settings Help Print Cancel Save

General Loads Footing Results Sketch Printing

Description: Vertical Pt & Unif. Loads & Lateral Shear & Drag Loads

Wall Dimensions...

Wall Length: 15.000 ft

Wall Height: 12.000 ft

Wall Weight: 15.00 psf

Ht / Length: 0.800

Sheathing Data...

Plywood Layers: 1 Side 2 Sides

Plywood Grade: Structural I

Nail Size: 8d

Thickness: 15/32 in

Stud Spacing: 16.000 in

End Post Dimension: 3.50 in

Wall: 194 UBC Seismic Factor Z Ip Cp or Similar 1997 UBC Factor Divided by 1.4: 0.183

Nominal Sill Thick: 2x in

Summary: Simpson Hold Downs & Sill Bolting

Design OK

Wall Summary...

Using 15/32" Thick on 1 side/s, Nailing is at 4 in @ Edges, at 12 in @ Field

Applied Shear = 366.0#/#, Capacity = 430.000#/# -> OK

Wall Overturning = 62,964.0ft-#, Resisting Moment = 37,125.0ft-#, End Uplift = 1,722.64lbs

Max. Soil Pressures: @ Left = 628.5psf, @ Right = 771.1psf

Footing Summary...

Max. Footing Shear = 7.26psf, Allowable = 109.54psf -> OK

Bending Reinforcement Req'd @ Left = 0.43in², @ Right = 0.43in²

Minimum Overturning Stability Ratio = 2.231 : 1

Lateral Forces Acting in Direction

Soil Pressures...	To Left	To Right
Ecc. of Resultant @ Footing Centerline	3.611	5.046 ft
Soil Pressure @ LEFT Side of Footing	628.52	0.00 psf
Soil Pressure @ RIGHT Side of Footing	0.00	771.10 psf

Moments...

Actual Mu @ Left Wall Edge	5,063.55	6,617.04 ft-#
Actual Mu @ Right Wall Edge	2,017.06	2,141.02 ft-#
Steel Reinforcing Required	0.43	0.43 in ²

Shears...

wu/85 @ 'd' from Left Wall Edge	5.641	2.332 psi
wu/85 @ 'd' from Right Wall Edge	2.268	7.363 psi
Allowable Vn	109.545	109.545 psi

Overturning...

Overturning Moment	69,832.23	69,832.23 ft-#
Resisting Moment	175,269.06	155,789.06 ft-#
Overturning Stability Ratio	2.510 : 1	2.231 : 1

Basic Usage

- Lateral Loads can be specified by the user, and are applied to the top of the wall. Uniform loads are applied from an attached diaphragm, and Concentrated loads due to transfer of collector forces (drag struts). A Moment can also be applied to transfer

reactions from a wall section above to the current wall.

- Vertical Loads allow you to apply uniform floor loads, concentrated beam loads, and uplift/compression loads due to end reactions from a wall above.
- Design Data specifies all values affecting the plywood sheathing selection. Thickness, grade, number of sides, and nail size all affect the program's selection of required nailing. Wall Length, Height, and Weight are used to calculate unit shear, lateral wall weight, and moments created by lateral loads applied at the top of the wall.
- The Summary section provides the results of the wall design, giving plywood thickness, nailing, allowable and actual shear values, uplift, check values and end hold down requirements, and footing design data.
- Footing Analysis is where you can define the footing width, thickness, and projection beyond the end of the wall.
- Refining the Wall and Footing Design is simply a matter of recalculating the worksheet and refining wall construction and footing sizes.

Unique Features


- This program has all the capabilities to design an entire plywood shear wall/footing assembly in one pass. The what-If ability can quickly modify the design criteria and give the user many design options and resulting calculations quickly.
- The footing design capability of the program can quickly determine the proper size footing to satisfy soil pressure and overturning requirements, normally a very tedious procedure.

Assumptions & Limitations

- Allowable plywood shear wall values are taken from UBC Table 23-I-K-1 for Structural I and II. The program assumes two times the allowable value for one side is allowed, when both sides are sheathed.
- All loads are considered to be applied at the top of the wall.
- ACI equation 9-3 is used for footing analysis and design.
- All lateral loads are considered short term and ACI load factors are applied accordingly.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

The data in this section defines the material parameters used in determining the necessary nail spacing for the shear wall. YOU enter Plywood Grade, Thickness, Nail Size, and Number of Sides Applied, and the program determines the allowable shear values from its internally stored UBC 25-K table. The nail spacing and allowable shear values are given.

General	Loads	Footing
Description		
Vertical Pt & Unif. Loads & Lateral Shear & Drag Loads		
Wall Dimensions...		
Wall Length	15.000	ft
Wall Height	12.000	ft
Wall Weight	15.00	psf
Ht / Length	0.800	
Sheathing Data...		
# Plywood Layers	<input checked="" type="radio"/> 1 Side <input type="radio"/> 2 Sides	
Plywood Grade	Structural I	
Nail Size	8d	
Thickness	15/32" in	
Stud Spacing	16.000	
End Post Dimension	3.50	
Wall : '94 UBC Seismic Factor Z Ip Cp -or- Similar 1997 UBC Factor Divided by 1.4 ..	0.183	
Nominal Sill Thick.	2x in	

Wall Length

Enter the desired wall length to be used for the analysis. This length will be used to determine the shear per foot from lateral loads for design purposes, the wall weight, and will be carried through to the section for footing design.

Wall Height

The wall height entered will be used to determine overturning moments on the wall for uplift calculations and overall stability moments. All lateral loads are applied at this height above the top of footing. Also, this height is used to calculate the wall weight for vertical loads.

Wall Weight

Enter the actual weight of the wall here. This weight is not used to contribute lateral seismic loads, only vertical loadings for uplift, soil pressure, and overturning calculations.

Ht/Width

Ratio Wall height divided by wall length.

Sheathing Data

Plywood Layers

Enter either 1" or 2" to indicate whether one or both sides of the wall will have plywood sheathing.

Plywood Grade

Select Structural I = 1" or Structural II = 2". These values should conform to the values allowed in the UBC.

Nail Size

Enter 6, 8, or 10" to indicate the penny size of the nails to be used.

Sheathing Thickness

This represents the nominal thickness of sheathing used on one or both sides. Enter this thickness in decimal form. These thicknesses should be only those which are available in UBC Table 23-I-K-1.

Stud Spacing

Enter the stud spacing which will be used as the sheathing attachment. The program checks whether stud spacing is 16" or less for some sheathing combinations to determine if higher values may be used. See the footnotes of Table 25-K for further information on which combinations are applicable.

End Post Dimension

This information will be used to determine the Simpson (or equivalent) connector to be called out for resisting uplift.

Seismic Factor For Wall Wt

Enter the seismic factor to be applied to the wall's weight for calculating that lateral force.

Nominal Sill Thickness

This program stores bolt values from UBC Table 23-I-K-1, and uses UBC code section 2311.2, paragraph 2, which states Allowable shear values used to connect a wood member to concrete or masonry are permitted to be determined as one-half the tabulated double shear values for a wood member twice the thickness of the member attached to the concrete or masonry.

Loads Tab

This program allows the user to apply lateral loads to the top of the wall, and have these lateral loads transformed to a per foot shear on the wall for design calculations. Both uniform and concentrated lateral loads are allowed, giving you the ability to model diaphragm and drag strut loadings.

General	Loads	Footing
Overburden Load Over Footing		<input type="text"/> psf
Vertical Loads...		
Point Load #1	<input type="text" value="1,300.0"/> lbs	at <input type="text" value="0.00"/> ft
Point Load #2	<input type="text" value="1,300.0"/> lbs	at <input type="text" value="15.00"/> ft
Point Load #3	<input type="text" value="546.0"/> lbs	at <input type="text" value="7.00"/> ft
Uniform #1	<input type="text" value="150.0"/> #/ft	<input type="text" value="0.00"/> to <input type="text" value="7.00"/> ft
Uniform #2	<input type="text" value="213.0"/> #/ft	<input type="text" value="8.00"/> to <input type="text" value="15.00"/> ft
Lateral Loads... (Net after applying seismic factors)		
Uniform Shear @ Top of Wall		
<input type="text" value="100.0"/> #/ft	*	15.000 ft = 1,500.00 lbs
Uniform Shear @ Top of Wall		
<input type="text" value="100.0"/> #/ft	*	15.000 ft = 1,500.00 lbs
Strut Force Applied @ Top of Wall	<input type="text" value="2,000.00"/> lbs	
Strut Force Applied @ Top of Wall	<input type="text" value="1,500.00"/> lbs	
Moment Applied @ Top of Wall	<input type="text" value="12.00"/> ft-#	
Total Applied Lateral Loads		6,500.000 lbs

Overburden Load over Footing

This is a uniform load resting over the wall footing. It is applied over the entire footing....even where there might be a wall area present.

Vertical Loading

The user can also apply vertical loads to the wall to account for vertical floor, roof, beam, or column loads. These loads are included in overturning and soil pressure calculations.

Point Load & X-left

The user can enter up to three concentrated loads applied to the wall. Enter the distance from the left side of the wall to where the loads is applied.

Uniform....& X-left, X-Right

The user can also enter up to two partial or full length uniform loads to the wall. X-Left indicates the distance from the left side of the wall to the beginning of the load. X-Right indicates the distance from the left end of wall to the end of the load.

Lateral Shear Applied To Wall

This input item represents the uniform shear force applied to the top of the wall. Uniform indicates the load is applied to the wall along its entire length (such as a load transferred to the wall from a horizontal diaphragm).

Strut Force Applied @Top Of Wall

The user can also apply a concentrated load at the top of the wall height. This strut force is provided to apply collector loads (drag struts) to the wall.

Moment Applied to Top of Wall

When you have a wall on the level above that must have its lateral forces and overturning moment transferred to the wall below (i.e. wall being designed), you can enter the moment here and it will be included in the calculations for uplift at the end of the wall and for footing calculations. Positive sign (+) applies the moment to the wall in a clockwise direction (increasing soil pressure at the right side of the wall). To apply the vertical components at the end of the wall on the story above, use the Point Load entry of the Vertical Loads section.

Footing Tab

General	Loads	Footing
Footing Dimensions...		
Past Left Edge of Wall	<input type="text" value="3.000"/>	ft
Wall Length	15.000	ft
Past Right Edge of Wall	<input type="text" value="3.000"/>	ft
Footing Length	21.00	ft
Footing Width	<input type="text" value="2.500"/>	ft
Footing Thickness	<input type="text" value="15.00"/>	in
Concrete Weight	<input type="text" value="145.00"/>	pcf
Rebar Cover	<input type="text" value="3.000"/>	in
f_c	<input type="text" value="3,000.0"/>	psi
F_y	<input type="text" value="60,000.0"/>	psi
Min. Steel A_s %	<input type="text" value="0.0012"/>	

Footing Dimensions

Past Left Edge of Wall

Enter the distance from the left edge of wall to the left end of the footing here. Modifying this value will alter soil pressure and overturning stability. A non-zero value will be the projection of the footing beyond the edge of the wall.

Wall Length

The Wall Length previously entered is automatically transferred to this cell, and used as the basis of determining footing calculations (considering left and right footing projecting lengths).

Past Right Edge of Wall

Enter the distance from the left edge of wall to the left end of the footing here. Modifying this value will alter soil pressure and overturning stability. A non-zero value will be the projection of the footing beyond the edge of the wall.

Footing Length

This is the summation of wall length and the distance the footing projects beyond ends of the wall.

Footing Width

Enter the footing width to be used in calculations of soil pressure and stability.

Footing Thickness

Enter the footing thickness to be used to calculate of soil pressure and stability.

Concrete Weight

Enter the concrete density to be used to calculate the added vertical load due to the footing weight. If you wish to omit the automatic inclusion of footing weight in soil pressure calculations, set this value to zero.

Rebar Cover

Enter the distance from the bottom of the footing to edge of the reinforcing.

f'c

Compressive strength of concrete.

Fy

Tension yield strength of reinforcing.

Min As %

Enter the absolute minimum reinforcing area ratio here. The actual required reinforcing area is calculated as follows:

- The required steel percentage is calculated by first finding the required steel area due to bending moments: $\% \text{ Req'd} = (1/m) * (1 - [1 - (2 * m * Ru) / Fy]^{1/2})^{1/2}$
- If this percentage is greater than $200 / Fy$ then it is compared to your Min. As % value, and the maximum used.
- If it's less than $200 / Fy$, it is multiplied by 1.33 and again compared to $200 / Fy$. The minimum of those two values is then compared to your Min. AS % value and the larger used
- The actual area required is equal to the As% value calculated previously multiplied by the footing width and (Footing Thickness - Rebar Cover).

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results / Summary Tab

Results Sketch Printing		
Summary Simpson Hold Downs & Sill Bolting		
Design OK		
Wall Summary...		
Using 15/32" Thick Structural I on 1 side/s, Nailing is ϕ d at 3 in @ Edges, ϕ d at 12 in @ Fie		
Applied Shear = 466.3#/#, Capacity = 550.000#/# -> OK		
Wall Overturning = 80,976.6ft-#, Resisting Moment = 61,411.5ft-#, End Uplift = 1,304.34lbs		
Max. Soil Pressures: @ Left = 856.8psf, @ Right = 883.2psf		
Footing Summary...		
Max. Footing Shear = 8.8psf, Allowable = 109.54psi -> OK		
Bending Reinforcement Req'd @ Left = 0.43in ² , @ Right = 0.43in ²		
Minimum Overturning Stability Ratio = 2.079 : 1		
<u>Lateral Forces Acting in Direction</u>		
Soil Pressures...	<u>To Left...</u>	<u>To Right...</u>
Ecc. of Resultant @ Footing Centerline	4.928	5.095 ft
Soil Pressure @ LEFT Side of Footing	856.83	0.00 psf
Soil Pressure @ RIGHT Side of Footing	0.00	883.23 psf
Moments...		
Actual Mu @ Left Wall Edge	7,698.59	7,981.92 ft-#
Actual Mu @ Right Wall Edge	2,141.02	2,141.02 ft-#
Steel Reinforcing Required	0.43	0.43 in ²
Shears...		
vu/85 @ 'd' from Left Wall Edge	8.557	2.332 psi
vu/85 @ 'd' from Right Wall Edge	2.332	8.876 psi
Allowable Vn	109.545	109.545 psi
Overturning...		
Overturning Moment	89,719.23	89,719.23 ft-#
Resisting Moment	189,468.56	186,486.56 ft-#
Overturning Stability Ratio	2.112 : 1	2.079 : 1

Wall Summary

This gives a complete summary of all values calculated for the shear wall.

Footing Summary

This gives a complete summary of all values calculated for the footing.

Soil Pressures

Using the lateral loads and vertical loads (including footing weight), the actual soil pressures are given. The program automatically checks cases where the resultant is outside the kern as well as inside.

Moments

Calculated moments in the footing taken at the face of the wall.

Shears

Calculated one-way shear stresses in the footing at a distance (footing thickness - rebar cover) from the end of the wall. Allowable shear equals $2.0 * f_c/2$

Overturning

Overturning Moment : Total overturning moment acting on the footing/wall system, taken about the bottom/outer edge of the footing (lateral weight of the footing is ignored).

Resisting Moment : Total overturning moment acting on the footing/wall system, taken about the bottom/outer edge of the footing (lateral weight of the footing is ignored).

Factor of Safety : Total Resisting Moment/Total Overturning moment. It is recommended that this value be greater than or equal to 1.5.

Results / Simpson Hold Down

Results
Sketch
Printing

Summary
Simpson Hold Downs & Sill Bolting

Choices for LEFT Side of Wall to Footing.....

Uplift Force @ Left end of Wall	1,304.34 lbs
HD2A, Capacity = 2775lbs	
HD2, Capacity = 2815lbs	
PHD2, Capacity = 3610lbs	
HD5A, Capacity = 4010lbs	

Choices for RIGHT Side of Wall to Footing.....

Uplift Force @ Right end of Wall	1,105.54 lbs
HD2A, Capacity = 2775lbs	
HD2, Capacity = 2815lbs	
PHD2, Capacity = 3610lbs	
HD5A, Capacity = 4010lbs	

Sill Bolt Size & Spacing...

1/2" Anchor Bolts (capacity = 845 lbs)	21.74 in
5/8" Anchor Bolts (capacity = 1,320 lbs)	33.89 in
3/4" Anchor Bolts (capacity = 1860 lbs)	47.92 in

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.

Results | Sketch | Printing |

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Loads	<input checked="" type="checkbox"/>
Footing	<input checked="" type="checkbox"/>
Summary	<input checked="" type="checkbox"/>
Simpson Hold Down Options	<input checked="" type="checkbox"/>
Footing Analysis	<input checked="" type="checkbox"/>

Note: When all are selected, the software will still omit unused sections

Sample Printout Page 1

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949.645.0151
 www.enercalc.com

Title: ENERCALC Example Problems **Job #** 97-000001
Dsgnr: NDB **Date:** 3:11PM, 25 OCT 03
Description: Collection of example problems
Scope: All programs in the Structural Engineering Library

Rev: 990000
 User: HW-0000001, W r 5.0.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software Page 1
c:\ec30\examples\ewal\Tribler Calc

Plywood Shear Wall & Footing

Description Vertical Pt & Unif. Loads & Lateral Shear & Drag Loads

General Information Code Ref: 1997 NDS, 2003 IBC, 2003 NFPA 5000. Base allowables are user defined.

# Plywood Layers	1	Wall Length	15.000 ft	End Post Dimension	3.50 in
Plywood Grade	Structural I	Wall Height	12.000 ft	Seismic Factor	0.183
Nail Size	8d	Wall Weight	15.000 psf	Nominal Sill Thick.	2.00
Thickness	15/32"	Ht / Length	0.800		
Stud Spacing	16.00 in				

Loads

Vertical Loads...

Point Load # 1	1,300.00 lbs	at	15.00 ft		
Point Load # 2	0.00 lbs	at	0.00 ft		
Point Load # 3	0.00 lbs	at	ft		
Uniform Load # 1	150.00 #/ft		0.00 ft	to	15.00 ft
Uniform Load # 2	0.00 #/ft		0.00 ft	to	0.00 ft

Lateral Loads...

Uniform Shear @ Top of Wall	100.00 #/ft	*	15.000 ft	=	1,500.00 lbs
Uniform Shear @ Top of Wall	100.00 #/ft	*	15.000 ft	=	1,500.00 lbs
Strut Force Applied @ Top of Wall	2,000.00 lbs				
Strut Force Applied @ Top of Wall	0.00 lbs				
Moment Applied @ Top of Wall	0.00 ft-lb				

Footing

Post Left Edge of Wall	3.000 ft	Concrete Weight	145.00 pcf
Wall Length	15.000 ft	Rebar Cover	3.00 in
Post Right Edge of Wall	3.000 ft	fc	3,000.00 psi
Footing Length	21.000 ft	Fy	60,000.00 psi
Footing Width	2.50 ft	Min. Steel As %	0.00120
Footing Thickness	15.00 in		

Summary Design OK

Wall Summary...
 Using 15/32" Thick Structural I on 1 side/s. Nailing is 8d at 4 in @ Edges, 8d at 12 in @ Field
 Applied Shear = 366.3#/ft, Capacity = 430.000#/ft -> OK
 Wall Overturning = 62,964.6ft-#, Resisting Moment = 37,125.0ft-#, End Uplift = 1,722.64lbs
 Max. Soil Pressures: @ Left = 628.5psf, @ Right = 771.1psf
 Sill Bolting: 1/2" Bolts @ 27.67in, 5/8" Bolts @ 43.14in, 3/4" Bolts @ 48.00in

Footing Summary...
 Max. Footing Shear = 7.36psi, Allowable = 109.54psi -> OK
 Bending Reinforcement Req'd @ Left = 0.43in², @ Right = 0.43in²
 Minimum Overturning Stability Ratio = 2.231 : 1

Simpson Hold Down Options

Choices for LEFT Side of Wall to Footing.....	Choices for RIGHT Side of Wall to Footing.....
HD2A, Capacity = 2775lbs	HD2A, Capacity = 2775lbs
HD2, Capacity = 2815lbs	HD2, Capacity = 2815lbs
PHD2, Capacity = 3610lbs	PHD2, Capacity = 3610lbs
HD5A, Capacity = 4010lbs	HD5A, Capacity = 4010lbs

Sample Printout Page 2

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 3:11 PM, 25 OCT 03
 Description: Collection of example problems

Scope: All programs in the Structural Engineering Library

Rev: 580000
 User: KW-0900001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

Plywood Shear Wall & Footing

Page 2

c:\ec55\examples.ecw\Timber Calc

Description Vertical Pt & Unif. Loads & Lateral Shear & Drag Loads

Footing Analysis

Soil Pressures...	Lateral Forces Acting in Direction	
	To Left...	To Right..
Ecc. of Resultant @ Footing Centerline	3.811 ft	5.048 ft
Soil Pressure @ LEFT Side of Footing	628.52 psf	0.00 psf
Soil Pressure @ RIGHT Side of Footing	0.00 psf	771.10 psf
Moments...		
Actual Mu @ Left Wall Edge	5,083.55 ft-#	6,617.04 ft-#
Actual Mu @ Right Wall Edge	2,017.06 ft-#	2,141.02 ft-#
Shears...		
vu/85 @ 'd' from Left Wall Edge	5.641 psi	2.332 psi
vu/85 @ 'd' from Right Wall Edge	2.288 psi	7.363 psi
Allowable Vn	109.545 psi	109.545 psi
Overturning...		
Overturning Moment	69,832.23 ft-#	69,832.23 ft-#
Resisting Moment	175,289.06 ft-#	155,789.06 ft-#
Overturning Stability Ratio	2.510 :1	2.231 :1

3.7 Horizontal Plywood Diaphragm

This program provides analysis and design of horizontal rectangular plywood diaphragms subjected lateral loads from wind or seismic forces.

This program calculates nailing requirements and shear values using UBC Table 23-I-J-1, including blocked and unblocked diaphragms. For conditions where high diaphragm loads create shears exceeding those available from the UBC table, you can use the High Load Plywood Diaphragm program, which uses ICBO Report #1952 for diaphragm design using 23/32" plywood applied according to the reports requirements.

Loads due to diaphragm self weight and lateral loads applied to the diaphragm boundary are allowed. To analyze diaphragms subjected to wind loads only, specify diaphragm weight as zero and seismic factor as 1".

Up to four partial or full length uniform loads can be applied to the diaphragm boundary in both the North-South or East-West direction. The partial length ability allows you to model seismic wall weight or wind loads on portions of the building with different tributary areas.

The program calculates total shear and unit shear for each of the four sides of the diaphragm, chord forces at 1/4 points, and will determine diaphragm nailing density and cut-off requirements for various diaphragm shear capacities.

A unique feature of the program allows the user to vary the nail size, plywood thickness, plywood grade, and member size and have the allowable shear values for the particular specification recalled from an internally stored table. The program will then calculate the minimum nail density reduction distances from each wall, based upon the actual shear variation across the diaphragm.

Nail Pattern, Allowable Shear & Cutoff Distance...			
	Nail Spacing Definition	Shear Value	Zone Distance from End
	in	#/ft	ft
At North Wall	2,5,3,12	735.0	0.00
2nd zone	2,3,12	650.0	43.68
3rd zone	4,6,12	385.0	64.48
Center Zone	6,6,12	290.0	
3rd zone	4,6,12	385.0	68.64
2nd Zone	2,5,3,12	650.0	42.64
At South Wall	2,3,12	735.0	0.00
Nail Pattern, Allowable Shear & Cutoff Distance...			
	Nail Spacing Definition	Shear Value	Zone Distance from End
	in	#/ft	ft
At West Wall	2,3,12	735.0	0.00
2nd zone	2,5,3,12	650.0	0.00
3rd zone	4,6,12	385.0	10.80
Center Zone	6,6,12	290.0	
3rd zone	4,6,12	385.0	13.68
2nd Zone	2,5,3,12	650.0	0.00
At East Wall	2,3,12	735.0	0.00

Allow. Shears per 2003 IBC Table 2306.3.1

Basic Usage

- Before using the program, establish a North/South axis system to use for reference. This will make data entry and interpretation of results much easier, since all program input and output makes reference to such a layout.
- Diaphragm Lengths & Chord Separations. Enter the length and width of the rectangular diaphragm, then enter the chord separations. We have provided the ability to separate chord distance from building dimensions to allow use of beam lines as chords, typically needed when the exterior walls have discontinuities.
- Diaphragm Weight only needs to be entered when seismic forces are being used, and will be multiplied by Short Term Factor before generating lateral loads. For wind analysis, set this item equal to zero.
- Short Term Factor will be applied to diaphragm weight and applied boundary loads to generate lateral forces. For wind analysis, this should be set to 1". For seismic analysis, enter the overall structural seismic factor.

- Blocked/Unblocked and Load Direction are used when retrieving allowable diaphragm shear values from the internally stored UBC tables.
- Applied Boundary Loads are used to transmit wind or seismic forces to the diaphragm. For wind analysis , the wind load on the tributary portion of the exposed structure is entered. For seismic analysis , enter the actual tributary weight before applying a seismic factor.
- Review Nailing Requirements. This table is used to iteratively design the diaphragm on a ZONE basis. Each row represents the diaphragm construction for the nail spacings listed under Spacing Req'd. The values YOU enter for Framing Size, Plywood Thickness, Plywood Grade, and Nail Size will be used to retrieve an allowable Shear Value from the internal UBC table. The Zone Distance indicates how far from the wall that particular construction and nail spacing must be used.
- If Zone Distance is "0" , then that particular nail density (diaphragm construction) is NOT NEEDED . The next lower nail spacing/construction type should be used at the wall. When no shears exceed the allowable for 6", 6",12" spacing, all Zone Distances will be "0", and the "typical" nail density/ construction type should be used.
- Refine Plywood Values and recalculate as required so that the nail density and shear values can adequately resist the shears.
- Print or Save the data for the worksheet, Reset all values to zero to start a new problem, or use the Access Menu to choose another program.

Unique Features

- Allows quick design of rectangular plywood diaphragms with self and varying length applied loads.
- User may vary chord spacing according to needs and obtain chord forces at 1/4 points of span (or other locations as specified).

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General	Uniform Loads	Point Loads	Diaphragm Construction
Description			
Illustrating Zone-Nailing Areas			
Dimensions...			
North-South Length	260.00	ft	
East-West Length	180.00	ft	
North-South Chord	260.00	ft	
East-West Chord	180.00	ft	
Diaphragm Weight	12.000	psf	
Wall : " Service Level Seismic Factor -or- Strength Design Factor Divided by 1.4	0.183		
Is Diaphragm Blocked ?	<input checked="" type="checkbox"/>		
Blocking Direction	North-South		

North/South Length

This defines the North-South dimension of the diaphragm. This length will be used to:

- Calculate the total lateral load due to the diaphragm's self-weight (multiplied by seismic factor).
- Used to divide the total shear at the east and west walls due to north-south forces, resulting in a shear per foot value which the diaphragm must resist.

East/West Length

Please see the description above, except reverse all the directions.

Distance Between Chords

Normally, the user will enter the same values here as the diaphragm lengths. When the distance between the chords is more or less than the length, enter these new distances here, and they will be used to determine the chord forces. An example where this might be necessary is when a building has a very broken up side and there is no way to run a continuous tension chord member along the wall. In those cases you would use a line of beams with heavy straps tying them together when interrupted at a connection or other break,

Length/Width Ratio

Equals Maximum Dimension/Minimum Dimension(most codes limit to 4:1).

Diaphragm Weight

Defines the actual self-weight of the plywood diaphragm (before any adjustments for seismic factor). This value will be multiplied by the Length, Width and Seismic Factor to determine the total lateral force acting. This weight is in addition to the Applied Boundary Loads as detailed below.

SET THIS ENTRY TO 0" FOR WIND LOAD ANALYSIS. Enter the wind loads in the section titled Applied Load in N/S & E/W Direction.

Seismic Factor

Working stress level seismic factor will be applied to the diaphragm self weight and boundary loads to determine the total lateral force acting on the diaphragm. Remember, enter all lateral loads without any factors applied.

Various codes specify this value in either "Working Stress" or "Factored Loads". For instance the recent UBC and IBC codes use a higher "factored" load factor that needs to be divided by 1.4 before entering it here.

If you are using the program to analyze a diaphragm subjected to WIND loads, enter a 1" in this area so the boundary loads you enter will be applied directly (and unfactored) to the diaphragm. Also, DO NOT ENTER DIAPHRAGM SELF WEIGHT, as it does not apply to wind load conditions.

Blocked/Unblocked

This entry specifies the proper UBC table to use when retrieving the allowable diaphragm shears.

Uniform Loads Tab

General	Uniform Loads	Point Loads	Diaphragm Construction
Note! Seismic factor will be applied to these loads			
Boundary Loads Acting North & South			
# 1	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="180.00"/> ft
# 2	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="30.00"/> to <input type="text" value="180.00"/> ft
# 3	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft
# 4	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft
Boundary Loads Acting East & West			
# 1	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="260.00"/> ft
# 2	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="200.00"/> ft
# 3	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft
# 4	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft

Boundary Loads Acting North & South

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act North-South and are resisted by shear in the East & West walls, and create tension cord forces in the North & South walls.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the westerly side of the diaphragm and extend eastward (in other works left to right). Entering both locations as "0.0" will apply the loads the full diaphragm dimension.

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor by the program).

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Boundary Loads Acting East & West

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act East-West and are resisted by shear in the North & South walls, and create tension cord forces in the East & West chord locations.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the **Northerly** side of the diaphragm and extend **Southward** (in other works top to bottom). Entering both locations as "0.0" will apply the loads the full diaphragm dimension.

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor) by the program.

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Point Loads Tab

General	Uniform Loads	Point Loads	Diaphragm Construction
Note! Seismic factor will be applied to these loads			
Point Loads Acting NORTH-SOUTH...			
# 1	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 2	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 3	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 4	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
Point Loads Acting EAST-WEST...			
# 1	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 2	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 3	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 4	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft

Boundary Loads Acting North & South

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act North-South and are resisted by shear in the East & West walls, and create tension cord forces in the North & South walls.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the **Westerly** side of the diaphragm and measured **Eastward**

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor) by the program.

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Boundary Loads Acting East & West

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act East-West and are resisted by shear in the North & South walls, and create tension cord forces in the East & West chord locations.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the **Northerly** side of the diaphragm and measured **Southward**

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor by the program.

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Diaphragm Construction Tab

This tab has all the entries used to define the construction of the diaphragm. Just as a beam has the shear forces higher the closer you get to a support, so the diaphragm works the same way. This table is designed so that you can specify a diaphragm construction with higher shear capacity the closer you get to the end walls.

There are two areas "North & South Walls & and "East & West Walls". Each of these two sections let you specify the diaphragm construction from one end of the building to the other. Note in the top section it starts with "At North wall", goes downward through some "zones", and then ends with the other wall...."At South Wall".

This table let you specify the changes in diaphragm construction THAT CAN BE USED if the shear at each end reaches a high enough level. TO SEE WHICH CONSTRUCTION NEEDS TO BE USED LOOK AT THE "**Diaphragm Design** TAB.

Example 1: If you have a diaphragm with very low loading you will probably not need anything more than the least thickness and nailing grade. In this case you will just need what is shown for the "Center" region....it just happens that this "center" zone extends all the way out to the end walls.

Example 2: If you have a very highly loaded diaphragm you will need very tough construction at the walls to take the high shear loads. The highest specification shown below is in the top and bottom entries and shows 3x framing. On the "**Diaphragm Design**" tab you will be given distances and nail spacing that will result in shear capacities that change from the lowly-loaded center region to the highly loaded outer regions. The entire purpose of this concept of "zones" is to develop a nailing pattern that results in the most economical diaphragm construction for the expected shear requirements of the diaphragm.

General Uniform Loads Point Loads Diaphragm Construction				
North & South Walls....				
	Framing	Thickness in	Grade	Nail Size
At North Wall	3x	1/2"	Grade C-D,C-C	10d
2nd Zone	3x	1/2"	Grade C-D,C-C	10d
3rd Zone	2x	1/2"	Grade C-D,C-C	10d
Center Zone	2x	1/2"	Grade C-D,C-C	10d
3rd Zone	2x	1/2"	Grade C-D,C-C	10d
2nd Zone	3x	1/2"	Grade C-D,C-C	10d
At South Wall	3x	1/2"	Grade C-D,C-C	10d
West & East Walls....				
	Framing	Thickness in	Grade	Nail Size
At West Wall	3x	1/2"	Grade C-D,C-C	10d
2nd Zone	3x	1/2"	Grade C-D,C-C	10d
3rd Zone	2x	1/2"	Grade C-D,C-C	10d
Center Zone	2x	1/2"	Grade C-D,C-C	10d
3rd Zone	2x	1/2"	Grade C-D,C-C	10d
2nd Zone	3x	1/2"	Grade C-D,C-C	10d
At East Wall	3x	1/2"	Grade C-D,C-C	10d

Framing Size

Enter a 2" to indicate 2x nominal framing or 3" for 3x nominal framing. This framing size will be used to determine the allowable shear capacities per UBC Table 23-I-J-1.

Plywood Thickness

Select the plywood thickness to be used. This thickness should be entered in decimal form, and consistent with the allowed thicknesses presented in UBC Table 23-I-J-1.

Plywood Grade

This defines the plywood grade to be used, and is consistent with the definitions in the UBC Table 23-I-J-1.

Nail Size

Enter the size of nail to be used with the plywood specified. The nail size should be entered as 6" for 6d, 8" for 8d, or 10" for 10d.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This tab displays the overall maximum shear and chord force values at the walls.

Results	Diaphragm Design	Sketch
Diaphragm Shears...		
	<u>North</u>	<u>South</u>
Total Shear	104,832	95,085 lbs
Shear per Foot	582.40	528.25 #/ft
	<u>West</u>	<u>East</u>
Total Shear	83,592	88,871 lbs
Shear per Foot	321.51	341.81 #/ft
Chord Forces...		
	<u>North/South Walls</u>	<u>East/West Walls</u>
@ 1/4 * Length	11,267.7 lbs	28,110.0 lbs
@ 1/2 * Length	15,290.1 lbs	37,327.9 lbs
@ 3/4 * Length	11,574.2 lbs	27,361.2 lbs
Length / Width Ratio	1.444 : 1	

Total Shear

From the loading, seismic factor, and diaphragm dimensions entered, the total and unit end shears are calculated using basic statics.

Unit Shear

This equals a wall's total shear divided by its length.

Chord Forces

From the loading, seismic factor, dimensions and distances between chords entered, the chord forces at 1/4 points of diaphragm span are given.

Diaphragm Design Tab

The primary purpose of the results on this tab is to indicate the distance from each end wall that a AT LEAST a certain nail spacing is required.

Results Diaphragm Design Sketch			
Nail Pattern, Allowable Shear & Cutoff Distance...			Zone
	Nail Spacing Definition	Shear Value	Distance from End
	in	#/ft	ft
At North Wall	2.5,3,12	735.0	0.00
2nd zone	2,3,12	650.0	43.68
3rd zone	4,6,12	385.0	64.48
Center Zone	6,6,12	290.0	
3rd zone	4,6,12	385.0	68.64
2nd Zone	2.5,3,12	650.0	42.64
At South Wall	2,3,12	735.0	0.00
	Nail Spacing Definition	Shear Value	Zone Distance from End
	in	#/ft	ft
At West Wall	2,3,12	735.0	0.00
2nd zone	2.5,3,12	650.0	0.00
3rd zone	4,6,12	385.0	10.80
Center Zone	6,6,12	290.0	
3rd zone	4,6,12	385.0	13.68
2nd Zone	2.5,3,12	650.0	0.00
At East Wall	2,3,12	735.0	0.00

Allow. Shears per 2003 IBC Table 2306.3.1

Nail Spacing Definition

This item is always constant, and defines the nail density to be used for the material specified on that row.

When a non-zero Zone Distance number is displayed for the row, it indicates that the plywood material should be nailed at this spacing or greater, out to that distance from the wall.

A typical spacing identification looks like this: 2.5", 4", 12". The first number (2.5) indicates the nailing required at the boundary and continuous plywood panel edges. The second number (4") is the spacing required at all other plywood panel edges. The third number (12") indicates the nailing required in the interior regions of the plywood panel. Note: 10" maximum spacing is usually allowed for floor diaphragms.

The user may specify the distances of each side of the load from a wall to define a partial length load.

Shear Value

For the diaphragm construction specified and nail spacing indicated on the line, the allowable diaphragm shear value is retrieved from the internally stored UBC tables and displayed here. When displayed as zero, this indicates that the program does not contain any data for this combination of

framing size, plywood thickness, plywood grade, nail size, and nail spacing.

Zone Distances


This table provides the designer with an easy way to determine the allowable cut-off points for different nailing densities. The table basically represents the diaphragm from one end to the other. You may specify a particular diaphragm construction to be used for the noted zones by changing the Nail Size, Plywood Grade, and Thickness values for each nailing density line. From your entered data, the program will calculate where that specific nailing area may be stopped (measured from the wall) and the lower diaphragm capacity used (indicating the transition in actual shear stresses).

- Between the wall and Zone Distance, the diaphragm construction must meet or exceed the shear values listed for that row.
- When the Zone Distance equals zero, this indicates that particular diaphragm specification for the particular nailing is not required.
- When the Zone Distance is displayed as "NA", this indicates that the actual diaphragm shears are higher than the diaphragm specification is capable of taking.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.

The sketch is designed to show the various nailing "zones" in different colors. Within each zone a certain diaphragm design is required according to the framing size, thickness, grade, and nail spacing that are developed in the previous input and "Diaphragm Design" tab.



Sample Printout

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949.645.0151
www.enercalc.com

Title : ENERCALC Example Problems Job # 97-000001
Dsgnr: MDB Date: 4:05PM, 25 OCT 03
Description : Collection of example problems

Scope : All programs in the Structural Engineering Library

Rev: 280000
User: K:\97000001_Ver 5.8.0_10-Sep-2003
©1983-2003 ENERCALC Engineering Software

Horizontal Plywood Diaphragm

Page 1

c:\ec06\examples\ew\Timber Calc

Description Illustrating Zone-Nailing Areas

General Information Code Ref: 1997 NDS, 2003 IBC, 2003 NFPA 5000.

North-South Length	260.00 ft	Diaphragm Weight	12.00 psf
East-West Length	180.00 ft	Seismic Factor	0.1830
North-South Chord	260.00 ft	Diaphragm is Blocked	
East-West Chord	180.00 ft	Blocking Direction	North-South

Boundary Loads Acting North & South

# 1	1,154.00 #/ft	from	0.000 ft	to	180.000 ft
# 2	1,154.00 #/ft	from	30.000ft	to	180.000 ft
# 3	#/ft	from	0.000 ft	to	0.000 ft
# 4	#/ft	from	0.000 ft	to	0.000 ft

Boundary Loads Acting East & West

# 1	1,154.00 #/ft	from	0.000 ft	to	260.000 ft
# 2	1,154.00 #/ft	from	0.000 ft	to	200.000 ft
# 3	#/ft	from	0.000ft	to	0.000 ft
# 4	#/ft	from	0.000 ft	to	0.000 ft

North & South Walls Design Data & Nailing Requirements Allow. Shears per 2003 IBC Table 2306.3.1

	Framing	Thickness in	Grade	Nail Size	Spacing in	Shear Value #/ft	Zone Distance ft
At North Wall	3x	1/2"	Grade C-D,C-C	10d	2,3,12	735.0	0.00
2nd zone	3x	1/2"	Grade C-D,C-C	10d	2,5,4,12	650.0	43.68
3rd zone	2x	1/2"	Grade C-D,C-C	10d	4,6,12	385.0	64.48
Center zone	2x	1/2"	Grade C-D,C-C	10d	6,6,12	290.0	
3rd zone	2x	1/2"	Grade C-D,C-C	10d	4,6,12	385.0	68.64
2nd zone	3x	1/2"	Grade C-D,C-C	10d	2,5,4,12	650.0	42.64
At South Wall	3x	1/2"	Grade C-D,C-C	10d	2,3,12	735.0	0.00

East & West Walls Design Data & Nailing Requirements Allow. Shears per 2003 IBC Table 2306.3.1

	Framing	Thickness in	Grade	Nail Size	Spacing in	Shear Value #/ft	Zone Distance ft
At West Wall	3x	1/2"	Grade C-D,C-C	10d	2,3,12	735.0	0.00
2nd zone	3x	1/2"	Grade C-D,C-C	10d	2,5,4,12	650.0	0.00
3rd zone	2x	1/2"	Grade C-D,C-C	10d	4,6,12	385.0	10.80
Center zone	2x	1/2"	Grade C-D,C-C	10d	6,6,12	290.0	
3rd zone	2x	1/2"	Grade C-D,C-C	10d	4,6,12	385.0	13.68
2nd zone	3x	1/2"	Grade C-D,C-C	10d	2,5,4,12	650.0	0.00
At East Wall	3x	1/2"	Grade C-D,C-C	10d	2,3,12	735.0	0.00

Shear & Chord Forces

Diaphragm Shears...	North	South	West	East
Total Shear	104831.7 lbs	95,084.8 lbs	83,591.7 lbs	88,871.2 lbs
Shear per Foot	582.40 #/ft	528.25 #/ft	321.51 #/ft	341.81 #/ft

Chord Forces...

@ 1/4 * Length	11,267.7 lbs	28,110.0 lbs
@ 1/2 * Length	15,290.1 lbs	37,327.9 lbs
@ 3/4 * Length	11,574.2 lbs	27,361.2 lbs

Length / Width Ratio 1.444

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 4:05PM, 25 OCT 03
 Description : Collection of example problems

Scope : All programs in the Structural Engineering Library

Rev: 580000
 User: KVV-0600001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software


Horizontal Plywood Diaphragm

Page 2

c:\ec5\examples.ecw\Timber Calc

Description Illustrating Zone-Nailing Areas

Sketch & Diagram



3.8 High-Load Plywood Diaphragm

This program provides analysis and design of horizontal rectangular plywood diaphragms subjected lateral loads from wind or seismic forces.

This program calculates nailing requirements and shear values using ICBO Report #1952 for diaphragm design using 23/32" plywood applied according to the report's requirements. Loads due to diaphragm self weight and lateral loads applied to the diaphragm boundary are allowed. The program is used to analyze diaphragms subjected to only wind loads by specifying diaphragm weight as zero and seismic factor as 1".

Up to four partial or full length uniform loads can be applied to the diaphragm boundary in both the North-South or East-West direction. The partial length ability allows you to model seismic wall weight or wind loads on portions of the building with different tributary areas.

The program calculates total shear and unit shear for each of the four sides of the diaphragm, chord forces at 1/4 points, and will determine diaphragm nailing density and cut-off requirements for typical diaphragm shear capacities.

A unique feature of the program allows the user to vary the nail size, plywood thickness, plywood grade, and member size and have the allowable shear values for the particular specification recalled from an internally stored table. The program will then calculate the minimum nail density reduction distances from each wall, based upon the actual shear variation across the diaphragm.

Design Data & Nailing Requirements

North & South Walls...

	Framing Size	Plywood Grade	# Lines of Fasteners	Boundary Spacing	@ Other Edges
At North Wall	3x	Structural II	2	2	2
2nd zone	3x	Structural II	2	2.5	3
Center Zone	3x	Structural II	2	4	4
2nd Zone	3x	Structural II	2	2.5	3
At South Wall	3x	Structural II	2	2	2

East & West Walls...

	Framing Size	Plywood Grade	# Lines of Fasteners	Boundary Spacing	@ Other Edges
At West Wall	3x	Structural II	2	2	2
2nd zone	3x	Structural II	2	2.5	3
Center Zone	3x	Structural II		4	4
2nd Zone	3x	Structural II	2	2.5	3
At East Wall	3x	Structural II	2	2	2

Diaphragm Shears...

	North	South
Total Shear	194852.8 lbs	205412.0 lbs
Shear per Foot	1,082.5 #/ft	1,141.2 #/ft

	West	East
Total Shear	187927.2 lbs	182647.7 lbs
Shear per Foot	466.5 #/ft	451.8 #/ft

Chord Forces...

	North/South Walls	East/West Walls
@ 1/4 * Length	15,508.6 lbs	75,422.5 lbs
@ 1/2 * Length	20,824.9 lbs	102177.8 lbs
@ 3/4 * Length	15,810.0 lbs	77,304.3 lbs

Length / Width Ratio 2.00 : 1

Basic Usage

- Before using the program, establish a North/South axis system to use for reference. This will make data entry and interpretation of results much easier, since all program input and output makes reference to such a layout.
- Diaphragm Lengths & Chord Separations. Enter the length and width of the rectangular diaphragm, then enter the chord separations. You can separate chord distances from building dimensions to allow use of beam lines as chords, typically needed when the exterior walls have discontinuities.
- Diaphragm Weight only needs to be entered when seismic forces are being used, and will be multiplied by Short Term Factor before generating lateral loads. For wind

- analysis, set this item equal to zero.
- Short Term Factor will be applied to diaphragm weight and applied boundary loads to generate lateral forces. For wind analysis, this should be set to 1". For seismic analysis, enter the overall structural seismic factor.
 - Fastener Size can be either 10d nails or 14 gauge staples.
 - Applied Loads are used to transmit wind or seismic forces to the diaphragm. For wind analysis, the wind load on the tributary portion of the exposed structure is entered. For seismic analysis, enter the actual tributary weight before applying a seismic factor.
 - Review Nailing Requirements. This table is used to iteratively design the diaphragm on a ZONE basis. Each row represents the diaphragm construction for the nail spacings listed under Spacing Req'd. The values YOU enter for Framing Size, Plywood Thickness, Plywood Grade, and Nail Size will be used to retrieve an allowable Shear Value from the internal UBC table. The Zone Distance indicates how far from the wall that particular construction and nail spacing must be used.
 - If Zone Distance is Zero, then that particular nail density(diaphragm construction) is NOT NEEDED . The next lower nail spacing/construction type should be used at the wall. When no shears exceed the allowable for 6", 6",12" spacing, all Zone Distances will be 0", and the typical" nail density/construction type can be used.
 - Refine Plywood Values and recalculate as required so that the nail density and shear values can adequately resist the shears.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General	Uniform Loads	Point Loads	Diaphragm Construction
Description			
Using Staples			
Dimensions...			
North-South Length	360.000	ft	
East-West Length	180.000	ft	
North-South Chord	360.000	ft	
East-West Chord	180.000	ft	
Diaphragm Weight	22.00	psf	
Wall : '94 UBC Seismic Factor Z Ip Cp -or- Similar 1997 UBC Factor Divided by 1.4 .	0.183		
Fastener Size	14ga		

North/South Length

This defines the North-South dimension of the diaphragm. This length will be used to:

- Calculate the total lateral load due to the diaphragm's self-weight (multiplied by seismic factor).
- Used to divide the total shear at the east and west walls due to north-south forces, resulting in a shear per foot value which the diaphragm must resist.

East/West Length

Please see the description above, except reverse all the directions.

Distance Between Chords

Normally, the user will enter the same values here as the diaphragm lengths. When the distance between the chords is more or less than the length, enter these new distances here, and they will be used to determine the chord forces. An example where this might be necessary is when a building has a very broken up side and there is no way to run a continuous tension chord member along the wall. In those cases you would use a line of beams with heavy straps tying them together when interrupted at a connection or other break,

Length/Width Ratio

Equals Maximum Dimension/Minimum Dimension(most codes limit to 4:1).

Diaphragm Weight

Defines the actual self-weight of the plywood diaphragm (before any adjustments for seismic factor). This value will be multiplied by the Length, Width and Seismic Factor to determine the total lateral force acting. This weight is in addition to the Applied Boundary Loads as detailed below. SET THIS ENTRY TO 0" FOR WIND LOAD ANALYSIS. Enter the wind loads in the section titled Applied Load in N/S & E/W Direction.

Seismic Factor

Working stress level seismic factor will be applied to the diaphragm self weight and boundary loads to

determine the total lateral force acting on the diaphragm. Remember, enter all lateral loads without any factors applied.

Various codes specify this value in either "Working Stress" or "Factored Loads". For instance the recent UBC and IBC codes use a higher "factored" load factor that needs to be divided by 1.4 before entering it here.

If you are using the program to analyze a diaphragm subjected to WIND loads , enter a 1" in this area so the boundary loads you enter will be applied directly (and unfactored) to the diaphragm. Also, DO NOT ENTER DIAPHRAGM SELF WEIGHT, as it does not apply to wind load conditions.

Fastener Size

Enter 10" to indicate 10d nails, or 14" to indicate 14 gauge staples.

Uniform Loads Tab

General	Uniform Loads	Point Loads	Diaphragm Construction
Note! Seismic factor will be applied to these loads			
Boundary Loads Acting North & South			
# 1	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="180.00"/> ft
# 2	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="30.00"/> to <input type="text" value="180.00"/> ft
# 3	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft
# 4	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft
Boundary Loads Acting East & West			
# 1	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="360.00"/> ft
# 2	<input type="text" value="1,154.00"/> #/ft	from	<input type="text" value="60.00"/> to <input type="text" value="360.00"/> ft
# 3	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft
# 4	<input type="text"/> #/ft	from	<input type="text" value="0.00"/> to <input type="text" value="0.00"/> ft

Boundary Loads Acting North & South

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act North-South and are resisted by shear in the East & West walls, and create tension cord forces in the North & South walls.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the westerly side of the diaphragm and extend eastward (in other works left to right). Entering both locations as "0.0" will apply the loads the full diaphragm dimension.

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor by the program.

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Boundary Loads Acting East & West

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act East-West and are resisted by shear in the North & South walls, and create tension cord forces in the East & West chord locations.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the **Northerly** side of the diaphragm and extend **Southward** (in other works top to bottom). Entering both locations as "0.0" will apply the loads the full diaphragm dimension.

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor) by the program.

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Point Loads Tab

General	Uniform Loads	Point Loads	Diaphragm Construction
Note! Seismic factor will be applied to these loads			
Point Loads Acting NORTH-SOUTH...			
# 1	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 2	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 3	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 4	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
Point Loads Acting EAST-WEST...			
# 1	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 2	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 3	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft
# 4	<input type="text"/>	lbs	at <input type="text" value="0.000"/> ft

Boundary Loads Acting North & South

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act North-South and are resisted by shear in the East & West walls, and create tension cord forces in the North & South walls.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the **Westerly** side of the diaphragm and measured **Eastward**

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor) by the program.

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on

tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Boundary Loads Acting East & West

The user may specify loads applied per foot at the diaphragm boundary, such as lateral weight of attached walls, mansard roofs, equipment, or loads applied due to wind forces on the exposed tributary height areas. These loads act East-West and are resisted by shear in the North & South walls, and create tension chord forces in the East & West chord locations.

These loads can have starting and ending locations. Assuming that North is "Up" in a plan view of the diaphragm, these locations are measured with respect to the **Northerly** side of the diaphragm and measured **Southward**

When performing a seismic analysis, enter these loads as ACTUAL TRIBUTARY WEIGHTS, which will be multiplied by the Short Term (Seismic Factor by the program.

When analyzing a diaphragm subject to wind loads, enter the applied wind loads due to wind force on tributary areas in this location. Also, Diaphragm Weight should be zero, and the Short Term Factor equal to 1".

Diaphragm Construction Tab

This tab has all the entries used to define the construction of the diaphragm. Just as a beam has the shear forces higher the closer you get to a support, so the diaphragm works the same way. This table is designed so that you can specify a diaphragm construction with higher shear capacity the closer you get to the end walls.

There are two areas "North & South Walls & and "East & West Walls". Each of these two sections let you specify the diaphragm construction from one end of the building to the other. Note in the top section it starts with "At North wall", goes downward through some "zones", and then ends with the other wall...."At South Wall".

This table let you specify the changes in diaphragm construction THAT CAN BE USED if the shear at each end reaches a high enough level. TO SEE WHICH CONSTRUCTION NEEDS TO BE USED LOOK AT THE "Diaphragm Design TAB.

Example 1: If you have a diaphragm with very low loading you will probably not need anything more than the least thickness and nailing grade. In this case you will just need what is shown for the "Center" region....it just happens that this "center" zone extends all the way out to the end walls.

Example 2: If you have a very highly loaded diaphragm you will need very tough construction at the walls to take the high shear loads. The highest specification shown below is in the top and bottom entries and shows 3x framing. On the "**Diaphragm Design**" tab you will be given distances and nail spacing that will result in shear capacities that change from the lowly-loaded center region to the highly loaded outer regions. The entire purpose of this concept of "zones" is to develop a nailing pattern that results in the most economical diaphragm construction for the expected shear requirements of the diaphragm.

NOTE! ..The next four items should be verified with ICBO Report #1952. This report is available from the International Conference of Building Officials, Workman Mill Road, Whittier, CA. (818) 699-0541.

General		Uniform Loads		Point Loads		Diaphragm Construction	
Design Data & Nailing Requirements							
North & South Walls....							Spacing in
	Framing Size	Plywood Grade	# Lines of Fasteners	Boundary Spacing	@ Other Edges		
At North Wall	3x	Structural II	2	2		2	
2nd zone	3x	Structural II	2	2.5		3	
Center Zone	3x	Structural II	2	4		4	
2nd Zone	3x	Structural II	2	2.5		3	
At South Wall	3x	Structural II	2	2		2	
East & West Walls....							Spacing in
	Framing Size	Plywood Grade	# Lines of Fasteners	Boundary Spacing	@ Other Edges		
At West Wall	3x	Structural II	2	2		2	
2nd zone	3x	Structural II	2	2.5		3	
Center Zone	3x	Structural II		4		4	
2nd Zone	3x	Structural II	2	2.5		3	
At East Wall	3x	Structural II	2	2		2	

Framing Size

Enter a 2" to indicate 2x nominal framing or 3" for 3x nominal framing. This framing size will be used to determine the allowable shear capacities per UBC Table 23-I-J-1.

Plywood Grade

This defines the plywood grade to be used, and is consistent with the definitions in the UBC Table 25-J (See below). Enter 1" for Structural I, and 2" for CDX.

Lines of Fasteners

You have the option of specifying either 1 or 2 lines of fasteners.

Boundary Spacing

Nails or staples can be spaced at either 2", 2.5" or 4" at the plywood panel boundary and continuous edges.

Spacing at Other Plywood Edges

- Nails or staples can be spaced at either 2", 3" or 4" at all other plywood panel edges.
- No shear values are available for 10d nails using 2" Other spacing, nor for 3" Other spacing combined with 2" Boundary spacing.
- No shear values are available for the following combinations of Boundary/Other spacing: 4"/2", 2.5"/2", 2"/4".

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

This tab displays the overall maximum shear and chord force values at the walls.

Results	Diaphragm Design	Sketch	Printing
Diaphragm Shears...			
	<u>North</u>	<u>South</u>	
Total Shear	194852.9 lbs	205412.0 lbs	
Shear per Foot	1,082.5 #/ft	1,141.2 #/ft	
	<u>West</u>	<u>East</u>	
Total Shear	167927.2 lbs	162647.7 lbs	
Shear per Foot	486.5 #/ft	451.8 #/ft	
Chord Forces...			
	<u>North/South Walls</u>	<u>East/West Walls</u>	
@ 1/4 * Length	15,509.6 lbs	75,422.5 lbs	
@ 1/2 * Length	20,924.9 lbs	102177.8 lbs	
@ 3/4 * Length	15,810.0 lbs	77,304.3 lbs	
Length / Width Ratio	2.00 : 1		

Total Shear

From the loading, seismic factor, and diaphragm dimensions entered, the total and unit end shears are calculated using basic statics.

Unit Shear

This equals a wall's total shear divided by its length.

Chord Forces

From the loading, seismic factor, dimensions and distances between chords entered, the chord forces at 1/4 points of diaphragm span are given.

Diaphragm Design Tab

The primary purpose of the results on this tab is to indicate the distance from each end wall that a AT LEAST a certain fastener spacing is required.

Results Diaphragm Design Sketch Printing		
North & South Walls....		
	Shear Value #/ft	Zone Distance ft
At North Wall	1,200.0	36.00
2nd Zone	900.0	87.84
Center Zone	600.0	
2nd Zone	900.0	84.96
At South Wall	1,200.0	38.88
East & West Walls....		
At West Wall	1,200.0	0.00
2nd Zone	900.0	0.00
Center Zone	600.0	
2nd Zone	900.0	0.00
At East Wall	1,200.0	0.00

Shear Value

For the diaphragm construction specified and nail spacing indicated on the line, the allowable diaphragm shear value is retrieved from the internally stored UBC tables and displayed here. When displayed as zero, this indicates that the program does not contain any data for this configuration.

Zone Distances

This table provides the designer with an easy way to determine the allowable cut-off points for different nailing densities.


The table basically represents the diaphragm from one end to the other. You may specify a particular diaphragm construction to be used for the noted Nail Density by changing the Nail Size, Plywood Grade, and Thickness values for each nailing density line. From your entered data, the program will

calculate where that specific nailing area may be stopped (measured from the wall) and the lower diaphragm capacity used (indicating the transition in actual shear stresses).

- Between the wall and Zone Distance, the diaphragm construction must meet or exceed the shear values listed for that row.
- When the Zone Distance equals zero, this indicates that the particular diaphragm specification for the particular nailing is not required.
- When the Zone Distance is displayed as NA, this indicates that the actual diaphragm shears are higher than the diaphragm specification is capable of taking.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal

that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results | Diaphragm Design | Sketch | Printing

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Boundary Loads	<input checked="" type="checkbox"/>
Point Loads	<input checked="" type="checkbox"/>
North & South Nailing	<input checked="" type="checkbox"/>
East & West Nailing	<input checked="" type="checkbox"/>
Shear & Chord Forces	<input checked="" type="checkbox"/>

Note: When all are selected, the software will still omit unused sections

Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 10:24AM, 26 OCT 03
Description : Collection of example problems
Scope : All programs in the Structural Engineering Library

Description Using Staples

General Information **Calculations are designed to 1997 NDS and 1997 UBC Requirements**

North-South Length	360.00 ft	Diaphragm Weight	22.00 psf
East-West Length	180.00 ft	Seismic Factor	0.1830
North-South Chord	360.00 ft	Fastener Size	14ga
East-West Chord	180.00 ft		

Boundary Loads Acting North & South **Boundary Loads Acting East & West**

#1	1,154.00 #/ft	from	180.000 ft	to	ft	#1	1,154.00 #/ft	from	ft	to	360.000 ft
#2	1,154.00 #/ft	from	30.000 ft	to	180.000 ft	#2	1,154.00 #/ft	from	60.000 ft	to	360.000 ft
#3	#/ft	from	ft	to	ft	#3	#/ft	from	ft	to	ft
#4	#/ft	from	ft	to	ft	#4	#/ft	from	ft	to	ft

North & South Walls **Design Data & Nailing Requirements**

	Framing Size	Plywood Grade	# Lines of Fasteners	Spacing		Shear Value	Zone Distance
				Boundary Spacing	@ Other Edges		
At North Wall	3x	Structural II	2	2 in	2 in	1,200.0 #/ft	36.00 ft
2nd zone	3x	Structural II	2	2.5 in	3 in	900.0 #/ft	87.84 ft
Center Zone	3x	Structural II	2	4 in	4 in	600.0 #/ft	
2nd Zone	3x	Structural II	2	2.5 in	3 in	900.0 #/ft	84.96 ft
At South Wall	3x	Structural II	2	2 in	2 in	1,200.0 #/ft	38.88 ft

East & West Walls **Design Data & Nailing Requirements**

	Framing Size	Plywood Grade	# Lines of Fasteners	Spacing		Shear Value	Zone Distance
				Boundary Spacing	@ Other Edges		
At West Wall	3x	Structural II	2	2 in	2 in	1,200.0 #/ft	0.00 ft
2nd zone	3x	Structural II	2	2.5 in	3 in	900.0 #/ft	0.00 ft
Center Zone	3x	Structural II	2	4 in	4 in	600.0 #/ft	
2nd Zone	3x	Structural II	2	2.5 in	3 in	900.0 #/ft	0.00 ft
At East Wall	3x	Structural II	2	2 in	2 in	1,200.0 #/ft	0.00 ft



ENERCALC Engineering Software
 P.O. Box 188, Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems
 Dsgnr: MDB
 Date: 10/21/01, 20:00, 26 OCT 03
 Job # 97-000001
 Description : Collection of example problems
 Scope : All programs in the Structural Engineering Library

Rev: 580000
 User: KW0600001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

High-Load Plywood Diaphragm Page 2
 c:\ec5\examples.ecw\Timber Calc

Description Using Staples

Sketch & Diagram

3.9 Timber Ledger

This program provides design analysis for wood ledgers carrying vertical and lateral loads. It is intended for buildings where ledgers are bolted to concrete or masonry walls, and transfer all loads to the wall via single shear in the bolts.

Vertical uniform dead and live loads, vertical concentrated dead and live loads, and horizontal shear can be applied to the ledger. Vertical loads are used to calculate maximum moments and shears considering that the ledger is a continuous beam over the bolted supports.

For the concentrated loads, you enter the distance from a bolt, and the load spacing. The program will then calculate the number of loads that are applied to the ledger between

bolts, combine that moment diagram with the uniform loads, and calculate maximum moments and vertical reactions at the bolts.

The vertical and horizontal loads are combined to give a resultant maximum force and application angle. The Hankinson formula is then applied to determine the maximum allowable force at that angle.

You may enter live load and short term load duration factors, ledger width and depth, bolt diameters, and whether the ledger is bolted to concrete or masonry (for use of UBC allowable increases to bolt shear values). Both ledger and bolts are checked for combination of DL+LL, DL+ST (short term), and DL+LL+ST.

ENERCALC c:\ECSS\EXAMPLES.EC\W - Ledger with Vertical & Lateral Loads

Ledger with Vertical & Lateral Loads

Tools & Settings | Help | Print | Cancel | Save

General | Ledger Load | Results | Sketch

Description: With Uniform Load, against concrete

Ledger Width: 3.500 in
 Ledger Depth: 5.500 in
 Bolt Diameter: 1 in
 Bolt Spacing: 24.000 in
 Attached to Concrete?
 Bldg Code Used: 1991 & Earlier UBC 1984 & Later UBC & NDS
 Stress: Douglas Fir - Larch, No.1
 Fb Allow: 1,000.0 psi
 Fv Allow: 95.0 psi
 Load Duration Factors...
 Live Load: 1.250
 Short Term: 1.330
 Lumber Species for Bolt Values Per NDS Table 8A

Wood Stress & Bolts OK

	DL + LL	DL + ST	DL + LL + ST
Bending Stress Ratio	0.104	0.077	0.098
Shear Stress Ratio	0.363	0.267	0.341
Diag Stress Ratio	0.607 :1	0.452 :1	0.575 :1

Bolt Forces

	Maximum Force	Allowable Force	Maximum Ratio
	1,150.00	1,893.75 lbs	0.807

Maximum Moment...

	DL + LL	DL + ST	DL + LL + ST
Maximum Moment...	2,300.00	1,800.00	2,300.00 in-#
Bending Stress	130.34	102.01	130.34 psi
Stress Ratio	0.104	0.077	0.098

Maximum Shear...

	DL + LL	DL + ST	DL + LL + ST
Maximum Shear...	829.56	649.22	829.56 lbs
Shear Stress	43.08	33.73	43.08 psi
Stress Ratio	0.363	0.267	0.341

Stress Summary

	DL + LL	DL + ST	DL + LL + ST
Max. Vertical Load	1,150.00	900.00	1,150.00 lbs
Allow Vertical Load	1,893.75	2,014.95	2,014.95 lbs
Max. Horizontal Load	0.00	312.00	312.00 lbs
Allow Horizontal Load	3,175.00	3,378.20	3,378.20 lbs
Angle of Resultant	90.0 deg	70.9 deg	74.8 deg
Diagonal Component	1,150.00	952.56	1,191.57 lbs
Allow Diagonal Force	1,893.75	2,106.13	2,072.28 lbs

Note: Using '94 UBC Table 23+F for allowable bolt values

Basic Usage

- Determine Dead and Live Loads. Since the program assumes repeating concentrated loads, you can enter the vertical loads as either uniform or a single concentrated load at a specified spacing.
- Horizontal Shear is entered as lbs/foot and is multiplied by the bolt spacing to get the tributary load per bolt. When you have combined drag strut and unit shears acting on the ledger, be sure to resolve them to a lbs/foot value.
- Enter Ledger Depth, Width, and Allowable Stresses. You must enter the exact member size (not nominal). You can use the timber database to get these values.


- The Against Concrete entry is used to determine whether the UBC modification to allowable bolt values should be used for single shear against concrete.
- Enter Bolt Size and Spacing. The program supports $\frac{1}{2}$ " -> 1" bolts, and will adjust the allowable values for the nearest size category.

Assumptions & Limitations

When calculating moments due to point loads, the program does not check an infinite number of location combinations when the point load spacing is an uneven multiple of the bolt spacing. It will, however, check if the Offset distance is greater than the Bolt Spacing, and move the load over to a new offset equal to Bolt Spacing - Offset

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General		Ledger Load	
Description		With Uniform Load, against concrete	
Ledger Width	<input type="text" value="3.500"/>	in	
Ledger Depth	<input type="text" value="5.500"/>	in	
Bolt Diameter	<input type="text" value="1"/>	in	
Bolt Spacing	<input type="text" value="24.000"/>	in	
Attached to Concrete ?	<input checked="" type="checkbox"/>		
Bldg Code Used	<input type="radio"/> 1991 & Earlier UBC <input checked="" type="radio"/> 1994 & Later UBC & NDS		
Stress		Douglas Fir - Larch, Utility	
Fb Allow	<input type="text" value="275.0"/>	psi	
Fv Allow	<input type="text" value="95.0"/>	psi	
Load Duration Factors...			
Live Load	<input type="text" value="1.250"/>		
Short Term	<input type="text" value="1.330"/>		
Lumber Species for Bolt Values Per NDS Table 8A			
<input type="text"/>			

Ledger Width & Depth

Exact sizes of ledger.

Bolt Diameter & Spacing

Enter the bolt diameter and spacing you wish to use. You can quickly change these values and recalculate to arrive at a satisfactory design.

Attached to Concrete ?

Enable this checkbox when the ledger is bolted to a concrete or masonry wall. This changes the way bolt values are pulled from UBC table 25-F. When the ledger is against concrete, the double shear values for a member $\frac{1}{2}$ the width are used.

Building Code Used

Select the building code you are using. This controls the allowable bolt values to be used. If "**1991 & earlier UBC**" is chosen then 1994 UBC Table 23-I-F allowable bolt values are used. If "**1994 & Later UBC and NDS**" is chosen then the bolt design value are from NDS 8.2 / UBC 2336.2.

[Stress] button & entry

This allows you to use the built-in NDS & Manufactured lumber allowable stress database to retrieve allowable stresses. When you press the button you will see this selection window. Please see the section earlier in this User's Manual that give information and usage for the databases.

Wood Stress Database

Species... **Douglas Fir - Larch**

Using 1997 UBC/NDS Stress Values

Size Classes to Show

2"->4" Thick, 2" & Wider 5" x 5" & Larger Glued-Laminated

Beams & Stringers Posts & Timbers Manufactured

All stresses in PSI

<- Sort Order + -

Species	Grade	Class	Fb	Ft	Fv	Fc - Perp	Fc - Prrl	Elastic Modulus	Grading Agency
			Bending	Tension	Shear	Comp.	Comp.		
Douglas Fir - Larch	Select structural	2-4	1,450	1,000	95	625	1,700	1,900,000	WCLIB WWPA
Douglas Fir - Larch	Dense Select Str	BS	1,900	1,100	85	730	1,300	1,700,000	WCLIB
Douglas Fir - Larch	No.1 & Better	2-4	1,150	775	95	625	1,550	1,800,000	WCLIB WWPA
Douglas Fir - Larch	Select structural	BS	1,600	950	85	625	1,100	1,600,000	WCLIB
Douglas Fir - Larch	Dense No.1	BS	1,550	775	85	730	1,100	1,700,000	WCLIB
Douglas Fir - Larch	No.1	2-4	1,000	675	95	625	1,500	1,700,000	WCLIB WWPA
Douglas Fir - Larch	No.2	2-4	875	575	95	625	1,350	1,600,000	WCLIB WWPA
Douglas Fir - Larch	No.1	BS	1,350	675	85	625	925	1,600,000	WCLIB
Douglas Fir - Larch	No.2	BS	875	425	85	625	600	1,300,000	WCLIB
Douglas Fir - Larch	No.3	2-4	500	325	95	625	775	1,400,000	WCLIB WWPA
Douglas Fir - Larch	Stud	2-4	675	450	95	625	850	1,400,000	WCLIB WWPA
Douglas Fir - Larch	Construction	2-4	1,000	650	95	625	1,650	1,500,000	WCLIB WWPA
Douglas Fir - Larch	Standard	2-4	550	375	95	625	1,400	1,400,000	WCLIB WWPA
Douglas Fir - Larch	Utility	2-4	275	175	95	625	900	1,300,000	WCLIB WWPA
Douglas Fir - Larch	Dense select Str	BS	1,850	1,110	85	730	1,300	1,700,000	WWPA
Douglas Fir - Larch	Select structural	BS	1,600	950	85	625	1,100	1,600,000	WWPA
Douglas Fir - Larch	Dense No.1	BS	1,550	775	85	730	1,100	1,700,000	WWPA
Douglas Fir - Larch	No.1	BS	1,350	675	85	625	925	1,600,000	WWPA
Douglas Fir - Larch	Dense No.2	BS	1,000	500	85	730	700	1,400,000	WWPA
Douglas Fir - Larch	No.2	BS	875	425	85	625	600	1,300,000	WWPA

Select + Change - Delete Cancel

Fb & Fv Allowable

Basic allowable bending & shear stresses. These values will be increased by the Live Load and Short Term Load Duration factors when calculating allowable stresses for the three load combinations.

Live Load Stress Increase

This is a factor that will be applied to the allowable bending and shear stresses for calculation of final allowable values when live load is used within the three different load combinations.

Short Term Stress Increase

This is a factor that will be applied to the allowable bending and shear stresses for calculation of final allowable values when the horizontal shear load is used within the second two load combinations.

Ledger Load Tab

NOTE! This program assumes the segment of ledger that you are designing behaves as a continuous beam, with negative moments over the bolts transferring to adjacent ledger sections. The point loads you enter will be used as is, so if your point load spacing is different from the ledger bolt spacing, enter the bolt offset such that the greatest moment will be generated using the continuous span assumption.

General		Ledger Load	
Uniform Load...			
Dead Load	<input type="text" value="520.00"/>	<input type="button" value="▲"/> <input type="button" value="▼"/>	#/ft
Live Load	<input type="text" value="223.00"/>	<input type="button" value="▲"/> <input type="button" value="▼"/>	#/ft
Point Load...			
Dead Load	<input type="text"/>	<input type="button" value="▲"/> <input type="button" value="▼"/>	lbs
Live Load	<input type="text"/>	<input type="button" value="▲"/> <input type="button" value="▼"/>	lbs
Spacing	<input type="text" value="0.000"/>	<input type="button" value="▲"/> <input type="button" value="▼"/>	ft
Offset	<input type="text" value="0.000"/>	<input type="button" value="▲"/> <input type="button" value="▼"/>	in
Horizontal Shear			
	<input type="text" value="156.00"/>	<input type="button" value="▲"/> <input type="button" value="▼"/>	#/ft

Uniform Load

Enter the uniform dead and live load applied to the ledger.

Point Load & Spacing

Enter the concentrated dead and live load that will be applied to the ledger at a typical spacing. This entry is intended for you to enter repeating loads from framing members.

Point Load Offset

This is the distance of the first point load from a ledger anchor bolt. The point loads will be automatically repeated in calculations from this point onward using the Point Load Spacing value.

Horizontal Shear

This is the shear applied to the ledger along its longitudinal axis. Be sure to adjust combined drag load and unit shears to a proper value.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Results		Sketch	
Diagonal Stress Ratio > 1.0 !			
	<u>DL + LL</u>	<u>DL + ST</u>	<u>DL + LL + ST</u>
Bending Stress Ratio	0.490	0.322	0.460
Shear Stress Ratio	0.469	0.308	0.441
Diag Stress Ratio	1.429 :1	0.960 :1	1.381 :1
	<u>Maximum Force</u>	<u>Allowable Force</u>	<u>Maximum Ratio</u>
Bolt Forces	1,486.00	1,039.73 lbs	1.429
	<u>DL + LL</u>	<u>DL + ST</u>	<u>DL + LL + ST</u>
Maximum Moment...	2,972.00	2,080.00	2,972.00 in-#
Bending Stress	168.42	117.87	168.42 psi
Stress Ratio	0.490	0.322	0.460
Maximum Shear...	1,071.93	750.21	1,071.93 lbs
Shear Stress	55.68	38.97	55.68 psi
Stress Ratio	0.469	0.308	0.441
Stress Summary			
Max. Vertical Load	1,486.00	1,040.00	1,486.00 lbs
Allow Vertical Load	1,937.50	2,061.50	2,061.50 lbs
Max. Horizontal Load	0.00	312.00	312.00 lbs
Allow Horizontal Load	5,437.50	5,785.50	5,785.50 lbs
Angle of Resultant	90.0 deg	73.3 deg	78.1 deg
Diagonal Component	1,486.00	1,085.79	1,518.40 lbs
Allow Diagonal Force	1,039.73	1,131.43	1,099.84 lbs
Note: Bolt Design Value from NDS 8.2 / UBC 2336.2			

Load Combination Columns

Each of the three columns represents different combinations of the dead, live, and lateral loads.

Maximum Moment

This is the maximum moment in the ledger, analyzed as a continuous beam, considering uniform and point loads.

Maximum Moment & Stress Ratio

Actual bending stress for the ledger using the Maximum Moment. Actual bending stress divided by allowable stress (after it is modified by the appropriate load duration factor).

Maximum Shear & Stress Ratio

Maximum shear stresses at the bolts considering vertical loads and a continuous span beam.

Stress Summary

Maximum Vertical Load

Using the applied uniform dead and live loads and point loads, the maximum vertical bolt reaction is

calculated.

Allowable Vertical Load

Allowable bolt shear value perpendicular to grain in wood members, adjusted by the load duration factors.

Maximum Horizontal Load

This is simply the applied horizontal shear * bolt spacing.

Allowable Horizontal Load

Load Allowable bolt shear value perpendicular to grain in wood members, adjusted by the load duration factors.

Diagonal Component

Using a square root sum of the squares combination of the maximum vertical and horizontal loads to the bolts, the resultant force is calculated.

Angle of Resultant


Angle of application of the Diagonal Component.

Hankinson Allowable

Using the Resultant Angle and allowable parallel and perpendicular to grain stress values, the final allowable force is calculated, to be compared with the Diagonal

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 11:29AM, 26 OCT 03
Description: Collection of example problems
Scope: All programs in the Structural Engineering Library

Rev: 680000 User: KW-0000001, Ver: 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software **Timber Ledger Design** Page 1
 c:\e06\examples.eaw\Timber Calc

Description With Uniform Load, against concrete

General Information Code Ref: 1997 NDS, 2003 IBC, 2003 NFPA 5000. Base allowables are user defined.

Ledger Width	3.500 in	Uniform Load...		Point Load...	
Ledger Depth	5.500 in	Dead Load	520.00 #/ft	Dead Load	0.00 lbs
Ledger is Bolted to Concrete		Live Load	223.00 #/ft	Live Load	0.00 lbs
Bolt Diameter	1"			Spacing	0.00 ft
Bolt Spacing	24.000 in	Horizontal Shear	156.00 #/ft	Offset	0.00 in
Load Duration Factors...		Douglas Fir - Larch, Utility			
Live Load	1.250	Fb Allowable	275.0 psi		
Short Term	1.330	Fv Allowable	95.0 psi		

Ledger Stresses

Load Combination :	DL + LL	DL + ST	DL + LL + ST
Maximum Moment	2,972.00 in-#	2,080.00 in-#	2,972.00 in-#
Bending Stress	168.42 psi	117.87 psi	168.42 psi
Stress Ratio	0.490	0.322	0.460
Maximum Shear	1,071.93 lbs	750.21 lbs	1,071.93 lbs
Shear Stress	55.68 psi	38.97 psi	55.68 psi
Stress Ratio	0.469	0.308	0.441

Bolt Loading Note: Bolt Design Value from NDS 8.2 / UBC 23 Using :

Stress Summary	DL + LL	DL + ST	DL+LL+ST
Max. Vertical Load	1,486.00 lbs	1,040.00 lbs	1,486.00 lbs
Allow Vertical Load	1,937.50 lbs	2,061.50 lbs	2,061.50 lbs
Max. Horizontal Load	0.00 lbs	312.00 lbs	312.00 lbs
Allow Horizontal Load	5,437.50 lbs	5,785.50 lbs	5,785.50 lbs
Angle of Resultant	90.0 degrees	73.3 degrees	78.1 degrees
Diagonal Component	1,486.00 lbs	1,085.79 lbs	1,518.40 lbs
Allow Diagonal Force	1,039.73 lbs	1,131.43 lbs	1,099.84 lbs
Final Stress Ratio	1.429 : 1.00	0.960 : 1.00	1.381 : 1.00

Summary **Diagonal Stress Ratio > 1.0 !**

Stress Summary	DL + LL	DL + ST	DL+LL+ST
Wood Bending Stress Ratio	0.490 : 1.00	0.322 : 1.00	0.460 : 1.00
Wood Shear Stress Ratio	0.469 : 1.00	0.308 : 1.00	0.441 : 1.00
Bolt Stress Ratio	1.429 : 1.00	0.960 : 1.00	1.381 : 1.00

3.10 Bolt Group in Timber Member

This program analyzes bolts in wood members subjected to forces either parallel or perpendicular to the center of gravity of the bolt group. It considers single or double shear, wood or metal side plates, load duration and side plate stress increase factors, and the reduction effect on bolt groups when forces are parallel to a rows of bolts.

The program performs two functions. When the number of bolts is unknown for a given load and member size, the program can determine the number of bolts required in each

row considering the bolts-in-a-row capacity reduction effects.

When the bolt group configuration is known, an analysis of the bolt group combines all input and determines the allowable bolt group load.

Special features allow the user to use either wood or steel side plates on one or both sides, and have all the associated effects considered. The program also provides a listing of the minimum required edge distances, end distances, bolt spacing, and row spacing which are applicable to your input. You can then cross check your values to ensure everything is within limits.

The screenshot shows the ENERCALC software interface for 'Bolt Groups in Timber Members'. The window title is 'ENERCALC c:\ECSS\EXAMPLES.ECWX - Bolt Groups in Timber Members'. The interface is divided into two main sections: 'General' and 'Results/Sketch'.

General Tab:

- Description:** Using metal plates @ both sides
- Applied Load:** 12,000.00 lbs
- Load Direction:** Parallel To Rows, Perpendicular To Rows
- Bolt Diameter:** 3/4"
- # Rows of Bolts:** 2
- # Bolts per Row:** 4
- Are Rows Staggered?:**
- Spacing Btwn Rows:** 4.00 in
- Spacing Btwn Bolts:** 4.00 in
- Shear Type:** Single Shear, Double Shear
- Member Width:** 5.125 in
- Member Depth:** 24.000 in
- Side Plate Data...:**
 - Side Plate Depth: 0.250 in
 - Side Plate Thickness: 0.000 in
- Load Duration Factor:** 1.000
- Side Plate Factor:** 1.250

Results/Sketch Tab:

Bolt Group OK

Applied Load	12,000.00 lbs
Capacity	27,742.00 lbs
Code Allowable Bolt Capacity	2,860.0 lbs
Check Adequacy for Applied Load...	
A _{member}	123.000 in ²
A _{plate}	4.000 in ²
A _{member} / A _{plate}	30.750
Basic Allow per Bolt	3,575.00 lbs
Bolt Cap Reduction Factor	0.9700
Allowable Load per Bolt	3,467.75 lbs
Bolt Group Capacity	27,742.00 lbs
Two Parallel Rows being used as one row ?	No
Required Clearances...	
Min. center-center spacing of bolts in a row	3.000 in
Min. spacing between adjacent rows of bolts	1.875 in
End distance with force ACTING toward END	5.250 in
End distance with force NOT ACTING toward END	3.000 in
Edge Distance with force ACTING toward END	1.125 in
Edge Distance with force NOT ACTING toward END	3.000 in
Maximum Row Spacing	5.000 in

Basic Usage

To Determine # Of Bolts Required: Enter all data except the number of bolts per row. You can estimate almost all of the sizes, because the program's first bolt quantity can be used as a starting point for refinement of nearly all other values. You can refine all the input data except the number of bolts, then enter the number of bolts per row and refine the other data items. When you enter a number in the Number of Bolts In A Row cell, the bolt analysis section will show the results of the complete analysis of the bolt group.


To Analyze A Bolt Group: Enter all the design values and calculate. The bolt group capacity will be shown for your use.

Assumptions & Limitations

- All loads must be applied along one axis and act through the center of stiffness of the bolt group. No provisions are made in the program for eccentric loadings.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General	
Description	Using metal plates @ both sides
Applied Load	12,000.00 lbs
Load Direction	<input checked="" type="radio"/> Parallel To Rows <input type="radio"/> Perpendicular To Rows
Bolt Diameter	3/4"
# Rows of Bolts	3
# Bolts per Row	4
Are Rows Staggered ?	<input type="checkbox"/>
Spacing Btwn Rows	2.50 in
Spacing Btwn Bolts	4.00 in
Shear Type	<input type="radio"/> Single Shear <input checked="" type="radio"/> Double Shear
Member Width	5.125 in
Member Depth	7.250 in
Side Plate Data...	
Side Plate Depth	0.250 in
Side Plate Thickness	8.000 in
Load Duration Factor	1.000
Side Plate Factor	1.250

Applied Load

Enter the applied load here

Load Direction

Enter the direction of the applied loading with respect to the grain of the members. This item is used to determine the allowable basic capacity of the bolts specified.

Bolt Diameter

Enter the bolt diameter to be used in the design or analysis. The diameter should be entered in decimal form, and should coincide with a bolt listed in UBC.

Of Rows Of Bolts

Indicates the number of rows of bolts to be used. This item should always be entered, whether or not you are performing a design or analysis.

Of Bolts In A Row

An entry here may or may not be made. If no entry is made, the program will use all other values, along with Applied Load Parallel To Rows to determine a minimum number of bolts per row which will

be needed. If an entry is made here, it will be used in the Bolt Group Analysis to determine the capacity of the bolt group.

Staggered?

If the bolt group is staggered, enter 1 to indicate this.

Spacing Between Rows

When two or more rows of bolts are used, this is the spacing between those rows.

Spacing Between

Bolts this is the spacing between each bolt in a row, and will effect the calculations when bolts are staggered and spaced very close.

Shear Type : Single or Double

Specify whether the bolts are in single or double shear. Single shear will typically mean that two members are being attached, while Double would mean that three are used, such as a wood member being bolted between two steel plates.

Member Width & Depth

Enter the width and depth of the main wood member for which the bolt capacities should be retrieved.

Load Duration Factor

If the load applied to the bolt group is of short term nature, enter the desired factor which will increase the bolt capacity. Typically a value of 1.33 is used.

Side Plate Factor

If metal side plates are used, the user may desire to enter a load factor which will increase the bolt capacity. Typically a value of 1.25 is used.

Side Plate Data

Width is measured parallel to the depth of the member, and thickness is measured parallel to the width of the member. The program will automatically double the side plate area when Double Shear has been specified.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Bolt Group OK	
Applied Load	12,000.00 lbs
Capacity	37,323.00 lbs
Code Allowable Bolt Capacity	2,860.0 lbs
Check Adequacy for Applied Load...	
A_{member}	37.156 in ²
A_{plate}	4.000 in ²
$A_{\text{member}} / A_{\text{plate}}$	9.289
Basic Allow per Bolt	3,575.00 lbs
Bolt Cap Reduction Factor	0.8700
Allowable Load per Bolt	3,110.25 lbs
Bolt Group Capacity	37,323.00 lbs
Two Parallel Rows being used as one row ?	No
Required Clearances...	
Min. center-center spacing of bolts in a row	3.000 in
Min. spacing between adjacent rows of bolts	1.875 in
End distance with force ACTING toward END	5.250 in
End distance with force NOT ACTING toward END	3.000 in
Edge Distance with force ACTING toward END	3.000 in
Edge Distance with force NOT ACTING toward END	1.125 in
Maximum Row Spacing	5.000 in

Applied Load & Capacity

These are the results of the analysis giving applied and allowable values.

Code Allowable Bolt Capacity

This indicates the basic allowable load per bolt, considering direction of load to grain, diameter, and width of main member. If there is no available bolt value from the table, 0" will be displayed.

A_{member}, A_{plate}, Ratio

These values are used to calculate a reduction factor based on the ratio of member area to the side plate area.

Basic Allowable Per Bolt

This value is the result of multiplying the basic bolt capacity by the Load Duration Factor and Side Plate Factor.

Bolt Capacity Reduction Factor

The reduction factor also considers the number of bolts in a row. This factor is applied to the Basic Allowable Per Bolt (see next) to determine the actual allowable bolt value considering the group's

effect. The factors can be found in the Design Handbook published by the American Institute of Timber Construction.

Allowable Load per Bolt

This is the Basic Allowable per bolt times the "**Bolt Capacity Reduction Factor**".

Two Parallel Rows being used as one row ?


This Yes/No item reports whether the program is considering two adjacent rows as one row because of limitations on bolt row spacing and spacing between bolts.

Req'd Bolt Clearances

Based on code requirements, the minimum spacings and edge & end distances are given here.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Sample Printout

ENERCALC Engineering Software
P.O. Box 188
Corona del Mar, CA 92660
Voice: 949-645-0151
www.enercalc.com

Title : ENERCALC Example Problems **Job #** 97-000001
Dsgnr: MDB **Date:** 11:58AM, 26 OCT 03
Description : Collection of example problems

Scope : All programs in the Structural Engineering Library

Rev: 590000
 User: KW-0600001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

Bolt Group in Timber Member

Page 1

c:\ec5\examples.ecw\Timber Calcs

Description Using metal plates @ both sides

General Information

Code Ref: 1997 UBC

Applied Load	12,000.00 lbs	# Rows of Bolts	2	Load Duration Factor	1.000
Bolt Diameter	3/4"	# Bolts per Row	4	Side Plate Factor	1.250
Member Width	5.125 in	Spacing Btwn Rows	4.000 in	Rows Are NOT Staggered	
Member Depth	24.000 in	Spacing Btwn Bolts	4.000 in	Force is Parallel To Rows	
Side Plate Data...				Bolts are in Double Shear	
Side Plate Depth	0.250 in				
Side Plate Thickness	8.000 in				

Check Adequacy for Applied Load...

Amember	123.000 in ²	Basic Allow per Bolt	3,575.00 lbs
Aplate	4.000 in ²	Bolt Cap Reduction Factor	0.9700
Amember/Aplate	30.750	Allowable Load per Bolt	3,467.75 lbs

Summary

Bolt Group OK

Using 2 rows with 4 - 3/4" bolts per row, Row Spacing = 4.00in, Bolt Spacing = 4.00in

27,742.00 lbs >= Applied Load = 12,000.00 lbs

Req'd Clearances

Min. center-center spacing of bolts in a row	3.000 in
Min. spacing between adjacent rows of bolts	1.875 in
End distance with force ACTING toward END	5.250 in
End distance with force NOT ACTING toward END	3.000 in
Edge Distance with force ACTING toward END	1.125 in
Edge Distance with force NOT ACTING toward END	3.000 in
Maximum Row Spacing	5.000 in

Part



4 Steel Design Modules

The programs in this section provide analysis and design for structural elements made of steel.

Code References

Program modules for STEEL design are designed to be in conformance with the **AISC 9th Edition Allowable Stress Design** and **AISC Third Edition LRFD Design**.

Limited load combinations supported are:

Allowable Stress Design: ASCE 7 Section 2.4.1, IBC 2003 Section 1605.3.1, 2003 NFPA 5000 Section 35.15.1 (which ties back to ASCE 2.4.1) and 1997 UBC Section 1612.3.2.

Load & Resistance Factor Design : ASCE 7 Section 2.3.2, IBC 2003 Section 1605.2.1, 2003 NFPA 5000 Section 35.15.1 (which ties back to ASCE 2.3.2) and 1997 UBC Section 1612.2.1.

Multi Span Steel Beam

Multi Span Steel Beam allows design of up to eight spans on one calculation sheet. All spans can be simply supported with optional cantilevers or can be continuous over supports with optional cantilevers and end fixities. Dead and live point, moment, and uniform/trapezoidal loads can be applied. Alternate span live loading is easily defined. Code stress checks are performed for W, S, H, M, C, MC, T, P, L, LL, WT, ST, and MT sections, including provisions for thin compression elements and details of Appendix C. Reactions, shears, moments, deflections, and stresses are given.

Steel Beam Analysis & Design

Steel Beam Analysis & Design supplies more extensive design ability than the multi-span program. Up to 26 point, moment, and uniform/trapezoidal loads may be applied, minor axis bending, secondary members, duration of load factors, and optimal section selection is available.

Torsional Analysis of Steel Beams

Torsional Analysis of Steel Beams can fully analyze and section beams subjected to distributed and point eccentric loads, bending moments, and twisting moments. The beam can have pin/pin or fix/fix torsional and bending fixity conditions, and all results use new procedures for rotation and stress calculations. Of course, full AISC allowable stresses are calculated based on slenderness, bracing, and moment variations.

Steel Biaxial Column Design

Steel Biaxial Column Design includes all the beam analysis capabilities of our Steel Beam

program, simultaneously about both axes, and combined with eccentric axial loads. Support fixity, unbraced lengths, side sway, effective length factors, and live/short term load combinations are all included in the evaluation of AISC combined stress equations H1-1, H1-2, and H1-3.

Composite Steel Beam

Composite Steel Beam provides detailed analysis of steel sections anchored to a concrete slab. Among the many items considered are solid slabs, slab over formed metal deck, partial composite action, and center/edge slab location. Concrete density, stud capacity, bottom flange cover plate, and effective slab width can also be specified. Loads may be point, uniform, or trapezoidal, and are divided into dead, construction, and live types. In addition to full stress evaluation, shear connector spacings, reactions, and load case deflections are given.

Steel Base Plate Design

Steel Base Plate Design allows you to design or analyze a square steel column base plate subjected to axial loads and bending moments. This program allows up to five designs per sheet and access to our extensive steel section databases. Number of bolts, area, capacity, location, support pier dimensions, concrete strength, and duration of load factors are all considered in generating the interaction equations determining stresses within the plates.

Bolt Group Analysis

Bolt Group Analysis distributes direct and torsional in-plane loads on a bolt group with up to 16 bolts to find the maximum load on each bolt.

4.1 Multi-Span Steel Beam

This program provides design and analysis of simple span or continuous steel beams. It allows you to design steel beams in production line form, letting you rapidly complete many designs simultaneously, and can handle up to eight spans at once.


The end fixities of each can easily be modified to model many types of beams, including (but not limited to):

- Simple span beams with cantilevers at one or both ends.
- Single span beams with fixed and/or free ends.
- Continuous beams with up to nine supports.
- Continuous beams with one or both ends fixed or cantilevered.

This flexibility is provided by allowing you to:

- Set a flag telling the program to consider all beams that have pinned ends to be either continuous over the support (attached to the adjacent beam) or consider each span is simply supported.
- For each beam, you can specify fixed, pinned, or free support conditions for each end. This allows you to model any type of span support condition you will encounter (limited to eight spans/nine supports).

Each span can be loaded with a uniform dead and live load, a partial length uniform dead and live load, a partial length trapezoidal dead and live load, up to four point dead and live loads, and one concentrated dead and live moment. To further aid your designing ability, you can easily omit the inclusion of live load on any span to perform alternate span load analysis. For each span, the program determines maximum center and support moments, shears, reactions, and deflections.



Basic Usage

- Review Scope of Design/Analysis Task. It is essential that you fully understand the use of this program, since its flexibility is the key to your rapid design of dozens of steel members. Remember that each worksheet column represents a single span between two supports, regardless of the end support conditions. When cantilevers are used, they are considered a span, even though one end is free.
- Spans, Supports, and Allowable Stresses. After you have reviewed the beams you wish to design (and how they will be entered using the programs All Spans Continuous feature and end fixity flags), enter this information in the top section of the worksheet. Remember, when you recalculate the worksheet later to get the results, you can always revise the support fixity data to change any mistakes you might have made.
- LL Flag, Unbraced Lengths, and Load Duration Factor. Use the Live Load Flag to

signal whether the live loads you will enter should be applied to the span. You can make changes to these flags to model different live load conditions. Unbraced length specifies the distance between lateral supports of the compression edge. Load duration factor will allow allowable stress increases.


- **Distributed Loads.** You can apply up to three distributed loads to each span, although the input for each is somewhat different. The first item applies the dead and live load entered to the full span. The second item applies a uniform magnitude dead and live load over all or a portion of the span. The third item allows you to specify a full trapezoidal load to any portion of the span.
- **Point Loads & Moments.** Point and moment dead and live loads can be applied anywhere on each span. Loads with negative X-distances, or distances that are longer than the span are ignored.
- **Modify beam sizes.** To refine your design, either type in a new section name and recall the data from the database (see next) and review the stresses and deflections.

Unique Features

- This program has the unique ability to easily analyze and design beams with a variety of span and support conditions.
- Full AISC code checks are made considering length effects on allowable bending stresses.
- A simple flag can be set on any span to ignore all live loads on that span, making alternate span loading analysis easy.
- Very flexible loadings may be applied to each span, including three uniform/partial/trapezoidal loads.
- The program can perform automatic member selection using stress and deflection criteria. All that is required of you is to specify the allowable stresses and desired beam widths.


Steel Section Database

Built into the software is a complete database of common rolled sections available from various mills in the United States. On each tab labeled #1, #2, etc. there will be a button that looks like this:



Steel Section

This button displays the steel section database as shown below.



On this window there are various controls and options.....

Steel Database : Allows you to select between several common shapes databases.

Section Type to Display: Allows you to select which steel section designation to display in the list. These shapes conform to the American Institute of Steel Construction shape designations. To make your selection simply move the mouse over the letter(s) and when the highlight activates left-click once with your left mouse button.

Depth Range: This item allows you to specify depth limits to be used for selecting which sections to display in the list. When the checkbox to the left is not checked the selection wording and entries will not appear and all sections will be displayed. These dimensions are compared to the "Depth" dimension of the sections.

Class Range : This item allows you to specify the limits in "Depth Class" to be displayed in the table. The "Depth Class" of a section is the first numeric number in the sections name. For instance a wide flange W14x22 is in depth class "14". a channel C9x15 is in depth class "9", and a L 5x3x1/4 is in depth class "5".

Equal & Unequal Legs : These two buttons appear when you have selected section type "L" which are single angles. The limit the display of the list to angle with equal dimension or unequally dimensioned sides.

Equal Legs, Long Leg Vertical, Short Leg Vertical: These three buttons appear when you have chosen to display section type "LL". These control the display of sections between pairs of angles with both sides of equal length, of unequal side length angles paired with the LONG side together, and unequal side length angles paired with the SHORTside together.

Square & Rectangular Tubes: These two buttons appear when you have chosen section types TS or HSS-T. These are square tubular sections. You can choose to display only square tubes or alternately tubes with unequal sides.

Sort Tabs for Database Table : Immediate above the database list of sections you will see tabs looking like this....

When selected each tab will sort the list in the order described by the text on that tab.

Sort order : These two buttons allow you to chose the list order of the sections. The sorting order will be according to the sort tab selected and shall be in ascending or descending order.

Database Table Itself : The main area on the window will be where the steel sections are displayed as a result of all of your choices as described above.

[Select] : This button is displayed when you have clicked on the **[Section]** button when you press [Select] the section in the list that is currently highlighted will be selected and the name and data brought into your calculation.

[Insert]: Use this button to add a steel section to the database. When pressed you will see the following window:

New Steel Section Data Entry

Section Name: MyVeryOwn 4x12 Tube

Type: TS

Depth Class: 36

AISC Handbook Edition: AISC 9th

Area: 0 in² I x-x: 0 in⁴

Depth: 0 in I y-y: 0 in⁴

Flange Width: 0 in

Flange Thickness: 0 in Xcg: 0 in

Web Thickness: 0 in Ycg: 0 in

Buttons: Cancel, OK

The only really important item to enter is the "Type" item. This specifies what standard rolled section type your section is. This item is used internally by the program to decide which stress analysis method to use for determining the sections allowable stress, how to consider unstiffened elements, and many other code checking items.

[Change]: Will display the same window as above but allow you to change section properties.

[Delete] : Will enable you to delete sections. Note: No sections in the supplied database can be deleted. Only Sections that you add can be later deleted.

[Cancel]: Exit the steel database window.

ASD & LRFD Design Modes

Allowable Stress Design and **Load & Resistance Factor Design** as specified by the American Institute of Steel Construction is provided by this program. Only screen captures and descriptions for ASD are presented in this book. More detailed LRFD documentation will be added and will be available in the electronically delivered versions of this book. Check these locations for electronic media:

- Latest Adobe Acrobat PDF documentation file here:
<ftp://208.36.30.226/sel5.pdf>.
- Latest Windows Help system file here : <ftp://208.36.30.226/enercalc.hlp>.
- Internet HTML help documentation presented as web pages at
www.enercalc.com/sel_help.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General # 1 # 2 # 3 # 4 # 5 # 6 # 7 # 8

Description 3 Span System, 2 Load Patterns

Operating Mode

All Spans Considered as Individual Beams

Spans Considered Continuous Over Supports

Fy - Yield Stress 36.00 ksi

Operating Mode

This item plays a critical role in governing the calculation procedure for the entire program.

- **Spans Considered Continuous Over Support** : When two beams share the same support , and the support fixity for both beams at that support is Pinned, then the two beams are tied together to form one continuous beam over that support.
- **All Spans Considered as Individual Beams** : When two beams share the same support , they are always considered as two separate beams and the stresses and rotations in one never affect the other.

Within each beam span information tab there is a setting for end fixity. Here is how those end fixities are described according to the selection for this item:

When "**All Spans Considered as Individual Beams**" is chosen:

- Free will indicate that the end is completely free of the support and adjacent beam.
- Pinned will affect the beam according to the end fixity of the adjacent beam. If the adjacent beam end is Fixed or Free, then the beam will be pinned and not affected by the adjacent beam. If the adjacent beam is pinned, the two beams are locked together, forming one beam continuous over the support.
- Fixed will attach the beam end to a rigid boundary element, allowing no rotation or vertical movement, and not linked to the adjacent beam.

When "**Spans Considered Continuous Over Support**" is chosen :

- Free will indicate that the end is completely free of the support, allowing translation and rotation.
- Pinned will allow the beam end to rotate but not translate.
- Fixed will attach the beam end to a rigid boundary element, allowing no rotation or vertical movement.

Fy

Steel yield stress used to determine allowable F'b and Fv.

Typical Span Tab : #1 to #8

Each tab that shows #1 through #8 specifies information for one of the beams of the multi-span beam. Tab #1 is the left-most beam and you work to the right to define additional adjacent spans.

General	# 1	# 2	# 3	# 4	# 5	# 6	# 7	# 8		
Span Description	<input type="text"/>									
Span	<input type="text" value="8.000"/>							ft		
Unbraced Length	<input type="text" value="0.000"/>							ft		
Left Fixity	Free							▼		
Right Fixity	Pinned							▼		
Steel Section	W21X111									
Loads		Section Properties								
Loads...	Apply Live Load This Span ? <input checked="" type="checkbox"/>									
	<u>Dead Load</u>			<u>Live Load</u>						
Uniform	<input type="text" value="1.750"/>	<input type="text" value="1.450"/>	k/ft							
Partial	<input type="text"/>	<input type="text"/>	k/ft		Start	<input type="text" value="0.00"/>	ft			
					End	<input type="text" value="8.00"/>	ft			
Trapezoidal										
@ Left	<input type="text" value="0.850"/>	<input type="text" value="0.650"/>	k/ft					Start	<input type="text" value="0.00"/>	ft
@ Right	<input type="text"/>	<input type="text"/>	k/ft					End	<input type="text" value="8.00"/>	ft
							<u>Location</u>			
Point Ld #1	<input type="text"/>	<input type="text"/>	k		<input type="text" value="0.00"/>	ft				
Point Ld #2	<input type="text"/>	<input type="text"/>	k		<input type="text" value="0.00"/>	ft				
Point Ld #3	<input type="text"/>	<input type="text"/>	k		<input type="text" value="0.00"/>	ft				
Point Ld #4	<input type="text"/>	<input type="text"/>	k		<input type="text" value="0.00"/>	ft				
Moment	<input type="text"/>	<input type="text"/>	k-ft		<input type="text" value="0.00"/>	ft				

Span Description

Enter a brief description of this span. Leaving it blank is fine.

Span

This equals the span distance of a beam segment.

Unbraced Length

If the span will have the compression edge laterally unbraced for some distance, enter the distance here. This length will be used to determine whether the beam falls into the short, intermediate, or long beam classification for determination of allowable bending stress.

For continuous beams, remember that the true meaning of this value is distance between points of contra flexure, and most likely will NOT be the distance between supports.

Left Fixity, Right Fixity

Specifies how the ends of the beam will be restrained.

Steel Section

This is where you specify the rolled steel section to be used in the design. There are two ways to enter & specify the section.

- Use the [Section] button to retrieve the section from the built-in steel database. See the description given previously for more information.
- Type in the section name and the program will automatically look through the database for a match. Upper or lower case is fine. If found the name and numeric section properties will be retrieved into this calculation. The numeric properties will be seen on the "Section Properties" tab.

Apply Live Load This Span?

This entry controls whether or not the live load entered for the span will be used or ignored. A YES/NO entry here gives you a simple way to try various live load alternates to determine maximum moments and shears on multi-span beams.

Applied Loads Tab

Uniform

Uniform dead and live load applied to the entire length of the center span. You should be aware that beam weight is not considered in the program, therefore this input should include allowance for beam weight. These values may be positive or negative.

Partial Length Distributed

Uniform dead and live load applied over a full or partial length of the center span. X-Left indicates the distance from the left support to the beginning of the load, and X-Right is the distance from the left support to the right end of the load. These values may be positive or negative.

Trapezoidal Distributed

Uniform or varying dead and live load applied over a full or partial length of the center span. DL/LL @ Left indicates the dead or live load magnitude at the X-Left distance location. DL/LL @ Right indicates the dead or live load magnitude at the X-Right distance location. These values may be positive, negative, or both. X-Left indicates the distance from the left support to the beginning of the load, and X-Right is the distance from the left support to the right end of the load.

Point Load

Concentrated dead and live load applied to the beam.

Moment

Dead and live moment applied to the beam.

Section Properties Tab

This secondary tab is where the steel section properties are listed. The properties shown here are used for the calculation.

Loads		Section Properties	
Area	<input type="text" value="32.700"/>	in ²	
Depth	<input type="text" value="21.510"/>	in	
Width	<input type="text" value="12.340"/>	in	
Tf	<input type="text" value="0.875"/>	in	
Tw	<input type="text" value="0.550"/>	in	
Ixx	<input type="text" value="2,670.000"/>	in ⁴	
Iyy	<input type="text" value="274.000"/>	in ⁴	
r t	<input type="text" value="3.280"/>	in	

The typical steel section measurements are given for the section chosen. When certain sections are used, the measurements will not conform to the typical W section naming conventions used here:

- For **Tubes** , **Flange Thickness** and Wall Thickness will both be set equal to the tube's wall thickness. rT is not used.
- For **Pipe** , **Flange Thickness** and Wall Thickness both equal the pipe's wall thickness. Flange Width and Depth will both be set to the pipe's outside diameter. rT is not used.
- For **Channels** , rT equals the distance from the flat face to the center of gravity of the section.
- For **Tees** , rT equals the distance from the top of the flange to the center of gravity of the section.
- For **Double Angles** , rT equals the spacing between the backs of the angles.
- For **Single Angles** , rT is not used.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Results	Sketch	Diagrams	Printing
Beam is OK			
Moments...			
Max. Moment @ Mid-Span . . .	0.0 k-ft	@	0.00 ft
Max @ Left End	0.0 k-ft		
Max @ Right End	-134.4 k-ft		
Bending Stress...			
Actual	6,496.3 psi		
Allowable	23,760.0 psi		
Shear Stress...			
Actual	2,671.1 psi		
Allowable	14,400.0 psi		
Max. Deflection			
	-0.082 in	@	0.00 ft
Span/Deflection Ratio	2,330.4		
	<u>@ Left</u>		<u>@ Right</u>
Shear @ Support	0.00 k		31.60 k
Reactions...			
Dead	0.00 k		53.69 k
Live	0.00 k		14.03 k
Total	0.00 k		67.72 k
Query Values....			
Location	0.000		ft
Moment	0.00 k-ft		
Shear	0.000 k		
Deflection	-0.0824 in		

Moments

These are the maximum values to use for design for this span. The "Mid-Span" moment can occur anywhere between the two end supports. It is possible that this number is right next to the support.

To determine maximum moments, the following technique is used:

- Fixed end moments are calculated for each span. When LL Flag is set to NO, no live loads are applied to that span.
- A 16 pass moment distribution is performed on the entire eight span system.
- The resulting end moments are then applied to each beam end and the resulting moments, shears, and deflections for the span are calculated. Each beam is divided into 250 increments for this process.

Bending Stress

Allowable bending stress calculated considering C_f , load duration factor, and from the evaluation of allowable bending stress, due to the unbraced length. Actual bending stress is the maximum of positive or negative moment, divided by section modulus of the beam at that span location. Continuous beams will have this value equal to the maximum stress between the supports.

Shear Stress

Allowable stress is calculated load duration factor applied to F_v (see below). Actual shear stress is the maximum unit shear stress at the end of the beam. To determine net shear at the beam end, all loads within a distance d away from the end of the member are subtracted from the end shear. This value is multiplied by 1.5 and divided by beam width times beam depth. When the beam is continuous over a support, shear on BOTH SIDES of the support is evaluated.

Maximum Deflection

Using the applied loads, support fixities, and moment distribution results, the resulting deflection curve at 250 points along the beam is searched for the maximum deflection and location. This is the maximum deflection, considering both upward and downward displacements. Negative sign is downward deflection.

Shear @ Support

The calculates shears at each support are given. This value is the maximum shear after checking both sides of the support.

Reactions


Reactions are calculated using dead load and the live load as selected to be applied for each span.

Query Values

In this area you can enter a distance location along the span, measured from the left support, and have the shear, moment, and deflection at that location calculated.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Diagrams Tab


This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.

Results | Sketch | Diagrams | Printing

[Print Diagram](#)


#1	#2	#3	#4	#5	#6	#7	#8
Location (ft)		Moment (kip-feet)		Shear (kips)		lection	
		0.0000		-134.3967		36.1234	0.0000
		0.2349		-128.4064		25.4651	0.0009
		0.4698		-122.5122		25.0567	0.0017
		0.7047		-116.7133		24.6484	0.0024
		0.9396		-111.0096		24.2401	0.0029
		1.1745		-105.4012		23.8317	0.0032
		1.4094		-99.8881		23.4234	0.0034
		1.6443		-94.4703		23.0151	0.0036
		1.8792		-89.1477		22.6067	0.0035
		2.1141		-83.9205		22.1984	0.0034
		2.3490		-78.7885		21.7901	0.0032
		2.5839		-73.7518		21.3817	0.0029
		2.8188		-68.8103		20.9734	0.0025
		3.0537		-63.9642		20.5651	0.0020
		3.2886		-59.2133		20.1567	0.0015
		3.5235		-54.5577		19.7484	0.0008
		3.7584		-49.9974		19.3401	0.0001
		3.9933		-45.5323		18.9317	-0.0006
		4.2282		-41.1626		18.5234	-0.0015
		4.4631		-36.8881		18.1151	0.0022

Graphic Diagram | Data Table



Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".



Sample Printout

4.2 Single Span Steel Beam

This program provides analysis and design for single span steel beams. Each beam may have a variety of end fixities, applied loads, factors governing allowable stresses, and cantilevers.

For rapid design of many simple span beams and multi-span continuous beams, the Multi-Span Steel Beam program may prove to be more useful. This program is primarily for beams that have more detailed loadings or are bent about the minor axis.

Fixed and pinned supports can be used at either end, and pinned ends may have a cantilever, allowing analysis of the following types of beams:

- Fixed/Fixed, Pinned/Pinned/ Fixed/Pinned, or Pinned/Fixed
- Single span, single cantilever with opposite support fixed or pinned, or double cantilever.

A maximum of 26 loads may be applied to the beam:

- Seven point loads
- Seven applied moments
- Seven full or partial length distributed loads
- Two full or partial length trapezoidal loads

Each of these loads may have dead, live, and short term load magnitudes. In addition, the beam's self weight can be added to the applied dead loads, and you can optionally include live loads with short term loads (seismic design usually omits live loads).

A variety of factors can be specified which effect the AISC code stress analysis of the beam. Unbraced compression flange lengths, minor axis bending, primary or secondary member status, and load duration factors can all be modified for the beam you are analyzing or designing.

To help you specify AISC sections to be analyzed, an internal database system gives you access to over 4,000 sections from the 6th, 7th, 8th, and 9th edition AISC handbooks.

You can either type in a section and have its properties automatically recalled, or display a window to scroll through the database of sections. Sections available include W, H, S, M, C, MC, B, JR, TS, P, WT, ST, MT, L, and LL.

A comprehensive analysis procedure provides reactions, shears, moments, and deflection for various load placement combinations to determine maximum and minimum values. A very thorough AISC code check procedure determines allowable bending and shear stresses for all members, considering compact section criteria and lateral buckling due to slenderness effects.

ENERCALC c:\ECSS\EXAMPLES\ECW - Single Span Steel Beam

Single Span Steel Beam

Tools & Settings | ? Help | Design | Print | Cancel | Save

General | Uniform | Trapezoidal | Concentrated | Moments | Section

Results | Sketch | Diagrams | Printing

Summary | Load Combinations

Description Fixed-Cantilevered Beam

Center Span 48.500 ft
 Left Cantilever 0.000 ft
 Right Cantilever 7.500 ft
 Lu : Unbraced Length 16.000 ft

End Fbdy
 Pin-Pin Fix-Fix Pin-Fix Fix-Pin Fix-Free

Steel Section W27X114

Fy 36.00 ksi
 Load Duration Factor 1.000
 Include LL w/ ST?
Used only in combinations with Short Term loads
 Minor Axis Bending?
 Elastic Modulus 29,000.0 ksi

Load Combination Results....
 These columns are Dead + Live Load placed as noted

	Placed for Max Value	DL Only	LL @ Center	LL+ST @ Center	LL @ Cants	LL+ST @ Cants	
Cntr M+		136.58	245.07		119.34		k-ft
Cntr M-		-290.49	-505.06		-271.16		
Overall Max M =		505.06					
@ Left		290.49	-505.06		-271.16		
@ Right		-45.41	-45.41		-84.07		
V @ Left	54.87	31.97	54.87		30.78		k
V @ Rt	39.40	22.88	39.40		24.08		
Cntr Defl.	-0.670	-0.377	-0.670	-0.377	-0.330	-0.377	in
Left Defl	0.000	0.000	0.000	0.000	0.000	0.000	in
Right Defl	0.407	0.210	0.407	0.210	0.148	0.210	in
...Query Loc	0.000	0.000	0.000	0.000	0.000	0.000	in
R @ Lt	54.87	31.97	54.87	31.97	30.78	31.97	k
R @ Rt	57.31	31.55	48.07	31.55	40.78	31.55	k

Basic Usage


- **Beam Data.** From the actual span condition of the beam to analyze, enter the center span and cantilever lengths as applicable. If you happen to enter a cantilever length past a support that is specified as Fixed (see "End Conditions"), that length will be ignored. You will also need to specify the unbraced compression flange length to be used for calculating allowable bending stresses, and specify whether to add beam weight loads or use live load during Short Term load cases.
- **Applied Loads.** This program provides plenty of load capability for loading any part of the beam. "All Dist" values position the load with respect to the left support. To apply a load to the left cantilever, enter the distances as negative.
- **Section Properties** can be entered by using the built-in section property databases. Please see the following two sections on using this capability. The analysis of the beam is performed using the numbers visible on the calcsheet, so you may enter any values here you wish. Just make sure their use is similar to the database.

Steel Section Database

Built into the software is a complete database of common rolled sections available from various mills in the United States. On each tab labeled #1, #2, etc. there will be a button that looks like this:

Steel Section

This button displays the steel section database as shown below.



On this window there are various controls and options.....

Steel Database : Allows you to select between several common shapes databases.

Section Type to Display: Allows you to select which steel section designation to display in the list. These shapes conform to the American Institute of Steel Construction shape designations. To make your selection simply move the mouse over the letter(s) and when the highlight activates left-click once with your left mouse button.

Depth Range: This item allows you to specify depth limits to be used for selecting which sections to display in the list. When the checkbox to the left is not checked the selection wording and entries will not appear and all sections will be displayed. These dimensions are compared to the "Depth" dimension of the sections.

Class Range : This item allows you to specify the limits in "Depth Class" to be displayed in the table. The "Depth Class" of a section is the first numeric number in the sections name. For instance a wide flange W14x22 is in depth class "14". a channel C9x15 is in depth class "9", and a L 5x3x1/4 is in depth class "5".

Equal & Unequal Legs : These two buttons appear when you have selected section type "L" which are single angles. The limit the display of the list to angle with equal dimension or unequal dimensioned sides.

Equal Legs, Long Leg Vertical, Short Leg Vertical: These three buttons appear when you have chosen to display section type "LL". These control the display of sections between pairs of angles with

both sides of equal length, of unequal side length angles paired with the LONG side together, and unequal side length angles paired with the SHORTside together.

Square & Rectangular Tubes: These two buttons appear when you have chosen section types TS or HSS-T. These are square tubular sections. You can choose to display only square tubes or alternately tubes with unequal sides.

Sort Tabs for Database Table : Immediate above the database list of sections you will see tabs looking like this....

When selected each tab will sort the list in the order described by the text on that tab.

Sort order : These two buttons allow you to chose the list order of the sections. The sorting order will be according to the sort tab selected and shall be in ascending or descending order.

Database Table Itself : The main area on the window will be where the steel sections are displayed as a result of all of your choices as described above.

[Select] : This button is displayed when you have clicked on the **[Section]** button when you press [Select] the section in the list that is currently highlighted will be selected and the name and data brought into your calculation.

[Insert]: Use this button to add a steel section to the database. When pressed you will see the following window:

The screenshot shows a dialog box titled "New Steel Section Data Entry". It contains the following fields and values:

- Section Name: MyVeryOwn 4x12 Tube
- Type: TS
- Depth Class: 36
- AISC Handbook Edition: AISC 9th
- Area: 0 in²
- I_{x-x}: 0 in⁴
- Depth: 0 in
- I_{y-y}: 0 in⁴
- Flange Width: 0 in
- Flange Thickness: 0 in
- Web Thickness: 0 in
- X_{cg}: 0 in
- Y_{cg}: 0 in

At the bottom of the dialog are two buttons: "Cancel" (with a red X icon) and "OK" (with a green checkmark icon).

The only really important item to enter is the "Type" item. This specifies what standard rolled section type your section is. This item is used internally by the program to decide which stress analysis method to use for determining the sections allowable stress, how to consider unstiffened elements, and many other code checking items.

[Change]: Will display the same window as above but allow you to change section properties.

[Delete] : Will enable you to delete sections. Note: No sections in the supplied database can be deleted. Only Sections that you add can be later deleted.

[Cancel]: Exit the steel database window.


ASD & LRFD Design Modes

Allowable Stress Design and **Load & Resistance Factor Design** as specified by the American Institute of Steel Construction is provided by this program. Only screen captures and descriptions for ASD are presented in this book. More detailed LRFD documentation will be added and will be available in the electronically delivered versions of this book. Check these locations for electronic media:

- Latest Adobe Acrobat PDF documentation file here:
<ftp://208.36.30.226/sel5.pdf>.
- Latest Windows Help system file here : <ftp://208.36.30.226/enercalc.hlp>.
- Internet HTML help documentation presented as web pages at
www.enercalc.com/sel_help.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow. Here is a basic sketch:



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General	Uniform	Trapezoidal	Concentrated	Moments	Section
Description		Fixed-Cantilevered Beam			
Center Span		48.500	ft		
Left Cantilever		0.000	ft		
Right Cantilever		7.500	ft		
Lu : Unbraced Length		16.000	ft		
End Fixity					
<input type="radio"/> Pin-Pin <input type="radio"/> Fix-Fix <input type="radio"/> Pin-Fix <input checked="" type="radio"/> Fix-Pin <input type="radio"/> Fix-Free					
Steel Section		W27X114			
Fy		36.00	ksi		
Load Duration Factor		1.000			
Include LL w/ ST ?		<input type="checkbox"/>		<i>Used only in combinations with Short Term loads</i>	
Minor Axis Bending ?		<input type="checkbox"/>			
Elastic Modulus		29,000.0	ksi		

Center Span

Span distance between the left and right supports for the beam.

Left & Right Cantilever

Specifies the length of the cantilevers, if applicable.

Unbraced Flange Length

This is the user specified unbraced length of the compression flange, used to determine the allowable stress based on flange buckling criteria.

End Fixity

The steel beam can have any of four different end fixity combinations; Fix/Fix, Pin/Pin, Fix/Pin, Pin/Fix, or Fix/Free. If cantilever data is entered past a support that has been specified as fixed, that cantilever data is ignored.

Steel Section

This is where you specify the rolled steel section to be used in the design. There are two ways to enter & specify the section.

- Use the [Section] button to retrieve the section from the built-in steel database. See the description given previously for more information.
- Type in the section name and the program will automatically look through the database for a match. Upper or lower case is fine. If found the name and numeric section properties will be retrieved into this calculation. The numeric properties will be seen on the "Section Properties" tab.

Fy

Yield stress of the steel used for the member being analyzed. All allowable stresses are calculated in accordance with AISC Specifications.

Load Duration Factor

Load duration factor is applied to the calculated allowable stresses and displayed as Allowable Stress in the Summary section.

Include LL with ST?

Typically when short-term loads are from seismic events, the live load is not used. This YES/NO entry specifies whether your live loads will be used with short-term loads.

Minor Axis

This YES/NO flag specifies whether the beam is bent about the X-X axis or the Y-Y axis. When set to YES (1"), the beam is bent about the Y-Y axis.

Elastic Modulus

Although rarely does this need to be changed, enter the elastic modulus of the steel material.

Uniform Loads Tab

Up to seven full or partial length uniform loads with dead, live, and short term components may be applied anywhere on the span. The "Start" and "End" values refers to the distance from the left support to where the beginning of the distributed load is applied. To specify loads on the left cantilever use negative distances.

General Uniform Trapezoidal Concentrated Moments Section

Auto Calc of Beam Weight ?

Uniform Loads...

	#1	#2	#3	#4	
Dead	0.510				k/ft
Live	0.340				k/ft
Short					k/ft
Start	0.000	0.000	0.000	0.000	ft
End	55.500	0.000	0.000	0.000	ft

	#5	#6	#7	
Dead				k/ft
Live				k/ft
Short				k/ft
Start	0.000	0.000	0.000	ft
End	0.000	0.000	0.000	ft

Auto Calc Beam Weight?

If the user desires, the simple span moment from the chosen steel section is added to the actual moment for design and analysis, by entering a 1" here.

Trapezoidal Loads Tab

Two full or partial length trapezoidal loads with dead, live, and short-term components may be applied anywhere on the span. The end magnitudes can be positive, negative, or of opposite signs. The "X-Left" and "X-Right" values refers to the distance from the left support to where the beginning of the trapezoidal load is applied. To specify loads on the left cantilever these values should be negative.

General	Uniform	Trapezoidal	Concentrated	Moments	Section
Trapezoidal Loads...					
#1: Dead Ld	@ Left :	<input type="text"/>	@ Right :	<input type="text"/>	k/ft
Live Ld	@ Left :	<input type="text" value="0.025"/>	@ Right :	<input type="text" value="0.500"/>	k/ft
Short Ld	@ Left :	<input type="text"/>	@ Right :	<input type="text"/>	k/ft
	X Left :	<input type="text" value="37.250"/>	X Right :	<input type="text" value="55.500"/>	ft
#2: Dead Ld	@ Left :	<input type="text"/>	@ Right :	<input type="text"/>	k/ft
Live Ld	@ Left :	<input type="text"/>	@ Right :	<input type="text"/>	k/ft
Short Ld	@ Left :	<input type="text"/>	@ Right :	<input type="text"/>	k/ft
	X Left :	<input type="text" value="0.000"/>	X Right :	<input type="text" value="0.000"/>	ft

Concentrated Loads Tab

You may apply up to eight point loads with dead, live, and short-term components. The Dist. value refers to the distance from the left support to where the point load is applied. To specify loads on the left cantilever, Dist. should be negative.

General	Uniform	Trapezoidal	Concentrated	Moments	Section
Point Loads...					
	<u>#1</u>	<u>#2</u>	<u>#3</u>	<u>#4</u>	
Dead	<input type="text" value="12.300"/>	<input type="text" value="12.300"/>	<input type="text" value="4.245"/>	<input type="text"/>	k
Live	<input type="text" value="10.500"/>	<input type="text" value="10.500"/>	<input type="text" value="2.796"/>	<input type="text"/>	k
Short	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	k
Location	<input type="text" value="9.500"/>	<input type="text" value="41.000"/>	<input type="text" value="55.500"/>	<input type="text" value="0.000"/>	ft
	<u>#5</u>	<u>#6</u>	<u>#7</u>		
Dead	<input type="text"/>	<input type="text"/>	<input type="text"/>		k
Live	<input type="text"/>	<input type="text"/>	<input type="text"/>		k
Short	<input type="text"/>	<input type="text"/>	<input type="text"/>		k
Location	<input type="text" value="0.000"/>	<input type="text" value="0.000"/>	<input type="text" value="0.000"/>		ft

Moments Tab

Up to eight moments with dead, live, and short-term components may be applied anywhere on the span. Moments with a positive sign impart a counterclockwise torque to the beam

(following the right hand rule). The "Location" values refers to the distance from the left support to where the moment is applied. To specify loads on the left cantilever this value should be negative.

	#1	#2	#3	#4	
Dead	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	k-ft
Live	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	k-ft
Short	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	k-ft
Location	<input type="text" value="0.000"/>	<input type="text" value="0.000"/>	<input type="text" value="0.000"/>	<input type="text" value="0.000"/>	ft
	#5	#6	#7		
Dead	<input type="text"/>	<input type="text"/>	<input type="text"/>		k-ft
Live	<input type="text"/>	<input type="text"/>	<input type="text"/>		k-ft
Short	<input type="text"/>	<input type="text"/>	<input type="text"/>		k-ft
Location	<input type="text" value="0.000"/>	<input type="text" value="0.000"/>	<input type="text" value="0.000"/>		ft

Section Data Tab

This secondary tab is where the steel section properties are listed. The properties shown here are used for the calculation.

	General	Uniform	Trapezoidal	Concentrated	Moments	Section
Steel Section	W27X114					
Depth	<input type="text" value="27.290"/>	in	Weight	<input type="text" value="113.79"/>	#/ft	
Web Thick	<input type="text" value="0.570"/>	in	Ixx	<input type="text" value="4,090.000"/>	in4	
Width	<input type="text" value="10.070"/>	in	Iyy	<input type="text" value="159.000"/>	in4	
Flange Thick	<input type="text" value="0.930"/>	in	Sxx	<input type="text" value="299.743"/>	in3	
Area	<input type="text" value="33.50"/>	in2	Syy	<input type="text" value="31.579"/>	in3	
Rt	<input type="text" value="2.580"/>	in	r-xx	<input type="text" value="11.049"/>	in	
			r-yy	<input type="text" value="2.179"/>	in	

The typical steel section measurements are given for the section chosen. When certain sections are

used, the measurements will not conform to the typical W section naming conventions used here:

- For **Tubes** , Flange Thickness and Wall Thickness will both be set equal to the tube's wall thickness. rT is not used.
- For **Pipe** , Flange Thickness and Wall Thickness both equal the pipe's wall thickness. Flange Width and Depth will both be set to the pipe's outside diameter. rT is not used.
- For **Channels** , rT equals the distance from the flat face to the center of gravity of the section.
- For **Tees** , rT equals the distance from the top of the flange to the center of gravity of the section.
- For **Double Angles**, rT equals the spacing between the backs of the angles.
- For **Single Angles**, rT is not used.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results / Summary Tab

Results Sketch Diagrams Printing		
Summary Load Combinations		
Beam OK		
Maximum Values....	<u>Actual</u>	<u>Allowable</u>
Moment	505.06 k-ft	535.74 k-ft
Bending Stress	20.22 ksi	21.45 ksi
fb / Fb	0.943 : 1	
Static Load Case Governs Stress		
Shear	54.869 k	223.996 k
Shear Stress	3.53 ksi	14.40 ksi
fv / Fv	0.245 : 1	
<hr/>		
Maximum Center Defl.		-0.670 in
Maximum Left Cant Defl		0.000 in
Maximum Right Cant Defl		0.407 in
Max. Defl.		-0.670in
Length / (dl)		857.9 : 1
Length / (dl+ll)		441.8 : 1
Maximum Shear @ Left		54.87 k
Maximum Shear @ Right		39.40 k
Maximum Left Reaction		54.87 k
Maximum Right Reaction		57.31 k
Fa calc'd per Eq. E2-2, $K \cdot L_T > C_c$		
I Beam, Major Axis, $(102,000 \cdot C_b / F_y)^{1.5} \leq L_T \leq (510,000 \cdot C_b / F_y)^{1.5}$, Fb per E		
I Beam, Major Axis, Fb per Eq. F1-8, $F_b = 12,000 C_b A_f / (l^2 d)$		

Maximum Values

Using the beam span, applied loads, section properties, unbraced length, and member data, the maximum bending and shear forces and stresses are listed. More details of how the allowable bending stress is calculated is given at the beginning of the Steel chapter in this manual, and in the worksheet area titled Allowable Stress Analysis Values.

fb/Fb

This is the actual bending stress divided by the allowable.

fv/Fv

This is the actual shear stress divided by the allowable.

Deflections

Center span deflection is the maximum magnitude (positive or negative) between the supports. Deflection at left and right will only be given when cantilevers are present, and are the deflections at the ends of the cantilever.

Shears

Shears are calculated equal to the end reaction for beams with fixed ends or pinned ends without cantilevers. When a cantilever is present, shear at both sides of the support are evaluated.

Reactions

These are simply the left and right beam reactions due to the load combinations used.

Results / Load Combinations Tab

This section of the summary area displays, in tabular form, the beam's moments, shears, deflections, and reactions for different dead, live, and short term loading patterns. When no cantilevers are used, many of these areas will be blank or equal to others. It is from this tabulation of values that the maximums are selected.

Moments M+ and M- are determined by checking 250 points along the span for maximum and minimum values. Moments at the left and right end are calculated at the supports for conditions with cantilevers or fixed ends.


Results Sketch Diagrams Printing						
Summary Load Combinations						
Load Combination Results....						
These columns are Dead + Live Load placed as noted						
	Placed for Max Value	DL Only	LL @ Center	LL+ST @ Center	LL @ Cants	LL+ST @ Cants
Cntr M+		136.58	245.07		119.34	k-ft
Cntr M-		-290.49	-505.06		-271.16	
Overall Max M =		505.06				
@ Left		-290.49	-505.06		-271.16	
@ Right		-45.41	-45.41		-84.07	
V @ Left	54.87	31.97	54.87		30.78	k
V @ Rt	39.40	22.88	39.40		24.08	
Cntr Defl.	-0.670	-0.377	-0.670	-0.377	-0.330	-0.377 in
Left Defl	0.000	0.000	0.000	0.000	0.000	0.000 in
Right Defl	0.407	0.210	0.407	0.210	0.148	0.210 in
...Query Loc		<input type="text" value="0.000"/>				
		0.000	0.000	0.000	0.000	0.000 in
R @ Lft	54.87	31.97	54.87	31.97	30.78	31.97 k
R @ Rt	57.31	31.55	48.07	31.55	40.78	31.55 k

Notes on Allowable Stress Determination

In this section, various messages will be displayed indicating what factors governed the calculation of allowable bending stress. The internal AISC code checking system can evaluate allowable stresses for all members EXCEPT SINGLE AND DOUBLE ANGLES. Although the program will calculate actual bending stresses, THE DESIGNER MUST DETERMINE IF THE BENDING IS VALID, DUE TO THE UNEQUAL CROSS PRODUCT NATURE OF THE SECTION. For all sections, allowable stress calculations are based on lateral-torsional buckling tendencies and compact section criteria. You will notice that a message regarding allowable axial stress will also be displayed, and this is only valid for the Steel Column program.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Diagrams Tab

This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.



Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results | Sketch | Diagrams | Printing |

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Distributed Loads	<input checked="" type="checkbox"/>
Trapezoidal Loads	<input checked="" type="checkbox"/>
Point Loads	<input checked="" type="checkbox"/>
Moments	<input checked="" type="checkbox"/>
Summary	<input checked="" type="checkbox"/>
Force & Stress Summary	<input checked="" type="checkbox"/>
Stress Check Messages	<input checked="" type="checkbox"/>
Section Properties	<input checked="" type="checkbox"/>

Note: When all are selected, the software will still omit unused sections

[Sample Printout](#)

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job #97-00001
 Dsgnr: MDB Date: 2:56PM, 26 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 500.000
 Use: 1: 10/5-06/0001, Ver 5.8.0, 10-Sep-2003
 © 1983-2003 ENERCALC Engineering Software Page 1
Steel Beam Design ch055\exampl\ex04\SteelCabs

Description Fixed-Cantilevered Beam

General Information Code Ref. AISC 9th ASD, 1997 UBC, 2003 IBC, 2003 NFPA 5000

Steel Section: W27X114	Fixed-Pinned	Fy	36.00 ksi
Center Span	48.50 ft	Load Duration Factor	1.00
Left Cant.	0.00 ft	Elastic Modulus	29,000.0 ksi
Right Cant.	7.50 ft		
Lu: Unbraced Length	16.00 ft		

Distributed Loads

	# 1	# 2	# 3	# 4	# 5	# 6	# 7	
DL	0.510							k/ft
LL	0.340							k/ft
ST								k/ft
Start Location								ft
End Location	55.500							ft

Trapezoidal Loads

#1	DL @ Left	LL @ Left	0.025	ST @ Left	k/ft	Start	37.250 ft
	DL @ Right	LL @ Right	0.500	ST @ Right	k/ft	End	55.500 ft

Point Loads

	# 1	# 2	# 3	# 4	# 5	# 6	# 7	
Dead Load	12.300	12.300	4.245					k
Live Load	10.500	10.500	2.796					k
Short Term								k
Location	9.500	41.000	55.500					ft

Summary **Beam OK**
 Static Load Case Governs Stress

Using: W27X114 section, Span = 48.50ft, Fy = 36.0ksi, Left Cant. = 0.00ft, Right Cant. = 7.50ft
 End Fixity = Fixed-Pinned, Lu = 16.00ft, LDF = 1.000

	Actual	Allowable		
Moment	505.057 k-ft	535.744 k-ft	Max. Deflection	-0.670 in
fb: Bending Stress	20,220 ksi	21,448 ksi	Length/DL Def	857.9 : 1
fb / Fb	0.943 : 1		Length/(DL+LL Def)	441.8 : 1
Shear	54.869 k	223.896 k		
fv: Shear Stress	3.527 ksi	14.400 ksi		
fv / Fv	0.245 : 1			

Force & Stress Summary

<<< These columns are Dead + Live Load placed as noted >>>

	Maximum	DL Only	LL @ Center	LL+ST @ Center	LL @ Cants	LL+ST @ Cants	
Max. M +	505.06 k-ft	136.58	245.07		119.34		k-ft
Max. M -		-290.49	-505.06		-271.16		k-ft
Max. M @ Left		-290.49	-505.06		-271.16		k-ft
Max. M @ Right		-45.41	-45.41		-84.07		k-ft
Shear @ Left	54.87 k	31.97	54.87		30.78		k
Shear @ Right	39.40 k	22.88	39.40		24.08		k
Center Def.	-0.670 in	-0.377	-0.670	-0.377	-0.330	-0.377 in	
Left Cant Def	0.000 in	0.000	0.000	0.000	0.000	0.000 in	
Right Cant Def	0.407 in	0.210	0.407	0.210	0.148	0.210 in	
...Query Def @	0.000 ft	0.000	0.000	0.000	0.000	0.000 in	
Reaction @ Left	54.87	31.97	54.87	31.97	30.78	31.97 k	
Reaction @ Rt	57.31	31.55	48.07	31.55	40.78	31.55 k	

Fb calc'd per Eq. E2-2, $K'Lt > Cc$
 I Beam, Major Axis, $(0.02,000 * Cb / Fy)^{1.5} <= Lt <= (510,000 * Cb / Fy)^{1.5}$, Fb per Eq. F1-6
 I Beam, Major Axis, Fb per Eq. F1-8, Fb = 12,000 Cb Af / (l * d)

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 2:56PM, 26 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 580000
 User: KVF0800001 Ver 5.0.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

Steel Beam Design


Page 2

c:\e05\examples.com\Steel Calc

Description Fixed-Cantilevered Beam

Section Properties		W27X114			
Depth	27.290 in	Weight	113.79 #/ft	F-xx	11.049 in
Width	10.070 in	I-xx	4,090.00 in ⁴	r-yy	2.179 in
Web Thick	0.570 in	I-yy	159.00 in ⁴	Rt	2.580 in
Flange Thickness	0.930 in	S-xx	299.743 in ³		
Area	33.50 in ²	S-yy	31.579 in ³		

Sketch & Diagram



4.3 Steel Beam w/Torsion

This program analyzes rolled AISC steel W, H, S, M, C, B, JR, and MC I sections and channels subjected to applied loads causing torsion within the beam. Both plane and bending stresses are determined in addition to typical AISC code checks for compactness and lateral-torsional buckling.

Two end fixity combinations are allowed to separately determine torsional and bending stresses; Pinned/Pinned and Fixed/Fixed. With these end fixity conditions combined with torsional analysis, a variety of load and span conditions can be analyzed.

In order to perform the extensive torsional analysis, the typical torsional equations presented in the AISC publication (Torsional Analysis of Members ©1983), have been

derived and used to calculate analysis values at 1/250 span increments. Only cases # 3, 4, 6, 7, and 12 have been incorporated:

- Case 3: Ends torsionally pinned with a concentrated twisting moment applied between supports.
- Case 4: Ends torsionally pinned with a uniform load applied to the beam at an off-center eccentricity.
- Case 6: Ends torsionally fixed with a concentrated twisting moment applied between supports.
- Case 7: Ends torsionally fixed with a uniform load applied to the beam at an off-center eccentricity.
- Case 12: Left end torsionally fixed, right end torsionally pinned, uniform load applied to the beam at an off-center eccentricity.

These stresses are combined with the actual stresses from normal X-X axis bending and compared with allowable values based on compactness and lateral buckling criteria.

Final stresses are determined by combining major axis bending and shears with torsional moments. Normal and shear stresses from plane bending are combined with torsional bending, warping shear, and pure torsional shear forces to give a final analysis of the actual stresses, deflections, and rotations of the beam's slenderness effects.

Torsional Analysis of Steel Beam

Tools & Settings | Help | Design | Print | Cancel | Save

General | Uniform Loads | Point Loads | Moments | Section Props | Results | Sketch | Diagrams | Printing

Description: Single offset point load @ mid-span

Beam Span: 15.000 ft
 Unbraced Length: 0.000 ft
 Torsional End Fixity: Pin-Pin
 Bending End Fixity: Pin-Pin

Steel Section: W18x60

Fy: 36.00 ksi
 Load Duration Factor: 1.000
 Elastic Modulus: 29,000.0 ksi

	DL	LL	DL+LL	DL+LL+ST
Bending...				
Flange Bend +Warp	19.50	4.73	22.79	22.79 ksi
Allowable...	23.76	23.76	23.76	23.76 ksi
Stress Ratio.....	0.821	0.199	0.959	0.959
Shear....				
Flange Bend+Warp+Tors	8.73	1.93	10.66	10.66 ksi
Web Bend +Warp	6.61	1.49	8.10	8.10 ksi
Allowable...	14.40	14.40	14.40	14.40
Stress Ratio.....	0.607	0.134	0.740	0.740
Moments :				
Left				k-ft
Center	43.24	12.66	55.40	55.40 k-ft
Right				k-ft
Reactions :				
Left	14.70	3.37	18.07	18.07 k
Right	9.30	3.37	12.67	12.67 k
Deflections :				
...X-Dist to Max	0.062	0.018	0.080	0.080 in
...X-Dist to Max	7.20	7.50	7.20	7.20 ft
Rotations :				
...X-Dist to Max	0.046	0.012	0.057	0.057 rad
...X-Dist to Max	6.80	7.40	6.90	6.90 ft

Basic Usage

- Enter the span length of the member. (Please note that cantilevers are not allowed.) Torsional Fixity indicates whether the flanges are capable of Warping . Warping is a condition where the two flanges can move so that they are no longer parallel. Bending Fixity indicates if the ends are free to rotate about the beam's X-X axis. When Pin/Pin is chosen for either end, no end normal bending or warping torsional moments will occur.
- If your beam is subjected to loads of a short term nature, Load Duration Factor can be used to increase the allowable stresses. You can also specify to include the weight of the beam as a uniform dead load automatically from the member you've chosen. When the beam's compression flange is unbraced for lateral buckling, enter the distance you wish to use for allowable stress calculations.
- Applied Loads. We've provided the capability to enter up to 14 loads on the member, all of which create torsional or normal bending stresses. All loads also have dead, live, and short term components. Uniform and point loads can be applied at eccentricities causing torsion. Bending moments create purely normal axis bending, and twisting moments apply a concentrated torque to the beam. (i.e. opposing point loads at equal lateral eccentricity).
- Section Properties can be entered by using the built-in section property databases. Please see the following two sections on using this capability.

Unique Features


- Combine applied bending loads with torsional loads for a complete stress analysis of the entire beam.
- Specify different end fixities for bending and torsional analysis procedures.
- Handles up to 14 different loads which can be dead, live, or short term.

Assumptions & Limitations

Only wide flange and channel type sections are allowed....tubes, pipes, tees, and angles are not supported.

Steel Section Database

Built into the software is a complete database of common rolled sections available from various mills in the United States. On each tab labeled #1, #2, etc. there will be a button that looks like this:



Steel Section

This button displays the steel section database as shown below.

Steel Section Database

Section Type to Display: W HP JR C **TS** HSS-T L WT
S M B MC P HSS-P LL MT
WF BP JRC ST

Steel Database: AISC 9th AISC 8th AISC 7th AISC 6th Korean

Name | Area | Depth | Width | Sx | Ix | Sy | Iy | J | Section Count : 71

Section Name	Area in ²	Depth in	Wall Thickness in	Ixx in ⁴	Sxx in ³	Rxx in	Zx in ³
TS2x2x3/16	1.270	2.000	0.188	0.668	0.668	0.726	0.8
TS2x2x1/4	1.590	2.000	0.250	0.766	0.766	0.694	1.0
TS2x2x5/26	1.860	2.000	0.313	0.880	0.880	0.690	1.1
TS2.5x2.5x3/16	1.640	2.500	0.188	1.420	1.140	0.930	1.4
TS2.5x2.5x1/4	2.090	2.500	0.250	1.690	1.350	0.899	1.7
TS2.5x2.5x5/16	3.110	2.500	0.313	3.580	2.390	1.070	1.9
TS3x3x3/16	2.020	3.000	0.188	2.600	1.730	1.130	2.1
TS3x3x1/4	2.590	3.000	0.250	3.160	2.100	1.100	2.6
TS3x3x5/16	3.110	3.000	0.313	3.580	2.390	1.070	3.0
TS3.5x3.5x3/16	2.390	3.500	0.188	4.290	2.450	1.340	2.9
TS3.5x3.5x1/4	3.090	3.500	0.250	5.290	3.020	1.310	3.7
TS3.5x3.5x5/16	3.730	3.500	0.313	6.090	3.480	1.280	4.3
TS4x4x3/16	2.770	4.000	0.188	6.590	3.300	1.540	3.9
TS4x4x1/4	3.590	4.000	0.250	8.220	4.110	1.510	4.9
TS4x4x5/16	4.360	4.000	0.313	9.580	4.790	1.480	5.9
TS4x4x3/8	5.080	4.000	0.375	10.700	5.350	1.450	6.7
TS4x4x1/2	6.360	4.000	0.500	12.300	6.130	1.390	8.0
TS4.5x4.5x3/16	3.140	4.500	0.188	9.600	4.270	1.750	5.0
TS4.5x4.5x1/4	4.090	4.500	0.250	12.100	5.360	1.720	6.4
TS5x5x3/16	3.520	5.000	0.188	13.400	5.360	1.950	6.2
TS5x5x1/4	4.590	5.000	0.250	16.900	6.780	1.920	8.0
TS5x5x5/16	5.610	5.000	0.313	20.100	8.020	1.890	9.7
TS5.5x5.5x1/4	6.590	5.000	0.375	23.000	9.110	1.860	11.6

Depth Range : Class Range :

On this window there are various controls and options.....

Steel Database : Allows you to select between several common shapes databases.

Section Type to Display: Allows you to select which steel section designation to display in the list. These shapes conform to the American Institute of Steel Construction shape designations. To make your selection simply move the mouse over the letter(s) and when the highlight activates left-click once with your left mouse button.

Depth Range: This item allows you to specify depth limits to be used for selecting which sections to display in the list. When the checkbox to the left is not checked the selection wording and entries will not appear and all sections will be displayed. These dimensions are compared to the "Depth" dimension of the sections.

Class Range : This item allows you to specify the limits in "Depth Class" to be displayed in the table. The "Depth Class" of a section is the first numeric number in the sections name. For instance a wide flange W14x22 is in depth class "14". a channel C9x15 is in depth class "9", and a L5x3x1/4 is in depth class "5".

Equal & Unequal Legs : These two buttons appear when you have selected section type "L" which are single angles. The limit the display of the list to angle with equal dimension or unequal dimension sides.

Equal Legs, Long Leg Vertical, Short Leg Vertical: These three buttons appear when you have chosen to display section type "LL". These control the display of sections between pairs of angles with both sides of equal length, of unequal side length angles paired with the LONG side together, and unequal side length angles paired with the SHORT side together.

Square & Rectangular Tubes: These two buttons appear when you have chosen section types TS or

HSS-T. These are square tubular sections. You can choose to display only square tubes or alternately tubes with unequal sides.

Sort Tabs for Database Table : Immediate above the database list of sections you will see tabs looking like this....

When selected each tab will sort the list in the order described by the text on that tab.

Sort order : These two buttons allow you to choose the list order of the sections. The sorting order will be according to the sort tab selected and shall be in ascending or descending order.

Database Table Itself : The main area on the window will be where the steel sections are displayed as a result of all of your choices as described above.

[Select] : This button is displayed when you have clicked on the **[Section]** button when you press **[Select]** the section in the list that is currently highlighted will be selected and the name and data brought into your calculation.

[Insert]: Use this button to add a steel section to the database. When pressed you will see the following window:

New Steel Section Data Entry

Section Name: MyVeryOwn 4x12 Tube

Type: TS

Depth Class: 36

AISC Handbook Edition: AISC 9th

Area: 0 in² I x-x: 0 in⁴

Depth: 0 in I y-y: 0 in⁴

Flange Width: 0 in

Flange Thickness: 0 in Xcg: 0 in

Web Thickness: 0 in Ycg: 0 in

Buttons: Cancel OK

The only really important item to enter is the "Type" item. This specifies what standard rolled section type your section is. This item is used internally by the program to decide which stress analysis method to use for determining the sections allowable stress, how to consider unstiffened elements, and many other code checking items.

[Change]: Will display the same window as above but allow you to change section properties.

[Delete] : Will enable you to delete sections. Note: No sections in the supplied database can be deleted. Only Sections that you add can be later deleted.

[Cancel]: Exit the steel database window.


ASD & LRFD Design Modes

Allowable Stress Design and **Load & Resistance Factor Design** as specified by the American Institute of Steel Construction is provided by this program. Only screen captures and descriptions for ASD are presented in this book. More detailed LRFD documentation will be added and will be available in the electronically delivered versions of this book. Check these locations for electronic media:

- Latest Adobe Acrobat PDF documentation file here:
<ftp://208.36.30.226/sel5.pdf>.
- Latest Windows Help system file here : <ftp://208.36.30.226/enercalc.hlp>.
- Internet HTML help documentation presented as web pages at
www.enercalc.com/sel_help.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab provides data entry for everything except loading on the beam.

General	Uniform Loads	Point Loads	Moments	Section Props
Description Single offset point load @ mid-span				
Beam Span		15.000	ft	
Unbraced Length		0.000	ft	
Torsional End Fixity		Pin-Pin		
Bending End Fixity		Pin-Pin		
Steel Section		W12X40		
Fy		36.00	ksi	
Load Duration Factor		1.000		
Elastic Modulus		29,000.0	ksi	

Beam Span

Enter the span length here. No cantilevers are allowed.

Unbraced Length

This is the user specified unbraced length of the compression flange, used to determine the allowable F_b based on flange buckling criteria.

Torsional End Fixity

Enter the end fixities to use in determining the restraint case to be selected. The end fixities should be thoroughly understood, since warping restraint is difficult to achieve in actual practice.

Bending End Fixity

Enter the end fixity combination that will be used to calculate bending moments due to applied loads (not torsional forces). Only Fix/Fix and Pin/Pin conditions are allowed.

Steel Section

This is where you specify the rolled steel section to be used in the design. There are two ways to enter & specify the section.

- Use the [Section] button to retrieve the section from the built-in steel database. See the description given previously for more information.
- Type in the section name and the program will automatically look through the database for a match. Upper or lower case is fine. If found the name and numeric section properties will be retrieved into this calculation. The numeric properties will be seen on the "Section Properties" tab.

Fy

Yield stress of the steel used for the member being analyzed. All allowable stresses are calculated in accordance with the latest AISC Specifications.

Load Duration Factor

This factor applied to the calculated allowable stresses and displayed as Allowable Stress in the Summary section.

Elastic Modulus

Although rarely does this need to be changed, enter the elastic modulus of the steel material.

Uniform Loads Tab

Up to seven full or partial length uniform loads with dead, live, and short term components may be applied anywhere on the span. The "Start" and "End" values refers to the distance from the left support to where the beginning of the distributed load is applied. To specify loads on the left cantilever use negative distances.

	Dead Load	Live Load	Short Term
# 1	1.000 k/ft	0.450 k/ft	k/ft
	Ecc. from Beam CL		4.500 in
# 2	k/ft	k/ft	k/ft
	Ecc. from Beam CL		0.000 in
# 3	k/ft	k/ft	k/ft
	Ecc. from Beam CL		0.000 in
# 4	k/ft	k/ft	k/ft
	Ecc. from Beam CL		0.000 in

Point Loads Tab

You may apply up to eight point loads with dead, live, and short-term components. The Dist. value refers to the distance from the left support to where the point load is applied. To specify loads on the left cantilever, Dist. should be negative.

	General	Uniform Loads	Point Loads	Moments	Section Props
Point Loads...					
		<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	
#1		<input type="text" value="9.000"/>	<input type="text"/>	<input type="text"/>	k
	Eccentricity	<input type="text" value="6.000"/>	in	Location	<input type="text" value="3.000"/>
#2		<input type="text"/>	<input type="text"/>	<input type="text"/>	k
	Eccentricity	<input type="text" value="0.000"/>	in	Location	<input type="text" value="0.000"/>
#3		<input type="text"/>	<input type="text"/>	<input type="text"/>	k
	Eccentricity	<input type="text" value="0.000"/>	in	Location	<input type="text" value="0.000"/>
#4		<input type="text"/>	<input type="text"/>	<input type="text"/>	k
	Eccentricity	<input type="text" value="0.000"/>	in	Location	<input type="text" value="0.000"/>
#5		<input type="text"/>	<input type="text"/>	<input type="text"/>	k
	Eccentricity	<input type="text" value="0.000"/>	in	Location	<input type="text" value="0.000"/>
#6		<input type="text"/>	<input type="text"/>	<input type="text"/>	k
	Eccentricity	<input type="text" value="0.000"/>	in	Location	<input type="text" value="0.000"/>

Moments Tab

Up to eight moments with dead, live, and short-term components may be applied anywhere on the span. Moments with a positive sign impart a counterclockwise torque to the beam (following the right hand rule). The "Location" values refers to the distance from the left support to where the moment is applied. To specify loads on the left cantilever this value should be negative.

General	Uniform Loads	Point Loads	Moments	Section Props
Bending Moments...				
	<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	
#1 . .	<input type="text"/>	<input type="text"/>	<input type="text"/>	k-ft
		Location . . .	<input type="text" value="0.000"/>	ft
#2 . .	<input type="text"/>	<input type="text"/>	<input type="text"/>	k-ft
		Location . . .	<input type="text" value="0.000"/>	ft
Torsional Moments...				
#1 . .	<input type="text"/>	<input type="text"/>	<input type="text"/>	k-ft
		Location . . .	<input type="text" value="0.000"/>	ft
#2 . .	<input type="text"/>	<input type="text"/>	<input type="text"/>	k-ft
		Location . . .	<input type="text" value="0.000"/>	ft

Section Properties Tab

This secondary tab is where the steel section properties are listed. The properties shown here are used for the calculation.

General	Uniform Loads	Point Loads	Moments	Section Props
Steel Section		W18X60		
Section Properties...				
Depth	<input type="text" value="18.240"/>	in	Area	<input type="text" value="17.60"/> in ²
Web Thick	<input type="text" value="0.415"/>	in	I _{xx}	<input type="text" value="984.000"/> in ⁴
Flange Width	<input type="text" value="7.555"/>	in	I _{yy}	<input type="text" value="50.100"/> in ⁴
Flange Thick	<input type="text" value="0.695"/>	in	S _{xx}	<input type="text" value="107.895"/> in ³
			S _{yy}	<input type="text" value="13.263"/> in ³
Torsional Properties...				
Sw : 1	<input type="text" value="43.500"/>	in ⁴	Weight	<input type="text" value="59.78"/> #/ft
Sw : 2	<input type="text" value="0.000"/>	in ⁴	Q _f	<input type="text" value="21.766"/> #/ft
Sw : 3	<input type="text" value="0.000"/>	in ⁴	Q _w	<input type="text" value="60.790"/> #/ft
E _o	<input type="text" value="0.000"/>		J	<input type="text" value="2.240"/> in ⁴
W _{no}	<input type="text" value="33.138"/>	in ²	a	<input type="text" value="66.758"/> in
W _{n2}	<input type="text" value="0.000"/>	in ²	C _w	<input type="text" value="3,855.533"/> in ²
r _{xx}	<input type="text" value="7.477"/>	in	r _T	<input type="text" value="1.960"/> in
r _{yy}	<input type="text" value="1.687"/>	in		

The typical steel section measurements are given for the section chosen. When certain sections are used, the measurements will not conform to the typical W section naming conventions used here:

- For **Tubes**, Flange Thickness and Wall Thickness will both be set equal to the tube's wall thickness. r_T is not used.
- For **Pipe**, Flange Thickness and Wall Thickness both equal the pipe's wall thickness. Flange Width and Depth will both be set to the pipe's outside diameter. r_T is not used.
- For **Channels**, r_T equals the distance from the flat face to the center of gravity of the section.
- For **Tees**, r_T equals the distance from the top of the flange to the center of gravity of the section.
- For **Double Angles**, r_T equals the spacing between the backs of the angles.
- For **Single Angles**, r_T is not used.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information

on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results / Summary Tab

Beam OK	
Max Flange Bending Stress	22.79 ksi
Allowable	23.76 ksi
Flange Stress Ratio	0.959 : 1
Max Flange Shear Stress	10.66 ksi
Allowable	14.40 ksi
Flange Stress Ratio	0.740 : 1
Max. Deflection	0.080 in
Max. Rotation	0.05742 rad
Fa calc'd per Eq. E2-1, $K \cdot L_r < C_c$	
I Beam Passes Table B5.1, Fb per Eq. F1-1, $F_b = 0.66 F_y$	

Maximum Flange Bending Stress

This is the maximum flange bending stress (See Results/Details tab).

Maximum Flange Shear Stress

This is the maximum flange or web shear stress (See Results/Details tab).

Maximum Deflection

Center span deflection is the maximum magnitude (positive or negative) between the supports.

Maximum Rotation

Using the applied loads and their torsional eccentricities, the maximum rotation and its location from the left support is given.

Results / Details Tab

This section provides analysis results for various combinations of dead, live, and short term loads. Each column gives values for the combination listed at the top.

Results Sketch Diagrams Printing				
Summary Details				
Bending...	<u>DL</u>	<u>LL</u>	<u>DL + LL</u>	<u>DL+LL+ST</u>
Flange Bend + Warp	19.50	4.73	22.79	22.79 ksi
Allowable...	23.76	23.76	23.76	23.76 ksi
Stress Ratio.....	0.821	0.199	0.959	0.959
Shear...				
Flange Bend+Warp+Tors	8.73	1.93	10.66	10.66 ksi
Web Bend + Warp	6.61	1.49	8.10	8.10 ksi
Allowable...	14.40	14.40	14.40	14.40
Stress Ratio.....	0.607	0.134	0.740	0.740
Moments :				
Left				k-ft
Center	43.24	12.66	55.40	55.40 k-ft
Right				k-ft
Reactions :				
Left	14.70	3.37	18.07	18.07 k
Right	9.30	3.37	12.67	12.67 k
Deflections :				
....X-Dist to Max	0.062	0.018	0.080	0.080 in
....X-Dist to Max	7.20	7.50	7.20	7.20 ft
Rotations :				
....X-Dist to Max	0.046	0.012	0.057	0.057 rad
....X-Dist to Max	6.80	7.40	6.90	6.90 ft

Bending

This item gives stresses in the flange due to combined bending and torsional loads. The forces act parallel to the span of the beam, and are fb stresses to be compared with the allowable bending stress F'b. To determine the maximum value presented here, a stress diagram is internally constructed at 250 points along the beam and is then evaluated for maximum values.

Bending + Warping Bending stress is calculated by dividing the actual moment by section modulus. Warping torsional stress is calculated by $E_s * W_{no} * j''$ is calculated using the typical torsional equations found in the AISC reference, and varies along the span with torsional moment.

The allowable bending stress is evaluated considering beam slenderness.

Shear

This item gives shearing stresses in the flange and web due to the combined action of bending and torsional stresses.

Flange The flange shearing stresses have three components: bending, warping, and Torsional. Bending flange shear stresses are calculated using $(V * Q_f) / (I_{xx} * T_f)$.

Warping shear stress is calculates using $(E_s * S_w * j''') / T_f$. Torsional flange shear stress is calculated

using $(G \cdot T_f \cdot j')$.

Web The web shearing stresses have two components: bending and torsion. Bending web shear stresses are calculated using $(V \cdot Q_w) / (I_{xx} \cdot T_w)$. Torsional web shear stress is calculated using $(G \cdot T_w \cdot j')$.

The allowable shear stress = $0.4 F_y$.

Moments

M+ and M- are determined by checking 250 points along the span for maximum and minimum values.

Reactions

These are simply the left and right beam reactions due to the load combinations used.

Deflections


Center span deflection is the maximum magnitude (positive or negative) between the supports.

Rotations

Using the applied loads and their torsional eccentricities, the maximum rotation and its location from the left support is given.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Diagrams Tab

This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.



Results | Sketch | Diagrams | Printing

Graphic Diagram | Data Table

Location (ft)	Moment (kip-feet)	Shear (kips)	Deflection
0.0000	0.0000	18.0750	0.0000
0.1000	1.8002	17.9300	-0.0018
0.2000	3.5860	17.7850	-0.0036
0.3000	5.3572	17.6400	-0.0055
0.4000	7.1140	17.4950	-0.0073
0.5000	8.8562	17.3500	-0.0091
0.6000	10.5840	17.2050	-0.0109
0.7000	12.2972	17.0600	-0.0127
0.8000	13.9960	16.9150	-0.0145
0.9000	15.6802	16.7700	-0.0163
1.0000	17.3500	16.6250	-0.0181
1.1000	19.0052	16.4800	-0.0198
1.2000	20.6460	16.3350	-0.0216
1.3000	22.2722	16.1900	-0.0233
1.4000	23.8840	16.0450	-0.0250
1.5000	25.4812	15.9000	-0.0268
1.6000	27.0640	15.7550	-0.0284
1.7000	28.6322	15.6100	-0.0301
1.8000	30.1860	15.4650	-0.0318
1.9000	31.7252	15.3200	-0.0334
2.0000	33.2500	15.1750	-0.0351
2.1000	34.7602	15.0300	-0.0367
2.2000	36.2560	14.8850	-0.0382

Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Results | Sketch | Diagrams | Printing |

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Uniform Loads	<input checked="" type="checkbox"/>
Bending Moments	<input checked="" type="checkbox"/>
Torsional Moments	<input checked="" type="checkbox"/>
Point Loads	<input checked="" type="checkbox"/>
Summary	<input checked="" type="checkbox"/>
AISC Check Messages	<input checked="" type="checkbox"/>
Summary Analysis	<input checked="" type="checkbox"/>
Section Properties	<input checked="" type="checkbox"/>

Note: When all are selected, the software will still omit unused section

Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949.645.0151
 www.enercalc.com

Title: ENERCALC Example Problems Job #97-00001
 Dsgnr: MDB Date: 3:30PM, 26 OCT 03
 Description: Collection of example problems

Scope: All programs in the Structural Engineering Library

Rev: 06000
 User: MW-050001, Ver: 5.00, 10-Sep-2003
 ©1983-2003 ENERCALC Engineering Software

Steel Beam w/ Torsional Loads

Page 1

c:\e\example\ex03\SteelCalc

Description Single offset point load @ mid-span

General Information

Code Ref AISC 9th ASD, 1997 UBC, 2003 IBC, 2003 NFPA 5000

Steel Section	W12X40	Fy	36.00 ksi
Beam Span	15.00 ft	Load Duration Factor	1.00
Torsional End Fixity	Pin-Pin	Beam Vlt. Ignored	
Bending End Fixity	Pin-Pin	Unbraced Length	0.00 ft
		Elastic Modulus	29,000.00 ksi

Point Loads

#	Dead Load	Live Load	Short Term	Eccentricity	Location
# 1	9.000		k	6.000 in	3.000 ft

Summary

Beam OK

Using W12X40, Span = 15.00ft, Fy = 36.0ksi, End Fixity: Bending= Pinned-Pinned, Torsion= Pinned-Pinned

Max Flange Bending Stress	23.54 ksi	Allowable	23.76 ksi	Flange Stress Ratio	0.991 : 1	Max. Deflection	0.070 in
Max Flange Shear Stress	8.76 ksi	Allowable	14.40 ksi	Flange Stress Ratio	0.608 : 1	Max. Rotation	0.05204 rad

Summary Analysis

	Dead	Live	DL + LL	DL + LL + Short Term
Flange Bend + Warp	23.54 ksi		23.54 ksi	23.54 ksi
Allowable...	23.76 ksi	23.76 ksi	23.76 ksi	23.76 ksi
Stress Ratio.....	0.991 : 1	: 1	0.991 : 1	0.991 : 1
Flange Bend+Warp+Tors	8.76 ksi		8.76 ksi	8.76 ksi
Web Bend + Warp	6.36 ksi		6.36 ksi	6.36 ksi
Allowable...	14.40 ksi	14.40 ksi	14.40 ksi	14.40 ksi
Stress Ratio.....	0.608 : 1	: 1	0.608 : 1	0.608 : 1
Moments				
Left	k-ft	k-ft	k-ft	k-ft
Center	21.60 k-ft	k-ft	21.60 k-ft	21.60 k-ft
Right	k-ft	k-ft	k-ft	k-ft
Reactions				
Left	7.20 k	k	7.20 k	7.20 k
Right	1.80 k	k	1.80 k	1.80 k
Deflections				
....X-Dist to maximum	0.070 in	in	0.070 in	0.070 in
	6.50 ft	15.00 ft	6.50 ft	6.50 ft
Rotations				
....X-Dist to maximum	0.052 rad	rad	0.052 rad	0.052 rad
	5.90 ft	ft	5.90 ft	5.90 ft

Fa calc'd per Eq. E2-1, $K'Lf < C_c$
 Beam Passes Table B6.1, Fb per Eq. F1-1, $F_b = 0.66 F_y$

Section Properties

Section Name	W12X40	Sw: 1	23.565in4	Weight	40.081 #/ft
Depth	11.940 in	Sw: 2	0.000in4	rT	2.1400 in
Web Thick	0.295 in	Sw: 3	0.000in4	rxx	5.1255 in
Flange Width	8.005 in	Qf	11.341	ryy	1.9332 in
Flange Thick	0.515 in	Qw	27.939		
Area	11.800 in2	J	0.877in4		
Ixx	310.000in4	Ep	0.000		
Iyy	44.100in4	Wno	22.864in2		
Sxx	51.925in3	Wn2	0.000in2		
Syy	11.018in3	Cw	1,439.100		
		a	65.199in		

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 3:30PM, 26 OCT 03
 Description : Collection of example problems

Scope : All programs in the Structural Engineering Library

Rev: 580000
 User: KVV-0600001, Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software


Steel Beam w/ Torsional Loads

Page 2

c:\ec5\examples\ecw\Steel Calc5

Description Single offset point load @ mid-span

Sketch & Diagram



4.4 Steel Column

This program can analyze or design a standard AISC steel section subjected to axial loads and simultaneous bending moments about each axis. A variety of factors can be specified which effect the AISC code stress analysis of the beam. Unbraced compression flange lengths, minor axis bending, primary or secondary member status, and load duration factors can all be modified for the beam you are analyzing or designing.

Fixed and pinned supports can be used at either end, allowing analysis for the following types: Fix/Fix, Pin/Pin, Fix/Pin, Pin/Fix, or Fix/Free.

Axial dead, live, and short term loads may be applied to the column at eccentricities for both axes. Also, concentrated moments, point loads, and distributed loads can be applied to the column as beam-type loads, causing moments about the X-X and Y-Y axis from dead, live, and short term components .

To help you specify AISC sections to be analyzed, an internal database system gives you access to over 4,000 sections from the 6th, 7th, 8th, and 9th edition AISC handbooks. Data for these sections was acquired from many published sources, and represents the

only standard rolled sections economically available to constructors in the United States.

You can either type in a section and have its properties automatically recalled, or display a window to scroll through the database of sections. Sections available include W, H, S, M, C, MC, B, JR, TS, P, WT, ST, MT, L, and LL.

A comprehensive analysis procedure provides moments and maximum and allowable axial and bending stresses. A very thorough AISC code check procedure determines allowable bending stresses for all members, considering compact section criteria and lateral buckling due to slenderness effects.

Steel Column

Tools & Settings | ? Help | Design | Print | Cancel | Save

General | Point & Dist. Loads | Moments | Section Properties | Summary | Details | Sketch | Printing

Description: Axial Load w/ X & Y Eccentricities

Column Height: 16.500 ft

Distance between bracing preventing deflection along Axis.....

X-X Unbraced: 24.000 ft

Y-Y Unbraced: 18.500 ft

X-X Sidesway: Restrained Free to Sway

Y-Y Sidesway: Restrained Free to Sway

Kxx: 1.000

Kyy: 1.000

End Fixities: Pin-Pin Pin-Fix Fix-Free Fix-Fix Fix-Pin

Steel Section: W14X159

Fy: 36.0 ksi

Include Live w/ Short Term Loads:

Load Duration Factor: 1.330

Elastic Modulus: 29,000.0 ksi

Column Design OK

Combined Stress Ratios

	Dead Load	Live Load	Dead + Live	DL + Short
AISC Formula H1 - 1				
AISC Formula H1 - 2				
AISC Formula H1 - 3	0.5793	0.3499	0.9083	0.4356

Axial & Bending Stresses...

	Dead	Live	DL + LL	DL + Short
Fa: Allowable	16.226	16.226	16.226	21.580
fa: Actual	1.394	0.916	2.310	1.394
Fbx: Allow [F1-6]	21.600	21.600	21.600	28.728
Fbx: Allow [F1-7] & [F1-8]	21.600	21.600	21.600	28.728
fb: xx Actual	3.058	1.350	4.201	3.058
Fby: Allow [F1-6]	27.000	27.000	27.000	35.910
Fby: Allow [F1-7] & [F1-8]	27.000	27.000	27.000	35.910
fb: yy Actual	9.599	6.234	15.717	9.599

Stress Check Comments...

XX Axis: Fa calc'd per Eq. E2-1, $K^2 L^2 < C_c$

XX Axis: I Beam, Major Axis, $(102,000 * C_b / F_y)^{1.5} <= L_r T <= (510,000 * C_b / F_y)^{1.5}$

XX Axis: I Beam, Major Axis, Fb per Eq. F1-8, $F_b = 12,000 * C_b A_f / (l * d)$

YY Axis: Fa calc'd per Eq. E2-1, $K^2 L^2 < C_c$

YY Axis: I Beam, Minor Axis, Passes Table B5.1, $F_b = 0.75 F_y$ per Eq. F2-1

Basic Usage

- From the actual span condition of the column, enter the total column height to be used for slenderness and moment calculations. By entering 1, 2, 3, 4, or 5 you can easily specify a variety of support conditions. However, this fixity is assumed about BOTH AXES. At one end of the column, you can't have Y-Y bending fixed while allowing X-X axis rotation. You will also need to specify the unbraced lengths to be used for calculating bending and axial stresses.
- When you are using condition 5", Fix/Free, the bottom of the column is considered fixed.
- The X-X axis is always considered the major axis. Entering Y-Y axis loads, moments,

and axial eccentricity will generate minor axis bending.

- Sidesway indicates whether the column is free to deflect in the direction of the Y-Y or X-X axis. Sidesway effects the internal calculation of C_m . Effective length factors will be applied to the unbraced lengths to determine actual lengths for determining allowable axial stress (but not for determining allowable bending stress).
- This program provides plenty of load capability for loading any part of the column. Axial dead, live, and short term loads can be applied with an eccentricity on each axis, resulting in concentrated moments being applied to the top of the column along with the axial load. Those moments will be combined with the applied loads about each axis to determine total combined stresses. The tabular load entry area allows you to specify point loads, moments, and uniform loads to the column, with each having dead, live, and short term components. All Dist. values position the load with respect to the Bottom of the column.
- Section Properties can be entered by using the built-in section property databases. Please see the following two sections on using this capability.
- Reviewing Forces and Stresses. In the Summary section of the worksheet, the results of AISC stress combination equations H1-1, H1-2, and H1-3 will be listed. Also, actual and allowable axial and bending stresses are given.

Unique Features

As mentioned earlier, the user can either have a column automatically selected using your design criteria, or specify a section to be analyzed.

You can specify bending loads on the column in addition to the axial loads, and all loads can have dead, live, and short term components.

Any W, H, S, M, B, JR, C, MC, TS, P, WT, ST, MT, L, or LL sections listed in the databases will have a thorough AISC code working stress analysis performed, including checks for lateral buckling and compactness for all provisions including appendix C.

Assumptions & Limitations

The unbraced lengths used for axial stress slenderness and lateral torsional buckling calculations are considered to be the same.

Steel Section Database

Built into the software is a complete database of common rolled sections available from various mills in the United States. On each tab labeled #1, #2, etc. there will be a button that looks like this:



Steel Section

This button displays the steel section database as shown below.

Steel Section Database

Section Type to Display

W HP JR C **TS** HSS-T L WT
 S M B MC P HSS-P LL MT
 WF BP JRC ST

Steel Database

AISC 9th AISC 8th AISC 7th AISC 6th Korean

Name | Area | Depth | Width | Sx | Ix | Sy | Iy | J | Section Count : 71

Section Name	Area in ²	Depth in	Wall Thickness in	Ixx in ⁴	Sxx in ³	Rxx in	Zx in ³
TS2x2x3/16	1.270	2.000	0.188	0.668	0.668	0.726	0.8
TS2x2x1/4	1.590	2.000	0.250	0.766	0.766	0.694	1.0
TS2x2x5/26	1.860	2.000	0.313	0.880	0.880	0.690	1.1
TS2.5x2.5x3/16	1.640	2.500	0.188	1.420	1.140	0.930	1.4
TS2.5x2.5x1/4	2.090	2.500	0.250	1.690	1.350	0.899	1.7
TS2.5x2.5x5/16	3.110	2.500	0.313	3.580	2.390	1.070	1.9
TS3x3x3/16	2.020	3.000	0.188	2.600	1.730	1.130	2.1
TS3x3x1/4	2.590	3.000	0.250	3.160	2.100	1.100	2.6
TS3x3x5/16	3.110	3.000	0.313	3.580	2.390	1.070	3.0
TS3.5x3.5x3/16	2.390	3.500	0.188	4.290	2.450	1.340	2.9
TS3.5x3.5x1/4	3.090	3.500	0.250	5.290	3.020	1.310	3.7
TS3.5x3.5x5/16	3.730	3.500	0.313	6.090	3.480	1.280	4.3
TS4x4x3/16	2.770	4.000	0.188	6.590	3.300	1.540	3.9
TS4x4x1/4	3.590	4.000	0.250	8.220	4.110	1.510	4.9
TS4x4x5/16	4.360	4.000	0.313	9.580	4.790	1.480	5.9
TS4x4x3/8	5.080	4.000	0.375	10.700	5.350	1.450	6.7
TS4x4x1/2	6.360	4.000	0.500	12.300	6.130	1.390	8.0
TS4.5x4.5x3/16	3.140	4.500	0.188	9.600	4.270	1.750	5.0
TS4.5x4.5x1/4	4.090	4.500	0.250	12.100	5.360	1.720	6.4
TS5x5x3/16	3.520	5.000	0.188	13.400	5.360	1.950	6.2
TS5x5x1/4	4.590	5.000	0.250	16.900	6.780	1.920	8.0
TS5x5x5/16	5.610	5.000	0.313	20.100	8.020	1.890	9.7
TS5.5x5.5x1/4	6.590	5.000	0.375	23.000	9.110	1.860	11.6

Depth Range : Class Range :

On this window there are various controls and options.....

Steel Database : Allows you to select between several common shapes databases.

Section Type to Display: Allows you to select which steel section designation to display in the list. These shapes conform to the American Institute of Steel Construction shape designations. To make your selection simply move the mouse over the letter(s) and when the highlight activates left-click once with your left mouse button.

Depth Range: This item allows you to specify depth limits to be used for selecting which sections to display in the list. When the checkbox to the left is not checked the selection wording and entries will not appear and all sections will be displayed. These dimensions are compared to the "Depth" dimension of the sections.

Class Range : This item allows you to specify the limits in "Depth Class" to be displayed in the table. The "Depth Class" of a section is the first numeric number in the sections name. For instance a wide flange W14x22 is in depth class "14". a channel C9x15 is in depth class "9", and a L5x3x1/4 is in depth class "5".

Equal & Unequal Legs : These two buttons appear when you have selected section type "L" which are single angles. The limit the display of the list to angle with equal dimension or unequal dimension sides.

Equal Legs, Long Leg Vertical, Short Leg Vertical: These three buttons appear when you have chosen to display section type "LL". These control the display of sections between pairs of angles with both sides of equal length, of unequal side length angles paired with the LONG side together, and unequal side length angles paired with the SHORTside together.

Square & Rectangular Tubes: These two buttons appear when you have chosen section types TS or

HSS-T. These are square tubular sections. You can choose to display only square tubes or alternately tubes with unequal sides.

Sort Tabs for Database Table : Immediate above the database list of sections you will see tabs looking like this....

When selected each tab will sort the list in the order described by the text on that tab.

Sort order : These two buttons allow you to choose the list order of the sections. The sorting order will be according to the sort tab selected and shall be in ascending or descending order.

Database Table Itself : The main area on the window will be where the steel sections are displayed as a result of all of your choices as described above.

[Select] : This button is displayed when you have clicked on the **[Section]** button when you press [Select] the section in the list that is currently highlighted will be selected and the name and data brought into your calculation.

[Insert]: Use this button to add a steel section to the database. When pressed you will see the following window:

The screenshot shows a dialog box titled "New Steel Section Data Entry". It contains the following fields and controls:

- Section Name:
- Type:
- Depth Class:
- AISC Handbook Edition:
- Area: in²
- Ixx: in⁴
- Depth: in
- Iyy: in⁴
- Flange Width: in
- Flange Thickness: in
- Web Thickness: in
- Xcg: in
- Ycg: in
- Buttons: and

The only really important item to enter is the "Type" item. This specifies what standard rolled section type your section is. This item is used internally by the program to decide which stress analysis method to use for determining the sections allowable stress, how to consider unstiffened elements, and many other code checking items.

[Change]: Will display the same window as above but allow you to change section properties.

[Delete] : Will enable you to delete sections. Note: No sections in the supplied database can be deleted. Only Sections that you ad can be later deleted.

[Cancel]: Exit the steel database window.

ASD & LRFD Design Modes

Allowable Stress Design and **Load & Resistance Factor Design** as specified by the American Institute of Steel Construction is provided by this program. Only screen captures and descriptions for ASD are presented in this book. More detailed LRFD documentation will be added and will be available in the electronically delivered versions of this book. Check these locations for electronic media:

- Latest Adobe Acrobat PDF documentation file here:
<ftp://208.36.30.226/sel5.pdf>.
- Latest Windows Help system file here : <ftp://208.36.30.226/enercalc.hlp>.
- Internet HTML help documentation presented as web pages at
www.enercalc.com/sel_help.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

This tab provides the data entry for all items in the calculation except loadings.

General	Point & Dist. Loads	Moments	Section Properties
Description Axial Load w/ X & Y Eccentricities			
Column Height		16.500	ft
Distance between bracing preventing deflection along Axis.....			
X-X Unbraced		24.000	ft
Y-Y Unbraced		18.500	ft
X-X Sidesway	<input checked="" type="radio"/> Restrained	<input type="radio"/> Free to Sway	
Y-Y Sidesway	<input checked="" type="radio"/> Restrained	<input type="radio"/> Free to Sway	
K _{xx}		1.000	
K _{yy}		1.000	
End Fixities			
<input checked="" type="radio"/> Pin-Pin	<input type="radio"/> Pin-Fix	<input type="radio"/> Fix-Free	<input type="radio"/> Fix-Fix <input type="radio"/> Fix-Pin
Steel Section		W14X159	
F _y		36.0	ksi
Include Live w/ Short Term Loads ...		<input type="checkbox"/>	
Load Duration Factor		1.330	
Elastic Modulus		29,000.0	ksi

Column Height

The total column height is used to calculate moments applied to the column as Applied Loads.

Distance between bracing preventing deflection along Axis

This is the actual unbraced length of the column with respect to the X-X and Y-Y axis. This unbraced length will be multiplied by the effective length factor to determine the overall slenderness of the column about each axis.

The "X-X Unbraced" length entry specifies the distance between elements that are bracing the column against movement along its local X-X axis. For wide flange beams this is parallel to the flanges. Similar definition holds for bracing lengths for the Y-Y axis movement.

Sidesway Status

Indicate whether or not the column is subject to sidesway. Enter a 1" if sidesway will be restrained, 0" if it will not. Sidesway is used for determining CM.

K_{xx} & K_{yy} Values

This effective length factor should be evaluated by the user according to the actual conditions present

or anticipated. Reference is made to Table C1.8.1 and Figure C1.8.2 of the 1989 AISC specification and other sources on structural stability. These factors will modify the Unbraced Length value to determine the actual unbraced length to be used in the analysis.

End Fixities

The steel column can have any of five different end fixity combinations; Fix/Fix, Pin/Pin, Fix/Pin, Pin/Fix, or Fix/Free. These refer to the bottom and top column ends respectively. However, the end fixities apply to BOTH X-X and Y-Y axes.

If you are designing a column with end moments calculated from another program (e.g. FastFrame), set the support fixity to Pin/Pin and enter the end moments as Top and Bottom moments. DO NOT USE FIXED/FIXED support condition.

For all the end fixity combinations, remember the order is Bottom/Top. For example, Fix/Pin = Fixed @ Bottom and Pinned @ Top.

Steel Section

This is where you specify the rolled steel section to be used in the design. There are two ways to enter & specify the section.

- Use the [Section] button to retrieve the section from the built-in steel database. See the description given previously for more information.
- Type in the section name and the program will automatically look through the database for a match. Upper or lower case is fine. If found the name and numeric section properties will be retrieved into this calculation. The numeric properties will be seen on the "Section Properties" tab.

Fy

Yield Strength Indicates the yield strength of the steel section.

Include Live Load w/ Short Term Loads ?

Typically when short-term loads are from seismic events, the live load is not used. This YES/NO entry specifies whether your live loads will be used with short-term loads.

Load Duration Factor

Load duration factor is applied to the calculated allowable stresses and displayed as Allowable Stress in the Summary section.

Elastic Modulus

Although rarely does this need to be changed, enter the elastic modulus of the steel material.

Point & Distributed Loads Tab

General	Point & Dist. Loads	Moments	Section Properties
Axial Load...			
Dead	<input type="text" value="65.100"/>	k	
Live	<input type="text" value="42.800"/>	k	
Short Term	<input type="text"/>	k	
		Axial Eccentricity...	
		X-X Moments	<input type="text" value="8.000"/> in
		Y-Y Moments	<input type="text" value="14.000"/> in
Point lateral Loads...			
Along Y-Y (x-x moments)			
<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	<u>Height</u>
<input type="text" value="1.000"/> k	<input type="text"/>	<input type="text"/>	<input type="text" value="2.000"/> ft
Along X-X (y-y moments)			
<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	<u>Height</u>
<input type="text" value="1.000"/> k	<input type="text"/>	<input type="text"/>	<input type="text" value="16.000"/> ft
Distributed lateral Loads...			
Along Y-Y (x-x moments)			
<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	
<input type="text" value="1.000"/> k/ft	<input type="text"/>	<input type="text"/>	
	<u>Start</u>	<u>End</u>	
	<input type="text" value="5.000"/> ft	<input type="text" value="12.000"/> ft	
Along X-X (y-y moments)			
<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>	
<input type="text" value="2.000"/> k/ft	<input type="text"/>	<input type="text"/>	
	<u>Start</u>	<u>End</u>	
	<input type="text" value="12.000"/> ft	<input type="text" value="15.000"/> ft	

Axial Loads

Specify your the axial loads acting on the column. Positive values apply compression to the column.

Axial Eccentricity

Enter the eccentricity from the geometric center of the column to the location where the axial load is applied if you want to consider the effect of axial load induced moments in your design.

Point Lateral Loads

Using these entries you can apply lateral loads between the endpoints of the column. Loads applied "Along Y-Y" are applied parallel to the Y-Y axis of the steel section. For a wide flange section this is parallel to the web.

The "Height" location of the application of the point load is measured with respect to the bottom of the column. **Note! Be careful if you are using "Fixed" column ends NOT to apply point loads at a 0.0 or Column Height location.....they will not act on the column and simply be taken by the end rigid supports.**

Distributed Lateral Loads

Using these entries you can apply uniform lateral loads between the endpoints of the column. Loads applied "Along Y-Y" are applied parallel to the Y-Y axis of the steel section. For a wide flange section this is parallel to the web.

The "Start" and "End" Locations are entered as the distances from the column base,

Moments Tab

These entries allow you to specify applied moments at the top, bottom, or between the ends of the column. When entering a moment between the ends enter the "Distance above base" as the distance above what you are considering the bottom of the column. The important thing is that the distances you enter for all applied loads uses the same end of the column as the reference.

Note: Do not apply a moment to a "fixed" end of the column. You are just applying the load to a rigid end and none of the moment will create bending in the column.

General	Point & Dist. Loads	Moments	Section Properties
Applied Moments...			
X-X Axis Moments			
	<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>
At TOP	<input type="text" value="12.00"/>	<input type="text"/>	<input type="text"/>
			k-ft
Btwn. Ends	<input type="text" value="12.00"/>	<input type="text"/>	<input type="text"/>
			k-ft
	Distance above base		<input type="text" value="14.000"/>
			\$\$\$
At BOTTOM	<input type="text" value="12.00"/>	<input type="text"/>	<input type="text"/>
			k-ft
Y-Y Axis Moments			
	<u>Dead Load</u>	<u>Live Load</u>	<u>Short Term</u>
At TOP	<input type="text"/>	<input type="text"/>	<input type="text"/>
			k-ft
Btwn. Ends	<input type="text"/>	<input type="text"/>	<input type="text"/>
			k-ft
	Distance above base		<input type="text" value="0.000"/>
			ft
At BOTTOM	<input type="text"/>	<input type="text"/>	<input type="text"/>
			k-ft

Section Properties Tab

This secondary tab is where the steel section properties are listed. The properties shown here are used for the calculation.

General		Point & Dist. Loads		Moments		Section Properties	
Steel Section		W14X159					
Depth	<input type="text" value="14.980"/>	in	Weight	<input type="text" value="158.63"/>	#/ft		
Web Thick	<input type="text" value="0.745"/>	in	I _x	<input type="text" value="1,900.000"/>	in ⁴		
Width	<input type="text" value="15.565"/>	in	I _y	<input type="text" value="748.000"/>	in ⁴		
Flange Thick	<input type="text" value="1.190"/>	in	S _x	<input type="text" value="253.672"/>	in ³		
Area	<input type="text" value="46.70"/>	in ²	S _y	<input type="text" value="96.113"/>	in ³		
R _t	<input type="text" value="4.300"/>	in	r _x	<input type="text" value="6.378"/>	in		
			r _y	<input type="text" value="4.002"/>	in		

The typical steel section measurements are given for the section chosen. When certain sections are used, the measurements will not conform to the typical W section naming conventions used here:

- For **Tubes**, Flange Thickness and Wall Thickness will both be set equal to the tube's wall thickness. r_T is not used.
- For **Pipe**, Flange Thickness and Wall Thickness both equal the pipe's wall thickness. Flange Width and Depth will both be set to the pipe's outside diameter. r_T is not used.
- For **Channels**, r_T equals the distance from the flat face to the center of gravity of the section.
- For **Tees**, r_T equals the distance from the top of the flange to the center of gravity of the section.
- For **Double Angles**, r_T equals the spacing between the backs of the angles.
- For Single Angles, r_T is not used.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Summary Tab

The summary area provides results of combining all generated moments about both axes with axial load stresses. The three AISC interaction equations indicate the state of combined stresses within the column.

- Formula H1-1 The result of applying the values calculated in the following section to AISC interaction formula H1-1.
- Formula H1-2 The result of applying the values calculated in the following section to AISC interaction formula H1-2.
- Formula H1-3 This is the result of applying the values calculated in the following section to AISC interaction formula H1-13, and is only used for column selection if $f_a/F_y \leq 0.15$. When

f_a/F_a exceeds 0.15, this value will be displayed as N/A.

Summary	Details	Sketch	Printing	
Column Design OK				
Combined Stress Ratios				
	<u>Dead Load</u>	<u>Live Load</u>	<u>Dead + Live</u>	<u>DL + Short</u>
AISC Formula H1 - 1				
AISC Formula H1 - 2				
AISC Formula H1 - 3	0.5793	0.3499	0.9083	0.4356
Axial & Bending Stresses...				
	<u>Dead</u>	<u>Live</u>	<u>DL + LL</u>	<u>DL + Short</u>
Fa : Allowable	16.226	16.226	16.226	21.580 ksi
fa : Actual	1.394	0.916	2.310	1.394 ksi
Fb _{xx} : Allow [F1-6]	21.600	21.600	21.600	28.728 ksi
Fb _{xx} : Allow [F1-7] & [F1-8]	21.600	21.600	21.600	28.728 ksi
fb : xx Actual	3.058	1.350	4.201	3.058 ksi
Fb _{yy} : Allow [F1-6]	27.000	27.000	27.000	35.910 ksi
Fb _{yy} : Allow [F1-7] & [F1-8]	27.000	27.000	27.000	35.910 ksi
fb : yy Actual	9.599	6.234	15.717	9.599 ksi
Stress Check Comments....				
XX Axis : Fa calc'd per Eq. E2-1, $K^*Lr < Cc$				
XX Axis : I Beam, Major Axis, $(102,000 * Cb / Fy)^{.5} \leq LrT \leq (510,000 * Cb / Fy)^{.5}$				
XX Axis : I Beam, Major Axis, Fb per Eq. F1-8, $Fb = 12,000 Cb Af / (l * d)$				
YY Axis : Fa calc'd per Eq. E2-1, $K^*Lr < Cc$				
YY Axis : I Beam, Minor Axis, Passes Table B5.1, $Fb = 0.75 Fy$ per Eq. F2-1				

Axial & Bending Stresses

This table presents the results for different combinations of loadings on the column and their resulting calculated actual and allowable stresses.

Stress Check Comments

In this section, various messages will be displayed indicating what factors governed the calculation of allowable bending stress. The internal AISC code checking system can evaluate allowable stresses for all members EXCEPT SINGLE AND DOUBLE ANGLES. Although the program will calculate actual bending stresses, THE DESIGNER MUST DETERMINE IF THE BENDING IS VALID DUE TO THE UNEQUAL CROSS PRODUCT NATURE OF THE SECTION.

Details Tab

This tab present more details of the intermediate values calculated for the analysis of the


allowable axial and bending stresses for the column.

Also given is the lateral deflections of the column for each axis as a result of applied lateral loads and a moment applied from an eccentric axial load.

Summary	Details	Sketch	Printing
F'ex : DL+LL	123,277.0 psi	F'ex : DL+LL+ST	163,958.4 psi
F'ey : DL+LL	28,837.1 psi	F'ey : DL+LL+ST	38,353.3 psi
Cm:x DL+LL	1.00	Cb:x DL+LL	1.00
Cm:y DL+LL	1.00	Cb:y DL+LL	1.00
Cm:x DL+LL+ST	1.00	Cb:x DL+LL+ST	1.00
Cm:y DL+LL+ST	1.00	Cb:y DL+LL+ST	1.00
Max X-X Axis Deflection	-0.065 in	at	9.240 ft
Max Y-Y Axis Deflection	-0.199 in	at	9.460 ft
Stress Check Comments....			
XX Axis : Fa calc'd per Eq. E2-1, $K^*L/r < C_c$			
XX Axis : I Beam, Major Axis, $(102,000 * C_b / F_y)^{.5} \leq L/r \leq (510,000 * C_b / F_y)^{.5}$			
XX Axis : I Beam, Major Axis, Fb per Eq. F1-8, $F_b = 12,000 C_b A_f / (l * d)$			
YY Axis : Fa calc'd per Eq. E2-1, $K^*L/r < C_c$			
YY Axis : I Beam, Minor Axis, Passes Table B5.1, $F_b = 0.75 F_y$ per Eq. F2-1			

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".

Summary | Details | Sketch | Printing

Please select printout sections to be printed...

General Information	<input checked="" type="checkbox"/>
Axial Loads	<input checked="" type="checkbox"/>
Lateral Point Loads	<input checked="" type="checkbox"/>
Lateral Uniform Loads	<input checked="" type="checkbox"/>
Applied Moments	<input checked="" type="checkbox"/>
Summary	<input checked="" type="checkbox"/>
AISC Check Messages	<input checked="" type="checkbox"/>
Stresses Components	<input checked="" type="checkbox"/>
Analysis Values	<input checked="" type="checkbox"/>
Section Properties	<input checked="" type="checkbox"/>

Note: When all are selected, the software will still omit unused sections

Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 4:33PM, 26 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 590000
 User: RW-0500001, Ver: 6.6.0, 10-06-2003
 ©1983-2003 ENERCALC Engineering Software

Steel Column

Page 1

c:\c65\examples\Steel Col

Description Axial Load w/ X & Y Eccentricities

General Information

Code Ref: AISC 9th ASD, 1997 UBC, 2003 IBC, 2003 NFPA 5000

Steel Section	W14X159	Fy	36.00 ksi	X-X Sidesway:	Restrained
Column Height	16.500 ft	Duration Factor	1.330	Y-Y Sidesway:	Restrained
End Fixity	Pin-Pin	Elastic Modulus	29,000.00 ksi	Kxx	1.000
Live & Short Term Loads Not Combined		X-X Unbraced	24.000 ft	Kyy	1.000
		Y-Y Unbraced	18.500 ft		

Loads

Axial Load...						
Dead Load	65.10 k	Ecc. for X-X Axis Moments	8.000 in			
Live Load	42.80 k	Ecc. for Y-Y Axis Moments	14.000 in			
Short Term Load	k					
Point lateral Loads...						
	<u>DL</u>	<u>LL</u>	<u>ST</u>	<u>Height</u>		
Along Y-Y (strong axis moments)	1.000		k	2.000 ft		
Along X-X (y moments)	1.000		k	16.000 ft		
Distributed lateral Loads...						
	<u>DL</u>	<u>LL</u>	<u>ST</u>	<u>Start</u>	<u>End</u>	
Along Y-Y	1.000		k/ft	5.000 -->	12.000 ft	
Along X-X	2.000		k/ft	12.000 -->	15.000 ft	

Applied Moments

X-X Axis Moments	<u>DL</u>	<u>LL</u>	<u>ST</u>	<u>Height</u>
At TOP	12.00		k-ft	14.000 ft
Between Ends	12.00		k-ft	
At BOTTOM	12.00		k-ft	

Summary

Column Design OK

Section: W14X159, Height = 16.50ft, Axial Loads: DL = 65.10, LL = 42.80, ST = 0.00k, Ecc. = 8.000in
 Unbraced Lengths: X-X = 18.50ft, Y-Y = 24.00ft

Combined Stress Ratios	<u>Dead</u>	<u>Live</u>	<u>DL + LL</u>	<u>DL + ST + (LL if Chosen)</u>
AISC Formula H1 - 1				
AISC Formula H1 - 2				
AISC Formula H1 - 3	0.5793	0.3499	0.9083	0.4356

XX Axis: Fa calc'd per Eq. E2-1, $K'L/r < C_c$ XX Axis: I Beam, Major Axis, $(102,000 * C_b / F_y)^{0.5} <= L/r <= (510,000 * C_b / F_y)^{0.5}$, Fb per Eq. F1-6XX Axis: I Beam, Major Axis, Fb per Eq. F1-8, $F_b = 12,000 C_b A_f / (l * d)$ YY Axis: Fa calc'd per Eq. E2-1, $K'L/r < C_c$ YY Axis: I Beam, Minor Axis, Passes Table B5.1, $F_b = 0.75 F_y$ per Eq. F2-1

Stresses

Allowable & Actual Stresses	<u>Dead</u>	<u>Live</u>	<u>DL + LL</u>	<u>DL + Short</u>
Fa : Allowable	16.23 ksi	16.23 ksi	16.23 ksi	21.58 ksi
fa : Actual	1.39 ksi	0.92 ksi	2.31 ksi	1.39 ksi
Fbxx : Allow[F1-6]	21.60 ksi	21.60 ksi	21.60 ksi	28.73 ksi
Fbxx : Allow[F1-7] & [F1-8]	21.60 ksi	21.60 ksi	21.60 ksi	28.73 ksi
fb : xx Actual	3.06 ksi	1.35 ksi	4.20 ksi	3.06 ksi
Fbyy : Allow[F1-6]	27.00 ksi	27.00 ksi	27.00 ksi	35.91 ksi
Fbyy : Allow[F1-7] & [F1-8]	27.00 ksi	27.00 ksi	27.00 ksi	35.91 ksi
fb : yy Actual	9.60 ksi	6.23 ksi	15.72 ksi	9.60 ksi

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems **Job #** 97-000001
Design: MDB **Date:** 4:33PM, 26 OCT 03
Description: Collection of example problems
Scope: All programs in the Structural Engineering Library


Rev: 880000
 User: HW-060001, Ver: 5.80, 10-Sep-2003
 © 1983-2003 ENERCALC Engineering Software Steel Column Page 2

Description Axial Load w/ X & Y Eccentricities

Analysis Values					
Flex: DL+LL	123.277 psi	Com:x DL+LL	1.00	Cb:x DL+LL	1.00
Flex: DL+LL	28.837 psi	Com:y DL+LL	1.00	Cb:y DL+LL	1.00
Flex: DL+LL+ST	163.958 psi	Com:x DL+LL+ST	1.00	Cb:x DL+LL+ST	1.00
Flex: DL+LL+ST	38.353 psi	Com:y DL+LL+ST	1.00	Cb:y DL+LL+ST	1.00
Max X-X Axis Deflection	-0.065 in at	9.240 ft	Max Y-Y Axis Deflection	-0.199 in at	9.460 ft

Section Properties W14X159					
Depth	14.98 in	Weight	158.63 #/ft	I-xx	1,900.00 in4
r_{x-min}	15.565 in	Area	46.70 in2	I-yy	748.00 in4
Web Thick	0.745 in	Rt	4.300 in	S-xx	253.672 in3
Flange Thickness	1.190 in			S-yy	96.113 in3
				r-xx	6.378 in
				r-yy	4.002 in

Sketch & Diagram



4.5 Composite Steel Beam

This program provides design and analysis of AISC steel sections acting compositely with a concrete slab interlocked along its compression flange. Factors provided for in the program include:

- The concrete slab can be either full depth or cast over formed steel decking, with rib orientation perpendicular or parallel.

- The concrete slab may extend past one or both sides of the beam.
- An optional steel plate may be attached below the bottom flange to allow strengthening of existing beams.
- When formed steel deck is used, stud capacity reduction factors are automatically calculated.
- Normal or lightweight concrete may be used for both design and deflection calculations.
- Shear connector requirements are given at six locations along the span, based on shear variations.
- Construction Only loads can be used to represent formwork that will be removed after curing to allow full composite action.
- Both shored and unshored construction techniques are analyzed by the program.

You can load the simple span beam with up to 17 distributed loads and 15 point loads. Distributed loads can be full or partial length, and all loads are separated between:

- Loads applied during and after construction (Dead Loads).
- Loads applied after 75% concrete curing (Live Loads).
- Loads applied ONLY before 75% curing (Construction Only).

Both shored and unshored conditions are examined for stresses and deflections. The program determines deflections for both shored and unshored conditions. Also, the user may specify different concrete properties for use in determining section properties for deflection calculations, in addition to transformed section properties for strength analysis.

The program can use any section from the internal AISC databases. Also provided is automatic member selection using criteria the user has specified.

	Actual	Allowable
@ Bottom of Beam	22,932.3	23,999.8 psi
Unshored DL Stress	21,002.9	23,999.8 psi
Actual Shear Stress	3,936.8	14,400.0 psi
Unshored Stress Check...		
(Mdl/Ss + Mll/Strans)	29,024.6	32,400.0 psi
Mll / Strans(top)	343.4	1,800.0 psi
Alternate Unshored Stress Check : (Mdl + Mll) / Ss		
	33,695.4	27,360.0 psi
Shored Concrete Stress Check... (Mdl + Mll) / (Strans:top * n)		
	791.2	1,800.0 psi

Basic Usage

- Enter Beam and Slab Data
- Enter the beam span to be used for calculation of moments and deflections, and the spacing between beams to be used for calculation of effective slab width.
- Enter the total slab thickness (distance from top flange to final surface). When metal deck is used, enter the data to describe the deck ribs. This will be used to calculate transformed section properties.
- Location should be set to 1" when the concrete slab only extends past one edge of the beam. To achieve the greatest economy of design, Partial can be set to YES to enable calculation of the minimum number of connectors allowable to achieve the minimum interlock to satisfy stress requirements.
- Enter Design Data. This sections allows you to enter the allowable material strengths for beam, slab, and shear connectors. Stud height will only be used when metal deck stud capacity reductions are required.
- Applied Loads :
 - Uniform loads apply to the entire span. Trapezoidal loads MUST BE POSITIVE , but can be of any starting and ending magnitude and any start or end location. Point loads may applied anywhere on the span.
 - Loads Applied Before 75% Curing are dead loads that will be applied to the beam for the duration of its life. If the beam is shored, the dead load will be applied to the composite section, not the beam alone, since all loads will be supported by the

shores until curing has reached 75%.


- Loads Applied After 75% Curing are typical live loads applied after the concrete has cured.
- Loads Applied During Construction are applied to the beam only during curing, and are taken out of the calculations for final, long term stresses. When the beam is shored, this type of load has no meaning.
- Section Properties can be entered by using the built-in section property databases. Please see the following two sections on using this capability.
- Reviewing Forces and Stresses. In the Summary section of the worksheet the actual and allowable bending and shear stresses will be listed. Also, various moments, shears, deflections and reactions due to six load placement conditions will be given.

Unique Features

- User may have the program automatically select the lightest section from the AISC section database.
- An additional steel plate can be added to the bottom flange of the beam to strengthen existing sections.
- The program allows the use of lightweight concrete. Different n values are calculated to determine section properties for strength design and for deflection calculations.

Steel Section Database

Built into the software is a complete database of common rolled sections available from various mills in the United States. On each tab labeled #1, #2, etc. there will be a button that looks like this:



Steel Section

This button displays the steel section database as shown below.

Steel Section Database

Section Type to Display: W HP JR C **TS** HSS-T L WT
S M B MC P HSS-P LL MT
WF BP JRC ST

Steel Database: AISC 9th AISC 8th AISC 7th AISC 6th Korean

Name | Area | Depth | Width | Sx | Ix | Sy | Iy | J | Section Count : 71

Section Name	Area in ²	Depth in	Wall Thickness in	Ixx in ⁴	Sxx in ³	Rxx in	Zx in ³
TS2x2x3/16	1.270	2.000	0.188	0.668	0.668	0.726	0.8
TS2x2x1/4	1.590	2.000	0.250	0.766	0.766	0.694	1.0
TS2x2x5/26	1.860	2.000	0.313	0.880	0.880	0.690	1.1
TS2.5x2.5x3/16	1.640	2.500	0.188	1.420	1.140	0.930	1.4
TS2.5x2.5x1/4	2.090	2.500	0.250	1.690	1.350	0.899	1.7
TS2.5x2.5x5/16	3.110	2.500	0.313	3.580	2.390	1.070	1.9
TS3x3x3/16	2.020	3.000	0.188	2.600	1.730	1.130	2.1
TS3x3x1/4	2.590	3.000	0.250	3.160	2.100	1.100	2.6
TS3x3x5/16	3.110	3.000	0.313	3.580	2.390	1.070	3.0
TS3.5x3.5x3/16	2.390	3.500	0.188	4.290	2.450	1.340	2.9
TS3.5x3.5x1/4	3.090	3.500	0.250	5.290	3.020	1.310	3.7
TS3.5x3.5x5/16	3.730	3.500	0.313	6.090	3.480	1.280	4.3
TS4x4x3/16	2.770	4.000	0.188	6.590	3.300	1.540	3.9
TS4x4x1/4	3.590	4.000	0.250	8.220	4.110	1.510	4.9
TS4x4x5/16	4.360	4.000	0.313	9.580	4.790	1.480	5.9
TS4x4x3/8	5.080	4.000	0.375	10.700	5.350	1.450	6.7
TS4x4x1/2	6.360	4.000	0.500	12.300	6.130	1.390	8.0
TS4.5x4.5x3/16	3.140	4.500	0.188	9.600	4.270	1.750	5.0
TS4.5x4.5x1/4	4.090	4.500	0.250	12.100	5.360	1.720	6.4
TS5x5x3/16	3.520	5.000	0.188	13.400	5.360	1.950	6.2
TS5x5x1/4	4.590	5.000	0.250	16.900	6.780	1.920	8.0
TS5x5x5/16	5.610	5.000	0.313	20.100	8.020	1.890	9.7
TS5.5x5.5x1/4	6.590	5.000	0.375	23.000	9.110	1.860	11.6

Depth Range : Class Range :

On this window there are various controls and options.....

Steel Database : Allows you to select between several common shapes databases.

Section Type to Display: Allows you to select which steel section designation to display in the list. These shapes conform to the American Institute of Steel Construction shape designations. To make your selection simply move the mouse over the letter(s) and when the highlight activates left-click once with your left mouse button.

Depth Range: This item allows you to specify depth limits to be used for selecting which sections to display in the list. When the checkbox to the left is not checked the selection wording and entries will not appear and all sections will be displayed. These dimensions are compared to the "Depth" dimension of the sections.

Class Range : This item allows you to specify the limits in "Depth Class" to be displayed in the table. The "Depth Class" of a section is the first numeric number in the sections name. For instance a wide flange W14x22 is in depth class "14". a channel C9x15 is in depth class "9", and a L5x3x1/4 is in depth class "5".

Equal & Unequal Legs : These two buttons appear when you have selected section type "L" which are single angles. The limit the display of the list to angle with equal dimension or unequal dimension sides.

Equal Legs, Long Leg Vertical, Short Leg Vertical: These three buttons appear when you have chosen to display section type "LL". These control the display of sections between pairs of angles with both sides of equal length, of unequal side length angles paired with the LONG side together, and unequal side length angles paired with the SHORTside together.

Square & Rectangular Tubes: These two buttons appear when you have chosen section types TS or

HSS-T. These are square tubular sections. You can choose to display only square tubes or alternately tubes with unequal sides.

Sort Tabs for Database Table : Immediate above the database list of sections you will see tabs looking like this....

When selected each tab will sort the list in the order described by the text on that tab.

Sort order : These two buttons allow you to choose the list order of the sections. The sorting order will be according to the sort tab selected and shall be in ascending or descending order.

Database Table Itself : The main area on the window will be where the steel sections are displayed as a result of all of your choices as described above.

[Select] : This button is displayed when you have clicked on the **[Section]** button when you press **[Select]** the section in the list that is currently highlighted will be selected and the name and data brought into your calculation.

[Insert]: Use this button to add a steel section to the database. When pressed you will see the following window:

The screenshot shows a dialog box titled "New Steel Section Data Entry". It contains the following fields and controls:

- Section Name**: Text input field containing "MyVeryOwn 4x12 Tube".
- Type**: Dropdown menu showing "TS".
- Depth Class**: Text input field containing "36".
- AISC Handbook Edition**: Dropdown menu showing "AISC 9th".
- Area**: Text input field with "0" and "in²".
- Depth**: Text input field with "0" and "in".
- Flange Width**: Text input field with "0" and "in".
- Flange Thickness**: Text input field with "0" and "in".
- Web Thickness**: Text input field with "0" and "in".
- I x-x**: Text input field with "0" and "in⁴".
- I y-y**: Text input field with "0" and "in⁴".
- Xcg**: Text input field with "0" and "in".
- Ycg**: Text input field with "0" and "in".
- Buttons**: "Cancel" (with a red X icon) and "OK" (with a green checkmark icon).

The only really important item to enter is the "Type" item. This specifies what standard rolled section type your section is. This item is used internally by the program to decide which stress analysis method to use for determining the sections allowable stress, how to consider unstiffened elements, and many other code checking items.

[Change]: Will display the same window as above but allow you to change section properties.

[Delete] : Will enable you to delete sections. Note: No sections in the supplied database can be deleted. Only Sections that you add can be later deleted.

[Cancel]: Exit the steel database window.

ASD Design Modes

Allowable Stress Design as specified by the American Institute of Steel Construction is provided by this program. Only screen captures and descriptions for ASD are presented in this book. Check these locations for electronic media:

- Latest Adobe Acrobat PDF documentation file here:
<ftp://208.36.30.226/sel5.pdf>.
- Latest Windows Help system file here : <ftp://208.36.30.226/enercalc.hlp>.
- Internet HTML help documentation presented as web pages at
www.enercalc.com/sel_help.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

All of the information for the beam design except for loading is entered on this tab.

General	Dead Loads	Live Loads	Const Loads	Section Props
Description Part 2, Ribs Perpendicular, Showing Auto-Design				
Beam Span	60.500 ft			
Beam Spacing	18.000 ft			
Beam Location	<input checked="" type="radio"/> Center <input type="radio"/> Edge			
Partial Composite Action	<input type="checkbox"/>			
Steel Section	W40X149			
Slab & Shear Studs...				
Slab Thickness	6.500 in			
Stud Diameter	0.750 in			
Stud Height	4.000 in			
Metal Deck Data				
Deck Rib Height	2.500 in			
Rib Spacing	16.000 in			
Rib Width	10.000 in			
Rib Orientation	<input checked="" type="radio"/> Perpendicular <input type="radio"/> Parallel			
Material Data...				
Fy	36.0 ksi			
fc	4,000.0 psi			
Concrete Density	145.00 pcf			
Elastic Modulus	29,000.0 ksi			

Beam Span

The beam span length is used for determination of effective flange width and evaluation of moments and shears.

Beam Spacing

Enter the center to center spacing for the beam to be used to determining effective flange width.

Beam Location

This specifies whether the beam is an interior beam with slab extending a distance of (Trib Width)/2 on each side of the beam. If beam to be designed will have slab on only one side select "Edge". If the slab extends on both side select "Center". This item will be used to determine the effective flange width for the composite section.

Partial Composite Action

Designer may choose whether or not to use a reduced shear force if transformed section modulus supplied is greater than that required. If user does not use partial action, shear force calculated from AISC equations 1.11-3 & 1.11-4 is used to determine connector requirements.

Steel Section

This is where you specify the rolled steel section to be used in the design. There are two ways to enter & specify the section.

- Use the [Section] button to retrieve the section from the built-in steel database. See the description given previously for more information.
- Type in the section name and the program will automatically look through the database for a match. Upper or lower case is fine. If found the name and numeric section properties will be retrieved into this calculation. The numeric properties will be seen on the "Section Properties" tab.

Slab Thickness

This is the TOTAL THICKNESS of the structural material over the top of the beam. If you are using metal decking with concrete fill this thickness is the deck height plus concrete topping.

Stud Diameter

The diameter of the shear studs is measured at the base, not the maximum head diameter. This dimension is used to calculate stud capacities using internal tables and reduction equations if metal deck is used.

Stud Height

The stud height is used to calculate stud capacities when metal decking is used.

Metal Deck Notes

When metal decking is used, the program automatically decides what concrete area is to be used. When the deck ribs are oriented parallel to the beam, the total actual concrete area (based on the rib dimensions and effective flange width) is used for calculations. The center of area is adjusted for the area distribution as it occurs (it varies due to ribs). When ribs are perpendicular to the beam, only the concrete area between the top of the slab and top of the ribs is used.

Deck Rib Height

Rib height is the total depth of the metal decking (distance from the top flange of the beam to the top surface of the decking). Used along with Rib Spacing and Rib Width to determine the net concrete area for composite section properties.

Rib Spacing

Center to center spacing of the metal deck ribs. This is used with Rib Height and Rib Width to determine the net concrete area for composite action.

Rib Opening Width

When viewed from above the decking, this represents the width of the CONCAVE section of the metal deck which will be filled with concrete. Used with Rib Height and Rib Spacing to determine the net concrete area for composite action.

Rib Orientation

This entry indicates if the metal deck ribs are parallel with the steel beam. If parallel, the transformed section properties will include the concrete area within the Rib Opening Width areas. If perpendicular, that area will not be used. Also, shear stud reduction factors will be used.

F_y

Indicates yield strength of structural steel to be used. For unshored construction, .89 F_y is used as a maximum allowable steel stress for service loading conditions.

f'_c

Indicates design strength of concrete to be used. Allowable compressive stress for design at top of slab is limited to .45 f'_c.

Concrete Density

Density Unit weight of concrete, and is used to determine the n ratio to be used in calculation of transformed moment of inertia, to be used in deflection calculations.

Elastic Modulus

Although rarely does this need to be changed, enter the elastic modulus of the steel material.

General Information About Loads

- Negative loads should not be entered. Negative moments will cause tension in the concrete, which is not acceptable in this program!!
- For SHORED conditions, no load is applied to the steel beam alone. Upon removal of the shores when 75% curing has been attained, all load is transferred to the full composite section. Construction Only loads are meaningless and never used.
- For UNSHORED conditions, the steel beam alone supports the BEFORE 75% loads and Construction Only loads. You Must Insure Adequate Lateral Support Of The Compression Flange So Lateral Buckling Does Not Occur. When the shores are removed, the Construction Only loads are assumed to be removed, and the full composite section takes live loads. Theoretically, when the Construction Only load is removed, the beam deflection decreases, thus causing tension in the concrete. This Effect Is Ignored By The Program.

Dead Loads Tab

"Dead Loads" in this program are Loads Applied **BEFORE** 75% Curing. These loads are considered typical dead loads, placed on the beam for its entire life.

Auto Calc Beam Weight uses the area of the beam and standard density of steel PLUS the area of the slab (considering metal deck ribs if used) and entered concrete density to add in the total beam weight as a uniform dead load on the span. (This is done internally).

Load locations are measured from the left support going to the right.

General	Dead Loads	Live Loads	Const Loads	Section Props		
<p>These loads are applied BEFORE concrete curing and are long term loads.</p> <p style="text-align: right;">Auto Calc Beam Weight <input type="checkbox"/></p>						
Full Span Uniform Loads...						
# 1	<input type="text" value="1.750"/>	k/ft				
# 2	<input type="text"/>	k/ft				
# 3	<input type="text"/>	k/ft				
# 4	<input type="text"/>	k/ft				
<p>Note! Weight of concrete slab must be entered as an applied dead load.</p>						
Point Loads...						
# 1	<input type="text" value="0.650"/>	k	Location	<input type="text" value="20.000"/>	ft	
# 2	<input type="text" value="0.650"/>	k	Location	<input type="text" value="40.000"/>	ft	
# 3	<input type="text"/>	k	Location	<input type="text" value="0.000"/>	ft	
# 4	<input type="text"/>	k	Location	<input type="text" value="0.000"/>	ft	
# 5	<input type="text"/>	k	Location	<input type="text" value="0.000"/>	ft	
# 6	<input type="text"/>	k	Location	<input type="text" value="0.000"/>	ft	
Trapezoidal Loads...						
	<u>@ Left</u>	<u>@ Right</u>	<u>Start</u>	<u>End</u>		
# 1	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/>	>>	<input type="text" value="0.00"/>	ft
# 2	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/>	>>	<input type="text" value="0.00"/>	ft
# 3	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/>	>>	<input type="text" value="0.00"/>	ft

Live Loads Tab

"Live Loads" in this program are Loads Applied **AFTER** 75% Curing. These loads are considered typical live loads that may or may not be applied to the span

General	Dead Loads	Live Loads	Const Loads	Section Props																																												
<p>These loads are applied AFTER concrete curing and are long term loads.</p> <p>Full Span Uniform Loads...</p> <p>#1 <input type="text" value="1.350"/> k/ft</p> <p>#2 <input type="text"/> k/ft</p> <p>#3 <input type="text"/> k/ft</p> <p>#4 <input type="text"/> k/ft</p> <p>Point Loads...</p> <table> <tr> <td>#1</td> <td><input type="text" value="0.310"/> k</td> <td>Location</td> <td><input type="text" value="20.000"/> ft</td> </tr> <tr> <td>#2</td> <td><input type="text" value="0.310"/> k</td> <td>Location</td> <td><input type="text" value="40.000"/> ft</td> </tr> <tr> <td>#3</td> <td><input type="text"/> k</td> <td>Location</td> <td><input type="text" value="0.000"/> ft</td> </tr> <tr> <td>#4</td> <td><input type="text"/> k</td> <td>Location</td> <td><input type="text" value="0.000"/> ft</td> </tr> <tr> <td>#5</td> <td><input type="text"/> k</td> <td>Location</td> <td><input type="text" value="0.000"/> ft</td> </tr> <tr> <td>#6</td> <td><input type="text"/> k</td> <td>Location</td> <td><input type="text" value="0.000"/> ft</td> </tr> </table> <p>Trapezoidal Loads...</p> <table> <thead> <tr> <th></th> <th>@ Left</th> <th>@ Right</th> <th>Start</th> <th>End</th> </tr> </thead> <tbody> <tr> <td>#1</td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text" value="0.00"/> ft</td> <td><input type="text" value="0.00"/> ft</td> </tr> <tr> <td>#2</td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text" value="0.00"/> ft</td> <td><input type="text" value="0.00"/> ft</td> </tr> <tr> <td>#3</td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text" value="0.00"/> ft</td> <td><input type="text" value="0.00"/> ft</td> </tr> </tbody> </table>					#1	<input type="text" value="0.310"/> k	Location	<input type="text" value="20.000"/> ft	#2	<input type="text" value="0.310"/> k	Location	<input type="text" value="40.000"/> ft	#3	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft	#4	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft	#5	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft	#6	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft		@ Left	@ Right	Start	End	#1	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft	#2	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft	#3	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft
#1	<input type="text" value="0.310"/> k	Location	<input type="text" value="20.000"/> ft																																													
#2	<input type="text" value="0.310"/> k	Location	<input type="text" value="40.000"/> ft																																													
#3	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft																																													
#4	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft																																													
#5	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft																																													
#6	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft																																													
	@ Left	@ Right	Start	End																																												
#1	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft																																												
#2	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft																																												
#3	<input type="text"/>	<input type="text"/>	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft																																												

Construction Loads Tab

These loads are **only considered for UNSHORED construction**. These loads cause dead load stress in the STEEL SECTION ONLY. When the concrete has attained 75% curing, these loads are assumed to be removed and only the other two types of loads will be used. These loads are ignored for shored construction.

General | Dead Loads | Live Loads | Const Loads | Section Props

These loads are applied BEFORE concrete curing and are REMOVED afterward.

Uniform Loads...

# 1	<input type="text" value="0.180"/> k/ft	Location	<input type="text" value="0.000"/> >> <input type="text" value="60.500"/> ft
# 2	<input type="text"/> k/ft	Location	<input type="text" value="0.000"/> >> <input type="text" value="0.000"/> ft
# 3	<input type="text"/> k/ft	Location	<input type="text" value="0.000"/> >> <input type="text" value="0.000"/> ft

Point Loads...

# 1	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft
# 2	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft
# 3	<input type="text"/> k	Location	<input type="text" value="0.000"/> ft

Section Properties Tab

This secondary tab is where the steel section properties are listed. The properties shown here are used for the calculation. Also given are the calculated transformed section properties for the beam

General	Dead Loads	Live Loads	Const Loads	Section Props
Steel Section		W40X149		
Depth		38.200	in	
Width		11.810	in	
Flange Thick		0.830	in	
Web Thick		0.630	in	
Area		43.80	in ²	
Weight		148.78	#/ft	
Ixx : Steel Only		9,780.00	in ⁴	
Optional Bottom Flange Cover Plate...				
Plate Width			in	
Plate Thick			in	
Transformed Sction Properties...				
I-steel		9,780.00	in ⁴	
S steel : top		512.04	in ³	
S steel : bottom		512.04	in ³	
I transformed		26,324.27	in ⁴	
Strans : top		2,710.71	in ³	
Strans : bot		752.36	in ³	
Strans : eff @ bot		752.36	in ³	
n*Strans : eff @ top		21,806.0	in ³	
X-X Axis from Bot		34.99	in	
Vh @ 100%		788.40	k	

Optional Bottom Flange Cover Plate

These two entries allow you to add a steel plate to the bottom flange of the beam. Many times existing beams are strengthened by raising up the beam to release loads, welding on a plate to the bottom flange, and then releasing the beam so that the cover plate comes into play creating different transformed section properties.

I-Steel

Moment of inertia of the entire steel section (with added cover plate), but not including concrete area.

S-Steel-Top

Section modulus of steel section with added cover plate (not including concrete area), for calculation of top of beam stresses.

S-Steel - Bottom

Section modulus of steel section with added cover plate (not including concrete area) for calculation of top of beam stresses.

I-Trans Effective

Transformed moment of inertia of the section when concrete slab is combined with the steel section (and optional cover plate). Used to determine the transformed section modulus and for live load deflection calculation. If partial composite action has been specified, this value is adjusted for the effect of partial composite action

$$I_{eff} = I_{steel} + [(I_{trans} - I_{steel}) * (V'h/V_h)^{1/2}]$$

Where $V'h$ is the adjusted shear stress based on the number of shear connectors used. If partial action has not been specified, the full value of $I_{composite}$ is used.

S-Trans Top

Transformed section modulus at top of steel beam. This is used to calculate $n * STR$ for use in calculating concrete stresses.

S-Trans Bottom

Transformed effective section modulus including concrete area and optional cover plate. Also used to determine partial shear force when S-tr required is less than S-tr supplied for calculation of required number of shear connectors.

Actual STR Effective

This is the actual STRANS being used. The effective transformed section modulus is the calculated STRANS modified for partial composite action (i.e. for a reduced number of shear studs).

n * S-tr Top

Modular ratio E_s/E_c times the transformed section modulus at the top of the composite section (top of the slab). Used to determine the service load concrete stress (which should be less than $.45 f'_c$).

X-X Axis Bottom

Distance measured upward from the bottom of the steel section (not bottom of the optional cover plate), to the neutral axis of the transformed section. Used only to determine transformed section modulus of the steel section.

V-Horiz @ 100%

Horizontal shear, calculated as the minimum of AISC equations 1.11-3 and 1.11-4:

$$0.85 * f'_c * A_c/2 \text{ -or- } A_s * F_y/2.$$

Used to calculate required shear connectors unless partial composite action is allowed.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results / Results Tab

Results	Shear Studs	Deflection	Reactions	Moments, Shears, Misc
OK Shored & Unshored				
Stress Checks for Shored & Unshored Cases...				
		<u>Actual</u>		<u>Allowable</u>
@ Bottom of Beam		22,932.3		23,999.8 psi
Unshored DL Stress		21,002.9		23,999.8 psi
Actual Shear Stress		3,936.8		14,400.0 psi
Unshored Stress Check....				
(Mdl/Ss + Mll/Strans)		29,024.6		32,400.0 psi
Mll / Strans(top)		343.4		1,800.0 psi
Alternate Unshored Stress Check : (Mdl + Mll) / Ss				
		33,695.4		27,360.0 psi
Shored Concrete Stress Check....(Mdl + Mll) / (Strans:top * n)				
		791.2		1,800.0 psi

Stress Checks for Shored & Unshored Cases

The stress checks in this area **MUST BE SATISFIED** if the beam is to be used at all. These are basic stress checks for composite beams.

@ Bottom of Beam

This value is the maximum stress if both loads applied after 75% curing (but not construction only loads) are applied to the fully composite section.

$$\text{Stress} = (\text{MDL} + \text{MLL}) / \text{STRANSFORMED}$$

Unshored Dead Load Stress

This stress results from applying Loads before 75% and Construction Only loads to the steel beam only. This is the maximum moment the steel beam will have to support by itself. (You need to check the beam for lateral buckling and compact section criteria).

$$\text{Stress} = \text{MDL} / \text{SSTEEL}$$

Actual Shear Stress

This is the maximum shear stress in the beam web from all combinations of applied loads.

Unshored Stress Check

The stress checks in this area **MUST BE SATISFIED** if the beam can be constructed without shoring.

This section provides information checking whether or not the section can be constructed as an unshored member, $(1.35 + .35M_{LL}/M_{DL}) * S_s$

This value is the maximum allowable **Strans** that can be allowed to determine unshored stresses. This equation effectively limits the steel beams tension stress to $0.89 F_y$. You will notice that the stress check (below) compares the actual maximum unshored steel stress against $0.89 F_y$.

(M_{DL} / S_s + M_{II} / Strans)

This equation calculates the maximum steel stress at the bottom of the member for unshored construction. This stress must not exceed $0.89 F_y$.

M_{II} / Strans(top)

This equation calculates the maximum concrete compressive stress for unshored construction.

Alternate Unshored Stress Check

This check compares the load combination $(M_{DL} + M_{II}) / S_s$, the total moment divided by the steel section modulus. If this stress is OK, the applied loads will not overstress the steel section acting alone, therefore composite action isn't really being taken advantage of (except for deflection control).

Shored Concrete Stress Check

$(M_{DL} + M_{LL}) / (STR:TOP * n)$: This equation calculates the maximum concrete compressive stress for shored construction.

Results / Shear Studs Tab

This section gives details of the shear connector requirements, and allows you to specify the actual number of shear connectors used when examining an existing beam.

Results	Shear Studs	Deflection	Reactions	Moments, Shears, Misc
Actual # Studs	<input type="text" value="0"/>	per 1/2 beam span		
Stud Capacity	13.30 k			
Total req'd 1/2 Span	60 studs			
Vh @ 100%	788.40 k			
Vh : min	788.40 k			
Vh : Used	788.40 k			
Zone 1 from	0.000 ft	to	10.083 ft	, Use 20 studs
Zone 2 from	10.083 ft	to	20.167 ft	, Use 18 studs
Zone 3 from	20.167 ft	to	30.250 ft	, Use 22 studs
Zone 4 from	30.250 ft	to	40.333 ft	, Use 19 studs
Zone 5 from	40.333 ft	to	50.417 ft	, Use 21 studs
Zone 6 from	50.417 ft	to	60.500 ft	, Use 20 studs

Actual #Of Shear Studs Used

This is an optional entry, and can be used when you want to analyze an as built beam. If this entry is 0", the program calculates the required number of studs, and the shear stud spacing values reflect that force. If you enter the actual number of studs per 1/2 span in this location, that number will be multiplied by the allowable shear connector capacity and the result shown as Shear Force Used For Connector Design".

Vh @ 100%

This is the maximum horizontal to be resisted (by code), calculated as the minimum of AISC equations 1.11-3 and 1.11-4:

$$0.85 * f_c * A_c / 2 \text{ -or- } A_s * F_y / 2.$$

Vh Minimum

When partial composite action has been allowed, this value is Vh @ 100% adjusted by the formula:

$$V_h = V_h * [(SREQ'D-SSTEEL) / (STRANS-SSTEEL)]^2$$

This force is the minimum force which the connectors should be designed to resist. If no entry has been made for OPTIONAL ACTUAL STUDS....., the shear stud spacings will be listed for this value, otherwise Shear Force Used For Connector Design (below) will be used to determine spacings.

Shear Force Used For Connector Design

This is either the maximum value of either V_h Minimum or V_h @ 100% adjusted for partial composite action (see above), or if a non-zero number has been entered for Actual Number of Shear Studs, that value is multiplied by allowable connector capacity and used.

Total Studs Required

The shear force is divided by the individual connector capacity to determine the number of connectors required between the point of maximum shear and zero shear. If partial action has been chosen, the adjusted shear force is used, otherwise the result of AISC formula 1.11-3 & 1.11-4 is used.

Shear Connector Table

This table lists the shear connectors required between the distance ranges shown.

Results / Deflection Tab

Deflections for both shored and unshored conditions are listed. The deflections are calculated for various combinations of loads at 250 points along the span, and the maximums listed.

Results	Shear Studs	Deflection	Reactions	Moments, Shears, Misc
I : Transformed		26,383.43 in ⁴		
I : Effective		26,383.43 in ⁴		
<i>(Note: I:Eff for deflections uses concrete weight for modular ratio "n")</i>				
<u>Deflections</u>				
		<u>Shored</u>	<u>Unshored</u>	
Before 75 % Curing		0.701 in	1.890 in	
Construction Loads Only		0.071 in	0.191 in	
After 75% Curing		0.537 in	0.537 in	
Total Uncured Deflection		0.772 in	2.081 in	
Length/Defl. Ratio		940.9	348.8	
Composite Deflection		1.238 in	2.427 in	
Length/Defl. Ratio		586.3	299.1	

I-Transformed


This is the overall transformed moment of inertia before any modification has been made for partial composite action.

I-Effective

Transformed moment of inertia after allowance has been made for partial composite action.

Results / Reactions Tab

This tab gives the support reactions for various combinations of dead, live and construction loads.



The screenshot shows a software interface with several tabs: Results, Shear Studs, Deflection, Reactions, and Moments, Shears, Misc. The 'Reactions' tab is active, displaying a table titled 'Reactions...'. The table has three columns: 'Load Combinations...', '@Left', and '@Right'. It lists three load combinations: 'Dead + Constuction', 'Composite', and 'Max DL + LL', with their respective reaction values in kilonewtons (k).

<u>Load Combinations...</u>	<u>@Left</u>	<u>@Right</u>
Dead + Constuction	59.04 k	59.03 k
Composite	41.15 k	41.14 k
Max DL + LL	94.74 k	94.73 k

Results / Moments, Shears, etc. Tab

This tab displays a breakdown of the moments & shears for the various combinations of load types.

Results	Shear Studs	Deflection	Reactions	Moments, Shears, Misc
Maximum Moments				
Dead Load Alone				813.84 k-ft
Dead + Const				896.20 k-ft
Live Load Only				623.94 k-ft
Dead + Live				1,437.79 k-ft
Support Shears				
Shear @ Left				94.74 k
Shear @ Right				94.73 k
Fb : Allow				23.76 psi
n : Strength				8.04
n : Deflection				7.96
Effective Flange Width...				
Based on Beam Span				15.125 ft
Based on Beam Spacing				18.000 ft
Effective Width				15.125 ft

Const. Only

This values is due to Loads applied Before 75% and Construction Only Loads being applied to the beam.

Const. + Composite

This values is due to Loads applied Before 75% and Loads applied After 75% being applied to the beam.

Max. Shear

This value is the maximum shear at each end due to all combinations of loads.

Effective Flange Width**Based On Span**

$$\begin{aligned} \text{Center Beam Location} &= \text{SPAN}/4 \\ \text{Edge Beam Location} &= \text{SPAN}/12 + B_f \end{aligned}$$

Based on Beam Spacing


$$\begin{aligned} \text{Center Beam Location} &= \text{BEAM SPACING} \\ \text{Edge Beam Location} &= (\text{BEAM SPACING} + B_f)/2 \end{aligned}$$

Effective Width

The effective width is the minimum of the above three equations.


Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Diagrams Tab


This displays a moment, shear, and deflection diagram for the beam with the applied loads and end conditions. Note the two tabs...."Graphic Diagram" and "Data Table". The Data Table tab provides the entire internal analysis at the 1/500th points within the beam.



Results Sketch Diagrams Printing			
Graphic Diagram		Data Table	
Location	Moment	Shear	arDeflec
0.0000	0.0000	94.7429	0.0000
0.4033	37.9608	93.4926	-0.0264
0.8067	75.4173	92.2422	-0.0528
1.2100	112.3696	90.9919	-0.0792
1.6133	148.8175	89.7416	-0.1055
2.0167	184.7611	88.4912	-0.1318
2.4200	220.2004	87.2409	-0.1580
2.8233	255.1354	85.9906	-0.1841
3.2267	289.5661	84.7402	-0.2101
3.6300	323.4925	83.4899	-0.2360
4.0333	356.9146	82.2396	-0.2618
4.4367	389.8324	80.9892	-0.2875
4.8400	422.2460	79.7389	-0.3130
5.2433	454.1552	78.4886	-0.3384
5.6467	485.5601	77.2382	-0.3636
6.0500	516.4607	75.9879	-0.3886
6.4533	546.8570	74.7376	-0.4135
6.8567	576.7490	73.4872	-0.4381
7.2600	606.1367	72.2369	-0.4625
7.6633	635.0201	70.9866	-0.4868
8.0667	663.3992	69.7362	-0.5107
8.4700	691.2740	68.4859	-0.5344

Printing Tab

This tab allows you to control which areas of the calculation to print. Checking a box will signal that the information described by the item will be printed. However, if there is no information in for a particular selection it will not be printed. So these checkboxes are best described as "If this particular area of the calculations contains data then print it".



Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 8:29PM, 26 OCT 03
 Description: Collection of example problems
 Scope: All programs in the Structural Engineering Library

Rev: 00000
 User: JWW000001 Ver 5.8.0, 10-Sep-2003
 (c)1983-2003 ENERCALC Engineering Software

Composite Steel Beam

Page 1

c:\ec06\examples.ecw:Steel Calc

Description Part 2, Ribs Perpendicular, Showing Auto-Design

Design Input

Code Ref. AISC 9th ASD, 1997 UBC, 2003 IBC, 2003 NFPA 5000

Section Name	W40X149	Fy	36.00 ksi
Beam Span	60.500 ft	f'c	4,000.00 psi
Beam Spacing	18.000 ft	Concrete Density	145.00 pcf
Slab Thickness	6.500 in	Stud Diameter	0.750 in
Deck Rib Height	2.500 in	Stud Height	4.000 in
Rib Spacing	16.000 in	Beam Weight not added	
Rib Width	10.000 in	Using Full Composite Action	
Rib Orientation	Perpendicular	Elastic Modulus	29,000.00 ksi
Beam Location	Slab Both Sides		

Dead Loads (applied before 75% curing)

Full Span Uniform Loads...		Point Loads...	
#1	1.750 k/ft	#1	0.650 k 20.000ft
#2	k/ft	#2	0.650 k 40.000ft

Live Loads (applied after 75% curing)

Full Span Uniform Loads...		Point Loads...	
#1	1.350 k/ft	#1	0.310 k 20.000ft
#2	k/ft	#2	0.310 k 40.000ft

Construction Loads

Point Loads...		Uniform Loads...	
#1	k	#1	0.180 k/ft --> 60.500 ft

Summary

OK Shored & Unshored

Using: W40X149, Span = 60.50ft, Slab Thickness = 6.500in, Deck Rib Ht= 2.50in, Rib Spac= 16.00in, Rib Width= ##in w/ Slab Both Side

Stress Checks for Shored & Unshored Cases...

@ Bottom of Beam	Actual =	22,932.3 psi	Allowable =	23,999.8 psi	OK
Unshored DL Stress	Actual =	21,002.9 psi	Allowable =	23,999.8 psi	OK
Actual Shear Stress	Actual =	3,936.8 psi	Allowable =	14,400.0 psi	OK

Unshored Stress Check...

(Mdl/Ss + Mll/Strans)	Actual =	29,024.6 psi	Allowable =	32,400.0 psi	OK
Mll / Strans(top)	Actual =	343.4 psi	Allowable =	1,800.0 psi	OK
Alternate Unshored Stress Check: (Mdl + Mll) / Ss		33,695.4		27,360.0 psi	
Shored Concrete Stress Check... (Mdl + Mll) / (Strans.top * n)		791.2		1,800.0 psi	

Shear Studs & Shear Transfer

Actual # studs	0 - per 10' beam span	stud capacity	11,150 k	5th min	50,400 k
Total req'd 1/2 Span	60 studs	req'd 100%	788,400	5th 100%	788,400 k
Zone 1 from	0.000 ft	to	10.183 ft	Use	21 studs
Zone 2 from	10.183 ft	to	20.167 ft	Use	15 studs
Zone 3 from	20.167 ft	to	30.150 ft	Use	22 studs
Zone 4 from	30.150 ft	to	40.133 ft	Use	19 studs
Zone 5 from	40.133 ft	to	50.117 ft	Use	21 studs
Zone 6 from	50.117 ft	to	60.100 ft	Use	20 studs

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title : ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 8:29PM, 26 OCT 03
 Description : Collection of example problems
 Scope : All programs in the Structural Engineering Library

Rev: 550000 User: MW-0600001, Ver 5.8.0, 10-Sep-2003 Page 2
 ©1983-2003 ENERCALC Engineering Software Composite Steel Beam c:\examples\example03\SteelBeam

Description Part 2, Ribs Perpendicular, Showing Auto-Design

Deflections

I : Transformed	26,383.43 in ⁴	I : Effective	26,383.43 in ⁴
	Shored		Unshored
Before 75 % Curing	0.701 in (after shores are used)		1.890 in
Construction Loads Only	0.071 in		0.191 in
After 75% Curing	0.537 in		0.537 in
Total Uncured Deflection	0.772 in : L / 940.9		2.081 in : L / 348.8
Composite Deflection	1.238 in : L / 586.3		2.427 in : L / 299.1

Reactions

Load Combinations...	@ Left	@ Right
Dead + Constuction	59.04 k	59.03 k
Composite	41.15 k	41.14 k
Max DL + LL	94.74 k	94.73 k

Analysis Values

Maximum Moments		Effective Flange Width...	
Dead Load Alone	813.84 k-ft	Fb: Allow	23.76 psi
Dead + Const	896.20 k-ft	n: Strength	8.04
Live Load Only	623.94 k-ft	n: Deflection	7.96
Dead + Live	1,437.79 k-ft	Based on Beam Span	15.125 ft
		Based on Beam Spacing	18.000 ft
		Effective Width	15.125 ft
Support Shears			
Shear @ Left	94.74 k		
Shear @ Right	94.73 k		

Section Properties

Section Name	W40X149		
Depth	38.200 in	Ixx : Steel Section	9,780.00 in ⁴
Width	11.810 in	I transformed	26,324.27 in ⁴
Flange Thick	0.830 in	Strans : top	2,710.71 in ³
Web Thick	0.630 in	Strans : bot	752.36 in ³
Area	43.800 in ²	Strans : eff @ bot	752.36 in ³
Weight	148.775 #/ft	n*Strans : E1 @ top	21,806.0 in ³
I-steel	9,780.00 in ⁴	X-X Axis from Bot	34.99 in
S steel : top	512.04 in ³	Vh @ 100%	788.40 k
S steel : bottom	512.04 in ³		

4.6 Base Plate

This program performs column base plate design for W, S, or HP sections. The designer can :

- For a selected base plate size, axial load, and column, the required base plate thickness is determined.
- Determine base plate dimensions and thickness for a given column and axial load

per AISC.

This program follows the design procedure detailed in the AISC specification as an absolute minimum plate thickness, and provides an extended plate analysis when moments are applied to the plate.

Both axial loads and moments about the X-X axis of the column can be applied. The analysis procedure checks for different resultant force locations, and uses an appropriate analysis technique considering anchor bolt location, plate thickness, column flange and web dimensions, and concrete strengths.

Basic Usage

- This program can either calculate the required thickness of a baseplate using the design criteria or you can enter the thickness and have plate and bearing stresses determined.
- Bolt Data specifies the tension capacity of the anchor bolts, number of bolts per side of the column, the area of each bolt, and distance of the bolts from the edge of the base plate. These values will be used to define the base plate geometry to determine resultant force zones in the analysis.
- Baseplate and Pier Dimensions are needed to determine bearing area and area ratios for determining allowable concrete bearing stress.
- Material Strengths to be entered include F_y of column, f'_c of supporting concrete,

and load duration factor to use (which would indicate that the applied axial load and moment is due to seismic, wind, or other short term event).

- Reviewing Forces and Stresses. In the "Summary section of the worksheet the actual and allowable bending and shear stresses will be listed. Also, various moments, shears, deflections and reactions due to six load placement conditions will be given.

Unique Features


This program provides a thorough analysis of the iteration of plate and bearing surface. Four separate zones are define depending upon the position of the force resultant in relation to the plate, bolt, and column dimensions for use in calculating stresses.

Assumptions & Limitations

- The program offers both ground up design of the base plate size and thickness, or just thickness determination based upon user specified overall plate dimensions.
- The allowable bearing stress on concrete is calculated based upon an allowable increase using on the ratio of plate and concrete areas.


Steel Section Database

Built into the software is a complete database of common rolled sections available from various mills in the United States. On each tab labeled #1, #2, etc. there will be a button that looks like this:



Steel Section

This button displays the steel section database as shown below.



On this window there are various controls and options.....

Steel Database : Allows you to select between several common shapes databases.

Section Type to Display: Allows you to select which steel section designation to display in the list. These shapes conform to the American Institute of Steel Construction shape designations. To make your selection simply move the mouse over the letter(s) and when the highlight activates left-click once with your left mouse button.

Depth Range: This item allows you to specify depth limits to be used for selecting which sections to display in the list. When the checkbox to the left is not checked the selection wording and entries will not appear and all sections will be displayed. These dimensions are compared to the "Depth" dimension of the sections.

Class Range : This item allows you to specify the limits in "Depth Class" to be displayed in the table. The "Depth Class" of a section is the first numeric number in the sections name. For instance a wide flange W14x22 is in depth class "14". a channel C9x15 is in depth class "9", and a L5x3x1/4 is in depth class "5".

Equal & Unequal Legs : These two buttons appear when you have selected section type "L" which are single angles. The limit the display of the list to angle with equal dimension or unequal dimension sides.

Equal Legs, Long Leg Vertical, Short Leg Vertical: These three buttons appear when you have chosen to display section type "LL". These control the display of sections between pairs of angles with both sides of equal length, of unequal side length angles paired with the LONG side together, and unequal side length angles paired with the SHORTside together.

Square & Rectangular Tubes: These two buttons appear when you have chosen section types TS or

HSS-T. These are square tubular sections. You can choose to display only square tubes or alternately tubes with unequal sides.

Sort Tabs for Database Table : Immediate above the database list of sections you will see tabs looking like this....

When selected each tab will sort the list in the order described by the text on that tab.

Sort order : These two buttons allow you to choose the list order of the sections. The sorting order will be according to the sort tab selected and shall be in ascending or descending order.

Database Table Itself : The main area on the window will be where the steel sections are displayed as a result of all of your choices as described above.

[Select] : This button is displayed when you have clicked on the **[Section]** button when you press **[Select]** the section in the list that is currently highlighted will be selected and the name and data brought into your calculation.

[Insert]: Use this button to add a steel section to the database. When pressed you will see the following window:

The only really important item to enter is the "Type" item. This specifies what standard rolled section type your section is. This item is used internally by the program to decide which stress analysis method to use for determining the sections allowable stress, how to consider unstiffened elements, and many other code checking items.

[Change]: Will display the same window as above but allow you to change section properties.

[Delete] : Will enable you to delete sections. Note: No sections in the supplied database can be deleted. Only Sections that you add can be later deleted.

[Cancel]: Exit the steel database window.

ASD & LRFD Design Modes

Allowable Stress Design and **Load & Resistance Factor Design** as specified by the American Institute of Steel Construction is provided by this program. Only screen captures and descriptions for ASD are presented in this book. More detailed LRFD documentation will be added and will be available in the electronically delivered versions of this book. Check these locations for electronic media:

- Latest Adobe Acrobat PDF documentation file here:
<ftp://208.36.30.226/sel5.pdf>.
- Latest Windows Help system file here : <ftp://208.36.30.226/enercalc.hlp>.
- Internet HTML help documentation presented as web pages at
www.enercalc.com/sel_help.

Example

The data entry for this example is shown in the screen captures that accompany the Data Entry Tabs and Results & Graphics Tabs sections to follow.

Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General

Description W14x74 Column with Moment

Loads...

Axial Load 573.821 k

X-X Axis Moment k-ft

Plate Dimensions...

Plate Length 45.720 in

Plate Width 30.480 in

Plate Thickness 0.750 in

Support Pier Size...

Pier Length 53.340 in

Pier Width 53.340 in

Steel Section W12x40

Usage Mode | Anchor Bolts | Steel Shape Data | Allow Stresses

Usage Mode....

Determine Size & Thickness

Determine Thickness Only

Check Stresses for Plate Size & Load

Axial Load

Vertical load applied to the base plate.

X-X Axis Moment

Moment applied to the baseplate via the column. Please note that only major axis bending is allowed.

Plate Height & Width

This item changes its visible display depending on the "Usage Mode" specified on the tab at the bottom of the screen.

If usage mode is "Determine Size & Thickness" or "Determine Thickness Only" this item is not an entry....is it displayed as the calculated minimum plate height and width to satisfy stress limits.

If usage mode is "Check Plate for Plate Size Entered & Loading" then these items are shown as entries for you to specify the sizes.

"Height" dimension is measured along the Y-Y axis of the column. "Width" dimension is measured

along the X-X axis of the column.

Plate Thickness

This item changes its visible display depending on the "Usage Mode" specified on the tab at the bottom of the screen.

If usage mode is "Determine Size & Thickness" or "Determine Thickness Only" this item is not an entry...is it displayed as the calculated minimum thickness to satisfy stress limits.

If usage mode is "Check Plate for Plate Size Entered & Loading" then this item is shown as an entry for you to specify the plate thickness.

Pier Height

Pier dimension measured along the Y-Y axis of the column.

Pier Width

Pier dimension measured along the X-X axis of the column.

Steel Section

This is the steel section name that you have specified, either by typing in the name and using the database search abilities (see above)

Usage Mode Tab

Select how the program should work :

- **Determine Size & Thickness** calculates the minimum required plate size and thickness to satisfy stress requirements using the loads, pier dimensions, bolt data and column size data.
- **Determine Thickness Only** calculates the minimum required plate thickness to satisfy stress requirements using the loads, plate dimensions, pier dimensions, bolt data and column size data.
- **Check Stresses for Plate Size & Load** uses your entered plate height, width and thickness along with all other entered data and calculates the stresses.



Anchor Bolt Tab

Usage Mode	Anchor Bolts	Steel Shape Data	Allow Stresses
Dist. from Plate Edge	<input type="text" value="5.080"/>	in	
Bolt Count per Side	<input type="text" value="2"/>		
Tension Capacity	<input type="text" value="24.465"/>	k	
Bolt Area	<input type="text" value="1.122"/>	in ²	

Dist. From Plate Edge

Distance from the plate edge to the centerline of the anchor bolt.

Bolt Count Per Side

Number of bolts on each side of the column.

Tension Capacity

Tension capacity of one anchor bolt.

Bolt Area

Area of each anchor bolt.

Steel Shape Data Tab

This tab shows the dimensions of the selected steel section.

Usage Mode	Anchor Bolts	Steel Shape Data	Allow Stresses
Section Length	<input type="text" value="30.328"/>	in	
Section Width	<input type="text" value="20.333"/>	in	
Flange Thickness	<input type="text" value="1.308"/>	in	
Web Thickness	<input type="text" value="0.749"/>	in	

Allowable Stresses Tab

Usage Mode	Anchor Bolts	Steel Shape Data	Allow Stresses
f _c	<input type="text" value="20.685.4"/>	psi	
F _y	<input type="text" value="248.2"/>	ksi	
LDF	<input type="text" value="1.000"/>		

f_c

Allowable concrete compressive stress for support of the baseplate.

F_y

Allowable yield stress for steel baseplate.

Load Duration Factor

Allowable stress increase factor to be applied to steel and concrete stresses for determining allowable stresses.

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Results Tab

Summary... Full Bearing : No Bolt Tension	
Concrete Bearing Stress...	
Actual Bearing Stress	Bearing Stress OK 411.8 psi
Allow per ACI 318-95, A3.1 = 0.3 * f _c * Sqrt(A ₂ /A ₁) * LDF ..	7,494.0 psi
Allow per AISC J9	8,743.0 psi
Plate Bending Stress...	
Actual fb	Thickness OK 156,970.6 psi
Max Allow Plate Fb	186,165.8 psi
Tension Force per Bolt	
Actual Tension	Bolt Tension OK 0.000 k
Allowable	24.465 k
Baseplate OK	

Actual Bearing Stress

Maximum bearing stress under the baseplate at the edge where axial load and compressive force due to bending is combined.

Allow. per ACI 318-02, A3.1

Absolute maximum baseplate capacity for the calculated maximum allowable bearing stress.

Allow per AISC J9

Maximum allowable concrete bearing stress considering load duration factor and ratio of pier area to baseplate area.

Actual fb

Actual bending stress in the plate.

Maximum Allowable Plate Fb

Allowable bending stress in plate.

Actual Bolt Tension


Calculated tension in anchor bolt on one side of the plate when a moment is present and there is tension forces in the anchor bolts.

Allowable Bolt Tension

Entered allowable bolt tension * Load Duration Factor

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.

**Sample Printout**

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949-645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 9:35PM, 26 OCT 03
 Description: Collection of example problems

Scope: All programs in the Structural Engineering Library

Rev: 990000
 Usr: 10/000001, Ver 58.0, 10-Sep-2003
 (c) 1983-2003 ENERCALC Engineering Software

Steel Column Base Plate

c:\EC88\EXAMPLES\ECW\Steel Colos

Description W14x74 Column with Moment

General Information

Code Ref: AISC 9th Ed ASD, 1997 UBC, 2003 IBC, 2003 NFPA 5000

Loads

Axial Load 573.82 k
 X-X Axis Moment 0.00 k-ft

Plate Dimensions

Plate Length 45.720 in
 Plate Width 30.480 in
 Plate Thickness 0.750 in

Support Pier Size

Pier Length 53.340 in
 Pier Width 53.340 in

Steel Section

Section Length 30.328 in
 Section Width 20.333 in
 Flange Thickness 1.308 in
 Web Thickness 0.749 in

Allowable Stresses

Concrete f_c 20,685.4 psi
 Base Plate F_y 248.22 ksi
 Load Duration Factor 1.000

Anchor Bolt Data

Dist. from Plate Edge 5.080 in
 Bolt Count per Side 2
 Tension Capacity 24.465 k
 Bolt Area 1.122 in²

Summary

Baseplate OK

Concrete Bearing Stress Bearing Stress OK
 Actual Bearing Stress 411.8 psi
 Allow per ACI 318-95, A3.1
 $= 0.3 * f'_c * \sqrt{A_2/A_1} * LDF$ 7,494.0 psi
 Allow per AISC J9 8,743.0 psi

Full Bearing: No Bolt Tension

Plate Bending Stress Thickness OK
 Actual f_b 156,970.6 psi
 Max Allow Plate F_b 186,165.8 psi

Tension Bolt Force Bolt Tension OK
 Actual Tension 0.000 k
 Allowable 24.465 k

4.7 Bolt Group

This program provides force distribution from loads applied to a group of up to 16 bolts.

The user enters a vertical and horizontal loads and its location from a datum point. Also with respect to a datum point, the coordinates of up to sixteen bolts are entered.

Using these force and bolt coordinates, the program calculates direct shears and torsional shears on each bolt due to their relative location within the group.

ENERCALC c:\ECSS\EXAMPLES.ECW - Bolt Group Analysis

Bolt Group Analysis

Tools & Settings ? Help Print Cancel Save

General | Bolt Locations | Bolt Calculations | Sketch

Description 10 Bolt Group w/ Vert & Lat Loads

Applied Load

Vertical Load 46.800 k
 ... Horiz Dist from Datum 14.500 in

Horizontal Load 62.400 k
 ... Vert Dist from Datum 20.500 in

Center of Bolt Group (CBG) Location...

Y Distance 10.000 in
 X Distance 7.000 in

Load Eccentricity from C.B.G

Y Distance 10.500 in
 X Distance 7.500 in

Moment : Mx -351.00 in-k
 Moment : My 855.20 in-k

	Bolt Dist. From C.B.G.		Direct Shear Force		Torsional Shear Force		Bolt Force
	in		k		k		
	X	Y	X	Y	X	Y	k
#1	-3.00	-6.00	-6.24	-4.68	6.76	-3.38	8.08
#2	-3.00	-3.00	-6.24	-4.68	3.38	-3.38	8.55
#3	-3.00	0.00	-6.24	-4.68		-3.38	10.19
#4	-3.00	3.00	-6.24	-4.68	-3.38	-3.38	12.55
#5	-3.00	6.00	-6.24	-4.68	-6.76	-3.38	15.30
#6	3.00	-6.00	-6.24	-4.68	6.76	3.38	1.40
#7	3.00	-3.00	-6.24	-4.68	3.38	3.38	3.14
#8	3.00	0.00	-6.24	-4.68		3.38	6.37
#9	3.00	3.00	-6.24	-4.68	-3.38	3.38	9.71
#10	3.00	6.00	-6.24	-4.68	-6.76	3.38	13.06
#11	0.00	0.00					
#12	0.00	0.00					
#13	0.00	0.00					
#14	0.00	0.00					
#15	0.00	0.00					
#16	0.00	0.00					
Totals =			-62.40	-46.80			

Basic Usage

Vertical and Horizontal Loads and locations are entered after locating a Datum point from which the loads and all bolt locations will be referenced.

Location of Each Bolt is entered starting from the top row in the table, and working downward.

Note!! The last entry in the table that has a (0,0) bolt location is used to tell the program where the last bolt was entered. If any of your bolt locations is (0,0), ENTER THAT BOLT ON THE FIRST ROW OF THE TABLE.


Assumptions & Limitations

- When determining the actual load per bolt, at least one load, (either vertical or horizontal) must be specified, otherwise output will be 0".
- At least two bolts should be specified.
- All bolts are assumed to be of the same deformation characteristics when loads are distributed.
- Vertical and Horizontal forces are divided by the number of fasteners to give direct shears.

Example

The data entry for this example is shown in the screen captures that accompany the Data

Entry Tabs and Results & Graphics Tabs sections to follow.



Data Entry Tabs

This set of tabs provides entries for all input in this calculation. While you are entering data and switching between these tabs you can view the desired resulting information on the tabs on the right-hand side of the screen (calculated values, sketches, diagrams, etc.). A recalculation is performed after any entry data is changed. After each data entry you can view the results on the right-hand set of tabs.

General Tab

General		Bolt Locations	
Description		10 Bolt Group w/ Vert & Lat Loads	
Applied Load			
Vertical Load		46.800	k
... Horiz Dist from Datum		14.500	in
Horizontal Load		62.400	k
... Vert Dist from Datum		20.500	in
Center of Bolt Group (CBG) Location...			
Y Distance		10.000	in
X Distance		7.000	in
Load Eccentricity from C.B.G			
Y Distance		10.500	in
X Distance		7.500	in
Moment : Mx		-351.00	in-k
Moment : My		655.20	in-k

Eccentric Loads

These loads will be applied to the bolt group. If the actual load is at an angle to the coordinate axis you are using, be sure to resolve it into its vertical and horizontal components.

Eccentricity From Datum

Enter the X or Y coordinate of the point of application of the load according to your X-Y axis system.

Center of Bolt Group (CBG) Location

The program calculates the center of the bolt group you've specified and displays it here. The distances are referenced to the coordinate axis datum being used, and is calculated using statics.

Load Eccentricity from CBG

These values are the distance of the applied load to the center of the bolt group.

Eccentric Moments

This is the actual moment about the calculated Center of Bolt Group. This moment is equal to the vertical or horizontal load, multiplied by the Load Eccentricity.

Bolt Locations Tab

This tab contains the entry areas for the bolt locations. All locations should be entered with reference to a datum point you selected.

General		Bolt Locations	
Bolt Coordinates...			
	X in	Y in	
# 1	4.000	4.000	
# 2	4.000	7.000	
# 3	4.000	10.000	
# 4	4.000	13.000	
# 5	4.000	16.000	
# 6	10.000	4.000	
# 7	10.000	7.000	
# 8	10.000	10.000	
# 9	10.000	13.000	
# 10	10.000	16.000	
# 11	0.000	0.000	
# 12	0.000	0.000	
# 13	0.000	0.000	
# 14	0.000	0.000	
# 15	0.000	0.000	
# 16	0.000	0.000	

Results & Graphics Tabs

This set of tabs provides the calculated values resulting from your input on the "Data Entry Tabs". Because a recalculation is performed with each data entry, the information on these tabs always reflects the accurate and current results, problem sketch, or stress/deflection diagram.

Bolt Calculations Tab

	Bolt Dist. From C.B.G		Direct Shear Force		Torsional Shear Force		Bolt Force k
	in		k		k		
	X	Y	X	Y	X	Y	
#1	-3.00	-6.00	-6.24	-4.68	6.76	-3.38	8.08
#2	-3.00	-3.00	-6.24	-4.68	3.38	-3.38	8.55
#3	-3.00	0.00	-6.24	-4.68		-3.38	10.19
#4	-3.00	3.00	-6.24	-4.68	-3.38	-3.38	12.55
#5	-3.00	6.00	-6.24	-4.68	-6.76	-3.38	15.30
#6	3.00	-6.00	-6.24	-4.68	6.76	3.38	1.40
#7	3.00	-3.00	-6.24	-4.68	3.38	3.38	3.14
#8	3.00	0.00	-6.24	-4.68		3.38	6.37
#9	3.00	3.00	-6.24	-4.68	-3.38	3.38	9.71
#10	3.00	6.00	-6.24	-4.68	-6.76	3.38	13.06
#11	0.00	0.00					
#12	0.00	0.00					
#13	0.00	0.00					
#14	0.00	0.00					
#15	0.00	0.00					
#16	0.00	0.00					
Totals =			-62.40	-46.80	k		

Bolt Dist. from Center of Bolt Group

From the user defined bolt location and the calculated center of bolt group, the distance from bolt to center of bolt group is found. If the bolt is to the left or above the C.B.G., it will be displayed negative, and vice versa.

Direct Shears

The direct shear to each bolt is simply the applied vertical or horizontal load divided by the total number of bolts.

Torsional Shears

The torsional shears are calculated considering the actual bolt location with the C.B.G.

The following relationship is used:

$$\text{Torsion} = \text{Applied Load} * \text{Arm}$$

-also-

$$\text{SUM} (\text{Bolt Force} * \text{Bolt Dist to C.B.G.}) = \text{SUM} (d_i * F_i)$$

Where:

d_i = Absolute distance from bolt to C.B.G.

F_i = Absolute Force on each bolt.

Setting: $F_i = \text{Alpha} * d_i$

We get: $P_e = \text{SUM} (\text{Alpha} * d_i^2)$

Then: $\text{Alpha} = P * e / \text{SUM} (d_i^2)$

But : $d_i^2 = (X\text{-Dist to CBG})^2 + (Y\text{-Dist to CBG})^2$

From the above relationship, we can easily calculate Alpha.


Therefore, $F_i = \text{Alpha} * d_i$

Resultant Bolt Force

This is simply the resultant of the direct and torsional shear components for each bolt, added vectorially to determine the maximum load per bolt.

Sketch Tab

This tab provides a sketch of the beam with loads and resulting values shown. Using the [Print Sketch] button will print the sketch in large scale on a single sheet of paper.



Sample Printout

ENERCALC Engineering Software
 P.O. Box 188
 Corona del Mar, CA 92660
 Voice: 949 645-0151
 www.enercalc.com

Title: ENERCALC Example Problems Job # 97-000001
 Dsgnr: MDB Date: 10:08PM, 26 OCT 03
 Description: Collection of example problems

Scope: All programs in the Structural Engineering Library

Rev: 080000
 User: K:\970800001, Ver 5.8.0, 10-Sep-2003
 ©1983-2003 ENERCALC Engineering Software

Bolt Group Analysis

Page 1

c:\ec5\examples.ecw\Steel Calc

Description 10 Bolt Group w/ Vert & Lat Loads

General Information

Code Ref: AISC 9th ASD, 1997 UBC, 2003 IBC, 2003 NFPA 5000

Vertical Load	46.80 k	Bolt Group Centroid..	Load Eccentricity from C.B.G
eccentricity	14.500 in	Y Distance	10.000 in
		X Distance	7.500 in
Horizontal Load	62.40 k		Moment : Mx
eccentricity	20.500 in		Moment : My
			-351.00 in-k
			655.20 in-k

Group Data & Results

	Bolt Coordinates		Bolt Dist. From C.B.G		Direct Shear Force		Torsional Shear Force		Final Force
	X	in Y	X	in Y	X	k Y	X	k Y	
#1	4.000	4.000	-3.00	-6.00	-6.24	-4.68	6.76	-3.38	8.08
#2	4.000	7.000	-3.00	-3.00	-6.24	-4.68	3.38	-3.38	8.55
#3	4.000	10.000	-3.00		-6.24	-4.68		-3.38	10.19
#4	4.000	13.000	-3.00	3.00	-6.24	-4.68	-3.38	-3.38	12.55
#5	4.000	16.000	-3.00	6.00	-6.24	-4.68	-6.76	-3.38	15.30
#6	10.000	4.000	3.00	-6.00	-6.24	-4.68	6.76	3.38	1.40
#7	10.000	7.000	3.00	-3.00	-6.24	-4.68	3.38	3.38	3.14
#8	10.000	10.000	3.00		-6.24	-4.68		3.38	6.37
#9	10.000	13.000	3.00	3.00	-6.24	-4.68	-3.38	3.38	9.71
#10	10.000	16.000	3.00	6.00	-6.24	-4.68	-6.76	3.38	13.06