




## Structural Engineering Library

**ENERCALC, INC**

© 2020 ENERCALC, Inc.



# **Structural Engineering Library**

**Version 6.0**

---

*by Michael D. Brooks, S.E., P.E.*

*A product of*  
**ENERCALC, INC.**

# Structural Engineering Library

© 2020 ENERCALC, Inc.

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

## **Publisher**

*ENERCALC, INC.*

### **Managing Editor**

*Michael D. Brooks, S.E., P.E.*

ENERCALC Engineering Software

Post Office Box 188  
Corona del Mar, CA 92625  
(949) 645-0151  
(800) 424-2252  
Fax: (949) 645-3881

Sales: [info@enercalc.com](mailto:info@enercalc.com)  
Support : [support@enercalc.com](mailto:support@enercalc.com)  
Web : [www.enercalc.com](http://www.enercalc.com)

**Vesion 6 User's Reference**  
**March 2010**  
**Corona del Mar, CA, USA**

# Table of Contents

Foreword	0
<b>Part I Introduction</b>	<b>1</b>
1 Welcome.....	3
2 Our History.....	5
3 Warning & Disclaimer.....	7
4 License & Copyright.....	8
5 End of Service Policy.....	9
<b>Part II Installation &amp; Activation</b>	<b>10</b>
1 License Types.....	12
2 Installation Overview.....	14
3 Activation Types.....	15
4 Manual Activation.....	17
5 Moving & Maintaining Your Activation.....	19
<b>Part III Software Updates</b>	<b>23</b>
1 Web Update.....	25
2 Update from Website.....	28
<b>Part IV Support &amp; Maintenance</b>	<b>29</b>
1 Maintenance & Support Plan.....	31
2 Getting Assistance.....	32
3 Viewing Enhancements and Changes to the Software.....	34
<b>Part V Getting Started</b>	<b>35</b>
1 System Overview & Design Philosophy.....	37
2 About Our Documentation.....	38
3 Building Codes Supported.....	39
4 Learning Structural Engineering Library.....	40
5 Introductory Videos.....	41
6 Request for Suggestions.....	42
<b>Part VI Program Overview</b>	<b>43</b>
1 Introduction.....	45
2 Typical Worksession.....	47
3 Program Settings.....	48
4 Files & File Locations.....	55

5	Project Assistant.....	56
6	Databases.....	58
7	Screen Layout.....	59
8	Generating Reports.....	62
9	General Calculation Screen Usage.....	64
10	3D Renderings.....	66

**Part VII Main Menu 68**

1	File .....	70
2	Settings.....	76
	Default Values .....	78
3	Databases.....	79
	Steel Section Database .....	80
	Wood Section Database .....	81
	Wood Reference Design Values Database .....	82
	Masonry Database .....	83
	Load Combination Database .....	84
4	Tools.....	87
5	License.....	89
6	Help .....	90

**Part VIII Project Manager 94**

1	General Division.....	101
	Building Code Information .....	102
	Project Information .....	103
	Client Information .....	104
	Designer Notes .....	105
	Revision List .....	106
2	Loads & Forces Division.....	107
3	Calculation List.....	108
	Divisions .....	112
	Adding, Deleting, Copying .....	116
	Sorting by Division, Type & Material .....	118
	Changing Calculation Order .....	122
	Importing Calculations .....	126
4	Project Printing.....	131


**Part IX Sample Session 134**

1	Starting the Program.....	136
2	Project Assistant.....	137
3	Creating a Project File.....	139
4	Entering Project Information.....	141
5	Setting up your Title Block.....	143
6	Adding a Calculation.....	145
7	Viewing the Calculation Screen.....	148

8	Changing the Default Values/Settings.....	149
9	Entering Data.....	150
10	Selecting Sections and Materials from Built-in Databases.....	161
11	Displaying a Sketch.....	166
12	Displaying Diagrams.....	167
13	Automatic Member Section Selection.....	169
14	Printing a Calculation.....	172
15	Saving a Calculation.....	175
16	Editing a Division Name and Adding a New Division.....	176
17	Adding Another Calculation.....	180
18	Creating a Technical Support Question.....	183
19	Closing a Project File.....	188
 <b>Part X Calculation Modules</b>		<b>189</b>
1	Loads & Forces Division.....	191
	ASCE Seismic Base Shear .....	192
	ASCE Seismic Demands on Nonstructural Components .....	205
	ASCE Seismic Wall Anchorage .....	206
	ASCE Wind Enclosure .....	208
	ASCE 7-10/7-16 Wind Forces, Chapter 27, Part 1 .....	210
	ASCE 7-05 Section 6.4, MWFRS:Simplified Forces .....	225
	IBC Alternate All-Heights Wind Method .....	228
	ASCE Snow Loads .....	234
	ASCE Live and Roof Live Load Reduction .....	239
	Project Load Group Builder .....	240
2	Beams.....	245
	Multiple Simple Beam .....	258
	General Beam Analysis .....	269
	Wood Beam .....	273
	Steel Beam .....	283
	Concrete Beam .....	288
	Beam on Elastic Foundation .....	294
	Composite Steel Beam .....	295
	Wood Ledger .....	307
	Masonry Beam .....	313
	Steel Beam with Torsional Loads .....	321
3	Columns.....	326
	Column Slenderness .....	331
	Wood Column .....	335
	Steel Column .....	344
	Concrete Column .....	350
	Masonry Column .....	366
4	General Walls.....	372
	Concrete Slender Wall .....	373
	Masonry Slender Wall .....	387
5	Shear Walls.....	400
	Concrete Shear Wall .....	401

	<b>Masonry Shear Wall</b> .....	411
	<b>Wood Shear Wall</b> .....	418
<b>6</b>	<b>Retaining Walls</b> .....	<b>435</b>
	<b>Cantilevered Retaining Wall</b> .....	436
<b>7</b>	<b>Foundations</b> .....	<b>467</b>
	<b>General Footing</b> .....	468
	<b>Combined Footing</b> .....	480
	<b>Wall Footing</b> .....	489
	<b>Pile Group</b> .....	499
	<b>Pole Footing Embedded in Soil</b> .....	503
	<b>Beam on Elastic Foundation</b> .....	510
<b>8</b>	<b>2D Frame Analysis</b> .....	<b>511</b>
	<b>Frame Wizard</b> .....	516
	<b>Joints &amp; Joint Loads</b> .....	521
	Joint Data.....	524
	Joint Loads & Results.....	528
	<b>Members &amp; Member Loads</b> .....	531
	Member Data.....	534
	Member Loads.....	543
	Member Forces.....	549
	<b>Sections &amp; Materials</b> .....	550
	Section Data.....	550
	Material Data.....	552
	<b>Load Combinations</b> .....	555
	<b>Wood Design</b> .....	558
	<b>Results</b> .....	559
	Extreme Values.....	559
	Joint Displacements & Reactions.....	562
	Member End Forces.....	563
	Member Details.....	564
	Member Check Results.....	565
	Sign Convention.....	567
	<b>Frame Sketch</b> .....	570
	<b>Member Diagrams</b> .....	571
	<b>Reports</b> .....	573
	<b>Printout</b> .....	574
<b>9</b>	<b>Miscellaneous Calculation Modules</b> .....	<b>580</b>
	<b>Torsional Analysis of Rigid Diaphragm</b> .....	581
	<b>Point Load on Slab</b> .....	595
	<b>General Section Property Calculator</b> .....	598
	<b>Rebar Development Table</b> .....	605
	<b>Steel Bolt Group Analysis</b> .....	607
	<b>Steel Base Plate</b> .....	611
<b>10</b>	<b>External Items</b> .....	<b>619</b>
	<b>EXCEL Spreadsheet</b> .....	620
	<b>WORD Document</b> .....	624
	<b>Adobe Acrobat PDF</b> .....	628
	<b>Scanned Document</b> .....	632

**Part**





# 1 Introduction

Last Revised: 3 February 2020

## 1.1 Welcome

### [Welcome to Structural Engineering Library](#)

You've chosen one of the most respected Structural Engineering software packages available today. In continuous development since 1983, Structural Engineering Library is the culmination of years of development and refinement from suggestions of engineers worldwide.

**Structural Engineering Library** is developed with the practicing engineer in mind. Although large complex frames are fun projects, structural engineers spend most of their time designing and analyzing the components of structures. Because most of the buildings worldwide rely on simple beams, columns, foundations, walls, and other small items, this software system will quickly become your best friend. **Structural Engineering Library** remembers the mathematics, building code provisions, and standard materials you need to perform a detailed and economical design.

Because we feel that simple, repetitive engineering problems are far more common than extensive 3-D frame analysis, this software package is designed specifically for fast, interactive engineering design of building components. We've combined the typical working methods of engineers, national building code provisions, and construction material databases with the principles of structural mechanics into each "calcsheet" module. You will find that these modules operate very much like an electronic calculation pad....simply fill in the data entries and the entire calculation will be instantly updated for your review.

To add even more power and utility to the system, we've added detailed design sketches and stress diagrams, automatic design and sizing, an online help system, material databases, and elegant calculation printing to **Structural Engineering Library**.

**Structural Engineering Library** is designed around a file of calculations called a "**Project**". This single file with the extension "**EC6**" can hold one or thousands of individual calculations. You add, edit, and delete the calculations in your Project File during the in-office design stage. Then, when it's time for submittal to a governing agency, you can print a complete set of calculations.

Because of the ever-expanding number of modules, we invite you to stay in close contact with our website at [www.enercalc.com](http://www.enercalc.com). Maintenance releases, up-to-the-minute technical advice, revised electronic documentation, and new product information will all be provided there FIRST.

ENERCALC has put years of work into this package in support of the highly technical and dedicated service Structural Engineers provide to the people of the world. We continue to enhance this product weekly and are committed to developing this product well into the future. We extend our thanks for choosing ENERCALC, and look forward to using your suggestions to provide you with ever improving tools for your daily work.



## 1.2 Our History

**ENERCALC Engineering Software** (now **ENERCALC, INC.**) originated as one young engineer playing with his new T.I. programmable calculator in 1980. In 1981, a set of Lotus 1-2-3 spreadsheet templates was developed to automate the repetitive design of components of tilt-up and small office buildings. The software proved so productive and time saving that it was decided to market it in the newly founded microcomputer industry. The entire set of 26 spreadsheet "templates" was named **Structural Engineering Library** and shipped on three 360K 5 1/4" diskettes, running on a 4.77 MHz 8086 IBM PC. Typical cost of this state of the art engineering hardware and software system was \$6,000!

As years went by, sales of the product increased. For engineers to purchase a technical software system based as a pre-programmed spreadsheet "template", it was a testament both to the intelligence of the users and to the easy and simple design of the spreadsheet based software package.

In 1986, Lotus Development introduced a tool for programmers to link programs written in "C" to the very guts of 1-2-3. Called the "Add-In Toolkit", it offered a unique opportunity for **ENERCALC** software designers. A decision was made to rewrite all of the current engineering spreadsheet "templates" into the "C" language, and link these powerful programs to simple 1-2-3 "templates". The Lotus 1-2-3 spreadsheets would become data entry/output screens driving powerful "C" language compiled processing programs. This solved the major problem with a spreadsheet.....lack of iteration capability that was critical to engineering tasks.

Our first application of this technology was **FastFrame 2-D** introduced in 1987. **FastFrame** transformed a simple, off-the-shelf spreadsheet program into a powerful finite-element analysis system with full graphics. Prior to founding RISA Technologies, Bruce Bates worked on a "lightning fast" 16 MHz PC to develop the FastFrame solver. That solver would later become the guts of the first version of RISA 2-D. Users were amazed that the previously complex batch processed frame analysis systems were reduced to entering a number in a spreadsheet and INSTANTLY the entire frame was recalculated. At the 1987 Lotus Developers Conference in Boston, MA, the actual software authors of Lotus 1-2-3 were stunned to see their "business tool" doing complex analysis for multi story buildings!

With the decline of DOS and Lotus 1-2-3, **ENERCALC** rewrote the entire "user interface" portion that provided the calculation screens and printing. Keeping the same "look and feel" to ease the change for users, our programmers wrote our own user interface program, as simple and fast as 1-2-3, complete with support for hundreds of printers. Version 4.4 for DOS was released in August of 1994, and produced a large increase in ENERCALC's user base. Version 4.4 for DOS has become known as the "Volkswagen of structural engineering software"... simple, enduring, yet designed to get you almost anywhere.

**Structural Engineering Library 5.0 for Windows** was introduced in 1996 as a completely new rewrite of the legacy systems of the previous 15 years. Although much of the proven "C" language engineering calculation processes were retained, the rest of the system was redesigned and written from scratch for the modern Windows based computer systems. The days of a spreadsheet based program were now gone, and a new system designed to be as easy as 1-2-3 was introduced.

---

In 2007 ENERCALC released **Version 6 of Structural Engineering Library**. Over the course of three decades since ENERCALC began we've enjoyed a large, loyal and consistently growing base of users. This new version is a **complete rewrite**....the first of its kind. New solvers, graphics, reporting, user interface, and database designs prepare this new platform with the future in mind. We look forward to years of enhancements based on this new release!

In 2017 ENERCALC released the next generation of Structural Engineering Library. With this release, we de-emphasize the "version" number, and rely solely on the build number to identify the release. The software is now based on new development tools that are available to make processes more efficient and to provide a fresh, new look.

Sincerely,

Michael D. Brooks, P.E., S.E.  
*President & Founder*  
**ENERCALC, INC.**

## 1.3 Warning & Disclaimer

Although it is our intent that the information contained in this manual and associated software program is accurate and reliable, it is possible that there may be errors, both of omission and commission, that we are not aware of at any time. ENERCALC, Inc. can make no warranties, either express or implied, as to the accuracy of the material in this manual and software nor its suitability for a specific purpose or application for which it is advertised.

ENERCALC, Inc., its owners, directors, and employees, can offer no guarantee and will accept no liability for damages of any kind resulting from the use of the information contained or generated by this document and the accompanying computer software.

If you do not agree to be bound by these conditions and the conditions contained in the [License Agreement](#) contained herein, then you may Internet deactivate the program and uninstall the software within the trial period after the date of your order and request a full refund of the License Fee.

## 1.4 License & Copyright

The complete License Agreement can be viewed by using the following link:

[License Agreement](#)

## 1.5 End of Service Policy

At some point in the future the current version software will undergo a major overhaul of capability increase. At this time the prior version reaches its "**End of Service**" time.

When a version reaches its "End of Service", access to support and maintenance will cease in about 6 months (the time frame will be set by ENERCALC and is at our discretion). The software will continue to operate but technical support, updates, and other support related items will cease to be available.

All software products, Structural Engineering Library included, have a practical commercial lifetime. In order to provide the highest quality products and support to our customers, each product is developed utilizing a product life cycle methodology, which includes an End-of-Service (EOS) phase.

The ENERCALC product EOS policy is to support the current release plus the previous (one back) release for up to six (6) months by default. After this time, ENERCALC's product development ceases active development and support of that software release within the Maintenance and Support Plan. ENERCALC does not create or make available maintenance releases or patches for software that has reached the EOS milestone.

During the EOS phase, ENERCALC will continue to investigate, troubleshoot, and characterize issues in an attempt to provide solutions and workarounds using the production releases. If a solution cannot be found using software that has reached the EOS milestone, ENERCALC will suggest that the system be upgraded to a more recent software release.


Once the EOS process starts on a product release, a notice will be posted on all relevant pages stating that the product release has entered the EOS process.

**Note: This policy is subject to revision.**



# Part

---



## 2 Installation & Activation

### General

**Structural Engineering Library (SEL)** must be installed on each computer where it will be used.

SEL has a new license security system that activates the software.

This requires a copy & paste of the **Product Control Code (PCC)** into the activation section of the program and then using the [**Internet Activate**] button to obtain activation permission from our Internet Activation server.

**You can install SEL on ANY computer that you may wish to use it on, BUT before you can RUN the program, you must Activate it.**

This means you can easily move the activation of the software around between all of your computers. You can just use this Internet based activation and deactivation ability to use the software wherever you wish.

### Important: Anti-Virus software and Firewalls

Our **Internet Activation** system and Web Update system use the Internet with typical "http over port 80" communications. You may have to tell your anti-virus and firewall software to allow our programs to communicate over the Internet. The important program file names are **EC6.exe** and **ec6webupdate.exe**, and they are typically installed in the Program Files\ENERCALC\_6 folder. You will may also need to give your computer permission to communicate with enercalc.net. (Note that it does NOT use the www. prefix.)

If you do not perform this task then your activation request may not receive a response.

There are other methods of manually activating the software if you do not have an Internet Connection. Please see the "For Our Users" page at [www.enercalc.com/users.html](http://www.enercalc.com/users.html) under **Manual License Activation** and also the last section in this guide.

## 2.1 License Types

**Structural Engineering Library** can be licensed in a variety of formats:

### [Annual Subscription \(Installed on your computer\)](#)

You will receive a Product Control Code that will allow you to activate the software. After you have entered your Product Control Code and performed an activation, the product will be completely operational. Your user registration number and licensee name will appear on all printouts and you will see a subscription expiration date on the licensing screen. Usage ends when the subscription expires or is canceled, but all Project Files remain intact.

### [Monthly Subscription \(Installed on your computer\)](#)

You will receive a Product Control Code that will allow you to activate the software. After you have entered your Product Control Code and performed an activation, the product will be completely operational. Your user registration number and licensee name will appear on all printouts and you will see a subscription expiration date on the licensing screen. Usage ends when the subscription expires or is canceled, but all Project Files remain intact.

### [Perpetual License \(Installed on your computer\)](#)

You will receive a Product Control Code that will allow you to activate the software. After you have entered your Product Control Code and performed an activation, the product will be completely operational. Your user registration number and licensee name will appear on all printouts and you will see a Maintenance & Support Plan (MSP) expiration date on the licensing screen. When MSP expires, you can choose to renew MSP to keep up to date on new versions. If you do not renew your MSP, then you can continue to use the software indefinitely at whatever version you have when MSP expired.

### [Academic License](#)

This is a special version/mode for students. Each time an Academic license is granted an expiration date is set after which time the software stops operating. In addition the printouts have a watermark stating that it is an educational version and the student's name and registration number are printed. [Click here](#) for an application for an Academic License.

### [Plan Check License](#)

This is a special version/mode for public plan review agencies. Each time a Plan Check license is granted an expiration date is set after which time the software stops operating. In addition the printouts have a watermark stating that it is a plan check version and the agency's name and registration number are printed. [Click here](#) for an application for a Plan Check License.

### [ENERCALC SE Cloud Subscription](#)

This subscription offering allows access to our cloud-based applications: STRUCTURE, EARTH, and ENERCALC 3D. STRUCTURE is the cloud format of Structural Engineering Library. EARTH is the cloud format of RetainPro. ENERCALC 3D is our general purpose 3D finite element analysis and design application. No installations are required for ENERCALC SE. The applications run through your Internet browser, and data is stored in our secure online storage for universal availability and ease of collaboration.

## 2.2 Installation Overview

### General

For the most current installation information you need to review this document located on our website:

[http://www.enercalc.com/pdf/EC\\_V6\\_Install\\_SingleLicense.pdf](http://www.enercalc.com/pdf/EC_V6_Install_SingleLicense.pdf)


**Structural Engineering Library (SEL)** must be installed on each computer where it will be used. Click here for a video on installation: [Installation](#)

Feel free to install the software on any computer where you may want to run it, but keep in mind that you will need to Activate an installation before it will actually run. More on that in the Activation section...

When using our installation program you will be asked to paste in your **Product Control Code (PCC)** for security. Then simply follow the on-screen prompts to complete the installation.

## 2.3 Activation Types

When Internet activating SEL, the following activation types will be offered:



Click here for a video on Internet Activation:

Internet Activation

The activation types behave as follows:

### Indefinite:

This option saves activation info to your computer, so it will result in an installation that will remain activated until it is Internet deactivated by the user, or until another user forcibly deactivates this computer.

This option is useful in situations where the number of users is equal to the number of available seats, such that there is no need to share seats among multiple computers. It is also useful in situations where a laptop will be taken to a remote location where Internet access is uncertain.

### Automatic Activation/Deactivation:

This option automatically activates the program when it is launched (if a seat is available), and it automatically deactivates when the user exits the program.


This option is useful in situations where the number of users is greater than the number of available seats, such that there is need to share seats among multiple computers.

---


Note: To change to a different activation type, such as to change from "Automatic" to "Indefinite", simply Internet Deactivate temporarily. Then Internet Activate once again and you will be offered the "Select Activation Type" dialog where you can choose the desired activation type.

## 2.4 Manual Activation

If you cannot activate the software using the simple **[Internet Activate]** method (because you have no connection, restricted access to the Internet due to a firewall, or your company prefers not to activate your installation this way), you can activate your software using the **[Manual Activation]** method.



Click the **[Manual Activation]** button. The system will provide some information in a Caution box:






Then instructions will be provided to you using the screen shown below:

Manual Product Activation

**Manual Activation Code Request String :**

Please send Manual Activation Code for: KW-06000215-CHRISDELL-PC[D481D7DF4492]215|vJzVvBu4H5TEz1a1J1IHwRgjB|0|0, MSP Expiration: Nov 2019, Build: 10.19.1.30


 Copy to Clipboard

**STEP 1 :**  
Send this "Manual Activation Code Request String" to ENERCALC.  
Please paste the Request String into an email...DO NOT send a screen capture.


[Click here to automatically create an email](#)

**STEP 2 :**  
After you receive the "Manual Activation Code" enter it below and click **Activate**

*Paste Manual Activation Code below . . .*



**Activate**

 Close

NOTE: When using the Manual Activation method, the Manual Activation Code that you receive from ENERCALC can only be used to activate the **specific machine** that was used to make the Manual Activation Code request, because the request and the code actually contain the Computer Name and other data that is specific to that particular machine. However, you can still use the Internet Deactivate function to return a manually activated seat to your pool. And then you would be able to use that available seat from your pool to perform a normal Internet Activation on a different computer if desired.

## 2.5 Moving & Maintaining Your Activation

A Structural Engineering Library license has some number of "seats" associated with it. Each activation uses one of your available seats. When an installation gets deactivated, that seat returns to your pool of available seats.


This section will assist you in moving your activation from one computer to another.

### Moving Your Activation


When you originally activated the software, if you used [**Internet Activate**], then you can use [**Internet Deactivate**] to return this activation to our server, so that it can be available to another computer.

#### **Follow these steps:**


Start **Structural Engineering Library**. You will probably see the Project Assistant screen as shown below:



Click the **[Close]** button. Click **License > Software Activation** from the main menu as shown below:



You will now see the Software License Control dialog as shown below:



Click the **[Deactivate This Computer]** button to return your activation to our server.

Note! You must allow the ENERCALC file “EC6.EXE” Internet access through your firewall or anti-virus software. Also, be sure to trust enercalc.net (note no www.).


After a moment, the system will indicate that the installation has been successfully deactivated by offering an **[Internet Activate]** button in the Software License Control dialog as shown below:



Your activation has now been returned to our server, and you can go to another computer where **Structural Engineering Library** is installed, and activate it by clicking **License >Software Activation > [Internet Activate]** from the main menu.

# Part

---



### 3 Software Updates

### 3.1 Web Update


At **ENERCALC** we are continually improving and enhancing our software. It is fairly simple to make changes to the software here in our offices, however it can be overwhelming to ship thousands of CDs to our user base. To distribute the latest software builds to the entire user base, we depend on a Web Update system. The update is provided in two ways:

Web Update System: This system is built into your **Structural Engineering Library** software package. It will check with our server to see if a newer version of the software is available and prompt you with an option to install it if available. See *What Actually Happens* below for a description of how it works.

The Web Update system uses Internet protocol HTTP on port 80 to check if a newer version of the software is available and to transfer those files from our server to your computer as needed. You can configure the program to perform this check automatically every time you start the software, but it can also be performed on an on-demand basis if desired.

Select **Settings > Updates** from the main menu to display the web update screen as shown below:





**What actually happens during an update check:** What actually happens during an update check is that the software runs a program in the ENERCALC program folder named EC6WebUpdate.exe. This program connects to our Internet servers using the "HTTP" protocol on port 80. It compares the version number you have installed with the current build of the software stored on our servers. If there is a newer build available, you are notified and upon approval, a small update installation program named EC6\_WebUpdate.exe is transferred from our server to your computer. This file then executes to complete the file download and software updating/installation process.

EC6WebUpdate.exe and EC6\_WebUpdate.exe are digitally signed applications that are secure to run and are virus free.

The actual updating program EC6\_WebUpdate.exe that is downloaded from our server will need "write" access to the program installation folder.

**Check for MAJOR updates now:** This button will download the updating program from our server. This program will check your computer for a non-expired Maintenance & Support Plan and update the software to the latest allowed version.

**Note:** The "WebUpdate" procedure may send information to ENERCALC, Inc. about your installation and use of the software licensed from ENERCALC, Inc. This may include any of the following: your ENERCALC assigned User Registration Number, the Installed Build Number of your ENERCALC software, Internet IP address of the computer that will receive the updated files, time usage for the various portions of the software, and potentially other information only related specifically to the use of the software license. Absolutely no files, configurations, settings, or other information not specifically regarding the usage of the ENERCALC license will be sent. If you are concerned about this, please contact us for information on what is being sent. We have an open policy on providing you with information showing what might be included.

**TECH NOTE:** Some users with multiple installations may prefer to set the status of the automatic check directly through the registry entry for convenience:

REG\_CURRENT\_USER\Software\ENERCALC\V6\DoCheckForUpdates

Yes = 1

No = -1

## 3.2 Update from Website

In addition to the Web Update system that is built into the software, it is also possible to initiate updates by visiting the "For Our Users" page of [www.enercalc.com](http://www.enercalc.com) and using the [UPDATE Structural Engineering Library](#) link.

**Note:**

There are times where a more recent build will be available on the website than is offered/detected by the built-in Web Update system. The reason for this is as follows. The built-in Web Update system offers those updates that are regarded as "major" or that have a significant impact on a majority of the users. On the other hand, the website will always offer an update for the absolute latest available build of Structural Engineering Library, regardless of whether it is categorized as a "major" update or not.

**Part**



## 4 Support & Maintenance

## 4.1 Maintenance & Support Plan

Our **Maintenance & Support Plan (MSP)** ensures that you will always have full technical support and access to the latest build of the software during the term of the plan.

While your MSP is current, you will receive every new build, feature enhancement, and improvement for your licensed software, ensuring you're always using the most current technology.

You will have access to voice/fax/email technical assistance from our staff.

You will also receive discounts on new software releases and additional software licenses. This is the easiest and most economical way for you and your company to keep your software investment current.

Please see this web page for details on the Maintenance & Support Plan:

[http://www.enercalc.com/support\\_maintenance.html](http://www.enercalc.com/support_maintenance.html)

## 4.2 Getting Assistance


There are several ways to get assistance with using **Structural Engineering Library**.

Click here for a video: [Getting Assistance](#)

HOWEVER, with the exception of referring to the program documentation and reviewing the FAQ section on the website, all options require that your Maintenance & Support Plan is current.

- Refer to the program documentation.
- Contact ENERCALC Technical Services by email:

From the main menu:



From your email program: [support@enercalc.com](mailto:support@enercalc.com)

- Contact ENERCALC Technical Services by fax: 949-645-3881
- Contact ENERCALC Technical Services by phone: 949-645-0441, Extension #3

- Review the "Frequently Asked Questions" (FAQ) page on our website:

[http://www.enercalc.com/support\\_knowledge.html](http://www.enercalc.com/support_knowledge.html)



## 4.3 Viewing Enhancements and Changes to the Software

The program offers a detailed list of revisions that have been made to the software.

Click **Help > Enhancement/Change History**. The following window will be displayed:

Enhancement & Change History - Structural Engineering Library

Show Enhancements Only MSP Expires 30 NOV 2019

Build Order Click on revision item to display full text in box to right.

Build Number	Module Name / Change	Revision	Date
10.19.03.04	Section Properties		
	Corrected calc of trapezoid	10.19.03.04	4 Mar 2019
10.19.01.31	General Update Comments		
	New Print Preview Added	10.19.01.31	31 Jan 2019
10.19.01.30	General Update Comments		
	Window Resizing System Improved	10.19.01.30	30 Jan 2019
	New Activation System	10.19.01.30	30 Jan 2019
10.19.01.25	General Update Comments		
	New Activation System	10.19.01.25	25 Jan 2019
10.19.01.17	Snow Loads		
	ASCE 7-16 Exposure Factor	10.19.01.17	17 Jan 2019
10.18.12.30	Column Analysis		
	Steel : Channels as columns	10.18.12.30	30 Dec 2018
	Multi Beam & Joist Design		

Installed Build : 10.19.1.30    Allowed Version : 10.19.1.30    Close

This list can be set to display enhancements **only**, or it can display enhancements **and** changes/corrections. When the list is set to display both enhancements and changes/corrections, it can be sorted by version or by module.

**Part**



## 5 Getting Started

## 5.1 System Overview & Design Philosophy

**Structural Engineering Library** is a collection of modules that provides analysis and design functionality for components of buildings.

Walls, columns, beams, footings, diaphragms, frames, and other common elements can be thoroughly engineered through the use of the modules in this package. If you are a typical engineer whose work consists of a regular flow of small and medium-sized projects, *this package is designed specifically for you.*

As an engineer you will find that each module combines the governing code provisions, mathematical analysis processes, and commonly available construction materials into a simple and effective "calcpad" style fill-in-the-blanks program. You can feel partially relieved that the software will consistently perform all the required checks that may be skipped over when doing repetitive hand calculations....especially when fatigue sets in and a deadline is near! You can enjoy the time to do more exhaustive design studies, come up with safer and more economical designs, and enjoy clearly documented calculations for review and archiving.

This software is not a "black box" program. Each calculation is designed to be a "visible calcpad" where you can work with the data and immediately view the resulting calculations. Automatic design is provided in most modules, and is intended primarily to automate tedious iterative tasks.

You, as an experienced structural engineer or architect, can quickly enter and change member sizes and other design parameters and view the results. In this way, **Structural Engineering Library** maximizes the use of your time and design skills by enabling you to quickly define a concept and then make necessary modifications to refine it into a final design.

## 5.2 About Our Documentation

Documentation of your software package is essential for your successful and pleasant use of our products. We try hard to supply you, now and on an ongoing basis, with detailed information on all aspects of the software. To support this commitment, we provide documentation of your software in multiple forms:

- A **Windows Help system file** named ENERCALC.CHM is installed with your software. This help system may be accessed by clicking **Help > Dynamic Help** from the main menu.
- A **User's Manual** in Adobe Acrobat PDF file format is available for download at any time from our website [http://www.enercalc.com/pdf/SEL60\\_DOCS.PDF](http://www.enercalc.com/pdf/SEL60_DOCS.PDF).
- An **Online Help system** is available at [www.enercalc.com/sel\\_help](http://www.enercalc.com/sel_help).

### Printed Documentation

Printed documentation is not provided with ENERCALC products. This is in keeping with the nearly universal industry move away from printed documentation.

### Updating your Documentation

The most up-to-date documentation for our software products is always available in electronic form. Whenever the software is updated with the built-in Web Update system, part of the process includes transferring the latest documentation to your computer. This ensures that the content that you view by clicking **Help > Dynamic Help** from the main menu is current and coordinated.

## 5.3 Building Codes Supported

As of May 2019, SEL supports the following codes and design standards:

### **Design Standards:**

- American Concrete Institute publication ACI 318-05/08/11/14
- American Concrete Institute publication ACI 530-05/08/11/13
- American Forest & Paper Association publication NDS 2005/2012/2015/2018 Editions
- American Society of Civil Engineers publication ASCE/SEI 7-05/7-10/7-16
- American Institute of Steel Construction publication AISC 360-05, -10, and -16
- The Masonry Society publication TMS 402/602-16

### **General Building Codes:**

- International Code Council publication International Building Code 2006, 2009, 2012, 2015 and 2018 editions. IBC references the above publications in Chapter 35. The modifications to each referenced design standard have been incorporated if applicable to the functionality provided by the individual calculation modules.
- California Building Standards Commission publication 2007 California Building Code, 2010 California Building Code, 2013 California Building Code, 2016 California Building Code and 2019 California Building Code. Chapter 19 references ACI 318, Chapter 21 references ACI 530/TMS 402/602, Chapter 22 references ANSI/AISC 360-05, Chapter 23 references NDS, and Chapter 16 which defines the forces on buildings is essentially the same as ASCE 7-05/ASCE 7-10/ASCE 7-16.

## 5.4 Learning Structural Engineering Library

There are several sources of information that will assist you with learning to use **Structural Engineering Library**.

- A series of tutorial videos is available at our website:

[http://www.enercalc.com/training\\_videos.html](http://www.enercalc.com/training_videos.html)

- This documentation. An Internet version of the help system is available at:

[http://www.enercalc.com/sel\\_help](http://www.enercalc.com/sel_help)

- Responses to "Frequently Asked Questions" are available at our website:


[http://www.enercalc.com/faq\\_help/](http://www.enercalc.com/faq_help/)

## 5.5 Introductory Videos

We continue to add topics to a series of videos that discuss all portions of the software.

To access nearly 40 videos please click here: [http://www.enercalc.com/training\\_videos.html](http://www.enercalc.com/training_videos.html)

Here is a partial view of what you will see....



The screenshot shows the ENERCALC website's "TRAINING VIDEOS" page. The page features a navigation menu with options like "Products & Pricing", "Solutions", "Support & Resources", "For Our Users", "Existing User Ordering", and "New Purchases / Quotes". The "Training Videos" link is highlighted in the navigation bar. The main content area is titled "TRAINING VIDEOS" and includes a paragraph explaining the availability of informative videos. Below this, there is a link to a "VIDEO TOUR of the Structural Engineering Library". The page also lists "Resources & Technical Support" and "Installation & Activation" sections, each with a list of links to related content.

**ENERCALC** Home Company Purchase

Products & Pricing Solutions Support & Resources For Our Users Existing User Ordering New Purchases / Quotes

Contact Technical Support Subscriptions Maintenance & Support Plan Knowledge Base & FAQ's Training Videos Software Updates Documentation

### TRAINING VIDEOS

In addition to the documentation supplied with the software we have an ever expanding series of informative videos available.

These are not Hollywood epics... they are narrated screen capture sessions by our staff in an easy to understand, informal style. Our goal is to give you easy visual instruction on many portions of the system to supplement the formal documentation. Please use the links below.

[» VIDEO TOUR of the Structural Engineering Library](#)

#### Resources & Technical Support

- [Where to Get Help](#)
- [Overview of Available Support Assistance](#)

#### Installation & Activation

- [Activation](#)
- [Installing the Structural Engineering Library](#)
- [Installing the Network License Manager](#)
- ["Activating" your Software - Internet](#)



## 5.6 Request for Suggestions

Although our intentions are to provide you with the best product possible, it is likely that there may be areas of this User's Guide and the software itself that could be improved to better suit your needs, be made simpler to operate, easier to understand, or support engineering technologies that have emerged since this publication.


To call these to our attention and to offer suggestions for improvement, we sincerely request that you send us your thoughts. Please address your comments to [support@enercalc.com](mailto:support@enercalc.com), or:

Michael D. Brooks, P.E., S.E.  
*President*  
ENERCALC, Inc.

[support@enercalc.com](mailto:support@enercalc.com)

Post Office Box 2208  
Newport Beach, California, USA 92659

**Part**



## 6 Program Overview

## 6.1 Introduction

**Structural Engineering Library** is a collection of modules (also referred to as "calcsheets") that provide functionality for the analysis and design of components of buildings. Walls, columns, beams, footings, diaphragms, frames, and other common elements can be thoroughly engineered through the use of the modules in this package. If you are a typical engineer, whose work consists of a monthly flow of small and medium-sized projects, this package is designed especially for you.

As an engineer, you will find that each module combines the governing code provisions, mathematical analysis processes, and commonly available construction materials into a simple and effective "calcpad" style fill-in-the-blanks program. You can feel partially relieved that the software will consistently perform all the required checks that may be skipped over when doing repetitive hand calculations. You can enjoy the time to do more exhaustive design studies, come up with safer and more economical designs, and enjoy clearly documented calculations for review and archiving.

This software is not a "black box" program. Each calculation is designed to be a "visible calcpad" where you can work with the data and immediately view the resulting calculations. Automatic design is provided in most modules, and is intended primarily to automate tedious iterative tasks.

You, as an experienced structural engineer or architect, can quickly enter and change member sizes and other design parameters and view the results. In this way, **Structural Engineering Library** maximizes the use of your time and design skills by enabling you to quickly define a concept and then make necessary modifications to refine it into a final design.

### The "Calcpad" Approach

When **Structural Engineering Library** was designed in 1983, our concept was revolutionary.....design it like an engineer's calculation pad. When an engineer prepares a calculation, the finished product is a neat and organized sheet of paper that follows the design flow from load tabulation, force and stress calculation, to the final adequacy check of the structural component that will satisfy the task.

At the time, all other competing programs were aging versions of mainframe programs that had been modified to run on microcomputers. Many of those programs executed "batch" design, where the user entered all the data, told the computer to run the program, and then opened a crude file to review the results. ENERCALC was unique in that the input and output was mixed on the same screen....easy to see at a glance. But the most revolutionary aspect was the tremendous speed it offered to prepare calculations.

This great speed was due to the fact that you could change a number and instantly see all the updated results on the screen.

Moving forward, the current version of SEL for Windows maintains that same fill-in-the-blanks approach with instant recalculation of results. When using any of the approximately 30 calculation modules, all input data and output results are presented on the same screen

---

and viewed just by selecting a tab that groups the information. **Whenever you change an input value, the entire module is recalculated and the results are immediately visible**. Thanks to efficient programming and fast modern computers, incredibly complex structural analysis and design is performed in a split second.

This instant updating also happens when you are viewing graphical sketches of designs or stress diagrams.....after any change, the graphics are instantly updated.

## 6.2 Typical Worksession


### A Typical Worksession

In order of occurrence, here are the steps in using the software:

1. Start the program.
2. The Project Assistant is displayed where you can choose to use the last calculation, the last project, a recent project, or create a new project.
3. A project is selected and you view the Project Manager. Here you can add new calculations, edit existing calculations, insert non-calculation items into the project (such as Microsoft Word or Excel files, Adobe Acrobat PDF files, or scanned images), and initiate project printing capabilities.
4. Editing or adding a calculation takes you to the calculation sheet for one of the modules.
5. Using the calculation sheet, you enter data on the top set of tabs while reviewing results and graphics on the bottom set.
6. When the structural calculation is complete, you can print it and/or save it to the project.
7. You can always return to the Project Manager where you can add/edit/delete/print other items within the current project, or save the current project and open a new one.

## 6.3 Program Settings

The **Settings** item in the main menu provides access to several selections that control how various aspects of **Structural Engineering Library** operates. A selection of one of the first four items will open the Program Settings window and preselect the appropriate tab for the chosen item.



### General Settings & File Locations

Program Settings

General Settings & File Locations   Printing & Title Block   Professional Engineer's Stamp   Update   Internal Values

Default File Locations . . .

Default location for Project Files you create & a file with default data for each module  
 ?

ENERCALC supplied & User Created database files (steel, wood, masonry, seismic, etc.)  
 ?

Load Combination Database File : LoadComb.TPS  
 ?

Eliminate redundant Load Combinations for ALL calculations  
 Forces ALL calculations to examine actual load types used and eliminates load combinations that result in duplicates.

: Number of backup files  
 Specifies the number of backup files to maintain each time a project file is SAVED. The backup file has a file extension "EC6SavBak\*" where the "\*" will be replaced by a number. The higher the number the more senior the backup file. Example : MyProjectFile.EC6SavBak5 is the 5th senior backup

Limit Activation Type to "Automatic Activate/Deactivate"  
 Activation system will ONLY offer "Automatic Activate & Deactivate". Use this option where many users will be in and out of the software frequently. When software is closed seat is returned to available seat count.

Calculations added at current Project Manager line highlighted

Set System font sizes to  points smaller.

Close

**Default Project File Location:** Specifies the default location where the program will point when using **File > Open** or **File > New** from the main menu.

Because modern operating systems allow multiple users per computer, Microsoft suggests that software manufacturers create their own folder under Documents and set that as the default location for user-created files. The program conforms to this recommendation by suggesting an appropriate directory during the installation process.

**Database File Location:** Specifies where the program should look for the steel database, wood database, and other files that contain the databases of standard values. This location needs to be accessible to all users on a specific computer. Microsoft suggests that software manufacturers set the following as the default location for data files that are referenced by the software, but not modified by the user: C:\Users\Public\Documents.

**Load Database File Location:** Specifies where the program should look for the load combination database file and other files that are potentially edited by the user. Because



---

this is a file that can be customized by the user, the default location for this file is the same as the default location offered for storing Project Files.

**Eliminate redundant Load Combinations for ALL calculations:** With this box checked the software will only run load combinations that are unique. It will automatically eliminate any load combinations that result in a combination that is redundant.

**Number of backup files:** Specifies the number of backup files to maintain for each Project File. With this box checked the software will automatically create a backup file with the **.EC6SavBak** file extension in the same folder as the original Project File. The backup files are created when a Project File is OPENED.

**Limit Activation Type to "Automatic Activate/Deactivate":** Removes the option to specify Indefinite activation.

**Calculations added at current Project Manager line highlighted:** This applies to the way calculations are inserted when using the Project Manager. When this box is checked and you use the **[+Add]** button, it adds a new calculation to the project, and the calculation is inserted directly above that position. What you see is that the new calculation takes that spot in the list, and the highlighted item is moved down. If this box is unchecked and you use the **[+Add]** button, the new calculation is inserted BELOW the highlighted item.

**Set System font sizes to X points smaller:** Provides a way to scale fonts down, for high resolution displays.

### **Printing & Title Block**

Program Settings

General Settings & File Locations   Printing & Title Block   Professional Engineer's Stamp   Update   Internal Values

Title Block . . .

Line 1 :

Line 2 :

Line 3 :

Line 4 :

Line 5 :

Line 6 :

What to Print . . .


Title Block (Upper-Left of Reports)

Project Information (Upper-Right of Reports)


Date & Time

Select Printing Color Mode . . . Color Greyscale


Logo File . . .  Print Logo  Add box around logo




Using a logo about 100x100 pixels helps report generation speed.



**NOTE !** Changes will not be reflected on printouts until they are edited.  
To have changes made here appear in printouts visible in the Project Printing section you must reload & save ALL calculations in your project -or- use File > Regenerate All Reports from main menu.

 Close

**Title Block:** These six entries correspond to the six lines in the upper-left corner of the printout.



**Masonry Column**  
 Lic. # : KW-06000001  
 Description : Masonry Column

General Information

Material Properties	Column Data
Flm - 1.500 0 psi	Column width along X Y -

**Logo File:** Provides an option to specify a graphics file to be printed at the LEFT edge of the title block. If used, the six lines of Title Block information will be printed immediately to the right of the logo. Logos can be Windows BMP, JPEG, GIF, and WMF formats.

When a logo is specified, the height is adjusted to fit into the title block area and the right-side "floats" according to the width of the image.

**What to Print - Title Block:** Check this box to print the title block at the top left of the report. With this item unchecked the printout begins with the calculation title bar (shown as "Masonry Column" in the image above)

**What to Print - Project Information:** Check this box to print the Project Information at the top right of the report.

**What to Print - Date & Time:** Check this box to print the computer date and time on the report as shown below:

Printed: 28 FEB 2009, 2:34PM  
 File: c:\EC6\AA\_TECH\_EC6\_FILES\sampleforvideos.ec6  
 ENERCALC, INC. 1983-2008, Ver: 6.0.21, N:00184  
**License Owner : ENERCALC, INC.**

**Select Printing Color Mode:** This sets the default mode for printed reports created from Structural Engineering Library.

### Professional Engineer's Stamp

This tab allows a graphic image of the user's PE stamp to be uploaded. Then the stamp can be placed on printout by selecting the checkbox.

### Update

The screenshot shows the 'Update' tab of the 'Program Settings' dialog box. The dialog has four tabs: 'General Settings & File Locations', 'Printing & Title Block', 'Professional Engineer's Stamp', and 'Update'. The 'Update' tab is active. It contains the following elements:

- Two input fields: 'Installed Build : 12.19.11.29' and 'Allowed Version : 12.19.11.29'. A blue question mark icon is positioned to the right of the 'Allowed Version' field.
- A button labeled 'Check for MAJOR updates now'.
- A note: 'You will receive a notice ONLY if an update is available.'
- A note: 'NOTE: Minor updates may also be available. Web Update doesn't detect minor updates.'
- A button labeled 'Click to launch "For Our Users" web page that has the latest Build Number'.
- A button labeled 'Click to launch web page with Installer download links'.
- A checkbox labeled 'Automatically check for updates at program startup', which is checked.
- A 'Close' button with a green checkmark icon in the bottom right corner.

**Click here to check for updates:** This button will download the updating program from our server. This program will check your computer for a non-expired Maintenance & Support Plan and update the software to the latest version.

[Click Here for web update overview](#) <sup>25</sup>

### Internal Values

**Internal Filenames:** Displays folder names and file names for the current configuration.

The screenshot shows a 'Program Settings' dialog box with the 'Internal Values' tab selected. The 'Internal Filenames' section contains the following fields:

Project File Folder :	C:\Users\Chris\Documents\ENERCALC Project Files\
Database Folder :	C:\Users\Public\Documents\ENERCALC Common Data Files\
Load File Folder :	C:\Users\Chris\Documents\ENERCALC Data Files\
Load Comb File :	C:\Users\Chris\Documents\ENERCALC Data Files\LoadComb.tps
Default Value File :	C:\Users\Chris\Documents\ENERCALC Project Files\EC6DefValues.tps
Temp/Work Folder :	C:\Users\Chris\AppData\Local\Temp\
Install Folder :	C:\Program Files (x86)\ENERCALC_6

At the bottom right of the dialog, there is a 'Close' button with a green checkmark icon.

## 6.4 Files & File Locations

### Project Files

**Structural Engineering Library** uses a single file to store the project information and all the calculations and items that are created as a part of that "Project". This file uses an "EC6" extension.

To backup an ENERCALC Project File simply copy the .EC6 file to the desired backup location.

To have the system automatically create a backup file, activate the checkbox labeled **Automatically create backup files** on the **Settings > General Settings** dialog.

As **Structural Engineering Library** advances in capabilities, the file formats used will change, but we will always provide conversion programs for previously saved Project Files.

#### *General Comments*

- Each ENERCALC Project File contains all information on a Project. There are no other files you will need to keep track of.
- Always remember that the Project Manager is showing you the Divisions and calculations for the current Project. It is NOT showing you a disk directory structure.
- There is no **Save** item on the **File** menu. After you have edited a calculation, you can either click [**Save Only**] or [**Save & Exit**] within the individual modules. Either one will save the calculation data to the Project File.

### Database Files

A number of database files are supplied with **Structural Engineering Library**. These files contain AISC section properties, NDS stress grades, wood section properties, seismic acceleration data, USA cities & Zip Codes, and other files. These files are not to be edited or modified in any way by the user.

### User-Created Database Files

The user can create User Defined database files to store their own steel sections, wood sections and wood stress databases. These files are created and stored in the same folder as the other database files. User defined database files are differentiated from the standard database files that are delivered with the software by inserting the word "\_USER" in the filename.


## 6.5 Project Assistant

When you launch **Structural Engineering Library** the Project Assistant is displayed by default, as shown below.

Click here for a video: [Project Assistant](#)

This single dialog allows you instant access to prior Project Files, the last Project File, the last-used calculation, or other functions to create or manage Project Files.

Please see the numbered references below the graphic for specific descriptions.



**(1)** Click to immediately open the last Project File that you worked on.

**(2)** Click to immediately open the last Project File that you worked on and open the last calculation you worked on.


- (3) This list shows the most recent Project Files that you opened on this computer, with the most recent Project File at the top of the list. Double-click on any item in the list to open that Project File.
- (4) Click to open the highlighted Project File in the list.
- (5) Click to remove the highlighted file from the Recent Projects list.
- (6) Click to open a Pick List that displays ALL Project Files in the various folders that you have used in the past. See the section [Main Menu > File](#)<sup>[70]</sup> for a description of the Pick List.
- (7) Click to open a Windows File Open dialog that allows you to navigate through disks and folders to locate and open a Project File.
- (8) Click to open the Windows File Create dialog that allows you to navigate through disks and folders and create a new ENERCALC Project File.
- (9) Uncheck this box if you do not wish to automatically display the Project Assistant at startup. To again have the Project Assistant automatically displayed at startup, click **File > Display Project Assistant** and then activate the checkbox to **Show Project Assistant at program startup**.
- (10) Link to a help video on the Project Assistant.



## 6.6 Databases

**Structural Engineering Library** contains several databases that you can use in the various modules.

To view the databases click **Databases > (database)** from the main menu. See below.




Specific information on each of the databases is provided here: [Databases item in Main Menu](#)<sup>79</sup>

## 6.7 Screen Layout

The ENERCALC **Structural Engineering Library** user interface is divided into a Main Menu and a Working Area. Click here for a video: [General Layout](#)

The **Working Area** is used to display the calculation module that you are currently editing. When you choose to view the Project Manager, it is displayed on the left side of the Working Area. See more to follow.


The Main Menu is described in much more detail here: [Main Menu description](#)<sup>[69]</sup>



### Working Area - Showing Project Manager

Immediately after a Project File is opened the Project Manager is displayed. As you can see in the image below, the Project Manager occupies a portion of the left side of the screen.

The Project Manager provides you with the ability to control the contents of your Project File. Double-click any calculation to open the associated module and edit the parameters of that calculation. Please [click here](#)<sup>[95]</sup> to jump to detailed information for the Project Manager.



After a calculation is selected for editing, the Project Manager automatically collapses, and the window fills with the user interface for that particular calculation module as shown below:

ENERCALC : examples.ec6 : Sample Wood Beam Calc

File Settings Databases Tools License Help

Licensed ENERCALC User: KW-06000215

### Wood Beam

10.0 ft 10.0 ft

3-2x12 3-2x12

Click on +/- to Add, Delete Spans Click on Span To Select Click on Support to Modify

Auto Calculate

Design Method: ASD LRFD

Design Values

Wood Species: Douglas Fir-Larch (North)

Wood Grade: Select Structural

Beam Material: Steel Concrete **Wood** None

Compression Edge Lateral Bracing: Compression Side Fully Braced Define Bracing Span-by-Span Set Uniform Spacing Completely Unbraced

Fb +: 1350 psi Fv: 180 psi  
 Fb -: 1350 psi Ft: 825 psi  
 Fc - Prill: 1900 psi Density: 30.59 pcf  
 Fc - Perp: 625 psi Calc Shear at 'd' from support?

E : Modulus of Elasticity  
 Ebend - xx: 1900 ksi  
 Eminbend - xx: 690 ksi

Summary Results Max. Combinations M-V-D Summary Support Reactions **Design OK**

Maximum Bending Stress Ratio = **0.955 : 1**  
 Section used for this span: **3-2x12**  
 fb : Actual = 1,289.90 psi FB : Allowable = 1,350.00 psi  
 Load Combination: +D+L+H  
 Location of maximum on span: 10.000 ft  
 Span # where maximum occurs: Span # 1

Maximum Shear Stress Ratio = **0.275 : 1**  
 Section used for this span: **3-2x12**  
 Fv : Actual = 57.00 psi Fv : Allowable = 207.00 psi  
 Load Combination: +D+L+H  
 Location of maximum on span: 9.106 ft  
 Span # where maximum occurs: Span # 2

Extreme Reactions ( service, kips )

	D	Lr	L	S	W	E	H
Support #1	-0.53			0.28	-0.08		
Support #2	1.07			1.12	0.52		
Support #3	1.17			0.40	1.36		

Deflection Ratios

Transient Load Deflection

Max Downward: 0.025 in Ratio = 4761 >=360

Max Upward: -0.009 in Ratio = 13581 >=360

Total Deflection

Max Downward: 0.119 in Ratio = 1009 >=240

Max Upward: -0.090 in Ratio = 1330 >=240

+D+L+H

Data Saved

IBC 2015, ASCE 7-10, CBC 2016, AISC 360-10, NDS 2015, ACI 318-14, ACI 830-13 | Build: 10.19.1.30

NOTE: It is normal for the Project Manager to hide while a calculation is being edited.

For a review of using a typical calculation screen [click here](#) <sup>64</sup>.

## 6.8 Generating Reports

In **Structural Engineering Library**, the term "report" refers to the results documents created by the program in either printed or PDF format.

For each of the ENERCALC modules, the generation of a report starts by clicking the Print button:



This opens a previewer that offers many options:

The screenshot shows the 'Print Document' window. On the left side, there are several options for printing:

- Print** and **PDF** buttons.
- # Copies**: Set to 1.
- Printer**: HP Officejet 5600 series.
- Settings**: Print All Pages.
- Sections to Include**:
  - Detailed Load Combination Results
  - Detailed Maximum Deflections
  - Section Properties
  - M-V-D Diagrams
  - Incremental V M & D for all LC
  - Use closely spaced increments
  - Vertical Reactions
  - Deflections
- Regenerate Report** button.

The main preview area shows page 1 of 20 at 70% zoom. The report content includes:

- Title Book Line 1
- Wood Beam** (Section 3-2x12)
- DESCRIPTION: Sample Wood Beam Calc
- CODE REFERENCES: Calculations per NDS-2018, IBC 2018, CBC 2016, ASCE 7-10
- MATERIAL PROPERTIES table:

Material Property	Value	Unit
Analysis Method	Allowable Stress Design	
Load Combination	IBC 2012	
Wood Species	Douglas Fir-Larch (North)	
Wood Grade	Select Structural	
Beam Bracing	Beam is Fully Braced against lateral-torsional buckling	
F <sub>b</sub>	1350	psi
F <sub>b</sub> - Adj	1350	psi
F <sub>c</sub> - Perp	1900	psi
F <sub>c</sub> - Parp	625	psi
F <sub>t</sub>	180	psi
F <sub>t</sub>	825	psi
E - Modulus of Elasticity	1900	ksi
E <sub>min</sub> - Modulus of Elasticity	690	ksi
Density	30.59	pcf

The preview also shows a diagram of the beam with applied loads and a **DESIGN SUMMARY** table:

Item	Value	Ratio	Limit	Status
Maximum Bending Stress Ratio	0.955	1		Design OK
Section used for this span	3-2x12			
F <sub>b</sub> - Actual	1,280.90	psi	F <sub>b</sub> - Allowable	1,350.00
F <sub>v</sub> - Actual	57.00	psi	F <sub>v</sub> - Allowable	207.00
Load Combination	-D+L+I		Load Combination	-D+L+I
Location of maximum on span	10.00ft		Location of maximum on span	8.10ft
Span # where maximum occurs	Span #1		Span # where maximum occurs	Span #2
Max Downward Transient Deflection	0.025	in	Ratio =	4761 =>360
Max Upward Transient Deflection	-0.009	in	Ratio =	13001 =>360
Max Downward Total Deflection	0.119	in	Ratio =	1009 =>240
Max Upward Total Deflection	-0.090	in	Ratio =	1330 =>240

At the bottom, there is a table for **Maximum Forces & Stresses for Load Combinations**.

Load Combination	Span #	Max Stress Ratio							Moment Values			Shear Values		
		M	V	C <sub>1</sub>	C <sub>2</sub>	C <sub>3</sub>	C <sub>4</sub>	C <sub>5</sub>	M	V	P <sub>h</sub>	V	P <sub>h</sub>	
1-Perp = 10.0 ft	1	0.944	0.25	1.00	1.00	1.00	1.00	1.00	0.0	1147.0	1514.0	1.25	36.27	162.00
1-Parp = 10.0 ft	2	0.721	0.25	1.00	1.00	1.00	1.00	1.00	6.01	874.4	1514.0	1.25	36.27	162.00
1-Perp = 10.0 ft	1	0.955	0.25	1.00	1.00	1.00	1.00	1.00	10.2	1380.0	1567.0	1.66	49.30	180.00

Print: Create a report and send directly to the currently selected printer.

PDF: Create a report as an Adobe Acrobat PDF file.

Close: Close the previewer without printing anything.

# Copies: Set the desired number of copies.

Printer: Select the desired printer.

Settings: Select what is to be printed.

Sections to Include: Select individual report topics to include in the report.

Regenerate Report: Recreate the report after changing the options in the Sections to Include area.

The right side of the screen displays a preview of the current calculation report and offers zooming and page scrolling controls.


In addition to the Regenerate Report button, reports are created and saved when you click the **[Save Only]** or the **[Save & Close]** buttons in the upper-right corner of all modules:



Clicking either of these buttons causes a full report for the current module to be created and saved into the Project File along with all of the input data for that module. **This is how the printouts are prepared for instant viewing and batch printing in the Project Printing system.**

## 6.9 General Calculation Screen Usage

Please refer to the typical screen below and the numbered items that relate screen areas to their descriptions:



(1) Indicates the module that you are working in.

(2) Indicates the name of the licensed owner of this installation & activation of the software.

(3) From left to right:

**Access to help system:** Opens the help system and displays the section specific to this module.

**Video Tutorial:** Opens a video tutorial specific to this module.

**Display Enlarged Graphic:** Displays an enlarged view of the 2D graphic for the current calculation.

(4) From left to right:

**Print:** Opens the Print Previewer where the report can be set up, previewed, printed to a printer, or printed to PDF.

**Cancel:** Cancels all changes made to this module since the last save, closes the module without saving, and returns to the Project Manager. If this calculation module was just Added to the Project File, and if it was never saved, then this option will cause the calculation to be removed without saving.

**New:** Uses the current calculation data to create a new calculation item in the Project Manager.

**Save Only:** Saves the current Project File (to capture all the data entered into this module), creates a report (which can be printed at a later time), and keeps the module open for further editing.

**Save & Close:** Saves the current Project File (to capture all the data entered into this module), creates a report (which can be printed at a later time), closes the module, and returns to the Project Manager.

**(5) Data input tabs:** Click these tabs to move to various categories of data input.


**(6) Major Result Category Tabs:** Select between major categories of result data to view; numerical values, sketches, diagrams or 3D renderings.

**(7) Numeric Result Tabs:** Click these tabs to view the various components of calculated results.



## 6.10 3D Renderings

The 3D tab in most modules offer a 3D rendering of the element in the current calculation.



Each calculation offers "Show" options that are specific to the type of element being displayed. Note that some of the show options will cause some renderings to switch into a semi-transparent mode for clarity. For example, when viewing the rendering for a General Footing, the rendering will automatically switch to semi-transparent mode when the display of rebar is turned on.

The X/Y/Z/Iso buttons allow the rendering to quickly be snapped to specific view angles. Rotate and Zoom controls make it easy to adjust the view, but note that the rendering can also be manipulated by clicking and dragging with the left mouse button to rotate or with the middle mouse button to pan.

The Enlarge/Reduce button toggles between a large and small display window for the rendering.

The Print button allows the 3D rendering to be printed to PDF or paper.

Run menu > sysdm.cpl > Advanced Tab > performance > select adjust for best performance > make sure you do not allow Windows to choose for you because your computer does not know whats best - Make sure Enable Aero Peek is checked.




**Part**

---



## 7 Main Menu

The main menu of **Structural Engineering Library** is always displayed.




The menu offers the following selections. Click an item below to jump to that help section page, or click here for a video: [Main Menu and Toolbar](#)

<a href="#">File</a> <sup>70</sup>	:	To create, load, close and print Project Files.
<a href="#">Settings</a> <sup>76</sup>	:	To establish settings, user information and default values
<a href="#">Databases</a> <sup>79</sup>	:	To view the various databases supplied with the software
<a href="#">Tools</a> <sup>87</sup>	:	To access utilities provided with the software
<a href="#">License</a> <sup>89</sup>	:	To directly access the licensing control window
<a href="#">Help</a> <sup>90</sup>	:	To access the help system, technical support options, Knowledge Base with FAQs, Enhancement/Change History and the ENERCALC website.


## 7.1 File

**Last Project:** Opens the last used Project File.


**Recent Projects:** Provides a list of Project Files that were recently opened.




**Pick Project:** The software remembers all prior folders on your computer (and other computers) that were accessed to load Project Files. This item opens a window that shows those folders and the ENERCALC Project Files contained within them to allow you one-stop selection of a Project File from your commonly used locations.




**Open Project:** Opens a standard Windows File Open dialog allowing you to navigate your disk drives and open a Project File.



**New Project:** Opens a standard Windows File Create dialog allowing you to navigate your disk drives and specify the name of a Project File to create.




**Save Project as New:** Allows you to save the currently open Project File as a new file using a different name. Opens a standard Windows File Create dialog allowing you to navigate your disk drives and specify the name of the Project File to create.



**Close Project:** Closes the currently open Project File (making sure any unsaved data is purged).

**Print Setup:** Displays a typical Windows Printer Selection dialog to specify the printer to be used for this work session.



**Print Project:** Opens the [Project Printing](#) <sup>131</sup> Manager.




**Regenerate Reports:** This selection is used to regenerate printouts so they will be updated and displayed correctly in the Project Printing Manager. It can be used any time the following information has changed:


- Project Information in the GENERAL Division of the Project Manager for the currently open Project File
- Title block information filled in using **Settings > Printing & Title Block** from the main menu

There is also a third situation where this command can come in handy. When running in Evaluation mode, the software adds a watermark on the background of all printouts. This watermark says "Evaluation Version" and "Unlicensed Usage", so the report is inconvenient to use for submittal purposes. When the user later runs the software in Licensed mode, those reports with the "Evaluation Version" watermark remain in the Project File until they are reopened and saved. This can be a laborious process if the Project File contains many calculations. So the easier way to remove the watermarks in one pass is to use the Regenerate Reports command.

When you click **File > Regenerate Reports > All**, the program will automatically save and close any open calculations. Then the program will show a progress window as it regenerates all the reports in your Project File:




**Display Project Assistant:** This option displays the Project Assistant which offers a convenient way of beginning work with a Project File.



**Exit:** Offers the option to save any pending work, then closes the currently open Project File, and exits the software.

## 7.2 Settings



Most of these items are covered in another section of this help document. Please click on an item in the list below to jump to that section.

[General Settings](#)<sup>[48]</sup>: Defines file locations, backup file creation and behavior items in the Project Manager.

[Printing & Title Block](#)<sup>[50]</sup>: Provides the ability for the user to define the look of their title block.

**Engineer's Stamp**: Allows the user to upload a graphic image of their Professional Engineer's stamp for inclusion on printed reports.

**Display Settings**: Provides options to configure the software for the resolution of the monitor being used.

[Web Update Settings](#)<sup>[25]</sup>: Allows control over behavior of web update system and direct access to the update installation program on the web.

[Default Values](#)<sup>[78]</sup>: Provides control over the values that serve as the defaults for each individual calculation module. Note that a particular calculation module must be open in order to use the functions provided by this item.

**User Information**: Provides access to user information.


**Utilities**: This selection provides items that are mostly used for support and maintenance of the software. At the time of this documentation writing, the only Utility item available is to start a process of registering components used by SEL with the operating system.



## 7.2.1 Default Values

Most of the user input values in the individual calculation modules have a default value or setting that is stored within the program. Many of these default values can easily be changed by the user. The procedure is as follows:


1. Open a new calculation of the particular module of interest.
2. Revise all of the initial values and settings as desired so that they represent the desired default values or settings.
3. Click Settings > Default Values > Save.



The current values will be saved as the new default values for that module, and these initial values and settings will be used when a new instance of this calculation module is added to any Project File.

## 7.3 Databases

This menu allows viewing of various databases supplied with the software.



Please see the specific subtopics in this section for more detailed information on the databases.

### 7.3.1 Steel Section Database

#### Steel Section Database

The steel section database is available in all applicable steel modules. It contains typical AISC rolled sections from many Editions of the AISC Steel Construction Manual. Click

here for a video: [Steel Section Database](#)

Note that it is also possible to create User Defined entries that can be referenced in calculations.

Steel Section Database

Steel Database

AISC

User Defined

Edition

15th	14th
13th	9th
8th	7th
6th	

Section Type to Display . . .

W	C	WT	HSS-P	HSS-Square	L - Equal	LL - Equal
HP	MC	MT	P	HSS-Rectangular	L - Unequal	LL - Long Leg Vert
S						LL - Short Leg Vert
M						

Displaying Data For 283 "W" Shapes Sort Order  Show Favorites Only

Order	Area	Depth	Web Thick	Width	Fl. Thick	Sx	Sy	Ix	Iy	J	Zx
Section Name	Wt. lbs	Area in^2	Depth in	Web Thick in	Fl. Width in	Fl. Thick in	K Dist in	K1 Dist in	T Dist in	Ixx in^4	
W4x13	13.00	3.83	4.160	0.280	4.060	0.345	0.595	0.500	0.000	11.30	
W5x16	16.00	4.71	5.010	0.240	5.000	0.360	0.660	0.438	0.000	21.40	
W5x19	19.00	5.56	5.150	0.270	5.030	0.430	0.730	0.438	0.000	26.30	
W6x8.5	8.50	2.52	5.830	0.170	3.940	0.195	0.445	0.500	0.000	14.90	
W6x9	9.00	2.68	5.900	0.170	3.940	0.215	0.465	0.500	0.000	16.40	
W6x12	12.00	3.55	6.030	0.230	4.000	0.280	0.530	0.563	0.000	22.10	
W6x16	16.00	4.74	6.280	0.260	4.030	0.405	0.655	0.563	0.000	32.10	
W6x15	15.00	4.43	5.990	0.230	5.990	0.260	0.510	0.563	0.000	29.10	
W6x20	20.00	5.87	6.200	0.260	6.020	0.365	0.615	0.563	0.000	41.40	
W6x25	25.00	7.34	6.380	0.320	6.080	0.455	0.705	0.563	0.000	53.40	
W8x10	10.00	2.96	7.890	0.170	3.940	0.205	0.505	0.500	0.000	30.80	
W8x13	13.00	3.84	7.990	0.230	4.000	0.255	0.555	0.563	0.000	39.60	
W8x15	15.00	4.44	8.110	0.245	4.020	0.315	0.615	0.563	0.000	48.00	
W8x18	18.00	5.26	8.140	0.230	5.250	0.330	0.630	0.563	0.000	61.90	
W8x21	21.00	6.16	8.280	0.250	5.270	0.400	0.700	0.563	0.000	75.30	

Depth Range :  Class Range :

Check availability at [www.aisc.org](http://www.aisc.org)

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\EC6\_STL\_W.TPS

## 7.3.2 Wood Section Database

### Wood Section Database

The wood section database contains the section properties for most of the sections listed in the NDS and for many Engineered Wood Products. Click here for a video:

[Wood Section Database](#)

The wood section database is available in all applicable wood modules. It contains typical wood sections available in the United States. These sections are also shown in the 2005 NDS. Also included are manufactured sections, however the list of those sections is only updated occasionally. Note that it is also possible to create User Defined entries that can be referenced in calculations.

Wood Section Database

Wood Database

2005 NDS    2012 NDS    2015 NDS

2018 NDS    User Defined

Select Types to Display . . .

Solid Sawn

General    Southern Pine

Glued Laminated

Western    Southern Pine

Manufactured

Trus Joist: Microllam    Trus Joist: Parallam    Louisiana Pacific P:Gang-Lam LVL    Trus Joist: Timber Strand

Boise Cascade : VersaLam :    Georgia Pacific : GP LAM LVL    RedBuilt RedLam LVL    Roseburg RigidLam

Rosboro X-Beam    Anthony

SortOrder

Ascending    Descending     Specify Depth Range

Favorites

Show Favorites Only

Toggle Favorite ON-OFF

Name    Type    Species    Width    Depth    Area    Ix    Sx    Iy    Sy    <<<--- Use Tabs To Sort

Name	Type	Species	Width in	Depth in	Area in <sup>2</sup>	Ix in <sup>4</sup>	Sx in <sup>3</sup>	Iy	Sy
2x3	Sawn	Graded Lumber	1.500	2.500	3.750	1.953	1.563		
2x4	Sawn	Graded Lumber	1.500	3.500	5.250	5.359	3.063		
2x5	Sawn	Graded Lumber	1.500	4.500	6.750	11.391	5.063		
2x6	Sawn	Graded Lumber	1.500	5.500	8.250	20.797	7.563		
2x8	Sawn	Graded Lumber	1.500	7.250	10.875	47.635	13.141		
2x10	Sawn	Graded Lumber	1.500	9.250	13.875	98.932	21.391		
2x12	Sawn	Graded Lumber	1.500	11.250	16.875	177.979	31.641		
2x14	Sawn	Graded Lumber	1.500	13.250	19.875	290.775	43.891		
3x4	Sawn	Graded Lumber	2.500	3.500	8.750	8.932	5.104		
3x5	Sawn	Graded Lumber	2.500	4.500	11.250	18.984	8.438		
3x6	Sawn	Graded Lumber	2.500	5.500	13.750	34.661	12.604		
3x8	Sawn	Graded Lumber	2.500	7.250	18.125	79.391	21.901		
3x10	Sawn	Graded Lumber	2.500	9.250	23.125	164.886	35.651		
3x12	Sawn	Graded Lumber	2.500	11.250	28.125	296.631	52.734		
3x14	Sawn	Graded Lumber	2.500	13.250	33.125	484.626	73.151		
3x16	Sawn	Graded Lumber	2.500	15.250	38.125	738.870	96.901		
4x4	Sawn	Graded Lumber	3.500	3.500	12.250	12.505	7.146		
4x5	Sawn	Graded Lumber	3.500	4.500	15.750	26.578	11.813		
4x6	Sawn	Graded Lumber	3.500	5.500	19.250	48.526	17.646		
4x8	Sawn	Graded Lumber	3.500	7.250	25.375	111.148	30.661		
4x10	Sawn	Graded Lumber	3.500	9.250	32.375	230.840	49.911		
4x12	Sawn	Graded Lumber	3.500	11.250	39.375	415.283	73.828		
4x14	Sawn	Graded Lumber	3.500	13.250	46.375	678.476	102.411		
4x16	Sawn	Graded Lumber	3.500	15.250	53.375	1,034.419	135.661		
5x5	Sawn	Graded Lumber	4.500	4.500	20.250	34.172	15.188		
6x6	Sawn	Graded Lumber	5.500	5.500	30.250	76.255	27.729		

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\EC6\_TIMBER.tps



### 7.3.3 Wood Reference Design Values Database

#### Wood Reference Design Values Database

The Wood Reference Design Values database is available in all applicable wood modules.

Click here for a video: [Wood Reference Design Values Database](#)

The Wood Reference Design Values database contains typical wood stress grades as defined in the NDS. Also included are manufactured sections, however the list of those sections is only updated occasionally. Note that it is also possible to create User Defined entries that can be referenced in calculations.

Wood Reference Design Values

**NDS Supplement Reference Design Values**

Edition: 2005, 2012, 2015, 2018

Size Classes to Show: [Table 4A: 2"->4" Thick, 2" & Wider](#), [Table 4D: 5" x 5" & Larger](#), [Table 5A: Glulam - Beams](#), [Engineered Wood Products](#), [Table 4D: Beams & Stringers](#), [Table 4D: Posts & Timbers](#), [Table 5B: Glulam - Columns](#), [User Defined](#)

Show Favorites Only     Toggle Favorite ON-OFF    Expand/Contract Trees :

Wood Species	Size/Group	Fb (psi)		Fv	Fc (psi)		Ft	E - Modulus (ksi)		
Common Name	Classification	Fb +	Fb -	psi	Perp.	Prll	psi	E Bend	E Min Bend	E Bend - YY
Select Structural	2"-4" Thick	1,350	1,350	180	625	1,900	825	1,900	690	
No. 1 & Btr	2"-4" Thick	1,150	1,150	180	625	1,800	750	1,800	660	
No. 1/No. 2	2"-4" Thick	850	850	180	625	1,400	500	1,600	580	
No. 3	2"-4" Thick	475	475	180	625	825	300	1,400	510	
Stud	2"-4" Thick	650	650	180	625	900	400	1,400	510	
Construction	2"-4" Thick	950	950	180	625	1,800	575	1,500	550	
Standard	2"-4" Thick	525	525	180	625	1,450	325	1,400	510	
Utility	2"-4" Thick	250	250	180	625	950	150	1,300	470	
<b>Douglas Fir-South</b>	2"-4" Thick									
Select Structural	2"-4" Thick	1,350	1,350	180	520	1,600	900	1,400	510	
No. 1	2"-4" Thick	925	925	180	520	1,450	600	1,300	470	
No. 2	2"-4" Thick	850	850	180	520	1,350	525	1,200	440	
No. 3	2"-4" Thick	500	500	180	520	775	300	1,100	400	
Stud	2"-4" Thick	675	675	180	520	850	425	1,100	400	
Construction	2"-4" Thick	975	975	180	520	1,650	600	1,200	440	
Standard	2"-4" Thick	550	550	180	520	1,400	350	1,100	400	
Utility	2"-4" Thick	250	250	180	520	900	150	1,000	370	
<b>Eastern Hemlock-Balsam Fir</b>	2"-4" Thick									
Select Structural	2"-4" Thick	1,250	1,250	140	335	1,200	575	1,200	440	

Buttons:  Select,  Cancel

## 7.3.4 Masonry Database

### Masonry Database

This is a reference table only. It consists of data for common hollow concrete masonry units:

Concrete Masonry Unit Information

Select List to View . . .

Select Code Ref for Masonry Values

ASTM C90-99a

Section Properties . . .

Equiv. Solid Thick Face Shell Only      I Net

Completed wall weights using 140pcf grout . . .

Light Weight Block      Medium Weight Block      Normal Weight Block

Completed wall weights using 105pcf grout . . .

Light Weight Block      Medium Weight Block      Normal Weight Block

Nominal Block Thickness (in)	Wall Weight - Normal Weight Block, 140 pcf Grout					
	8"	16"	24"	32"	40"	48"
6	63.000	52.000	48.000	47.000	46.000	45.000
8	84.000	66.000	61.000	58.000	56.000	55.000
10	104.000	86.000	78.000	74.000	72.000	70.000
12	133.000	103.000	94.000	89.000	86.000	83.000
14	155.000	114.000	101.000	94.000	91.000	88.000
16	175.000	129.000	113.000	106.000	101.000	98.000


Close

## 7.3.5 Load Combination Database

### Load Combination Database

This is the database of named load combination sets that can be automatically retrieved into a calculation. Click here for a video: [Load Combination Database](#)

A named load combination set can be established as a default and will be used whenever a new calculation is created in the Project File. Note that it is also possible to create new load combination sets and/or revise the load combinations that are in the existing sets.




The Load Combination Database is used to manage the load combinations that you can use across all of your Project Files.

**The load combinations specified in this section are stored in a separate file and ARE NOT specific to a particular Project File.**

With the Load Combination Database you can create many load combination sets. These are listed in the Code Reference column.


For each set, you can then specify the individual load combinations for both factored load and service load cases, which are used for LRFD and ASD respectively (also referred to as strength design and allowable stress design).

Please see the descriptions for the numbered keynotes on the screen capture below.



(1) This area lists the load combination sets available for use.


(2) Use these buttons to add, delete, copy or edit the name of load combination sets. The button with the triangle symbol means "Change" or "Edit" and is used to edit the displayed reference name for the set.



(3) This is the area that displays all the load factors for the various load combination types.

(4) Use these buttons to add or delete individual load combinations. The button with the triangle symbol means "Change" or "Edit" and is used to edit the numeric factors applied to each type of load for the load combination that is highlighted.

When clicking the [Add] or [Edit] button, the following dialog is displayed:



Use this dialog to specify the reference name and the values for each load factor.

(5) Click the various buttons to select the category of load combinations to display.

(6) Use the **Set As Default** button to make the highlighted load combination set the default that will be used in all new ENERCALC calculations.


### Using Load Combinations

When creating a NEW calculation in the Project Manager, the default load combination set is automatically loaded into the Load Combination tab in the module.

In the image below you can see that the load combinations have been loaded and are displayed on Load Combinations tab in the Masonry Column module.


The design method has been set to LRFD, so the software is displaying Factored Combinations.

We have clicked the **[Select]** button to open a list of the available load combination sets from the Load Combination database. Selecting one of them from this dropdown list will load those new load combinations into this particular calculation only.




## 7.4 Tools

This menu item provides access to useful tools that are supplied with **Structural Engineering Library**.



**Calculator:** We supply a **Reverse Notation Calculator (RPN)** for engineers to use for intermediate calculations when entering data. RPN calculators are the most commonly used among engineers because they allow faster mathematics solutions when nested (parenthetical) calculations are used. It also includes a Copy button, which allows a result value to be copied to the clipboard and then pasted into an input field in Structural Engineering Library.



For more information on Reverse Polish Notation try these links:

---

[http://en.wikipedia.org/wiki/Reverse\\_Polish\\_notation](http://en.wikipedia.org/wiki/Reverse_Polish_notation)

<http://www.hpmuseum.org/rpn.htm>


**Reset Calc Defaults:** This command resets the default values for the current calculation to the hard-coded internal default values. It may be a useful tool in some troubleshooting situations.

**Remove Saved Reports from Project File:** This command removes any reports that have been saved in the current Project File. It can be helpful in terms of reducing file size if a Project File is to be emailed, but it will require that the reports be regenerated before they can be printed.

**Optimize file by removing abandoned records:** This command removes lost records in a Project File which could occur if the program is terminated abnormally (perhaps from a power outage, lockup, network failure, lockup of another program, etc).

## 7.5 License


The License item displays the licensing and activation menu.





## 7.6 Help


The Help item displays the Help menu.



**Manage your Software License:** Automatically opens the Manage License page of our website.

**Dynamic Help:** Displays the help system for the software that is installed on your computer.

**Web Documentation (most up-to-date):** Displays the most up-to-date help information located on our website.



**Web FAQ Pages:** Provides a direct link to the **Frequently Asked Questions** section at [www.enercalc.com](http://www.enercalc.com).

**Download PDF Docs:** Downloads the PDF version of the documentation for the software currently available at our website. The documentation on our website will always be for the latest available version.

**Renew Maintenance & Support Plan:** Provides direct access to MSP renewal online.


**"For Our Users" Web Page:** Provides a link directly to the "For Our Users" page of our website, which offers information on current builds, Customer Information, Software Installation & Update Links, Installation Info & FAQ links, info on Maintenance Plans & Upgrades, Documentation Links, Links to PDF Files of Relevant Information and Useful Forms, and links for Prior Version Software Reinstallation.


**"Training Videos" Web Page:** Provides a link directly to the "Training Videos" page of our website, which offers videos on topics such as Installation, General Operation, Using Project the Manager, Designing Beams, Columns, Foundations, Slender Walls, working with some of the Miscellaneous modules, and working with External Files.

**Create Tech Support Email:** Provides you with a Tech Support form to fill out. When finished, the data is transferred to an email form to send to our Tech Support Group. (Note: Some computers and email software will not be able to paste the information into your email program. This is not an ENERCALC issue. In those situations, feel free to compose an email to [support@enercalc.com](mailto:support@enercalc.com) directly from your email program, and please remember to indicate your "KW" User Registration number on all correspondence.)

Create Technical Support Email




**Note !** Be thorough with your question. Attach a project file if needed.

Sending to : SUPPORT@ENERCALC.com  **Send**





Subject :   **Cancel**

Here's my Message . . . .

--- Your message here ---

File Attachment . . . .  **+ Add File**  **- Remove File**  **Save & Attach Current Project File**

My need . . .

 **Suggestion**  **Current Issue, Not Critical**  **Critical and Urgent**  **Other**

Pressing [Send] will open your email program and insert the above information.  
All you do then is press [Send]

**Check for MAJOR Updates:** Immediately runs the update check program named EC6WebUpdate.exe, which resides in the ENERCALC program installation folder. If a newer build is found, a window will be displayed prompting you to decide if you want to continue to update your software. If there is no newer build of the software available, then you will be informed that your installation is currently up-to-date.

**Enhancement/Change History:** Opens a window that lists revisions and enhancements that have been performed on the software. [Click here](#)<sup>[34]</sup> to access a specific section with additional information.

**Allowed Version Description:** Provides a thorough description of the terms "Installed Build" and "Allowed Version" now reported by Structural Engineering Library.

**License:** Displays the licensing and activation system window. [Click here](#)<sup>[89]</sup> to access a specific section with additional information.

**Screen Capture:** Provides a utility to create a screen capture, such as to send to us for a tech support question.

**About:** Displays a general window giving information about software version, copyright, licensed user, activation status, and contact information for ENERCALC.

**Licensed Software**

**Licensed ENERCALC User, KW-06000215**

---

**ENERCALC, INC.**  
[www.enercalc.com](http://www.enercalc.com)


***Structural Engineering Library***

**Allowed Version : 10.19.1.30**  
**Installed Build : 10.19.1.30**

**Technical Services :** [support@enercalc.com](mailto:support@enercalc.com)  
Voice: 949.645.0151, Ext. #3  
Fax: 949.645.3881


**Sales & Business Office :** [info@enercalc.com](mailto:info@enercalc.com)  
Voice: 800.424.2252, Ext. #1  
949.645.0151, Ext. #1  
Fax: 949.645.3881

**Postal Mail :** P.O. Box 188  
Corona del Mar, CA 92625  
United States of America

 **Close**

---

Copyright(c) 1983 - 2019 ENERCALC, INC.  
All rights reserved for Author, see License Agreement



**Part**



## 8 Project Manager

The Project Manager is displayed on the left side of the ENERCALC screen when a Project File has been opened. Click here for a video: [Project Manager](#)

The Project Manger provides the ability to create and modify a single Project File that can contain a set of calculations and external items for a specific project. The layout, which will be ever-improving, is designed to allow an ENERCALC Project File to be a single collection point for documents relating to the load development and structural design of a building or other structure.

The behavior of the Project Manager has been enhanced by introducing the ability to display and hide the Project Manager on-demand. This offers the following advantages:

- Larger area is available for use in the Project Manager when it is displayed.
- More verbose calculation descriptions can be provided with fewer cryptic abbreviations.
- Greater selection of "project level" operations buttons can be displayed.
- More efficient organization of GENERAL Division, LOADS & FORCES Division and custom Divisions within the Project Manager.
- Larger area available for the display of input and results when Project Manager is hidden.
- More verbose descriptions of input variables can now be provided.
- Less on-screen congestion and less need for horizontal scroll bars in results tables.

Components that all Project Files AUTOMATICALLY contain are:

### **GENERAL Division (Only one can exist in a Project File)**

A storage location for pieces of information pertaining to areas of the entire project, such as:

- Project Info, Building Department Contact Info, Designer Notes, Revisions, Client, Designer.
- Future additions

### **LOADS & FORCES Division (Only one can exist in a Project File)**

A storage location for pieces of information pertaining to areas of the entire project, such as:

- General forces for the project including Snow Loads, Wind Loads and Seismic Loads.
- Live load reductions.
- Future additions

Components that any Project File CAN contain are:

### **Custom Divisions (An unlimited number can exist in a Project File)**

Storage locations (folders) for organizing user-generated calculations and external items.

- Can be created, named, copied, organized, expanded, collapsed, and deleted.
- Are typically named in ways that are meaningful to the designer and that suit the specific project.
- Are generally populated with calculations and external items.
- Provide a convenient way to selectively control project printing operations for logical sets of calculations.
- Every new Project File is automatically populated with one Division named "Calculations".

### **Calculations (An unlimited number can exist in a Project File)**

User-generated calculations that are created using the built-in ENERCALC modules and are stored in the Custom Divisions.

- Can be created, moved between Divisions, and deleted.
- Can be copied to serve as the basis for a new calculation with similar input data.
- Can be imported from one Project File to another.
- Can be printed singly or in batch mode using the Project Printing Manager.


### **External Items (An unlimited number can exist in a Project File)**

User-generated external files that are created using external programs and then stored in the Custom Divisions.

- Can consist of MS Word documents, MS Excel spreadsheets, Adobe Acrobat PDFs, and scanned documents/images.
- Can be embedded within the Project File for maximum portability, or can be linked to the Project File to minimize file size.
- Can be created, moved between Divisions, and deleted.

Please see the descriptive keynotes on the following screen capture for information on various areas of the Project Manager.

Detailed descriptions are contained in the sections of this topic.






(1) **Project Printing:** These buttons allow you to print the report for the selected calculation, or open the Project Printing system, which allows you to review all report pages for all calculation items in the entire project. [Click here](#)<sup>[137]</sup> to review the specific section on Project Printing.

(2) **Buttons to Add, Copy, Edit & Delete Individual Calculations:** These buttons allow you to add, copy, edit and delete ENERCALC calculations or external source items (such as Excel sheets) in the selected Division. [Click here](#)<sup>[116]</sup> to review specific section.

(3) **Sort Options:** These three tabs sort your Project File content by Division grouping, Type of calculation (Steel Beam, Concrete Column, Excel sheet, etc.) or Material (Concrete, Steel, Wood, etc.). [Click here](#)<sup>[118]</sup> to review specific section. Note that the [Add], [Copy], and [Delete] options are not available in the Type view or the Material view.

(4) **Expand & Contract Tree:** These two buttons fully expand or fully contract the tree structure to display or hide the full contents of the Project File.

(5) **GENERAL Division:** The GENERAL Division is automatically created in each new Project File. There can only be one GENERAL Division, and its purpose is to contain and organize certain hard-coded pieces of general information that apply to the Project as a whole. [Click here](#)<sup>[101]</sup> to review the section describing these items. The screen capture below shows a view of the Project Manager with the GENERAL Division expanded to display its contents:




(6) **LOADS & FORCES Division:** The LOADS & FORCES Division is also automatically created in each new Project File. There can only be one LOADS & FORCES Division, and its purpose is to contain and organize load related calculations. The screen capture below shows a view of the Project Manager with the LOADS & FORCES Division expanded to display its contents:



(7) **Calculation Division:** The Calculations Division is also automatically created in each new Project File, but it is created merely as a user-convenience. It can be thought of as a "custom" Division, because its name can be changed and it can be moved or deleted. The user is free to create as many custom Divisions as the Project warrants, and to name them as best suits the Project.

(8) **Calculation List:** This is the main list that displays all the calculation items that you have added into your project. It allows you to organize your calculations into Divisions. See image below for another look at two Divisions labeled "Beams" and "Columns". Columns shows a [+] button to its left, indicating that the tree containing the calculations in that Division is compressed. [Click here](#) <sup>108</sup> to review the section describing these items.




(9) **Move Item in List:** These buttons move the highlighted calculation up and down within the list. [Click here](#)<sup>122</sup> to review specific section.

(10) **Import Calculations from other Project Files:** [Click here](#)<sup>126</sup> to review specific section.

## 8.1 General Division

This Division contains a list of items that describe the entire project. Click here for a video:

[General Division](#)



[Building Code Information](#)<sup>[102]</sup>: Allows entry of information relating to the building code, jurisdiction and building official's contact information.

[Project Information](#)<sup>[103]</sup>: Allows entry of general information about the project.


[Client Information](#)<sup>[104]</sup>: Allows entry of information specific to the engineer's client.

[Designer Notes](#)<sup>[105]</sup>: Allows entry of up to 18 specific notes assigned by a specific person on a certain date.

[Revisions](#)<sup>[106]</sup>: Allows entry of up to 18 specific revisions assigned by a specific person on a certain date.


### 8.1.1 Building Code Information

This form allows you to select the Governing Building Code and Default Load Combination Set, and to enter various information items pertaining to the jurisdiction where your project is located. This data is specific to your Project File.



## 8.1.2 Project Information

This form allows you to enter information specific to your project. This data is specific to your Project File.



The screenshot displays the ENERCALC software interface. The window title is "ENERCALC : examples.ec6". The menu bar includes "File", "Settings", "Databases", "Tools", "License", and "Help". The toolbar contains various icons for file operations and help. The user is identified as "Licensed ENERCALC User, KW-06000215".

The main window is titled "Project Information" and contains the following fields:

- Project Title:
- Project Description:
- Project ID:
- Job Address:
- City:  State:  Postal Code:
- Lead Engineer:
- Phone:  Fax:  eMail:
- Notes:

On the left side, there is a vertical sidebar with the text "Show Project Manager" and "Click to view" buttons. On the right side, there are "Cancel" and "Save & Exit" buttons.

### 8.1.3 Client Information

This form allows you to enter information on your client for a specific project. This data is specific to your Project File.

The screenshot shows the ENERCALC software interface with the 'Client Information' form open. The window title is 'ENERCALC: examples.ec6'. The menu bar includes 'File', 'Settings', 'Databases', 'Tools', 'License', and 'Help'. The toolbar contains various icons for file operations and help. The user is logged in as 'Licensed ENERCALC User, KW-06000215'. The form has a title bar with 'Client Information', a help icon, a save icon, and buttons for 'Cancel' and 'Save & Exit'. The form fields are as follows:

- Name:
- Street Address:
- City:  State:  Postal Code:
- Phone:  Fax:
- Email:
- Contact #1:
- Contact #2:
- Notes:

On the left side of the form, there is a vertical sidebar with the text 'Show Project Manager' and two 'Click to view' links.

## 8.1.4 Designer Notes

This form allows you to enter up to 18 distinct notes on the project, each with a specific author and creation date. This data is specific to your Project File.

The screenshot shows the ENERCALC software interface with the 'Designer Notes' dialog box open. The window title is 'ENERCALC : examples.ec6'. The menu bar includes 'File', 'Settings', 'Databases', 'Tools', 'License', and 'Help'. The status bar indicates 'Licensed ENERCALC User, KW-06000215'. The dialog box has a title bar 'Designer Notes' and buttons for 'Cancel' and 'Save & Exit'. On the left, a vertical 'Show Project Manager' pane contains a list of 18 notes, with note 1 selected and highlighted in yellow. The main area of the dialog box is titled 'Select Note:' and contains the following fields:


- Author :
- Date :  Today
- Details :

The 'Details' field is a large text area with a vertical scrollbar. The text 'Characters Still Available : 1,341' is displayed in the top right corner of this area. The list of notes on the left is numbered 1 through 18, with 'Click to view' text next to notes 1, 2, 15, and 16.




### 8.1.5 Revision List

This form allows you to enter up to 18 distinct revision explanations on the project, each with a specific author and creation date. This data is specific to your Project File.



## 8.2 Loads & Forces Division

The LOADS & FORCES Division contains a growing number of calculations including Snow Loads, Live Load Reduction, Wind Loads, and Seismic Loads.




See specific descriptions under [Calculation Modules > Loads & Forces Division](#)<sup>107</sup>.

## 8.3 Calculation List


The Calculation List is the main Project Manager view that you will use when building your calculation sets for projects. Click here for a video: [Calculations Division](#)

Most of a normal work session consists of adding and editing calculations in the list.


Please see the notes below as well as the following sections to learn what each button provides and how to manage the list of calculations.




**Divisions:** Divisions are the main organizational category for calculations. These are the left-most text item in the calculation list and will display either a [+] or [-] to the left of their name. Divisions can be created, copied, renamed, moved, and deleted. Calculations must always exist within a Division, but they can be moved freely between Divisions. [Click Here](#)<sup>112</sup> for the specific information section. The screen capture below illustrates an example of how a Division can be renamed with a title that is meaningful to your project:



**Adding, Deleting, Copying:** The four buttons shown below allow you to add, copy, edit, or delete calculations and external items. [Click here](#)<sup>116</sup> for the specific information section.



**Sorting by Division, Type and Material:** Click one of these tabs to change the sorting view of the calculations in your project. [Click here](#)<sup>118</sup> for the specific information section.




**Changing Calculation and Division Order:** The buttons you see below are used to move the **highlighted** calculation or Division up or down in the list. When moving a calculation downward, if moving a calculation would tend to replace a Division name, then the calculation item is moved into that Division. When moving a calculation upward, if moving a calculation would tend to replace a Division name, then the calculation item is moved into the Division above. [Click here](#)<sup>122</sup> for the specific information section.



**Importing Calculations:** Clicking the **[Import]** button  **Import** displays the calculation import system. [Click here](#) <sup>126</sup> for the specific information section.


### 8.3.1 Divisions

Divisions are used to organize calculations. The image below has custom Divisions named Beams, Columns, Analysis, etc.






- Clicking the [-] icon to the left of the Division name will compress the Division tree. See image below...note how only the Division names are displayed, but their contents are currently not visible.



Left-clicking on a Division name will display the following pop-up menu:




Selecting [**Change Division Name**] will display the following dialog:




### 8.3.2 Adding, Deleting, Copying

The four buttons shown below are used to manipulate the calculations and Divisions in your current Project File:



**Add:** Clicking [Add] displays the dialog below, where you can select the type of item to add to your Project File. The window contains two categories of items: Calculations and External Items.



The available Calculations are listed in the top portion of the dialog (and there will be more as the product matures). These are ENERCALC-created structural engineering calculations that you can use. The lower portion of the dialog lists the available External

Items that can be created externally from the ENERCALC software package and then inserted into an ENERCALC Project File. These item types are:

**Microsoft WORD Document:** You can include a Microsoft Word document as an item in your Project File. [Click here](#)<sup>620</sup> to go to the specific section.

**Microsoft EXCEL Spreadsheet:** You can include a Microsoft Excel spreadsheet as an item in your Project File. [Click here](#)<sup>624</sup> to go to the specific section.

**Adobe Acrobat PDF File:** You can include a PDF file as an item in your Project File. [Click here](#)<sup>628</sup> to go to the specific section.

**Scanned Document:** You can set up your scanner and scan documents or images to include as an item in your Project File. [Click here](#)<sup>632</sup> to go to the specific section.


**Copy:** For the currently highlighted item in the calculation list, clicking [**Copy**] creates a new calculation of the same type using all of the information in the current calculation to make the new calculation. The copy is added to the list and is automatically opened for editing.

**Edit:** For the currently highlighted item in the calculation list, clicking [**Edit**] opens the calculation for editing.


**Delete:** Deletes the item that is currently highlighted in the calculation list. You are prompted to confirm before the deletion is made.

### 8.3.3 Sorting by Division, Type & Material


Select the "Division", "Material", or "Type" tab to sort the calculation list based on these three primary organizational hierarchies.




**Division:** Organizes the calculation list by the Divisions you created, and sorts the calculations within each Division in the order that you established. See below.



**Material:** Organizes the calculation list by the materials to which they refer, and sorts the calculations within each material in the order that you established. See below.



**Type:** Organizes the calculation list by calculation type, and sorts the calculations within each type in the order that you established. See below.







### 8.3.4 Changing Calculation Order

The two buttons shown at the bottom of the calculation list (see image below) are used to move the currently highlighted calculation or Division up or down in the list.



In the images below, note the button that is used to move the item upward in the list:



Now we will show that moving the last item in a Division downward will move the item to the top of the next Division. Notice how the Wood Column calculation moves from the bottom of Floor Framing to the top of Analysis.

**Project Manager**

Project Print    Print Item    Delete    Add    Copy    Edit

Division    Material    Type    Import

+	GENERAL	
+	LOADS & FORCES	
+	Beams	(right-click to modify)
-	Columns	(right-click to modify)
	Concrete Column	This one
	Wood Column	Single Story Post at D-4
	Masonry Column	Check this out
	<b>Steel Column</b>	<b>Steel Column in Frame with Pinned Bases</b>
-	Analysis	(right-click to modify)
	Pole Footing	Sample Pole Footing Embedded in Soil
	Section Prop Calc	User Defined Built-Up General Section
	2D Frame	Frame with pinned bases
	Diaphragm Torsion	Sample Rigid Diaphragm Torsion Analysis
+	Foundations	(right-click to modify)



**Project Manager**


Project Print    Print Item    Delete    Add    Copy    Edit

Division    Material    Type    Import


+	GENERAL	
+	LOADS & FORCES	
+	Beams	(right-click to modify)
-	Columns	(right-click to modify)
	Concrete Column	This one
	Wood Column	Single Story Post at D-4
	Masonry Column	Check this out
-	Analysis	(right-click to modify)
	<b>Steel Column</b>	<b>Steel Column in Frame with Pinned Bases</b>
	Pole Footing	Sample Pole Footing Embedded in Soil
	Section Prop Calc	User Defined Built-Up General Section
	2D Frame	Frame with pinned bases
	Diaphragm Torsion	Sample Rigid Diaphragm Torsion Analysis
+	Foundations	(right-click to modify)



### 8.3.5 Importing Calculations


Clicking the  **Import** button will change the Project Manager screen to appear as shown in the following image. Click here for a video: [Importing Calculations](#)

Please see the descriptions following the numbered keynotes. The order of the notes follows the order of usage.




(1) Specify the source ENERCALC Project File from which you will import calculations into the current (destination) Project File.

Clicking the **[Select Source File]** icon will display a standard Windows File Open dialog:



Clicking the **[Use File Pick List]** icon will open a window that lists all the ENERCALC Project Files contained in the last few folders you have accessed:




(2) After identifying the source Project File, area (2) will show the calculations in that source file in a tree-structure list.

(3) Click on the desired calculation in the source file to select it. It will become highlighted.

(4) Click in the current (destination) Project File to highlight a line where the calculation should be imported. (The only restriction is that calculations cannot be imported into the GENERAL Division or the LOADS & FORCES Division, so be sure to select a location other than those two Divisions or any of their contents.)


(5) Click the [**Copy Calc Into Project at Highlight**] button.


Notice in the image below the [Concrete Beam] calculation is now highlighted in green in the current (destination) file to indicate the location where it will be inserted.





Note: If you made a mistake and want to cancel the selection, just highlight the calculation in green on the left and click the **[Remove Added Calc]** button (6).

(7) To finish the import process click the  button.


(8) To completely cancel the import click the  button.

## 8.4 Project Printing

The **Project Printing** system allows you to print a complete project full of reports in one simple process. Click here for a video: [Project Printing](#)

You can review all the reports in your project and then select which reports to print.


To open the Project Printing system, click the button shown bubbled in the screen capture below:



The screen will change to display the Project Printing Manager window.



On the left will be listed all of the calculations and external items in the Project File. The items in the GENERAL Division are placed at the top and the items in the other Divisions are placed on the bottom. When you highlight an item the full report appears on the right side of the screen.

See the numbered keynotes on the image below as we describe how to use the various controls on the screen. The information is given in order of typical usage.




**(1) List of project items for which reports are available :** This area is similar to the item list in the Project Manager. All available report items are listed here. Simply click an item and the report for that item will be displayed in area **(4)**. Please REMEMBER that the reports shown were created when you clicked [**Save Only**] or [**Save & Exit**] in the specific calculation.

**Note:** If your software is licensed and activated, and if you see Evaluation Version watermarks on any reports, use the [**Regenerate**] button **(6)** to have all the reports regenerated WITHOUT the watermark.


**(2) Print / No-print check mark:** This column contains a check mark  or an X  to denote whether that particular report item is scheduled for printing.

**(3) Clear All / Select All / Invert Selection buttons:** These three buttons perform bulk changes to the print/no-print status of all items in the project.



Clears the print tags on all reports, so none will be printed. A  is displayed to the left of all reports after clicking this button.



Selects the print tags on all reports, so all will be printed. A  is displayed to the left of all reports after clicking this button.



Inverts the print/no-print tags on all reports.

**(4) Report Preview area:** The complete preview of the report is shown in this area for the report item highlighted in the list.

**(5) Report page selection:** When the highlighted item is a multi-page report, this box selects the page to view.

**(6)** (Item removed)

**(7) Print selected reports to printer:** Displays the Windows standard Print dialog box and begins printing all selected project items.

**(8) Create single PDF file for selected reports:** Displays a Windows Open File dialog box to request a filename for a PDF file and then creates a PDF of all selected project items.

Click [**C**lose] to dismiss the Project Printing Manager.

**Part**

---



## 9 Sample Session

This section will guide you through a session of preparing and printing a calculation. We will use the Wood Beam calculation because it contains all the features available in Structural Engineering Library.

## 9.1 Starting the Program

### First....let's start the program

To start **Structural Engineering Library**, navigate to the ENERCALC program group from the Start menu.


Click the Windows [**Start**] button and move upward to highlight the Programs (or All Programs) item. Locate the ENERCALC program group and highlight it. You will see several selections. Move the cursor to highlight Structural Library and release the mouse button.

**Structural Engineering Library** will now open, and you will be viewing the Project Assistant as described below.

## 9.2 Project Assistant

### The Project Assistant


This dialog gives you the ability to instantly choose how you wish to begin your work session. All of these options can also be easily chosen from the main menu, and the Project Assistant can also be reopened from the main menu after the program has already started.



For this Sample Session we want to create a new Project File, so the next step will be to click the **[Create Project File]** button.

The next window to be displayed (see below) will allow you to define the file name and select the drive & directory where the file should be placed.






We will use the filename Sample Session and place it in a folder named ENERCALC Project Files that we created specifically to hold Project Files.

**Note:** You could place the file in other directories, but keep in mind that Microsoft is now recommending specific locations for saving user-generated files with the newer operating systems, and the default ENERCALC data folder conforms to these new best-practice recommendations. The important thing to recognize is that an ENERCALC Project File can hold thousands of calculations, so it is likely that there will only need to be a single ENERCALC Project File for each design project in the office.


## 9.3 Creating a Project File

### Creating a Project File

Here's the Create NEW Project File dialog box with the new filename entered. NO FILE EXTENSION is necessary....the program will append it. When the dialog appears as it does below, just click [**Save**] and the file will be created.



When a new Project File is created, the new Project File is immediately opened and displayed in the Project Manager window. You can see in the screen image below that the new Project File looks rather plain and simple.



Notice that the ONLY items appearing in the calculation list are the words "GENERAL", "LOADS & FORCES" and "Calculations".

These items are called Divisions. You can create as many Divisions as you like. They serve as a way to organize your calculations into logical groups for your convenience .


All newly created Project Files will contain these three Divisions by default. The "GENERAL" Division and the "LOADS & FORCES" Division cannot be renamed or deleted, and they serve specific purposes, which we will see shortly. But the "Calculations" Division is just created for convenience. It can be renamed, deleted, copied, etc.

Before we add any calculations to this Project File, the next step will be to enter some general information about the project itself.

## 9.4 Entering Project Information

### Entering Project Information

Click the **[+]** icon to the left of the **GENERAL** Division in the Project Manager to expand its contents, and then double-click the top item named **Project Information**.



The screenshot shows the ENERCALC software interface with the 'Project Information' dialog box open. The dialog box has a title bar 'ENERCALC: sample session.ec6' and a menu bar with 'File', 'Settings', 'Databases', 'Tools', 'License', and 'Help'. The user is identified as 'Licensed ENERCALC User, KW-06000215'. The dialog box contains the following fields:

- Project Title: Sample Session
- Description: (empty)
- ID -or- Job Number: (empty)
- Job Address: (empty)
- City: (empty) State: (empty) Postal Code: (empty)
- Lead Engineer: An ENERCALC User
- Phone: (empty) Fax: (empty) eMail: (empty)
- Notes: This is a guided session to instruct users on how to apply and get the most out of the Structural Engineering Library software system.]

Buttons for 'Cancel' and 'Save & Exit' are visible at the top right. A vertical sidebar on the left contains 'Show Project Manager' and 'Click to view' labels.

For this sample session you can fill in anything you like, just to see how the Project Information fields can be used. Then click the **[Save & Exit]** button and click **[OK]** in the Reminder dialog. The purpose of the Reminder dialog is to alert us to the fact that some data just changed in the title block. Under normal conditions, **Structural Engineering Library** generates the report for a single calculation at a time, and it does that when the Save command is issued while a calculation is open. This makes for a very efficient use of time by generating reports only on an as-needed basis. However, because we just made a change to title block data, it is likely that we want all reports regenerated and brought up to date at this time. This Reminder dialog guides us to the command in the main menu that manually forces all reports to be immediately regenerated.

NOTE: This Project Information is printed in the upper-right corner of your printouts. All **Structural Engineering Library** printouts have a Title Block area that contains your

company's information in the upper-left corner and the Project Information in the upper-right corner. The above project information (and the title block information described in the next section) will look like this on the printouts:



Title Block Line 1  
You can change this area by clicking Settings and then clicking Printing & Title Block. You can enter a total of six lines of data.

Title : Sample Session  
Engineer: An ENERCALC User  
Project Desc.:

Job # 123456789

Printed: 20 SEP 2012, 9:50AM

**Steel Base Plate**

Lic. #: KW-06000215

Description : -None-

File: c:\users\christi\documents\enercalc\project files\sample session.ec6

ENERCALC, INC. 1983-2012, Build:6.12.9.19, Ver:6.12.9.15


Licensee: Licensed ENERCALC User

## 9.5 Setting up your Title Block


### Setting up your Title Block

Before continuing on to add some calculations to the project, we'll demonstrate where to enter company information to be included on ALL calculations produced within **Structural Engineering Library**.


Click **Settings > Printing & Title Block** from the main menu.



The **Printing & Title Block** tab of the Program Settings dialog will be displayed. Here you can use six lines to customize the printout with your own company information. This information will be printed in the upper-left corner of ALL printouts (see sample previously).



The Logo File area of this dialog also offers the option to identify a graphic file of your


company's logo and specify that it be printed as part of the Title Block. Clicking the  button lets you use a file selection dialog to select a Windows Bitmap (BMP), GIF, JPG, or WMF file.

At this time, please enter some information in all six lines so you can see it printed later in this sample session. Click the **[Close]** button when finished, and then click the **[OK]** button in the Reminder dialog.

## 9.6 Adding a Calculation

### Adding a Calculation


To add a calculation in the Project Manager, first highlight the location where you would like the new calculation to be inserted. At present we have no calculations in the Division named "Calculations", so we will click on "Calculations" to highlight it as shown below:




Next, click the **[Add]** button.

The next dialog will allow you to select exactly which calculation type you wish to add:





For this sample session we will use the **Wood Beam** module, so click the [**Wood Beam**] button as shown below.




A Wood Beam calculation will be added in the Project Manager, and it will automatically be opened for editing. The screen will reconfigure itself to display the graphical user interface that is specific to the Wood Beam module.

## 9.7 Viewing the Calculation Screen

### Viewing the Calculation Screen

The screen should now appear as shown below. Please observe the following areas of the screen....they are typical of ALL calculations in **Structural Engineering Library**.



The data entry tabs on the top half of the screen are where you enter your input values.

The results and graphics tabs on the bottom half of the screen are where you review the calculated values, sketches, and graphs that result from calculations based on your input values.

This screen layout is consistent throughout the majority of **Structural Engineering Library** calculation modules. This enables you to display the tab of interest on the bottom and see how changes to input data on the top affect it.

## 9.8 Changing the Default Values/Settings

### Changing the Default Values/Settings

When you first add any calculation to a Project File, that calculation will come in with default values/settings for all user input items. If you find that you are almost always having to change certain items, it may make sense for you to revise those defaults to better suit your work. Revising the default values for any module is easy. Just follow these steps:


1. Add a new calculation of the module of interest to a Project File. It will come in with the existing default values/settings.
2. Revise the values/settings to suit.
3. Click Settings > Default Values > Save.

This will save all of your current settings/values as the new defaults for that particular module. From that point onward, any time you add a new calculation of that module type, it will automatically be populated with the default values/settings that you just established.

## 9.9 Entering Data


### Entering Data

Below is a diagram for a wood roof beam we wish to design.




The following steps will guide you through the process of setting the span lengths and entering the loads as shown. (In a subsequent step we will select the member section size and reference design values from the internal databases.)


The top portion of the screen should currently look like this:




The first thing we will do is add the left cantilever. To do this, click the [+/-] icon at the left end of the beam as shown bubbled below:




This opens the dialog named Select Add or Delete. It is currently set up to allow us to add a new beam span, which is exactly what we want to do. There are some additional settings offered at the bottom of the dialog in the form of checkboxes. We don't need to worry about these at this point, but it's good to know that they are available, because they can offer some time-saving conveniences in certain modeling situations. See the image of the Select Add or Delete dialog shown below:




For our purposes, all we need to do is click the [OK] button. This inserts a new beam span to the left of the original beam as shown below:




At this point, don't be concerned about the fact that the new span is not a cantilever and that it is not the intended length. We'll correct both of those items in just a moment. For now, let's repeat a similar process to add a new beam span on the right. First click the [+/-] icon that appears above the right-most support. The following dialog appears:




This is very similar to the Select Add or Delete dialog we saw before, except that it now has an extra option to delete the span that is to the left of the support. Although we don't want to do this, it's good to know that this is the way that you would delete a span if necessary. What we want to do is add a new beam span, and that is the option that is currently selected (highlighted in yellow), so we can just click the [OK] button. The screen should now display a 3-span continuous beam as shown below:




Now that we have three spans to work with, let's modify the support conditions to create the cantilevered spans at the left and the right. To do this, click on the left-most support icon shown bubbled below:




This will open the following pop-up menu that offers many options for defining the support condition at that location:




Click the **Free End** option to remove all restraint from the left end, creating a cantilever. Repeat the same process at the right-most support, but leave the remaining two supports as they are currently configured. (They represent pinned conditions that prevent translation in all directions but offer no moment restraint.) The result will be the double-cantilevered beam as shown below:



Now that the support conditions have been established correctly, we can wrap up this exercise by modifying the span lengths to match the problem definition. Start by clicking the Beam Span Data tab shown bubbled below:



The screen layout will change to display the Beam Span Data tab as shown below:




Now, we just need to adjust the span lengths for each of the three spans.

First, note that the graphical depiction of the beam helps us to make the association between the three individual spans and the span numbers. Click any of the three span




number buttons in the Select Span area and notice that a corresponding span becomes highlighted in the large graphic at the top of the view. Using this method, we can confirm that the spans are logically ordered from number one on the left to number three on the right. (Note that you can also click the highlighted rectangles shown above each beam span, and they act in exactly the same way that the numbered buttons do.)


So to finish things off, click the button for span [1] and verify that the left span becomes highlighted. According to the problem statement, this span is supposed to be 7'-3", so you can highlight the value that is presently displayed in the Span Length field, manually edit it to say 7.25, and then press the [Tab] key to enter that value. The display will update to show the proper span length for the left beam span as shown below:



Repeat the same process to set the Span Length for the middle span to 24'-0" and to set the Span Length for the right span to 9'-6", at which time the display should appear as shown below:




The next step will be to enter the loads on the beam. Let's begin by entering the concentrated load at the free end of the left beam span. Click the Span Loads tab to display the following screen:




This screen contains tools to apply loads to a selected span at a time. (Shortly, we will see a convenience tool that will allow us to apply loads to ALL spans of a beam at one time.)

Since we want to start by entering the concentrated load at the free end of the left beam span, click the [1] button in the Select Span area to put the focus on Span 1.

The blue highlighted band in the table now represents the first load on Span 1. But it currently indicates Load Type = None, because we have not defined the load yet. Click the button indicated in the screen capture below to identify the load as being a concentrated load:



This will reconfigure the screen with the appropriate input fields to fully define the magnitude, direction, and location of the concentrated load as shown below:



The Load Source input field provides a location where you can add some descriptive text for your own use to identify this particular load item. The use of this field is optional, so for this sample session we will leave it blank.

Select the checkbox for the Auto add beam weight option. This will trigger the program to determine the self weight of the beam that we eventually choose, and apply it as dead load when the analysis is performed.

Select the checkbox for the Auto Unbalanced Live load Placement option. This will initiate the generation of additional loading conditions to ensure that all possible permutations of live load placement are properly examined. Note that selecting this option can lead to longer analysis times because of the number of different conditions that must be analyzed. However, with the double-cantilevered beam configuration, it would be important for us to have the module examine all of these potential loading permutations.


When defining the magnitude of the concentrated load, note that the module is set up to receive this kind of load in units of kips, and notice that it has input fields for the common load cases, such as Dead, Live, Snow, etc.

Click in the input field for Dead, enter a magnitude of 3.03, and then press the **[Tab]** key. This enters the Dead load magnitude and moves the cursor to the next input field.

Note: For convenience this module is configured such that loads with positive magnitudes are assumed to act downward, since the majority of the load items are typically gravity loads of some sort.


The cursor is currently in the Lr input field, which represents Roof Live load. We don't need to enter any magnitude for Roof Live, so press the **[Tab]** key once again to place the cursor on the Live load input field. Enter a magnitude of 2.824, and then press the **[Tab]** key.

The final step in specifying this concentrated load is to identify its position using the Location input field. Always specify the distance from the left end of this span to the position of the concentrated load. In this case, the correct value is zero, which also happens to be the default value for the Location field, so the Location field can be left as-is. The screen should now appear as shown below:



The next step will be to define the other concentrated load, which occurs at the free end of the cantilever on the right end of the beam, by following a very similar process.


Click the [3] button in the Select Span area to put the focus on Span 3.

Click the  button to identify the load as being a concentrated load.

The magnitudes of this load are the same as those used at the opposite end of the beam, so click in the input field for Dead, enter a magnitude of 3.03, and then press the [Tab] key twice.

In the Live load input field enter a magnitude of 2.824, and then press the [Tab] key.


This concentrated load is to be positioned at the extreme right end of this span, so click in the Location input field, enter a distance of 9.5 (9'-6" from the support at the left end of Span 3), and then press the [Tab] key. The screen should now appear as shown below:




Span #	Location (ft)	D (k)	Lr (k)	L (k)	S (k)	W (k)	E (k)	H (k)
Point Load	9.500	1.000	3.030	2.824				

The next step in defining loads is to apply the uniformly distributed load across all three spans. This *could* be done by using the Uniformly Distributed Loading Type here on the Span Loads tab. But this would require some repetition, because the Span Loads tab is specifically set up to facilitate the application of loads to one span at a time.


To apply this load in a more efficient manner, click the Loads All Spans tab shown bubbled below:



The screen will reconfigure itself to display different tools for applying various types of loads to all spans of the beam. The one that is most appropriate for our application is the one shown bubbled below:



Click that tool and note that the screen displays input fields for Tributary Width and load magnitudes for the various Load Cases as shown below:




Note: When using this tool, you can either leave the Tributary Width input field at its default value of 1.0, and then enter the magnitudes for the various load cases in units of kips per foot, or you can specify a Tributary Width magnitude *other* than 1.0 foot, and then enter the magnitudes for the various load cases in units of kips per square foot, which will be multiplied by the Tributary Width to determine the magnitude of the effective line load in units of kips per foot.

For the purposes of our exercise, we will leave the Tributary Width input field at its default value of 1.0.


Click in the Dead load input field, enter a magnitude of 0.036, and press the **[Tab]** key twice.

In the Live load input field, enter a magnitude of 0.24, and press the **[Tab]** key once more.


The last item to take care of is to observe the load combinations that will be used for design. Click the Load Combinations tab shown bubbled below:



This will display the Load Combinations screen. On this screen, the first step is to make sure that we are referencing the correct set of load combinations. To do this, click the "Change Load Combination Set" button shown below bubbled below:




This will open a pop-up menu offering choices of load combination sets that exist on the current machine, similar to the one shown below:



Choose the option named IBC 2009. This will set up the calculation to use load combinations based on IBC 2009.

Next, click the **C<sub>D</sub>** button, and confirm by clicking the [Yes] button. This is a very convenient option for wood designs, because it automatically sets the C<sub>D</sub> value based on the shortest duration load case within each load combination. Note the various values of C<sub>D</sub> that result.

The final step in this section is to ensure that all of the listed load combinations will be used in the analysis and design. To do this, click the **Run** button. This will open a pop-up menu offering options for marking and clearing the Run status of all of the load combinations in the list, as shown below:



Simply click the **[Mark All]** option, and all of the load combinations in the list will be marked for use in the analysis and design.

## 9.10 Selecting Sections and Materials from Built-in Databases


### Selecting Sections and Materials from Built-in Databases

In the previous topic you experienced part of the advantage of using **Structural Engineering Library**...simplified data entry. The input screens naturally guide you through all of the necessary items, and you are simply entering data into a form.

We still have two critical items to specify.....the stress properties of the wood member to use and the physical size of the beam.

First, let's retrieve the reference design values. For this sample we want to use a Douglas Fir glued-laminated beam of type 24F-V8.

Click the General Data tab shown bubbled below:



In the Design Values category, click the [Display Wood Material Database] button . The Wood Stress Database will be displayed as shown below:

Wood Reference Design Values

**NDS 2005 Supplement Reference Design Values**

Size Classes to Show

Show Favorites Only

Expand/Contract Trees :


Wood Species	Size/Group	Fb (psi)	Fv	Fc (psi)	Ft	E - Modu				
Common Name	Classification	Tension	Compr.	psi	Perp.	Prll	psi	E Bend	E Min Bend	E Ber
No. 1	2"-4" Thick	775	775	170	555	1,000	350	1,100	400	
No. 2	2"-4" Thick	575	575	170	555	825	275	1,100	400	
No. 3	2"-4" Thick	350	350	170	555	475	150	900	330	
Stud	2"-4" Thick	450	450	170	555	525	200	900	330	
Construction	2"-4" Thick	675	675	170	555	1,050	300	1,000	370	
Standard	2"-4" Thick	375	375	170	555	850	175	900	330	
Utility	2"-4" Thick	175	175	170	555	550	75	800	290	
Eastern Softwood	2"-4" Thick									
Select structural	2"-4" Thick	1,250	1,250	140	335	1,200	575	1,200	440	
No. 1	2"-4" Thick	775	775	140	335	1,000	350	1,100	400	
No. 2	2"-4" Thick	575	575	140	335	825	275	1,100	400	
No. 3	2"-4" Thick	350	350	140	335	475	150	900	330	
Stud	2"-4" Thick	450	450	140	335	525	200	900	330	
Construction	2"-4" Thick	675	675	140	335	1,050	300	1,000	370	
Standard	2"-4" Thick	375	375	140	335	850	175	900	330	
Utility	2"-4" Thick	175	175	140	335	550	75	800	290	
Eastern White Pine	2"-4" Thick									
Select structural	2"-4" Thick	1,250	1,250	135	350	1,200	575	1,200	440	
No. 1	2"-4" Thick	775	775	135	350	1,000	350	1,100	400	

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\NDS\_2005.TPS



By default the last selection of stress grade is displayed. We want to display ONLY the glued-laminated sections for Douglas Fir.

In the Size Classes to Show category, click the [**Glulam Table 5A Beams**] button:



Click the [**Contract Trees**] button to collapse the display of Wood Species Common Names.

Click the [+] in front of the DF/DF item to expand the Douglas Fir list:

Wood Species	Size/Group
Common Name	Classification
+ AC/AC	Glu-Lam
+ DF/DF	Glu-Lam
+ DF/HF	Glu-Lam
+ Hardwoods - Glu-Lam	Glu-Lam
+ HF/HF	Glu-Lam
+ SP/SP	Glu-Lam
+ Willamette - Glu-Lam	Glu-Lam

The result of these choices will be a list of stress grades as shown....


Wood Species	Size/Group	Fb psi	Fv	Fc psi	Ft	E - Moc				
Common Name	Classification	Tension	Compr.	psi	Perp.	Prll	psi	E Bend	E Min Bend	E Ber
+ AC/AC	Glu-Lam									
+ DF/DF	Glu-Lam									
- 16F - V6	Glu-Lam	1,600	1,600	265	560	1,550	900	1,500	780	
- 16F - E3	Glu-Lam	1,600	1,200	215	560	1,600	925	1,600	830	
- 16F - E6	Glu-Lam	1,600	1,600	265	560	1,600	975	1,600	830	
- 20F - V3	Glu-Lam	2,000	1,450	265	560	1,550	975	1,600	830	
- 20F - V7	Glu-Lam	2,000	2,000	265	650	1,600	1,000	1,600	830	
- 20F - E3	Glu-Lam	2,000	1,200	265	560	1,600	1,000	1,700	880	
- 20F - E6	Glu-Lam	2,000	2,000	265	560	1,650	1,100	1,700	880	
- 24F - V4	Glu-Lam	2,400	1,850	265	650	1,650	1,100	1,800	930	
- 24F - V8	Glu-Lam	2,400	2,400	265	650	1,650	1,100	1,800	930	
- 24F - E4	Glu-Lam	2,400	1,450	265	650	1,700	1,100	1,800	930	
- 24F - E13	Glu-Lam	2,400	2,400	265	650	1,700	1,200	1,800	930	
- 24F - E18	Glu-Lam	2,400	2,400	265	650	1,700	1,100	1,900	980	
- 26F - V1	Glu-Lam	2,600	1,950	265	650	1,850	1,300	2,000	1,040	
- 26F - V2	Glu-Lam	2,600	2,600	265	650	1,850	1,300	2,000	1,040	
+ DF/HF	Glu-Lam									
+ Hardwoods - Glu-Lam	Glu-Lam									
+ HF/HF	Glu-Lam									

Click the **24F-V8** item as shown, and then click the [**Select**] button. The stress information area on the General tab will immediately be updated to reflect your selection:

Design Values					
Wood Species	DF/DF				
Wood Grade	24F - V8				
Fb - Tension	2400	psi	Fv	265	psi
Fb - Compression	2400	psi	Ft	1100	psi
Fc - Prll	1650	psi	Density	32.21	pcf
Fc - Perp	650	psi	Calc Shear at 'd' from support ?	<input checked="" type="checkbox"/>	
<i>E : Modulus of Elasticity</i>			Force Le = 1.0 Lu ?	<input checked="" type="checkbox"/>	
Ebend- xx	1800	ksi	Ebend- yy	1600	ksi
Eminbend - xx	930	ksi	Eminbend - yy	830	ksi

Next, let's retrieve the section property data for a 6.75" x 30" glulam beam

Click the Beam Span Data tab  and make sure that the [All Spans] option is selected as shown below:



General Data | **Beam Span Data** | Span Loads | Loads All Spans | D+L+? Load Combinations

Select Span : 1 | 2 | 3  
Span Length = 7.25 ft

Use Cr : Repetitive ?   
(non-glb only)

Cm : Wet Use Factor : Fb: 1 Fv: 1 E: 1  
Ct : Temperature Factor 1  
Apply Incising Factors   
(sawn only)  
See Max Combinations tab for CF & Cv


Wood Section Name : 4x8  
Database or Selected section used for :  All Spans  Current Span

Member Width = 3.50 in  
Member Depth = 7.250 in  
Area = 25.375 in<sup>2</sup>  
Ix = 111.148 in<sup>4</sup>  
Iy = 25.904 in<sup>4</sup>

Wood Grading/Manuf. : Graded Lumber  
Wood Member Type : Sawn

Select Section . . .  
2x3  
2x4  
2x6  
2x8  
2x10  
2x12  
2x14  
3x4  
3x6  
3x8  
3x10  
3x12  
3x14  
3x16

Then click the [Section Database] button shown bubbled below:



General Data | **Beam Span Data** | Span Loads | Loads All Spans | D+L+? Load Combinations

Select Span : 1 | 2 | 3  
Span Length = 7.25 ft

Use Cr : Repetitive ?   
(non-glb only)

Cm : Wet Use Factor : Fb: 1 Fv: 1 E: 1  
Ct : Temperature Factor 1  
Apply Incising Factors   
(sawn only)  
See Max Combinations tab for CF & Cv

Wood Section Name : 4x8  
Database or Selected section used for :  All Spans  Current Span

Member Width = 3.50 in  
Member Depth = 7.250 in  
Area = 25.375 in<sup>2</sup>  
Ix = 111.148 in<sup>4</sup>  
Iy = 25.904 in<sup>4</sup>

Wood Grading/Manuf. : Graded Lumber  
Wood Member Type : Sawn

Select Section . . .  
2x3  
2x4  
2x6  
2x8  
2x10  
2x12  
2x14  
3x4  
3x6  
3x8  
3x10  
3x12  
3x14  
3x16

The Wood Section Database will be displayed as shown below:

Wood Section Database

Wood Database

ENERCALC Supplied

User Defined

Favorites

Show Favorites Only

Toggle Favorite ON-OFF

Select Types to Display . . .

Solid Sawn

General Southern Pine

Glued Laminated

Western Southern Pine

Manufactured

iLevel: Microllam iLevel: Parallam LP:Gang-Lam LVL RedBuilt RedLam LVL

iLevel: Timber Strand BC : VersaLam Anthony Power

SortOrder

Ascending Descending

Specify Depth Range

Name	Type	Species	Width in^2	Depth in	Area in	Ix in^4	Sxx in^3
2x3	Sawn	Graded Lumber	1.500	2.500	3.750	1.953	1.56
2x4	Sawn	Graded Lumber	1.500	3.500	5.250	5.359	3.06
2x6	Sawn	Graded Lumber	1.500	5.500	8.250	20.797	7.56
2x8	Sawn	Graded Lumber	1.500	7.250	10.875	47.635	13.14
2x10	Sawn	Graded Lumber	1.500	9.250	13.875	98.932	21.39
2x12	Sawn	Graded Lumber	1.500	11.250	16.875	177.979	31.64
2x14	Sawn	Graded Lumber	1.500	13.250	19.875	290.775	43.89
3x4	Sawn	Graded Lumber	2.500	3.500	8.750	8.932	5.10
3x6	Sawn	Graded Lumber	2.500	5.500	13.750	34.661	12.60
3x8	Sawn	Graded Lumber	2.500	7.250	18.125	79.391	21.90
3x10	Sawn	Graded Lumber	2.500	9.250	23.125	164.866	35.66
3x12	Sawn	Graded Lumber	2.500	11.250	28.125	296.631	52.73
3x14	Sawn	Graded Lumber	2.500	13.250	33.125	484.626	73.15
3x16	Sawn	Graded Lumber	2.500	15.250	38.125	738.870	96.90
4x4	Sawn	Graded Lumber	3.500	3.500	12.250	12.505	7.14
4x6	Sawn	Graded Lumber	3.500	5.500	19.250	48.526	17.64
4x8	Sawn	Graded Lumber	3.500	7.250	25.375	111.148	30.66
4x10	Sawn	Graded Lumber	3.500	9.250	32.375	230.840	49.91
4x12	Sawn	Graded Lumber	3.500	11.250	39.375	415.283	73.82
4x14	Sawn	Graded Lumber	3.500	13.250	46.375	678.476	102.41
4x16	Sawn	Graded Lumber	3.500	15.250	53.375	1,034.419	135.66
6x6	Sawn	Graded Lumber	5.500	5.500	30.250	76.255	27.72
6x8	Sawn	Graded Lumber	5.500	7.500	41.250	193.359	51.56
6x10	Sawn	Graded Lumber	5.500	9.500	52.250	392.964	82.72
6x12	Sawn	Graded Lumber	5.500	11.500	63.250	697.068	121.22
6x14	Sawn	Graded Lumber	5.500	13.500	74.250	1,127.672	167.06

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\EC6\_TIMBER.tps

Western

Now click the **Western** button in the Glued Laminated category so that only those members are displayed. The result of this choice will be a list of glulam beams.

Scroll down through the database and highlight the 6.75" x 30" beam as shown below:

Wood Section Database

Wood Database

ENERCALC Supplied

User Defined

Favorites

Show Favorites Only

Toggle Favorite ON-OFF

Select Types to Display . . .

Solid Sawn

General Southern Pine

Glued Laminated

Western Southern Pine

Manufactured

iLevel: Microllam iLevel: Parallam LP:Gang-Lam LVL RedBuilt RedLam LVL

iLevel: Timber Strand BC : VersaLam Anthony Power

SortOrder


Ascending Descending

Specify Depth Range

Name	Type	Species	Width	Depth	Area	Ix	Sxx
			in^2	in	in	in^4	in^3
5.125x40.5	GLB	Western	5.125	40.500	207.563	28,371.199	1,401.04
5.125x42	GLB	Western	5.125	42.000	215.250	31,641.750	1,506.75
6.75x7.5	GLB	Western	6.750	7.500	50.625	237.305	63.28
6.75x9	GLB	Western	6.750	9.000	60.750	410.063	91.12
6.75x10.5	GLB	Western	6.750	10.500	70.875	651.164	124.03
6.75x12	GLB	Western	6.750	12.000	81.000	972.000	162.00
6.75x13.5	GLB	Western	6.750	13.500	91.125	1,383.961	205.03
6.75x15	GLB	Western	6.750	15.000	101.250	1,898.438	253.12
6.75x16.5	GLB	Western	6.750	16.500	111.375	2,526.820	306.28
6.75x18	GLB	Western	6.750	18.000	121.500	3,280.500	364.50
6.75x19.5	GLB	Western	6.750	19.500	131.625	4,170.867	427.78
6.75x21	GLB	Western	6.750	21.000	141.750	5,209.313	496.12
6.75x22.5	GLB	Western	6.750	22.500	151.875	6,407.227	569.53
6.75x24	GLB	Western	6.750	24.000	162.000	7,776.000	648.00
6.75x25.5	GLB	Western	6.750	25.500	172.125	9,327.023	731.53
6.75x27	GLB	Western	6.750	27.000	182.250	11,071.688	820.12
6.75x28.5	GLB	Western	6.750	28.500	192.375	13,021.383	913.78
6.75x30	GLB	Western	6.750	30.000	202.500	15,187.500	1,012.50
6.75x31.5	GLB	Western	6.750	31.500	212.625	17,581.430	1,116.28
6.75x33	GLB	Western	6.750	33.000	222.750	20,214.563	1,225.12
6.75x34.5	GLB	Western	6.750	34.500	232.875	23,098.289	1,339.03
6.75x36	GLB	Western	6.750	36.000	243.000	26,244.000	1,458.00
6.75x37.5	GLB	Western	6.750	37.500	253.125	29,663.086	1,582.03
6.75x39	GLB	Western	6.750	39.000	263.250	33,366.938	1,711.12
6.75x40.5	GLB	Western	6.750	40.500	273.375	37,366.945	1,845.28
6.75x42	GLB	Western	6.750	42.000	283.500	41,674.500	1,984.50
6.75x43.5	GLB	Western	6.750	43.500	293.625	46,290.000	2,128.70

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\EC6\_TIMBER.tps



Click the  button. The beam size information area on the Beam Span Data tab will immediately be updated to reflect your selection:

General Data **Beam Span Data** Span Loads Loads All Spans D+L+? Load Combinations

Select Span : 1 2 3

Span Length = 7.25 ft

Max. Allow Deflection Ratios:

Live Load : L / 240.0

Total : L / 180.0

Use Cr : Repetitive ?  (non-glb only)

Cm : Wet Use Factor : Fb: 1 Fv: 1 E: 1

Ct : Temperature Factor : 1

Apply Incising Factors  (sawn only)

See Max Combinations tab for CF & Cv

Wood Section Name : 6.75x30

Database or Selected section used for : All Spans Current Span

Member Width = 6.750 in

Member Depth = 30.0 in

Area = 202.50 in^2

Ix = 15,187.5 in^4

Iy = 768.87 in^4

Wood Grading/Manuf. : Western

Wood Member Type : GLB


Select Section . . .

- 2.5x6
- 2.5x7.5
- 2.5x9
- 2.5x10.5
- 2.5x12
- 2.5x13.5
- 2.5x15
- 2.5x16.5
- 2.5x18
- 2.5x19.5
- 2.5x21
- 3.125x6
- 3.125x7.5
- 3.125x9

## 9.11 Displaying a Sketch

### Displaying a Sketch

We now have a calculation with span lengths, loads, allowable stresses, and a beam size. It's time to review the sketch to confirm that we have entered the critical span and load information correctly. Click the Sketch tab, and the working area of your screen will be replaced with a simple diagrammatic representation of the beam.



## 9.12 Displaying Diagrams


### Displaying Diagrams


In addition to the Sketch of the beam, we can also display several types of diagrams. Selecting the Diagrams tab will display the Shear/Moment/Deflection diagram as shown below.

Of special interest are the checkboxes that control the location of live load for the analysis shown in the graphic. Because this program automatically moves the live load around on the beam to obtain the governing values of shear, moment, and deflection on each span for the final calculation results, there really is no single load case that represents the entire beam analysis.

By selecting the live load locations here you can view the detailed shear/moment/deflection variations produced by each load application.

Note: In the previous steps, we turned on the option to have the program automatically handle unbalanced Live load placement. While this is a helpful feature for design, it tends to produce an abundance of results. If you'd like to view shear, moment, and deflection diagrams that are similar to those shown below, click the Span Loads tab and temporarily turn off the option to have the program automatically perform unbalanced Live load placement.






## 9.13 Automatic Member Section Selection

### Automatic Member Section Selection


An additional feature of many of **Structural Engineering Library** calculation modules is automatic selection of sizes that satisfy your specified design criteria.

Note: If you turned off the option to have the program automatically perform unbalanced Live load placement in the previous topic, please click back to the Span Loads tab now and make sure the option for Auto Unbalanced Live Load Placement is selected once again.


Click the Calculations tab at the left edge of the screen as shown bubbled below:



When the screen displays the Calculations environment, click the Summary Results tab as shown bubbled below:




Take a look at the stress and deflection ratios bubbled in the screen capture below:






We can see that our 6.75" x 30" size guess may not be an optimum use of the section. It would be interesting to see if we could find a more efficient section. Rather than manually trying other sizes from the database, we will use the Automatic Design function to select an optimum member size for us. Click the [Design] button on the Beam Span Data tab shown bubbled below:



The Wood Member Design dialog is displayed, and it allows you to set the design criteria:



On the Wood Member Design dialog, click the [Glu-Lam - Western] section type, set the Maximum Stress Ratio to 1.0, and the Minimum Total Deflection Ratio to 180, then click the [Start Design] button.

The software will automatically search the built-in Wood Section Database for all sections that satisfy this criteria using the beam span, stress grade, and loading you have specified. In a few moments the following dialog will be displayed:

Sections Passing Design Criteria

Sort List By ...

Weight Bending Ratio Shear Ratio LL Defl Ratio Tot Defl Ratio Depth

Select Cancel

Wood Section	Max. Stress Ratio		Max Defl.				Section			
	Bending	Shear	Total	Ratio	LL	Ratio	Weight	Width	Depth	Inertia
5.125x27	0.609	0.337	1.005	226.9	0.562	405.7	30.95	5.125	27.000	8,406.28
5.125x28.5	0.549	0.319	0.854	266.8	0.478	477.1	32.67	5.125	28.500	9,886.61
5.125x30	0.498	0.303	0.733	311.2	0.410	556.5	34.39	5.125	30.000	11,531.25
5.125x31.5	0.454	0.289	0.633	360.3	0.354	644.2	36.11	5.125	31.500	13,348.86
6.75x24	0.594	0.288	1.086	209.9	0.608	375.3	36.24	6.750	24.000	7,776.00
5.125x33	0.416	0.276	0.550	414.2	0.308	740.7	37.83	5.125	33.000	15,348.09
6.75x25.5	0.530	0.271	0.906	251.7	0.507	450.1	38.50	6.750	25.500	9,327.02
5.125x34.5	0.382	0.264	0.482	473.3	0.269	846.3	39.55	5.125	34.500	17,537.59
6.75x27	0.475	0.256	0.763	298.8	0.427	534.3	40.77	6.750	27.000	11,071.69
5.125x36	0.352	0.253	0.424	537.8	0.237	961.6	41.27	5.125	36.000	19,926.00
5.125x37.5	0.326	0.243	0.375	607.9	0.210	1,086.9	42.99	5.125	37.500	22,521.97
6.75x28.5	0.429	0.242	0.649	351.4	0.363	628.4	43.03	6.750	28.500	13,021.38
8.75x22.5	0.532	0.237	1.017	224.2	0.569	400.8	44.04	8.750	22.500	8,305.66
5.125x39	0.303	0.233	0.333	683.8	0.186	1,222.6	44.71	5.125	39.000	25,334.16
6.75x30	0.389	0.230	0.556	409.9	0.311	732.9	45.30	6.750	30.000	15,187.50

Max Stress Ratio = 0.609 0.337 Min Ratio = 180.0 Min Ratio = 360.0

Notice how the listed members can be sorted in different orders based on: Weight, Bending Ratio, Shear Ratio, LL Deflection Ratio, Total Deflection Ratio, Depth, etc. This allows you to review the beam sizes that pass your criteria in different ways.

Click on the **5.125 x 27** beam and then click the **[Select]** button. The final design (with Summary Results tab showing) looks like this:

Summary Results Max. Combinations M-V-D Summary Support Reactions Design OK

Calculations

✓ Maximum Bending Stress Ratio = **0.613 : 1**  
 Section used for this span **5.125x27**  
 fb : Actual = 1,338.67 psi FB : Allowable = 2,183.70 psi  
 Load Combination +D+L+H, LL Comb Run (\*\*L)  
 Location of maximum on span 24.000 ft  
 Span # where maximum occurs Span # 2

✓ Maximum Shear Stress Ratio = **0.331 : 1**  
 Section used for this span **5.125x27**  
 fv : Actual = 87.63 psi Fv : Allowable = 265.00 psi  
 Load Combination +D+L+H, LL Comb Run (\*\*L)  
 Location of maximum on span 24.000 ft  
 Span # where maximum occurs Span # 2

Diagram

✓ Minimum Deflection Ratios (L+Lr) or (L+S) Deflection

		Ratio =	
Max Downward	0.562 in	404	
Max Upward	-0.269 in	1069	
Total Deflection			
Max Downward	1.006 in	226	
Max Upward	-0.468 in	615	

Extreme Reactions ( service, kips )

	D	Lr	L	S	W	E	H
Support #1							
Support #2	3.98			8.56			
Support #3	4.81			9.55			

## 9.14 Printing a Calculation


### Printing a calculation

Okay...congratulations! You've created a Project File, added a calculation, entered data, retrieved database information, performed an automatic design, and viewed some graphics. It's time to print this calculation and take a look at what the software provides for documentation.

Please remember that you have previously entered project information, title block information, and of course now you have a valid engineering calculation to print.


You have three printing options in **Structural Engineering Library**:



The  icon that looks like a printer sends the report report directly to the printer. The



icon that looks like a printer with a page symbol displays the print preview in a

window and allows you to review it before sending it to the printer. The  icon with the Adobe logo creates an Adobe Acrobat PDF file of the report.

The Print Preview window looks like this:

Report Preview

File View

Print PDF Cancel Select Pages Page: 1 of 6 Across: 1 Down: 1

Title Block Line 1  
 You can change this area using the "Settings" menu item and then using the "Printing & Title Block" selection.  
 Title Block Line 6

Title: Sample Session Job #  
 Dsgnr: An ENERCALC User  
 Project Desc.:  
 Project Notes:

Printed: 2 MAY 2011, 12:13PM  
 File: c:\Users\Chris\Documents\ENERCALC Project Files\sample session.e06  
 ENERCALC, INC. 1993-2011, Build 6.11.4.14, Ver 6.11.4.14  
 Licensee: Licensed ENERCALC User

**Wood Beam**  
 Lic. #: KW-06000215  
 Description: -None-

**Material Properties** Calculations per NDS 2005, IBC 2009, CBC 2010, ASCE 7-05

Analysis Method: Allowable Stress Design  
 Load Combination: 2009 IBC & ASCE 7-05

Wood Species: DF/DF  
 Wood Grade: 24F - V8  
 Beam Bracing: Beam is Fully Braced against lateral-torsion buckling

Fb - Tension	2,400.0 psi	E: Modulus of Elasticity	
Fb - Compr	2,400.0 psi	Ebend-xx	1,800.0 ksi
Fc - Prll	1,650.0 psi	Eminbend-xx	930.0 ksi
Fc - Perp	650.0 psi	Ebend-yy	1,600.0 ksi
Fv	265.0 psi	Eminbend-yy	830.0 ksi
Ft	1,100.0 psi	Density	32.210 pcf

**Applied Loads** Service loads entered. Load Factors will be applied for calculation

Beam self weight calculated and added to loads  
 Loads on all spans...  
 Uniform Load on ALL spans: D = 0.0360, L = 0.240 k/ft, Tributary Width = 1.0 ft  
 Load for Span Number 1  
 Point Load: D = 3.030, L = 2.824 k @ 0.0 ft  
 Load for Span Number 3  
 Point Load: D = 3.030, L = 2.824 k @ 9.50 ft

**DESIGN SUMMARY** Design OK

Maximum Bending Stress Ratio	=	0.613	1	Maximum Shear Stress Ratio	=	0.332	1
Section used for this span	=	5.125 X 27.0		Section used for this span	=	5.125 X 27.0	
fb: Actual	=	1,338.67 psi		fv: Actual	=	87.87 psi	
FB: Allowable	=	2,183.70 psi		Fv: Allowable	=	265.00 psi	
Load Combination	=	+D+L+H, LL Comb Run (**L)		Load Combination	=	+D+L+H, LL Comb Run (**L)	
Location of maximum on span	=	24.000ft		Location of maximum on span	=	24.000ft	
Span # where maximum occurs	=	Span # 2		Span # where maximum occurs	=	Span # 2	
Maximum Deflection							
Max Downward L+Lr+S Deflection		0.562 in	Ratio = 404				
Max Upward L+Lr+S Deflection		-0.271 in	Ratio = 1060				
Max Downward Total Deflection		1.295 in	Ratio = 226				

Page 1 of 6 Zoom (Page Width)

To continue, simply click the **[Print]** button and the standard Windows print dialog will be displayed. Select your printer and you will receive a printout looking very similar to the one below:

Title Block Line 1  
 You can change this area using the "Settings" menu item and then using the "Printing & Title Block" selection.  
 Title Block Line 6

Title : Sample Session Job #  
 Dsgnr: An ENERCALC User  
 Project Desc.:  
 Project Notes :

Printed: 2 MAY 2011, 12:13 PM


**Wood Beam** File: c:\Users\Chris\Documents\ENERCALC Project Files\sample session.ec5  
 ENERCALC, INC. 1983-2011, Build:6.11.4.14, Ver:6.11.4.14  
 Licensee : Licensed ENERCALC User

Lic. # : KW-06000215  
 Description : --None--

**Material Properties**

Calculations per NDS 2005, IBC 2009, CBC 2010, ASCE 7-05

Analysis Method : Allowable Stress Design	Fb - Tension	2,400.0 psi	E : Modulus of Elasticity
Load Combination 2009 IBC & ASCE 7-05	Fb - Compr	2,400.0 psi	Ebend-xx
Wood Species : DF/DF	Fc - Prll	1,650.0 psi	Eminbend-xx
Wood Grade : 24F - V8	Fc - Perp	650.0 psi	Ebend-yy
Beam Bracing : Beam is Fully Braced against lateral-torsion buckling	Fv	265.0 psi	Eminbend-yy
	Ft	1,100.0 psi	Density
			32.210pcf



**Applied Loads**

Service loads entered. Load Factors will be applied for calculations.

Beam self weight calculated and added to loads  
 Loads on all spans...  
 Uniform Load on ALL spans : D = 0.0360, L = 0.240 k/ft, Tributary Width = 1.0 ft  
 Load for Span Number 1  
 Point Load : D = 3.030, L = 2.824 k @ 0.0 ft  
 Load for Span Number 3  
 Point Load : D = 3.030, L = 2.824 k @ 9.50 ft

**DESIGN SUMMARY**

**Design OK**

Maximum Bending Stress Ratio = 0.613 : 1	Maximum Shear Stress Ratio = 0.332 : 1
Section used for this span = 5.125 X 27.0	Section used for this span = 5.125 X 27.0
fb : Actual = 1,338.67psi	fv : Actual = 87.87 psi
FB : Allowable = 2,183.70psi	Fv : Allowable = 265.00 psi
Load Combination +D+L+H, LL Comb Run (**L)	Load Combination +D+L+H, LL Comb Run (**L)
Location of maximum on span = 24.000ft	Location of maximum on span = 24.000 ft
Span # where maximum occurs = Span # 2	Span # where maximum occurs = Span # 2
<b>Maximum Deflection</b>	
Max Downward L+Lr+S Deflection = 0.562 in Ratio = 404	
Max Upward L+Lr+S Deflection = -0.271 in Ratio = 1060	
Max Downward Total Deflection = 1.005 in Ratio = 226	
Max Upward Total Deflection = -0.472 in Ratio = 610	

**Maximum Forces & Stresses for Load Combinations**

Load Combination	Segment Length	Span #	Max Stress Ratios							Summary of Moment Values			Summary of Shear Values			
			M	V	C <sub>d</sub>	C <sub>FV</sub>	C <sub>r</sub>	C <sub>m</sub>	C <sub>t</sub>	Mactual	Fb-design	Fb-allow	Vactual	Fv-design	Fv-allow	
+D																
	Length = 7.158 ft	1	0.209	0.159	0.900	1.000	1.000	1.000	1.000	-23.40	451.04	2,160.00	3.51	38.04	238.50	
	Length = 24.092 ft	2	0.312	0.160	0.900	0.910	1.000	1.000	1.000	-31.81	612.95	1,965.33	3.52	38.17	238.50	
	Length = 9.50 ft	3	0.284	0.160	0.900	0.998	1.000	1.000	1.000	-31.81	612.95	2,156.18	3.52	38.17	238.50	
+D+L+H, LL Comb Run (**L)																
	Length = 7.158 ft	1	0.188	0.144	1.000	1.000	1.000	1.000	1.000	-23.40	451.04	2,400.00	3.51	38.04	265.00	
	Length = 24.092 ft	2	0.613	0.332	1.000	0.910	1.000	1.000	1.000	-69.46	1,338.67	2,183.70	8.11	87.87	265.00	
	Length = 9.50 ft	3	0.559	0.332	1.000	0.998	1.000	1.000	1.000	-69.46	1,338.67	2,395.76	8.11	87.87	265.00	
+D+L+H, LL Comb Run (**L)																

## 9.15 Saving a Calculation


### Saving a Calculation

With as much as we have accomplished in this short period of time, it is very important to remember that we have not yet SAVED this calculation. Everything associated with this calculation is still stored in the computer's RAM. A power outage or severe system lockup would cause a loss of your current calculation.

So to save this new calculation to the Project File, click the **[Save & Exit]** button



. The current calculation will be saved and the display will return to the Project Manager. In the image below, you can see that a Wood Beam calculation has been added to the Division named "Calculations":



Congratulations! Your calculation is now saved and you have a real Project File with an actual calculation.


## 9.16 Editing a Division Name and Adding a New Division

### Editing a Division Name


Let's do a little more work here in the current Project File. We will edit the Division named "Calculations", and we will add a new Division.

#### **Edit a Division Name**


To edit a Division name, simply right-click the name and click **Change Division Name** in the pop-up menu.



In the Enter New Division Name dialog, revise the Division name to "2nd Floor Framing" as shown below:



Click [**Save**]. You will notice that the Division name has been revised from "Calculations" to "2nd Floor Framing", but it still contains the Wood Beam calculation.




Now we will add a NEW Division named "3rd Floor Framing". To do this, click on the




Division named "2nd Floor Framing" and then click the [Add] button . In the Select Item to Insert dialog, click the [Insert Division] button shown bubbled below:





Note: There is also an option in the right-click pop-up menu named Add Division.

Then enter the name "3rd Floor Framing" and click [**Save**]. Your Project calculation list should look like this:






## 9.17 Adding Another Calculation

### Adding Another Calculation in the New Division by using [Copy Calc]


Similar to the way we added our first calculation, we will now add another calculation in the 2nd Floor Framing Division by making a copy of the current Wood Beam calculation and then move it into the 3rd Floor Framing Division.

First, click on the Wood Beam calculation as shown in the screen capture below:




Then, click the  button. This will read all the data from the highlighted calculation, create an entirely new calculation that is an exact copy of the highlighted one, and open the new calculation so it can be edited as necessary.

When the Wood Beam calculation module opens, change the Description item to read "3rd Floor Cantilevered Beam" as shown below:



Next click the **[Save & Exit]** button to save this new calculation to the Project File and close the calculation. The Project Manager will appear as follows:



The final step is to move this new calculation into the 3rd Floor Framing Division. This is easily done by using these buttons:



While the new calculation is highlighted, click the Move Highlighted Item Down button to move it down to the 3rd Floor Framing Division. The Project Calculation list will appear like this:



## 9.18 Creating a Technical Support Question

### Creating a Technical Support Question

The occasion may arise that you will have a question about the software system. To best serve you, there are certain pieces of information that are essential. Among these are your name, the name of your company, your "KW" user registration number, and the build number of the software you are using.

To make it easy for you to give us all this AND state your question, **Structural Engineering Library** has a built-in technical support form. It allows you to simply type in your question and either email it directly to our Technical Support Group or print it out to fax to us.

By emailing or faxing us your Technical Support questions, we can easily identify you, determine if you are in need of a maintenance release, and easily read your questions. In addition, the email method offers the option of attaching the subject ENERCALC file.

#### **To create an email:**

Click **Help > Create Tech Support EMAIL** from the main menu. This opens the form shown below, in which you can enter your question and attach your Project File if desired.

Create Technical Support Email

**Note !** Be thorough with your question. Attach a project file if needed.

Sending to : SUPPORT@ENERCALC.com

Subject :

Here's my Message . . . .

--- Your message here ---

File Attachment . . . .


+ Add File    - Remove File    Attach Current Project File

My need . . . .

Pressing [Send] will open your email program and insert the above information.  
All you do then is press [Send]

When finished, click the **[Send]** button to transfer the completed message (with attachments) to your email program:

**To create a FAX:**

Click **Help > Create Tech Support FAX** from the main menu to use the form shown below to enter your question.



Create Technical Support FAX

Licensed ENERCALC User

Your Question | Your Information

**Note !** Please be very thorough with your question and include a printout if any numbers are in question ! We cannot respond to brief and general questions.

[Normal] Arial 12 B I U

Hello ENERCALC,  
Here is the text of my support question.  
Thanks!

Time Frame

- Suggestion
- Problem FYI
- Please Check**
- URGENT !

General Topic

- Don't Agree with Results
- Entering Data
- Project Manager
- Database
- Printout
- Graphics
- General**

Preview

Print

Print PDF

Quit

InsertImage FormatImage

Line 5 Col 7 100 % NUM

When finished, the completed message can be printed for faxing (or it can be sent directly from your computer-based fax software).

Here's the printed form, ready for transmission:

**ENERCALC Technical Support Request****Fax this form to 949-645-3881**

Type of Question : General

Time Frame : Please Check

Name : Michael D. Brooks  
Title : President  
Company : ENERCALC, INC  
Address : P.O. Box 188  
Corona del Mar, CA 92625  
email : michaelbrooks@enercalc.com  
License : ENERCALC, INC., KW-06000001

***Evaluation Version***

Todays Date : 2 MAR 09

Voice : 949-645-0441

Fax : 949-645-3881

Question...

Hello ENERCALC,


Here is the text of my support question.

Thanks!


## 9.19 Closing a Project File

### Closing a Project File

It is now time to close out our work session. The data is saved in the Project File already, so at this point we can close the current Project File by clicking **File > Close Project** from the main menu:



**Part**



## 10 Calculation Modules

## 10.1 Loads & Forces Division

The LOADS & FORCES Division in the Project Manager is automatically created for you when a new Project File is started. Click here for a video: [LOADS and FORCES Division](#)




There is only one LOADS & FORCES Division for each project, and it is always pre-populated with specific load-related calculation items. Their use is optional, but these calculation modules cannot be moved out of the LOADS & FORCES Division, nor can other calculation modules be moved into or added to the LOADS & FORCES Division.

In particular, the LOADS & FORCES Division includes modules that assist with the development of snow, wind, seismic, and reduced live load calculations.

As **Structural Engineering Library** is enhanced, the LOADS & FORCES Division will contain more and more tools to assist with developing your project load calculations.

### 10.1.1 ASCE Seismic Base Shear

[Need more? Ask Us a Question](#)

This module is a presentation of equivalent lateral force procedure seismic provisions in ASCE 7. Click here for a video: 


The module currently supports calculations based on ASCE 7-05 and ASCE 7-10. All of the references to ASCE 7 are given on the module screens. Above each screen capture are notes as needed to call attention to entries or explain usage.

The module is designed to allow you to work downwards through the tabs on the left side of the screen. ASCE 7 skips all around in its definitions of things to check. This module simplifies the process by properly ordering the items and the necessary decisions to be made in working toward a final seismic base shear value.

The program includes a complete national zip code database and USGS databases of seismic ground motion specifically for use with ASCE 7. Using city names or zip codes, you can look up the latitude and longitude of the representative center of the zip code.

The seismic ground motion databases consist of "gridded" values for small increments of latitude and longitude. Given the latitude and longitude for the city or zip code of interest, the surrounding grid data points are located and those seismic ground motion values are used to interpolate a value for the latitude and longitude specified. For this reason the values may not match the web-based USGS database values exactly, however the grid point interpolation is proper.

#### General




### $S_s, S_1$ : Ground Motion

Three options are available to specify the  $S_s$  and  $S_1$  values.

### Browse City Database


Use the Select State drop-down list box to select the State. Then click one of the City First Letter buttons to have all cities (in the database) listed in the scrolling box on the right. Then simply click on the city to select. Some city names have multiple zip codes.





**Enter S<sub>s</sub> and S<sub>1</sub> Directly**

Or, you can enter the S<sub>s</sub> and S<sub>1</sub> values directly.



**Enter Latitude & Longitude Directly**

Or, you have the option to enter the latitude and longitude for the project location. (Note that longitude is degrees WEST, so do not enter negative values.)

Choose how to specify ground motion . . .

Enter Site Location . . .

**Latitude** =  degrees NORTH  
**Longitude** =  degrees WEST  
**S<sub>s</sub>** = **1.588** g  
**S<sub>1</sub>** = **0.5795** g

Database : Gridded Ss & S1 values ASCE-7-10 Standard.  
 See : <http://earthquake.usgs.gov/hazards/designmaps/datasets/>

## Site Class, Site Coefficients and Seismic Design Category

Select the appropriate Site Class based on the geotechnical conditions.

ENERCALC : sample session.ec6

File Settings Databases Tools License Help

Licensed ENERCALC User, KW-06000215

ASCE Seismic Base Shear

Print

Calc 1   General  
 Calc 2  Ss, S1 : Ground Motion  
 Calc 3  Site Class, Coeff. & Category  
 Calc 4  Resisting System, R, Cd  
 Calc 5  p : Redundancy Factor  
 Calc 6  T : Building Period  
 Calc 7  Cs : Response Coefficient  
 Calc 8  Base Shear & Vert. Distrib.  
 Calc 9  Diaphragm Forces  
 Calc 10  Wall Anchorage

Proceed from top tabs downward.

Select Site Class per ASCE 7-10, Page 204, Table 20.3.1

: Shear Wave Velocity 1,200 to 2,500 ft/sec

Site Coefficients Fa per ASCE 7-10, Page 66, Table 11.4-1  
 Fa = 1.00 (using straight-line interpolation between table values)

Site Coefficients Fv per ASCE 7-10, Page 66, Table 11.4-2  
 Fv = 1.30 (using straight-line interpolation between table values)

Maximum Considered Earthquake Acceleration per ASCE 7-10, Page 66, 11.4.3  
 SMS = Fa \* Ss = 1.640  
 SM1 = Fv \* S1 = 0.778


Design Spectral Acceleration per ASCE 7-10, Page 66, 11.4.4  
 SDS = SMS \* 2/3 = 1.093  
 SD1 = SM1 \* 2/3 = 0.519

Seismic Design Category = D per ASCE 7-10, Page 67, Tables 11.6-1 and -2

## Selection of Seismic Force Resisting System


Click one of the large boxes at the top of the tab to load the table with specific selections for that general category of Seismic Force Resisting System.

Note the checkbox for systems with flexible diaphragms. This may not apply to some building systems...check ASCE for details on the particular system of interest.




### Redundancy Factor

Depending on the Seismic Design Category determined from the prior selections of Occupancy, Seismic Ground Motion and Building System, the Redundancy Factor per ASCE will be shown here.




### Specification of Building Period

All four ASCE 7 options for building period determination are available here.



### Evaluation of Approximate Building Period



### Approximate Period for Steel & Concrete Frames

Determine Building Period : Equivalent Lateral Force Method per ASCE 7-10, Page 89, 12.8

Select Method of Specifying Structure Period . . .

Enter Calculated Period      Approx. Period per Eq. 12.8-7      **Approx. Period for concrete or steel moment frame structures less than 12 stories per Eq. 12.8-8**      Approx. Period for Masonry Concrete wall structures per Eq. 12.8-9

Check here to acknowledge that the "Story Height" is at least 10 feet

Number of Stories =  ( limited to 12 )

"Ta" Approximate fundamental period using Eq. 12.8.2.1

Ta = 0.1 \* Number of Stories = **0.300 sec**

### Approximate Period for Masonry Structures

Determine Building Period : Equivalent Lateral Force Method per ASCE 7-10, Page 89, 12.8

Select Method of Specifying Structure Period . . .

Enter Calculated Period      Approx. Period per Eq. 12.8-7      Approx. Period for concrete or steel moment frame structures less than 12 stories per Eq. 12.8-8      **Approx. Period for Masonry Concrete wall structures per Eq. 12.8-9**

Check here to acknowledge using Masonry or Concrete Shear Wall Structure

"hn" : Height from base to highest level =  ft      "Ab" : Base area of structure =  ft<sup>2</sup>

Shear Wall Table...

Level Height "Hi"	Number of Walls at this level "n"	Average Area of each Wall "Ai"	Average Length of each Wall "Di"
12.00	10	8.00	10.00
22.00	10	8.00	10.00
32.00	10	8.00	10.00
44.00	10	8.00	10.00
56.00	10	8.00	10.00


Add      Edit      Delete

$$C_w = \frac{100}{A_b} * \text{Sum} (1 \rightarrow n) (h_n / h_i)^2 * \frac{A_i}{[1 + 0.83 * (h_i / D_i)^2]} = 4.058$$

$$T_a = \frac{0.0019}{\text{SQRT} (C_w)} * h_n = \mathbf{0.053 \text{ sec}}$$


### Long-Period Transition Period Reference Maps

Maps copyright ASCE.



### Cs: Seismic Response Coefficient

Please check ASCE 7 section references for details.



## Vertical Distribution of Base Shear

This tab calculates the vertical distribution of seismic forces. Use the **[Add]** button for each new level. To edit information for a level, highlight the corresponding line and click **[Edit]**.



ENERCALC: sample session.ecb

File Settings Databases Tools License Help

Licensed ENERCALC User, KW-06000215

### ASCE Seismic Base Shear

Print

- Calc 1  General
- Calc 2  S<sub>s</sub>, S<sub>1</sub> : Ground Motion
- Calc 3  Site Class, Coeff. & Category
- Calc 4  Resisting System, R, Cd
- Calc 5  p : Redundancy Factor
- Calc 6  T : Building Period
- Calc 7  Cs : Response Coefficient
- Calc 8  Base Shear & Vert. Distrib.
- Calc 9  Diaphragm Forces
- Calc 10  Wall Anchorage

Proceed from top tabs downward.

Base Shear & Vertical Distribution : Equivalent Lateral Force Method per ASCE 7-10, Page 91, Section 12.8.3

**Cs : Seismic Response Coefficient = 0.3364 per 12.8.1.1**

W (see Sum Wi below) = 500.00 k

\*k\* : h<sub>x</sub> exponent based on T<sub>a</sub> = 1.00

Seismic Base Shear V = Cs \* W = 168.22 k ASCE 7-10 Eq. 12.8-1

Please Create a Table of building Weights by Floor Level... Add Edit Delete

Level	Wi : Weight k	Hi : Height ft	Wi * Hi <sup>2</sup> / k k-ft	Cvx	Fx = Cvx * V k	Sum Story Shear k	Sum Story Mom k-ft
5	80.00	56.00	4,480.0	0.274	46.06	46.06	
4	120.00	44.00	5,280.0	0.323	54.29	100.35	552.77
3	100.00	32.00	3,200.0	0.196	32.90	133.26	1,757.01
2	100.00	22.00	2,200.0	0.134	22.62	155.88	3,089.57
1	100.00	12.00	1,200.0	0.072	12.34	168.22	4,568.94
Sum Wi = 500.00 k		Sum Wi * Hi <sup>2</sup> = 16,360.0 k-ft		Total Base Shear = 168.22 k		Base Moment = 6,666.9 k-ft	

*NOTE! These forces represent "QE" and must be multiplied by "rho" for use in load combinations !*

### Diaphragm Forces

Using the information entered above (on the prior tab) the force distribution results are shown here.

ENERCALC: sample session.ecb

File Settings Databases Tools License Help

Licensed ENERCALC User, KW-06000215

### ASCE Seismic Base Shear

Cancel Save Only Save & Exit

Calc 1  Print  
 Calc 2  General  
 Calc 3  S<sub>g</sub>, S<sub>1</sub>: Ground Motion  
 Calc 4  Site Class, Coeff. & Category  
 Calc 5  Resisting System, R, C<sub>d</sub>  
 Calc 6  p: Redundancy Factor  
 Calc 7  T: Building Period  
 Calc 8  C<sub>s</sub>: Response Coefficient  
 Calc 9  Base Shear & Vert. Distrib.  
 Calc 10  Diaphragm Forces  
 Wall Anchorage

Proceed from top tabs downward.

#### Diaphragm Forces per ASCE 7-10 Section 12.10.1.2

Level	W <sub>i</sub> k	F <sub>i</sub> k	Sum F <sub>i</sub> k	Sum W <sub>i</sub> k	F <sub>px</sub> : Min. (kips) 0.2 SDS I W <sub>px</sub>	F <sub>px</sub> : Max. (kips) 0.4 SDS I W <sub>px</sub>	F <sub>px</sub> : Final k
5	80.000	46.06	46.06	80.00	17.494	34.989	34.989
4	120.000	54.29	100.35	200.00	26.242	52.483	52.483
3	100.000	32.90	133.26	300.00	21.868	43.736	43.736
2	100.000	22.62	155.88	400.00	21.868	43.736	38.969
1	100.000	12.34	168.22	500.00	21.868	43.736	33.643

W<sub>px</sub> ..... Weight at level of diaphragm and other structure elements attached to it.  
 F<sub>i</sub> ..... Lateral Force at level as calculated by Equivalent Lateral Force procedure.  
 Sum F<sub>i</sub> ..... Sum of "Lat. Force" of current level plus all levels above

MIN Req'd Force @ Level .....  $0.20 * SDS * I * W_{px}$   
 MAX Req'd Force @ Level .....  $0.40 * SDS * I * W_{px}$


F<sub>px</sub>: Diaphragm Design Force @ x .....  $W_{px} * \frac{\sum_{i=x+1}^n F_i}{\sum_{i=x+1}^n w_i}$ , x = Current level, n = Top Level

NEED TO APPLY REDUNDANCY FACTOR PER 12.10.1.1, last big paragraph, 2nd sentence

Show Project Manager

## Wall Anchorage Forces

The calculation of seismic wall anchorage forces has been enhanced and moved to a separate module.



### 10.1.2 ASCE Seismic Demands on Nonstructural Components

This module is an implementation of the provisions for seismic demands on nonstructural components as per ASCE 7. The module currently supports calculations based on ASCE 7-05 and ASCE 7-10. Input parameters are taken directly from the nomenclature presented in ASCE 7.

The ASCE 7-05 version of this calculation produces component design forces using the defined parameters.

The ASCE 7-10 version of this calculation produces both component and connection design forces using the defined parameters.

ASCE 7-10 Section 13.3.1 and 13.4.1 | ASCE 7-05 Section 13.3.1

$S_{DS} = 1.129$  |  $h = 30.0$  ft

Print	Description	$a_p$	$W_p$	$z$ ft	$R_p$	$I_p$	$z/h$ Actual	$z/h$ Design	$F_p$ Upper Limit	$F_p$ Lower Limit	$F_p$ Calculated Component	$F_p$ Calculated Connection**	---- $F_p$ : Design ---- Component	Connection
<input checked="" type="checkbox"/>	RTU-1	5.0	1,440.0	30.0	7.0	1.0	1.0	1.0	2,601.22	487.728	1,393.51	1,625.76	1,393.51	1,625.76
<input checked="" type="checkbox"/>	AHU-3	5.0	1,220.0	30.0	7.0	1.0	1.0	1.0	2,203.81	413.214	1,180.61	1,377.38	1,180.61	1,377.38
<input checked="" type="checkbox"/>	Sample piece of equipment	2.0	555.0	20.0	1.50	1.0	0.6667	0.6667	1,002.55	187.979	779.76	779.76	779.76	779.76
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
<input type="checkbox"/>		1.0			1.50	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

$a_p$  : Component amplification factor (Table 13.5-1 or Table 13.6-1) |  $F_p$  - Calc'd : Calculated  $F_p$ , Eq (13.3-1), Same units as  $W_p$   
 $W_p$  : Component operating weight |  $F_p$  - Upper : Upper Limit on  $F_p$ , Eq (13.3-2), Same units as  $W_p$   
 $z$  : Height of point of attachment |  $F_p$  - Lower : Lower Limit on  $F_p$ , Eq (13.3-3), Same units as  $W_p$   
 $R_p$  : Component response modification factor (Table 13.5-1 or Table 13.6-1) |  $F_p$  - Design :  $F_p$  for design purposes, Same units as  $W_p$   
 $I_p$  : Component importance factor (Section 13.1.3)

\*\*\* Note: ASCE 7-10 Limits  $R_p$  to a max value of 6.0 for connections

### 10.1.3 ASCE Seismic Wall Anchorage

This module is an implementation of the provisions for design and anchorage of walls to resist seismic forces as per ASCE 7. The module currently supports calculations based on ASCE 7-05 and ASCE 7-10. Input parameters are taken directly from the nomenclature presented in ASCE 7.

The ASCE 7-05 version of this calculation produces:

- Out-of-Plane Force for Structural Wall Design
- Out-of-Plane Force for Concrete and Masonry Structural Wall Anchorage Design (for all Seismic Design Categories where structural walls connect to rigid diaphragms, and for SDC A and B where walls connect to flexible diaphragms)
- Out-of-Plane Force for Concrete and Masonry Structural Wall Anchorage Design (for Seismic Design Categories C through F where walls connect to flexible diaphragms)

The ASCE 7-10 version of this calculation produces:

- Out-of-Plane Force for Structural Wall Design
- Out-of-Plane Wall Anchorage Force

The module is configured to allow the definition of up to 20 different wall conditions. The user has the option to decide which (if any) of the calculations will be included in a Project Print.

ENERCALC : examples.ecb

File Settings Databases Tools License Help

Licensed ENERCALC User, KW-06000215

Seismic Wall Anchorage per ASCE

General Wall Anchorage

Print

Wall 1  Wall 2  Wall 3  Wall 4  Wall 5  Wall 6  Wall 7  Wall 8  Wall 9  Wall 10  Wall 11  Wall 12  Wall 13  Wall 14  Wall 15  Wall 16  Wall 17  Wall 18  Wall 19  Wall 20

Click to view

Show Project Manager

Click to view

Description:

ASCE Code Version =  ASCE 7-10  ASCE 7-05

$S_{DS}$  =  I: Importance Factor =

Wall Weight =  pcf Wall Height =  ft Parapet Height =  ft

Triburary Height = Wall height/2 + Parapet = 9.0 ft

Triburary Weight = Trib. Height \* Wall Weight = 909.0 b

Out-of-Plane Force for Structural Wall Design  
(For all SDCs)

0.4*SDS*I*Weight	57.015 pcf
10%*Weight	10.10 pcf
<b>Controlling Value</b>	<b>57.015 pcf</b>

Out-of-Plane Wall Anchorage Force

H =  ft

Z =  ft

Lf (Span of flexible diaphragm, or enter zero if rigid) =  ft

Anchorage is not at roof and all diaphragms are not flexible :  Yes  No

Multiplier = 0.8182

Ka = 1.780

Based on (12.11-1) = 747.30 pcf

Based on lower limit for Fp = 404.505 pcf

**Controlling Value** = **747.30 pcf**

### 10.1.4 ASCE Wind Enclosure

This module is an implementation of the provisions for determining the Enclosure Classification for the determination of Wind Loads as per ASCE 7. [Click here for a video:](#)

ASCE 7 Wind Enclosure Classification

The module currently supports calculations based on ASCE 7-05 and ASCE 7-10. Input parameters are taken directly from the nomenclature presented in ASCE 7.

The calculation sheet is set up to permit up to ten different analyses to be documented within a single Project File. This can be useful when a project includes multiple buildings, or in situations where multiple scenarios are being evaluated.

The data collection is presented in such a way as to guide the user through the module in a logical progression.

Values of gross area and area of openings are provided for walls on four sides of the building (arbitrarily designated "North", "South", "East", and "West"). Once these values are provided, the module can determine if the structure qualifies as "Open" or not. If the structure is determined to be "Open", then the module will indicate that result and stop there. If the structure does *not* qualify as an "Open" structure, then input fields for Roof Gross Area and Roof Opening Area will be displayed, and a set of four tabs will appear in the bottom half of the screen. Once the Roof areas are populated, the four tabs thoroughly present the calculations to determine whether the structure qualifies as "Enclosed" or "Partially Enclosed" when each of the four respective walls receives positive external pressure.

The results of this determination are useful for project documentation requirements, as well as in guiding the user to read the appropriate results values from other modules within Structural Engineering Library.

Note: The provisions of the ASCE Wind Enclosure module are already incorporated into the ASCE 7-10 Wind Loads module. So it is not necessary to run the standalone version of this module if the ASCE 7-10 Wind Loads module will be used.

ENERCALC : test - masonry slender wall.ec6

File Settings Databases Tools License Help

ASCE 7-05 & 7-10 Wind Enclosure

Licensed ENERCALC User, KW-06000215

Cancel Save Only Save & Exit

General Wind Enclosure Evaluation

Bldg 1  
Bldg 2  
Bldg 3  
Bldg 4  
Bldg 5  
Bldg 6  
Bldg 7  
Bldg 8  
Bldg 9  
Bldg 10

Print

Description: A sample building

Check that Building Qualifies as "OPEN"

	North Wall	South Wall	East Wall	West Wall	Roof	Total
Agross	100.0 ft <sup>2</sup>	100.0 ft <sup>2</sup>	100.0 ft <sup>2</sup>	100.0 ft <sup>2</sup>	100.0 ft <sup>2</sup>	500.0 ft <sup>2</sup>
Aopenings	18.0 ft <sup>2</sup>	2.0 ft <sup>2</sup>	2.0 ft <sup>2</sup>	2.0 ft <sup>2</sup>	0.0 ft <sup>2</sup>	24.0 ft <sup>2</sup>
Aopenings >= 0.8 * Agross ?	No	No	No	No		<b>Building does NOT qualify as "Open"</b>

NOT an "OPEN" Structure. Continue to check each direction for PARTIALLY ENCLOSED

North Wall | South Wall | East Wall | West Wall

Reference Area = Smaller of 4 sq. ft. or 1% of Agross	1.0 ft <sup>2</sup>
Aoi = Ao-total - Ao	6.0 ft <sup>2</sup>
Agi = Ag-total - Ag	400.0 ft <sup>2</sup>
Aoi / Agi	0.0150
Is Ao > 1.10 * Aoi ?	Yes
Is Ao > Reference Area ?	Yes
Is Aoi / Agi >= 0.20 ?	Yes

**Building qualifies as "Partially Enclosed" when the North wall receives positive external pressure**

Show Project Manager



## 10.1.5 ASCE 7-10/7-16 Wind Forces, Chapter 27, Part 1


[Need more? Ask Us a Question](#)

This module is a presentation of the Wind Forces provisions of Chapter 27, Part 1 of ASCE 7-10 and ASCE 7-16. Click here for a video: [ASCE 7-10 Wind Forces](#)

Limited documentation is provided here, because all of the references to ASCE 7 are given on the module screens.

### General

The General tab provides an input field for a general description of the project and/or the wind calculations that are being performed.



### ASCE 7-10 / 7-16 Wind Force Evaluation

This tab provides access to a series of Calculation tabs that can be used to store up to ten separate wind calculations. These might be useful for studying different project sites, different architectural concepts, or even evaluating separate buildings in a project.

The Description field can be used to distinguish from among the different wind load calculations that might be defined in a single Project File.

The Print checkbox specifies whether or not the particular wind load calculation will or will not be included when a Print command is clicked or when a Project Print is performed.

### General (sub-tab of the ASCE 7-10 / 7-16 Wind Force Evaluation tab)

This tab collects basic data such as Risk Category, Basic Wind Speed, Directionality Factor, Building Dimensions, Exposure Category, Topographic Factor, and information to determine how the building frequency will be determined.

The Risk Category is only for reference in documenting the design. It no longer influences the importance factor, but it does dictate which Wind Speed map to use to determine the Basic Wind Speed.

The Exposure Category is dependent upon the upwind characteristics. Therefore, as different building elevations become the windward face of the structure, it is possible that the Exposure Category will change. For this reason, the program allows the Exposure Category to be defined separately for each building face in turn becoming the windward face.

The Building Flexibility Selection offers three different options for defining the frequency of the building.


- The first option declares that the building will be assumed to be rigid (having a frequency greater than or equal to 1 Hz).
- The second option applies the prescriptive methods in Sections 26.9.2 and 26.9.3 of ASCE 7-10 to approximate the frequency of the building based on construction type/layout and mean roof height.
- The third option allows the user to explicitly specify the frequency in the North-South direction and in the East-West direction.

Note that if the second option is selected, a new tab named "Frequency" will be introduced between the "Story Data" tab and the "Gust Factor" tab.

***This tab contains the only difference between ASCE 7-10 and ASCE 7-16, which is the introduction of  $K_e$ , the Ground Elevation Factor in ASCE 7-16.***

### Story Data

This tab collects the data required to define the vertical locations of the stories with respect to finished grade.




The development of the story data table is controlled by the three buttons: Add Level, Edit Level, and Delete Level, which perform their respective operations on the table of story data.

Clicking Add or Edit opens the Story Information pop-up dialog as shown above. Two items are worthy of note on this dialog. First, the Height to Story is always referenced from grade, so it is looking to collect the height from grade to the story of interest, not the story to story height. Second, the values of  $e_{Rx}$  and  $e_{Ry}$  are only used if a building is determined (or defined) to be "Flexible" (< 1 Hz) in a particular direction. So if a building turns out to be "Rigid" in one or both directions, then the values of  $e_{Rx}$  and  $e_{Ry}$  are not required in those directions, and the values can be left at zero or a value can be entered, but the program will ignore it.

### Frequency (Only displayed if the option is selected on the General tab to "Calculate Frequency")


This tab displays the story data that was previously collected, and it requests the Building Construction Type and the values of  $L_i$  necessary to complete the check to determine if the approximate methods of frequency determination are applicable.



If the approximate methods of frequency determination are found to be applicable, this tab reports the approximate frequency. Otherwise, a message will be displayed to indicate that the approximate methods are not applicable, and that the building frequency must be determined another way.

### Gust Factor

This tab displays the results of the Gust Factor determination for each of the four elevations, in turn, being the face of the building that receives positive external pressure.



The North, South, East, and West tabs present the calculation and the resulting Gust Factor that will be used in subsequent calculations when the respective building elevation receives positive external pressure.


When the building is categorized as "Rigid" in a particular direction, the program offers the checkbox option to force the value of the Gust Factor to 0.85 when the referenced elevation receives positive external pressure.

When the building is categorized as "Flexible" in a particular direction, the program requires one more value, which is the damping ratio. This value is collected in an input box on the respective direction tab when appropriate, and the value is incorporated into the Gust Factor to be used when the referenced elevation receives positive external pressure.

It is worth noting that many of the parameters used in the calculation of the Gust Factor are dependent upon the Exposure category. Since the Exposure category can vary for each of the four cardinal directions, it is possible that the Gust Factor for use when the **North** elevation of the building receives positive external pressure may actually be different than the Gust Factor for use when the **South** elevation of the building receives positive external pressure.

## Enclosure

This tab displays the results of the Enclosure determination for each of the four elevations, in turn, being the face of the building that receives positive external pressure.



The upper half of this tab is dedicated to evaluating the building to determine whether or not it qualifies as an "Open" structure. The module collects the gross areas of each of the four walls along with the areas of opening in each of the four walls. Based on the data provided by the user, the module performs the calculations and checks the criteria to see if the building qualifies as an "Open" structure. If it does, then the module reports that result. If the building does NOT qualify as an "Open" structure" then additional input fields are displayed to collect the gross area of the Roof, and the area of openings in the roof, and the workflow continues to determine whether the building qualifies as "Enclosed" or "Partially Enclosed". This evaluation takes place four times, considering each of the four walls to be the windward wall, in turn. The intermediate calculations are performed and the results are reported on each of the four wall tabs.


It is worth noting that a building could potentially be considered "Partially Enclosed" when some of its elevations receive positive external pressure, and "Enclosed" when its other elevations receive positive external pressure.

It is also worth noting that convenience buttons have been provided on each of the four wall tabs to allow the user to simply declare the building to be "Enclosed" or "Partially Enclosed" when the selected elevation receives positive external pressure. These have been implemented for situations where the evaluation has already been performed and/or the user is already confident in making a decision by judgment.

The Enclosure classification is used downstream to select appropriate values of GCpi to use when each of the four elevations becomes the windward wall.

## Velocity Pressures

This tab displays the results of the Velocity Pressure determination for the various walls when each wall is under leeward, sidewall, and windward wall conditions.



ENERCALC : new elementary school.ec6  
 Licensed ENERCALC User, KW-06000215  
 ASCE 7-10 Wind Forces, Chapter 27, Part I  
 ASCE 7-10 Wind Force Evaluation  
 Description: Architectural Layout as of Noon Today  
 Print  
 General | Story Data | Gust Factor | Enclosure | **Velocity Pressures** | Pressure Coefficients | Wind Pressures | Story Forces | Base Shears & Torsions

When the following walls experience leeward or sidewall pressures, the value of  $K_h$  shall be (per Table 27.3-1):  
 North Wall = 0.8107    South Wall = 1.094    East Wall = 0.8107    West Wall = 1.270

When the following walls experience leeward or sidewall pressures, the value of  $q_h$  shall be (per Table 27.3-1):  
 North Wall = 27.563    South Wall = 37.188    East Wall = 27.563    West Wall = 43.187

$q_z$  : Windward Wall Velocity Pressures at various heights per Eq. 27.3-1

Height above Base (ft)	North Elevation		South Elevation		East Elevation		West Elevation	
	$K_z$	$q_z$	$K_z$	$q_z$	$K_z$	$q_z$	$K_z$	$q_z$
0.00	0.575	19.54	0.849	28.86	0.575	19.54	1.030	35.03
5.00	0.575	19.54	0.849	28.86	0.575	19.54	1.030	35.03
10.00	0.575	19.54	0.849	28.86	0.575	19.54	1.030	35.03
15.00	0.575	19.54	0.849	28.86	0.575	19.54	1.030	35.03
20.00	0.624	21.21	0.902	30.66	0.624	21.21	1.083	36.82
25.00	0.665	22.61	0.945	32.14	0.665	22.61	1.126	38.28
30.00	0.701	23.82	0.982	33.40	0.701	23.82	1.162	39.52
35.00	0.732	24.89	1.015	34.50	0.732	24.89	1.194	40.59
40.00	0.761	25.86	1.044	35.48	0.761	25.86	1.222	41.54
45.00	0.787	26.75	1.070	36.37	0.787	26.75	1.247	42.40
50.00	0.811	27.56	1.094	37.19	0.811	27.56	1.270	43.19




The first row of data reports the values of  $K_h$  that are applicable when each of the walls experiences leeward or sidewall pressures.

The second row of data reports the resulting values of  $q_h$  that are applicable when each of the walls experiences leeward or sidewall pressures.

Next, a table is presented that reports the values of  $K_z$  and the resulting values of  $q_z$  that are applicable, as a function of height, when each of the walls experiences windward wall pressures.

### Pressure Coefficients

This tab reports the values of  $G_{Cpi}$  that are applicable when each of the respective elevations receives positive external pressure. The remainder of this tab is dedicated to collecting the values of  $C_p$  or  $C_n$  as appropriate for the various surfaces of the building.




Wall values are collected first, and the input fields collect values of  $C_p$  that will be used when each of the four walls is a windward wall, a sidewall, or a leeward wall.

At the bottom of the tab is a customizable table that is set up to receive many lines of  $C_p$  or  $C_n$  values pertinent to the roof. A convenience button is provided to display the figures that define the  $C_p$  or  $C_n$  values for various conditions. A glance at the tables reveals that the factors for roofs are frequently dependent upon the wind direction with respect to the ridge, and also dependent upon whether pressures are desired for the windward or leeward surfaces of the roof. So some planning will be required to set this table up to yield the desired results. To make the downstream results most applicable and easy to read, the program has been set up so that a roof pressure value will only be calculated for situations where nonzero values of  $C_p$  or  $C_n$  have been specified. To put this another way, referring to the table above, there are no values of  $C_p$  defined for the North or South elevations for the "Perpendicular: Windward" or "Perpendicular: Leeward" conditions. This is because the ridge is assumed to run in the North-South direction in the hypothetical building being considered. As such, it would not make sense to ask the program to report windward or leeward roof pressures when the wind acts in the north or south directions. So to avoid overpopulating the output with meaningless results, the blank fields will be interpreted by the program as an indication that the corresponding calculation is not required. We will see the benefit of this when we move to the Wind Pressures tab and see how concisely these results are reported.

On a related note, it is worth mentioning that the  $C_p$  and  $C_n$  tables occasionally report values of zero for certain conditions. These are typically provided for interpolation purposes. But if a situation is ever encountered where a value of zero for  $C_p$  or  $C_n$  is actually required for design purposes, the user is advised to enter a small nonzero value.

### Wind Pressures

This tab reports the values of wind pressures that occur on the various surfaces of the building when the named elevation receives positive external pressure.



Looking at the screen capture above, we see that the North Wall tab is currently selected. Let's work through this tab thoroughly as an example. As indicated in the on-screen note, we interpret all of the results on this tab as being the pressures that occur on the named surface of the building when the North Wall receives positive external wind pressure. So when we are focused on the North Wall tab:

- The "Windward Wall Pressures" are those that would apply to the **North** Wall when the North Wall receives positive external pressure.
- The "Leeward Wall Pressures" are those that would apply to the **South** Wall when the North Wall receives positive external pressure.
- The "Sidewall Pressures" are those that would apply to the **East** and **West** Walls when the North Wall receives positive external pressure.
- The "Roof Pressures" are those that would apply to the identified areas measured from the **North** edge of the roof when the North Wall receives positive external pressure.


Just to drive home the proper interpretation of the values reported on the Wind Pressures tab, let's work through the East tab, so we can interpret some windward and leeward roof pressures. Remember that this hypothetical building is assumed to have a North-South oriented ridge. So when we are focused on the East Wall tab:

- The "Windward Wall Pressures" are those that would apply to the **East** Wall when the East Wall receives positive external pressure.
- The "Leeward Wall Pressures" are those that would apply to the **West** Wall when the East Wall receives positive external pressure.
- The "Sidewall Pressures" are those that would apply to the **North** and **South** Walls when the East Wall receives positive external pressure.
- The "Perp: Windward Roof Pressures" are those that would apply to the **windward (East)** portion of the roof when the East Wall receives positive external pressure.
- The "Perp: Leeward Roof Pressures" are those that would apply to the **leeward (West)** portion of the roof when the East Wall receives positive external pressure.

Note that all surfaces report pressures based on both the positive and the negative internal pressure conditions, and the algebraic sign convention follows that of ASCE 7, which is to say that positive values are interpreted to act toward the named surface and negative values act away from the named surface. Work this logic through an example such as a windward wall and see that it all makes sense. The negative internal pressure condition produces higher total pressures toward the windward wall, than the positive internal pressure condition does, because the negative internal pressure works in the same direction as the external pressure on a windward wall. Similar logic can be applied to all other surfaces to demonstrate that the mathematics are proper.

### Story Forces

This tab reports the values of wind forces tributary to each story in the building.



Using the story heights determined on the Story Data tab, the Story Forces tab determines the tributary heights for each floor by assuming a simply-supported wall construction that spans between adjacent floor/roof levels. Wind pressures are applied to the tributary heights and multiplied by the perpendicular dimension of the building to arrive at forces for each story.

The option is provided to either display or hide the forces tributary to the lower half of the lowest level. In some construction types, this component of load is delivered to a slab on grade and is not a design consideration for the Main Wind Force Resisting System.

The program reports results for each of the four "Cases" as presented by Figure 27.4-8 of ASCE 7-10. Cases 2 and 4 also incorporate a design torsional moment as defined in Figure 27.4-8. In all situations, the program reports the force magnitude. In situations where a torsional moment applies, the program reports the moment arm that is being considered for each component of force, as well as the resulting net moment.

The final item in the results on this tab is based on the minimum required wind loads per Section 27.4.7 of ASCE 7-10. That section requires that the wind load to be used in the design of the Main Wind Force Resisting System for an enclosed or partially enclosed building shall not be less than 16 psf multiplied by the wall area of the building (and 8 psf

multiplied by the roof area of the building projected onto a vertical plane normal to the assumed wind direction). So in this last item in the results list, the program reports story forces assuming 16 psf applied to each wall of the building. As of build 6.12.4.24, the program does not collect enough information to consider the 8 psf on the projection of the roof area, so this additional load may need to be considered with supplemental hand calculations on buildings with other than flat or low-slope roofs.

## Base Shears & Torsions

This tab reports the summation of the wind story forces and torsions for all levels in the building, for all four "Cases" and for the minimum required wind loads per Section 27.4.7.

ASCE 7-10 Wind Forces, Chapter 27, Part I

General | Story Data | Gust Factor | Enclosure | Velocity Pressures | Pressure Coefficients | Wind Pressures | Story Forces | **Base Shears & Torsions**

Values below are calculated based on a building with dimensions B x L x h as defined on the "Basic Values" tab.

Load Case	Windward Wall	Leeward Wall	Wind Base Shear Components		Building Torsion Mt (ft-k)
			In 'Y' Dir. (k)	In 'X' Dir. (k)	
Case 1	North	South	-110.32	---	---
Case 1	South	North	159.54	---	---
Case 1	East	West	---	-267.47	---
Case 1	West	East	---	475.68	---
Case 2	North	South	-82.74	---	+/- 1,241.2
Case 2	South	North	119.65	---	+/- 1,794.8
Case 2	East	West	---	-200.60	+/- 5,821.1
Case 2	West	East	---	356.76	+/- 10,178.1
Case 3	North & East	South & West	-82.74	-200.60	---
Case 3	North & West	South & East	-82.74	356.76	---
Case 3	South & West	North & East	119.65	356.76	---
Case 3	South & East	North & West	119.65	-200.60	---
Case 4	North & East	South & West	-62.11	-150.59	+/- 5,301.4
Case 4	North & West	South & East	-62.11	267.81	+/- 8,572.1
Case 4	South & West	North & East	89.82	267.81	+/- 8,987.6
Case 4	South & East	North & West	89.82	-150.59	+/- 5,717.0
Min per ASCE 27.4.7	North	South	-80.00	---	---
Min per ASCE 27.4.7	South	North	80.00	---	---
Min per ASCE 27.4.7	East	West	---	-160.00	---
Min per ASCE 27.4.7	West	East	---	160.00	---

Include force at ground level

Fig 27.4-8 - Design Wind Load Cases


North +Y  
South  
West +X East

Although "Base Shears" are not technically a part of the ASCE 7-10 design procedure for wind loads, the summation of all story forces is often of interest to designers for a variety of reasons. Some designers like to see how the wind "base shear" compares to the seismic base shear. For some designers, the summation of the wind forces is useful in the checking process to get a confidence level that the calculated pressures are reasonable. Whatever the reason, the values are reported on this tab if they are of interest.

As with the Story Forces tab, the Base Shears & Torsions tab provides the option to either include or exclude the component of shear and torsion that is tributary to the bottom half of the lowest level.

### Print Properties

Finally, the complexity of this wind method and its requirements to examine multiple cases and conditions can lead to voluminous output. In recognition of the fact that different designers have different needs, the Print Properties dialog has been provided for this module to enable the output to be tailored to suit.



## 10.1.6 ASCE 7-05 Section 6.4, MWFRS:Simplified Forces

[Need more? Ask Us a Question](#)

This module is a presentation of the Simplified Wind Forces provisions of ASCE 7-05.

Click here for a video:

[ASCE 7-05 Wind Forces](#)

Limited documentation is provided here, because all of the references to ASCE 7-05 are given on the module screens.

### General

ENERCALC: sample session.ec6

File Settings Databases Tools License Help

Licensed ENERCALC User, KW-06000215

ASCE 7-05 Sect 6.4, MWFRS:Simplified Forces

Cancel New Save Only Save & Exit

General Applicability Checklists Analysis Values

Description

--None--

Note! All code sections, figure and table references refer to ASCE7-05.

Design Wind Pressures *per Eq. 6-1 =  $\lambda I K_{zt} P_{s30}$*

Horizontal Pressures . . .

Zone: A = 57.79 psf	Zone: C = 38.53 psf
Zone: B = -24.19 psf	Zone: D = -13.89 psf

Vertical Pressures . . .

Zone: E = -61.82 psf	Zone: G = -43.01 psf
Zone: F = -37.63 psf	Zone: H = -29.12 psf

Overhangs . . .

Zone: Eoh = -86.46 psf	Zone: Goh = -67.65 psf
------------------------	------------------------

Component & Cladding Design Wind Pressures . . .

Roof Zone 1:	Positive :	23.744 psf
	Negative :	-58.240 psf
Roof Zone 2:	Positive :	23.744 psf
	Negative :	-97.664 psf
Roof Zone 3:	Positive :	23.744 psf
	Negative :	-146.944 psf
Wall Zone 4:	Positive :	58.240 psf
	Negative :	-63.168 psf
Wall Zone 5:	Positive :	58.240 psf
	Negative :	-77.952 psf
Roof Overhang Zone 2:		-23.520 psf
Roof Overhang Zone 3:		-38.752 psf


Minimum Additional Load Case per 6.4.2.1.1 = 10 PSF on entire vertical plane

Build: 6.11.4.14

### Applicability Checks

Please see ASCE 7-05 references for descriptions. This module performs wind load calculations for the "Simplified" method. ALL boxes must be checked for module to give results on the Analysis Values tab.





### Analysis Values

See ASCE 7-05 sections noted for description of values and other references.

The lower portion of this tab gives the resulting calculated wind pressures for the main wind force resisting system and for components & cladding.

ENERCALC: sample session.ec6  
 File Settings Databases Tools License Help  
 Licensed ENERCALC User, KW-06000215  
**ASCE 7-05 Sect 6.4, MWFRS:Simplified Forces**  
 General Applicability Checklists Analysis Values

Analytical Values . . .  
 V : Basic Wind Speed per Sect 6.5.4 & Figure 1  mph  
 Interpolate values based on wind speed   
 Roof Rise/Run Ratio   
 Select Occupancy per Table 1-1  I  II  III  IV  
All Buildings and other structures except those listed as Category I, III, and IV  
 Building is located in Alaska  
 Importance Factor per Sect. 6.5.5, & Table 6-1   
 Select Exposure Category per 6.5.6.3, .4 & .5   
 Mean Roof height  ft  
 Interpolate "Lambda" values based on height   
 $\lambda$  : Height & exposure factor per Figure 6.2, Pg 40

Topographic Factor per 6.5.7.2, K1, K2 & K3 per Figure 6-4, Page 45  
 K1 =  K2 =  K3 =  [View Figure 6-4](#)  
 Force Kzt to 1.0 per ASCE 6.5.7.2  
 Topographic Factor Kzt =  $(1+K1*K2*K3)^2$  =

Effective Wind Area of Component & Cladding  ft<sup>2</sup>  
(Area will be limited to 100 for Roof Zone 1, 2 & 3)  
 Roof pitch for cladding pressure   
 Please specify an absolute minimum design pressure  psf

Design Wind Pressures *per Eq. 6-1 =  $\lambda I K_{zt} P_{S30}$*

Horizontal Pressures . . .  
 Zone: A = 16.13 psf Zone: C = 10.75 psf  
 Zone: B = -10.00 psf Zone: D = -10.00 psf

Vertical Pressures . . .  
 Zone: E = -15.46 psf Zone: G = -10.75 psf  
 Zone: F = -10.08 psf Zone: H = -10.00 psf

Overhangs . . .  
 Zone: Eoh = -21.62 psf Zone: Goh = -16.91 psf

Component & Cladding Design Wind Pressures . . .  
 Roof Zone 1: Positive : 10.000 psf  
 Negative : -13.328 psf  
 Roof Zone 2: Positive : 10.000 psf  
 Negative : -23.184 psf  
 Roof Zone 3: Positive : 10.000 psf  
 Negative : -34.272 psf  
 Wall Zone 4: Positive : 14.560 psf  
 Negative : -15.792 psf  
 Wall Zone 5: Positive : 14.560 psf  
 Negative : -19.488 psf  
 Roof Overhang Zone 2: -30.464 psf  
 Roof Overhang Zone 3: -51.184 psf

**Minimum Additional Load Case per 6.4.2.1.1 = 10 PSF on entire vertical plane**

Build: 6.11.4.14


## 10.1.7 IBC Alternate All-Heights Wind Method

[Need more? Ask Us a Question](#)

This module is an implementation of the IBC Alternate All-Heights Wind Method.

### General, Checklist, & Analysis Values

This tab offers a checklist of the criteria that must be satisfied in order to apply the IBC 2009 Alternate All-Heights Wind Method. Once all of the checkboxes are checked, the module will offer input fields for analytical values such as Exposure Category, Mean Roof Height, Topographic Factor parameters, Basic Wind Speed, Occupancy category, and options for the selection of Velocity Pressure Coefficients.



### MWFRS - Wall

This tab reports design pressures on windward walls, leeward walls, sidewalls and parapets. Pressure values are distinguished for Enclosed and Partially Enclosed structures, and values are reported for the positive internal pressure condition and for the negative internal pressure condition.

ENERCALC: sample session.ec6  
 Licensed ENERCALC User, KW-06000215

File Settings Databases Tools License Help

General, Checklist & Analysis Values MWFRS - Wall MWFRS - Roof MWFRS - Non BLDG C & C - Roof & Overhang C & C - Wall & Parapet

**MWFRS Table per IBC 2009 1609.6.2 (2), Section 1** Design Pressure  $P_{net} = C_{net} K_z q_s I K_{zt}$

WINDWARD WALLS & PARAPETS psf

*Kz based on ASCE 7-05 Table 6-3 for each height*

Height	Kz	Enclosed		Partially Enclosed		PARAPETS	
		+Internal	-Internal	+Internal	-Internal	Enclosed	Partially Enclosed
0 - 15'	0.700	8.70	15.18	2.23	21.25	25.90	25.90
20'	0.700	8.70	15.18	2.23	21.25	25.90	25.90
25'	0.700	8.70	15.18	2.23	21.25	25.90	25.90
30'	0.700	8.70	15.18	2.23	21.25	25.90	25.90
40'	0.760	9.45	16.48	2.42	23.07	28.12	28.12
50'	0.810	10.07	17.56	2.58	24.58	29.97	29.97
60'	0.850	10.57	18.43	2.70	25.80	31.45	31.45
70'	0.890	11.06	19.29	2.83	27.01	32.93	32.93
80'	0.930	11.56	20.16	2.96	28.23	34.41	34.41
90'	0.960	11.93	20.81	3.05	29.14	35.52	35.52
100'	0.990	12.31	21.46	3.15	30.05	36.63	36.63

LEEWARD & SIDEWALLS

Kz per ASCE 7-05 Table 6.3 0.700 using mean roof height = 15.0

	Enclosed	Partially Enclosed		
	+Internal	-Internal	+Internal	-Internal
Leeward Wall	-4.25	-10.32	-16.79	2.23
Parapet Wall : Leeward	<i>Both Conditions</i>		<i>Both Conditions</i>	
		-17.20		-17.20

Build: 6.11.4.14

### MWFRS - Roof

This tab reports design pressures on roof surfaces. Pressure values are distinguished for the conditions of wind perpendicular to the ridge and wind parallel to the ridge. In the case of wind perpendicular to the ridge, pressure values are reported for flat roofs as well as for various slope angles. In all cases, results are presented for Enclosed and for Partially Enclosed structures, and values are reported for the positive internal pressure condition and for the negative internal pressure condition.

ENERCALC: sample session.ec6  
 Licensed ENERCALC User, KW-06000215  
 IBC 2009 1609.6 Alternate All-Heights Wind  
 MWFRS - Non BLDG

MWFRS Table per IBC 2009 1609.6.2 (2), Section 1

$P_{net} = C_{net} K_z q_s I K_{zt}$


Kz per IBC 2009 1609.6.4.2 (2) = 0.700 using mean roof height = 15.0

WIND PERPENDICULAR TO RIDGE	psf	Enclosed		Partially Enclosed	
		+Internal	-Internal	+Internal	-Internal
Leeward Roof or Flat Roof		-13.35	-7.08	-7.49	-0.81
<b>Windward Roof Slopes</b>					
Slope < 2:12 (10 deg)	Condition 1	-22.06	-15.99	-28.53	-9.51
	Condition 2	-5.67	0.40	-12.14	6.88
Slope < 4:12 (18 deg)	Condition 1	-14.77	-8.50	-21.04	-2.23
	Condition 2	-1.01	5.06	-7.49	11.53
Slope < 5:12 (23 deg)	Condition 1	-11.74	-5.67	-18.21	0.81
	Condition 2	0.61	6.88	-5.87	13.15
Slope < 6:12 (27 deg)	Condition 1	-9.51	-3.24	-15.78	3.04
	Condition 2	1.21	7.49	-5.06	13.76
Slope < 7:12 (30 deg)	Condition 1	-7.49	-1.21	-13.76	-5.26
	Condition 2	1.42	7.49	-5.06	13.96
Slope < 9:12 (37 deg)	Condition 1	-5.46	0.81	-11.74	7.08
	Condition 2	2.83	8.90	-3.64	15.38
Slope < 12:12 (45 deg)		2.83	8.90	-3.64	15.38
<b>WIND PARALLEL TO RIDGE</b>					
All slopes including Flat Roofs		Enclosed		Partially Enclosed	
		+Internal	-Internal	+Internal	-Internal
		-22.06	-15.99	-28.53	-9.51

Build: 6.11.4.14


### MWFRS - Non BLDG

This tab reports net design pressures on the projection of surfaces of non-building structures.



### C&C - Roof & Overhang

This tab reports design pressures on components and cladding within roof surfaces. Results are presented for Enclosed and for Partially Enclosed structures, and values are reported for the positive internal pressure condition and for the negative internal pressure condition.



### C&C - Wall & Parapet

This tab reports design pressures on components and cladding within wall and parapet surfaces. Results are presented for Enclosed and for Partially Enclosed structures, and values are reported for the positive internal pressure condition and for the negative internal pressure condition.

ENERCALC : sample session.ec6

File Settings Databases Tools License Help

Licensed ENERCALC User, KW-06000215

IBC 2009 1609.6 Alternate All-Heights Wind

General, Checklist & Analysis Values MWFRS - Wall MWFRS - Roof MWFRS - Non BLDG C & C - Roof & Overhang C & C - Wall & Parapet

Wall & Parapet Components & Cladding per IBC 2009 1609.6.2 (2), Section 4 & 5

Use	Description	Continuity	Item Type (IBC 2009 Table 1609.6.2(2))	Z, Height above ground level, ft	Eff. Area ft^2	Pnet = Cnet * (qs Kz I Kzt)	Enclosed	Enclosed
<input checked="" type="checkbox"/>	Stud at corner on third floor	Discontinuity Present	Wall Elements, hc=60 ft	30.0	48.0	0.700	19.84	26.30
							-26.31	-32.79

Build: 6.11.4.14




## 10.1.8 ASCE Snow Loads

[Need more? Ask Us a Question](#)

This module is an implementation of the ASCE method of determining Flat Roof Snow Load, Sloped Roof Snow Load, and Snow Drifts on Lower Roofs, and Snow Drifts at Roof Obstructions. The module currently supports calculations based on ASCE 7-05 and ASCE 7-10. The Snow Loads module does **not** currently address the calculation of unbalanced snow loads, rain on snow surcharges, or sliding snow surcharges.

### General

Provides a place to enter descriptive text.



### Flat Roof Snow Loads

Allows up to 10 different flat roof snow loads to be calculated by entering values for all of the parameters in accordance with ASCE 7.

The screenshot shows the ENERCALC software interface with the 'Snow Loads per ASCE 7-05' dialog box open. The dialog is titled 'Snow Loads per ASCE 7-05' and has a 'Licensed ENERCALC User, KW-06000215' header. The main window title is 'ENERCALC : sample session.ec6'. The menu bar includes 'File', 'Settings', 'Databases', 'Tools', 'License', and 'Help'. The toolbar contains various icons for file operations and help. The dialog has several tabs: 'General', 'Flat Roof Snow Loads', 'Sloped Roof Snow Loads', 'Snow Drifts on Lower Roofs', 'Snow Drifts at Roof Projections', 'Drift Ref. Diagrams', and 'Diagrams'. The 'Sloped Roof Snow Loads' tab is active.

On the left side of the dialog, there is a 'Show Project Manager' section with a list of 10 loads. Load 1 and 2 are checked with green checkmarks, while loads 3 through 10 are marked with red X's. A 'Click to view' link is next to each load. An 'Enable' checkbox is checked.

The main area of the dialog contains the following fields and values:

- Description: Low Slope Roof
- Ground Snow Load, per Figure 7-1: 30.0 psf
- Terrain Category: B (see ASCE 7-05 Section 6.5.6)
- Exposure of Roof: Partially Exposed
- Ce, Exposure Factor, Table 7-2: 1.00
- Ct, Thermal Factor: 1.1 : Just above freezing (see ASCE for more) per Table 7-3
- Occupancy, per Table 1-1: III
- Importance Factor, Table 7-4: 1.10
- Check Min. Values for Low Slope Roofs, Sec. 7.3.4:
  - Roof Slope, Section 7.3.4: 4.0 deg
  - W, Horiz. Dist from eave to ridge: 55.0 ft
  - Roof Configuration: Monoslope


At the bottom of the dialog, a summary box shows the following calculations:

pf, Minimum required snow load	=	22.00
pf, Calculated snow load per Eq. 7-1	=	25.41
pf, Design Snow Load $\text{Max}(pf \text{ min, } pf \text{ calc})$	=	25.41 psf

The status bar at the bottom left says 'Data Saved' and the bottom right says 'Build: 6.11.4.14'.

### Sloped Roof Snow Loads

Allows up to 10 different sloped roof snow loads. The input form provides the option to refer to a previously defined Flat Roof Snow Load, or to explicitly specify a Flat Roof Snow Load value along with the remaining values for all of the parameters in accordance with ASCE 7.



### Snow Drifts on Lower Roofs

Allows up to 10 different conditions to be evaluated for snow drifts on lower roofs. The input form collects values for all of the necessary parameters to determine the windward and leeward drifts and selects the controlling case in accordance with ASCE 7.

Enable	Description	Balanced Snow Load psf	Ground Snow Load psf	lu upper ft	lu lower ft	Ht. Roof step ft	Snow Density pcf	hb Bal. Snow ft	hc = Step Ht - hb ft	hc/hb	hd leeward ft	hd wndwrft ft	hd Max ft	hd Design ft	pd: Max Drift only psf	Max. = (pd + Balanced) psf	W Drift Width ft	Total snow load at end of drift psf	
<input checked="" type="checkbox"/>	East side of Auditorium	21.0	30.0	120.0	80.0	8.0	17.90	1.17	6.83	5.82	3.83	2.37	3.83	3.83	68.63	89.63	15.34	21.00	
<input checked="" type="checkbox"/>	Central Atrium	21.0	30.0	56.0	40.0	16.0	17.90	1.17	14.83	12.64	2.64	1.65	2.64	2.64	47.21	68.21	10.55	21.00	
<input type="checkbox"/>																			
<input type="checkbox"/>																			
<input type="checkbox"/>																			
<input type="checkbox"/>																			
<input type="checkbox"/>																			
<input type="checkbox"/>																			
<input type="checkbox"/>																			

### Snow Drifts at Roof Projections

Allows up to 10 different conditions to be evaluated for snow drifts at roof projections. The input form collects values for all of the necessary parameters to determine the windward drift in accordance with ASCE 7.

ENERCALC: sample session.ec6  
Licensed ENERCALC User, KW-06000215

File Settings Databases Tools License Help

Snow Loads per ASCE 7-05

General Flat Roof Snow Loads Sloped Roof Snow Loads Snow Drifts on Lower Roofs Snow Drifts at Roof Projections Drift Ref. Diagrams

Enable	Description	Balanced Snow Load psf	Ground Snow Load psf	lu upwind ft	Ht. Roof Projection ft	Snow Density pcf	hb Bal. Snow ft	hc = Ht. of Projection - hb ft	hc/hb	hd wndwrld ft	hd Design ft	pd : Max Drift only psf	Max. = (pd + Balanced) psf	W Drift Width ft
<input checked="" type="checkbox"/>	Mechanical Pop-Up	21.0	30.0	150.0	4.0	17.90	1.17	2.83	2.41	3.18	2.83	50.60	71.60	14.29

Click to view

Show Project Manager

Data Saved

Build: 6.11.4.14

### 10.1.9 ASCE Live and Roof Live Load Reduction

This section enables the user to calculate reduced live and roof live loads for various parts of a project.

This section is a direct application of ASCE 7-05 Sections 4.8 and 4.9 and ASCE 7-10 Sections 4.7 & 4.8 concerning live and roof live load reductions. We refer the user to those sections of the referenced design standards for specific descriptions of the values used in each column seen below.

ENERCALC: sample session.ec6  
 Licensed ENERCALC User, KW-06000215

**Live Load Reduction** Cancel Save & Exit

Per ASCE 7-05, Section 4.8 & 4.9

Print	Description	Select Load Type	Lo psf	A <sub>T</sub> : Trib Area ft <sup>2</sup>	K <sub>LL</sub>	Roof Patch	R1	R2	Reduced L -or- Lr
<input checked="" type="checkbox"/>	East Wing	Roof Live Floor Live <input checked="" type="checkbox"/> 2+ Levels?	40.0	900.0	4	n/a	0.50		20.0 psf
<input checked="" type="checkbox"/>	West Wing Roof	Roof Live Floor Live	20.0	350.0	n/a	3:12	0.850	1.0	17.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf
<input type="checkbox"/>		Roof Live Floor Live		100.0	n/a	Flat	1.0	1.0	0.0 psf


Notes :  
 - Review ASCE 7-05 Table 4-1 for live load requirements.  
 - See reduction limits for Lo > 100 psf in Section 4.8.2/3/4  
 - For one-way slabs see Section 4.8.5

Build: 6.11.4.14

### 10.1.10 Project Load Group Builder

The Project Load Group Builder enables the user to store commonly used "Load Items" and then combine them into various Groups to calculate total loads for the defined Groups.

Load Items are defined and organized on the right-hand side of the screen as indicated in the screen capture below:



You can type in a Category name (discussed in more detail below), a Load Name, choose the Load Type, and specify the Load Value, and then click "Add as New Load". The newly added Load Item will appear in the Load Items List below. To edit an existing Load Item, click on the item of interest in the Load Items List, edit the values in the individual fields above, and then click "Save Changes"

Load Items are very flexible in their definition. A Load Item could represent the weight of a particular building construction material, such as the Dead Load of 3/4" plywood floor sheathing in units of PSF. A Load Item could also represent an allowance of 5 PSF Dead Load for ceiling & lights. But Load Items can also take the form of load types other than Dead Load as well. For instance, you could define a Load Item consisting of 100 PSF Live Load, or 30 PSF Snow Load. In this way, the Project Load Group Builder is capable of tracking loads of all types that may be applicable to a particular area of a building.

One of the powerful features of the Project Load Group Builder is that it takes the Load Item data that you enter and it saves that data in a file that is separate and distinct from your Project File. (The file is named LoadDbase.tps, and it is saved in the folder that you have identified as your default Project File location.) In this way, the system continues to accumulate more and more of your commonly specified materials and loads as you work on different projects. And that ever-growing database of your custom Load Items is always available to you on future projects.

In order to bring some organization to the many load items that you may eventually accumulate, the Project Load Group Builder introduces the concept of the "Category". A Category can contain one or more Load Items. Here again, the way you use Categories can be extremely flexible. Some users may prefer to organize their Load Items into Categories that represent different types of materials or loads. For example, the organizational hierarchy might take on a form like this where the bullet items represent Load Items within the indicated Category:

Category: Roof Sheathing

- 1/2" sheathing
- 5/8" sheathing
- 3/4" sheathing
- 7/8" sheathing
- 1" sheathing

Category: Roof Framing

- 2x6@16" o/c
- 2x8@16" o/c
- 2x10@16" o/c
- 2x12@16" o/c

Category: NW Concrete Slab

- 4.5" total with 2" deck
- 5.0" total with 2" deck
- 5.5" total with 2" deck
- 6.0" total with 2" deck
- 5.5" total with 3" deck
- 6.0" total with 3" deck
- 6.5" total with 3" deck

Category: LW Concrete Slab

- 4.5" total with 2" deck
- 5.0" total with 2" deck
- 5.25" total with 2" deck
- 5.5" total with 2" deck
- 6.0" total with 2" deck
- 5.5" total with 3" deck
- 6.0" total with 3" deck
- 6.25" total with 3" deck



- 6.5" total with 3" deck

Category: Live Load

- Classroom
- First Floor Corridor
- Office
- Stack Rooms

Category: Snow Load

- 30 PSF
- 32 PSF
- 34 PSF
- 36 PSF

And so on...

But remember, this is just one way that Categories could be used. Here is yet another idea:

Category: Typical classroom on structural floor

- DL of flooring
- DL of concrete slab on metal deck
- DL of composite metal deck
- DL allowance for structural steel framing
- DL allowance for ceiling & lights
- DL allowance for mechanical & misc.
- LL for classroom occupancy
- LL for partition allowance

Category: Typical corridor on structural floor

- DL of flooring
- DL of concrete slab on metal deck
- DL of composite metal deck
- DL allowance for structural steel framing
- DL allowance for ceiling & lights
- DL allowance for mechanical & misc.
- LL for corridor above first floor occupancy

Category: Typical roof structure


- DL of asphalt shingles
- DL allowance for second layer of asphalt shingles
- DL of metal roof deck
- DL structural steel framing
- DL allowance for ceiling & lights
- DL allowance for mechanical & misc.
- SL for sloped roof

And so on...

So remember that your Load Items and your Categories are being stored in a separate file, and they are continuing to accumulate from one project to the next as you enter more data. Consider this as you decide on a system of organization that will work best for you.

Now that we have covered Load Items and Categories, we can introduce the *real* purpose for this module, which is the "Load Group". Very simply, a Load Group is a group of Load Items that will be summed together.

Load Groups are defined and manipulated on the right-hand side of the screen as indicated in the screen capture below:



The Load Groups in the current Project File are listed in the "Group Name" list in the upper left corner of the module. The toolbar buttons above the list perform the following functions:



Adds a new Load Group



Creates a copy of the selected Load Group



Allows the name of the selected Load Group to be edited



Deletes the selected Load Group

When a Load Group is selected in the "Group Name" list, the details of that Load Group are displayed in the lower left corner of the screen. (A newly created Load Group will display no detailed information until some Load Items are added to the Load Group.) The display will show the Load Items that have been added to the current Load Group including the Load Item name, the Load Type (Dead Live, Snow, etc.), the magnitude of the load, and the units.

So we have now covered Load Items and Load Groups. The final detail is...how do we add these Load Items to Load Groups? The answer lies in the buttons shown below:



Adds the selected Load Item to the current Load Group




Removes the selected Load Item from the current Load Group

Finally, the Print function will automatically include all defined Load Groups and provide a nice tabular summary of the Load Items that combine to produce each Load Group.

## 10.2 Beams


### Overview

There is one main module for designing Steel, Concrete and Wood beams. There are separate modules for Composite Steel Beams, Steel Beams with Torsional Loads, and one for Masonry Lintels.



This section deals ONLY with typical single- or multi-span Steel, Concrete & Wood beams.

The presentation screen is divided into three areas: **Beam representation & modification**, **Data Entry & Calculation Results** as illustrated in the screen capture below:




**(1) Beam representation & modification:** This area allows you to create and modify the beam layout.




Click on the support icons to select the type of support fixity: Fixed, Pinned, or Free.




Click on the [+/-] icon to display a window to add or delete beam spans:



Click on the beam representation to change the beam specific data on the **Beam Span Data** and **Span Loads** tabs.






**(2) Data Entry:** This set of tabs is where you enter all information for the beam. These tabs will show different information according to material type selected. See the specific chapters for the items provided for each material. Click one of the following to jump:

- Wood
- Steel
- Concrete

Here is a summary of the purpose of each tab:

### General Data



#### Beam Material

Clicking one of these buttons changes the material type used for the beam.

#### Compression Edge Lateral Bracing


These selections control how the module will evaluate the lateral compression edge bracing for the design. When **Define Bracing Span-by-Span** is selected, the unbraced length is defined on a span-by-span basis on the Beam Span Data tab. When any of the other options are selected, the unbraced length is defined here on the General Data tab, and that definition is applied to all spans of the beam.

#### Analysis Method

For wood & steel you can select ASD or LRFD design methods. Concrete design is always ultimate strength (LRFD).

## Beam Span Data

This tab is used to define span length and beam section information:



### Select Span

These buttons allow you to select which span the values in the data entry area apply to.

### Span Length

This is where you define the length of the currently selected span.


### Deflection Ratios

These are used as the basis for the deflection design check and also as the starting point for automatic member selection.

### Section Name & Buttons

For steel and wood you can enter the standard beam section designation. You can also type in the section name and the module will search the built-in database for a match. If a match is found, the section properties will be loaded from the database and they will appear on the Properties tab.

Click the button indicated below to open the section database for rolled steel shapes:





The database contains an extensive number of standard shapes commonly used in the USA.

Steel Section Database

Steel Database: AISC, User Defined

Edition: 13th, 9th, 8th, 7th, 6th

Section Type to Display: W, C, WT, HSS-P, HSS-Square, L - Equal, LL - Equal, HP, MC, MT, P, HSS-Rectangular, L - Unequal, LL - Long Leg Vert, S, ST, LL - Short Leg Vert, M

Displaying Data For 274 "W" Shapes

Section Name	Wt. lbs	Area in <sup>2</sup>	Depth in	Web Thick in	Fl. Width in	Fl. Thick in	K Dist in	K1 Dist in	T Dist in	Ixx in <sup>4</sup>	Sx in
W4x13	13.04	3.83	4.160	0.280	4.060	0.345	0.595	0.500	0.000	11.30	
W5x16	16.03	4.71	5.010	0.240	5.000	0.360	0.660	0.438	0.000	21.40	
W5x19	18.93	5.56	5.150	0.270	5.030	0.430	0.730	0.438	0.000	26.30	
W6x8.5	8.58	2.52	5.830	0.170	3.940	0.195	0.445	0.500	0.000	14.90	
W6x9	9.12	2.68	5.900	0.170	3.940	0.215	0.465	0.500	0.000	16.40	
W6x12	12.08	3.55	6.030	0.230	4.000	0.280	0.530	0.563	0.000	22.10	
W6x15	15.08	4.43	5.990	0.230	5.990	0.260	0.510	0.563	0.000	29.10	
W6x16	16.13	4.74	6.280	0.260	4.030	0.405	0.655	0.563	0.000	32.10	
W6x20	19.98	5.87	6.200	0.260	6.020	0.365	0.615	0.563	0.000	41.40	
W6x25	24.99	7.34	6.380	0.320	6.080	0.455	0.705	0.563	0.000	53.40	
W8x10	10.08	2.96	7.890	0.170	3.940	0.205	0.505	0.500	0.000	30.80	
W8x13	13.07	3.84	7.990	0.230	4.000	0.255	0.555	0.563	0.000	39.60	
W8x15	15.11	4.44	8.110	0.245	4.010	0.315	0.615	0.563	0.000	48.00	
W8x18	17.91	5.26	8.140	0.230	5.250	0.330	0.630	0.563	0.000	61.90	
W8x21	20.97	6.16	8.280	0.250	5.270	0.400	0.700	0.563	0.000	75.30	

Buttons: Select, Cancel, View All Properties for selected section, Check availability at www.aisc.org

Click the button indicated below to display the Steel Member Design dialog:

Wood Beam

Span Length = 14.0 ft

Wood Section Name: 2x12

Member Width = 1.50 in

Member Depth = 11.250 in

Area = 16.875 in<sup>2</sup>

Ix = 177.979 in<sup>4</sup>

Iy = 3.164 in<sup>4</sup>

Buttons: Auto Select, Select Section...

This provides control over the type of member to be selected and various stress ratio, deflection ratio and size limits to respect during the automatic member selection process.

Steel Member Design

Section Type to Select ( click on choice )

W	C	WT	HSS-P	HSS-Square	HSS-Rectangular
S	MC	ST	L - Equal	L - Unequal	
M		MT	LL - Equal	LL - Long Leg Vert	LL - Short Leg Vert
HP					

Maximum Stress Ratio =  : 1.0 Depth Class  -->

Minimum Total Deflection Ratio =

Minimum (L + Lr) Deflection Ratio =

Depth Limits  -->

*(W14 is a "14" class, W33 is a "33" class, etc.)*  
*(Depth Limits are the exact member depths)*

The Quick-List provides a fast way to select a member section from the database. Just select the type of member, scroll through the list and click on your selection.

Steel Section Name :

Quick-List Properties

Select AISC Type...


W	S	HP	L-Eq
M	C	MC	L-Uneq
WT	MT	ST	LL-Eq
HSS-P		P	LL-LLBB
HSS-Sq	TS-Sq		LL-SLBB
HSS-Rect	TS-Rect		

Select AISC Section . . .

- W12X230
- W12X252
- W12X279
- W12X305
- W12X336
- W14X22**
- W14X26
- W14X30
- W14X34
- W14X38
- W14X43
- W14X48
- W14X53
- W14X61

### Compression Edge Lateral Bracing


When you have selected Define Bracing Span-by-Span on the General tab you will see the following bracing options on the Beam Span Data tab:



These selections control how the module will evaluate the lateral compression edge bracing for the beam span selected above.

The top row has common selections for fully-braced conditions as well as options to divide the selected span into segments of equal braced length.

The Define Spacing option lets you set a starting point and subsequent spacing for the bracing within the selected span:



The Define Locations option lets you set up to three specific bracing locations referenced from the left end of the selected span:

## Span Loads

This tab is used to specify loads **FOR THE SELECTED SPAN ONLY** (except as noted below) using the tools shown on the following screen capture:

Span # 1	Trib.	D	Lr	L	S	W	E	H
Load Type	(ft)	(k/ft)	(k/ft)	(k/ft)	(k/ft)	(k/ft)	(k/ft)	(k/ft)
Full Uniform	1.000	0.30		2.0	2.0			

Use the **[Add Load]**, **[Copy Load]** and **[Delete Load]** buttons to add, copy, or delete loads on the selected span.

Use the **Load Type** selections to specify the type of load that will be added. This selection affects the **currently highlighted** item in the table of loads. The data entry areas on the right will change based on the type of load selected.

The **Auto Add Beam Weight** option will calculate the weight of the beam and add it to your applied loads as a uniform dead load on the beam. Note that this option applies to the **FULL LENGTH** of the beam...it is **NOT** a setting that can be set on a span-by-span basis.

The **Auto Unbalanced Live Load Placement** option is a **VERY** powerful selection. When you have two or more beam spans, you can select this item and the module will automatically generate load combinations for all possible permutations of patterned live


load being placed on alternate spans. For instance, on a two-span beam, it would create conditions that place live load on both spans, live load on the left span only and live load on the right span only. That is a total of three permutations of live load, and it will do this for ALL of the load combinations that are selected to run.

**NOTE:** This can significantly increase recalculation time needed for beams with many spans.

**Load classifications are:** D: Dead, Lr: Roof Live, L: Live, S: Snow, W: Wind, E: Earthquake, H: Earth Pressure

## Loads All Spans

This tab offers tools that are used to specify loads with spacings or lengths that might cause them to overlap multiple spans as shown in the screen capture below:



Click the load type button on the left and the appropriate load entry items will appear to allow you to define the magnitude, location and extent of the load. With all load items set to **[None]**, the tab will be almost entirely blank.

**Start Dist** and **End Dist** defines the application distance from the **FAR LEFT** end of the beam. For a beam with two 20' spans where you want to apply a uniform load 5' in from each end use Start Dist = 5.00 and End Dist = 35.00.

The third item allows you to define repeating point loads or moments. You define the position of the first load and the spacing increment thereafter.

The last item allows you to define repeating loads on EACH span. Load specification is for the load in EACH span. For example, consider a two-span beam where the first span is 25' and the second span is 45'. Selecting **[1/3 Points]** will place loads at 8.33', 16.66' from the left support of the first span and at 15' and 30' from the left support of the second span. The "Specify" option allows you to provide a unique spacing measured from the left end of each span.

Although this tab is not typically used for single-span beams, the tools are perfectly applicable to single-span beams.

## Load Combinations

This tab is used to specify the load combinations that will be run for the analysis of this beam, as shown in the screen capture below:

Load Combination	Run	D	Lr	L	S	W	E	H
+D	<input checked="" type="checkbox"/>	1.0						
+D+L+H	<input checked="" type="checkbox"/>	1.0		1.0				1.0
+D+Lr+H	<input checked="" type="checkbox"/>	1.0	1					1.0
+D+S+H	<input checked="" type="checkbox"/>	1.0			1.0			1.0
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1.0	0.750	0.750				1.0
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1.0		0.750	0.750			1
+D+W+H	<input checked="" type="checkbox"/>	1	0			1.0		1.0
+D+0.70E+H	<input checked="" type="checkbox"/>	1.0					0.70	1.0
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1.0	0.750	0.750		0.750		1.0
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1.0		0.750	0.750	0.750		1.0
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1.0	0.750	0.750			0.5250	1.0
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1.0		0.750	0.750		0.5250	1.0
+0.60D+W+H	<input checked="" type="checkbox"/>	0.60				1.0		1.0
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	0.60					0.7	1.0

The **[Change Load Combination Set]** button is used to retrieve load combinations sets from the [Load Combination](#)<sup>[84]</sup> database.

The lock symbol is used to enable editing of the load combination values. Click on the lock symbol, and the multipliers for the load types will change to data entry items. After you change an item's value and press **[Tab]**, you will see the Load Combination description at the left end of the line change to reflect your entered values.

**[Use Add'l...]** button, when clicked, displays a data entry item where you can specify the magnitude of  $S_{DS}$  to use as an additional internal factor in the load combinations.


**[Auto Reverse Wind Factors]** and **[Auto Reverse Seismic Factors]** buttons trigger the module to create additional load combinations with the "W" and "E" factors set to negative values. This has the effect of reversing the direction of application of the wind and seismic loads that have been applied to the member.

**(3) Calculation Result:** This set of tabs provides detailed results for the current calculation.




The vertical tabs on the left edge of the screen allow you to select the three major areas available for review:

**Calculations** provides several tabs that let you review the numeric detail of the calculation. The left-most tab is always the Summary where the concise design is given.




See the individual sections for each material type for specific discussions of these result sections.

**Sketch** provides a scale illustration of the item you are designing, including an indication of support conditions and applied load magnitudes.



**Diagram** provides a moment, shear, or deflection diagram for the item you are designing.






## 10.2.1 Multiple Simple Beam

[Need more? Ask Us a Question](#)

This module is specifically designed to provide rapid analysis and design of simple beams. For complex, multi-span beams please use the other beam modules for wood, steel and concrete beams.

This module has an added section above the beam representation that allows you to add and select up to 12 beams to design. This can be seen in the screen capture below:



Looking at the screen capture above you can see:

- (1) The button in yellow with green lines above and below represents the currently selected beam for which data is displayed.
- (2) The button labeled **[Bm 2]** represents the second beam that was defined. Clicking on that button will save all of the data for **[Bm 1]** and display all the data for **[Bm 2]**.
- (3) **[Add]** is used to add another beam to this calculation. When two beams have already been defined, clicking **[Add]** will add a button labeled **[Bm 3]**.
- (4) **[Delete Bm X]** is used to delete the noted beam. It will delete the beam that is currently selected.


Directly below the band of beam selection buttons is the graphic that shows the basic layout of the currently selected beam. See below for a more detailed description.

**Note:** In this module, the beam span length is always specified on the beam layout graphic.


### Beam Layout Graphic

This area shows a graphic representation of the selected beam. There are several variations of beams that you can specify using the **[Add Cant]** buttons and also by clicking on the end support graphics.


Here is a basic simple span beam:




Clicking on the right **[Add Cant]** button in the image above adds a single cantilever at the right support as shown below:



Clicking on the left support icon in the image above displays a selection box so you can select a fixed end. Doing this sets the left support to fixed as shown below:



Clicking on the left **[Add Cant]** button in the image above adds a single cantilever at the left support, resulting in the double cantilever as shown below:



Note that adding the cantilever on the left also had the effect of automatically revising the left support back to a pinned condition.

### General Data Tab

This tab is where you select the beam material, allowable stresses, beam size, and set the beam bracing layout.


For steel and wood you can select ASD or LRFD design methods. For concrete, only strength design is available.




### Steel Specific Tab Items

**Design Values:** This area enables you to enter the yield strength and elastic modulus of the steel. The paper-with-hand icon gives you access to the available AISC steel stress grades.

**Quick-List Tab:** This tab provides quick access to the built-in 13th Edition AISC steel section list. Clicking a section name like [W] or [HP] in the Select AISC Type category will display all the steel sections of that type in the list to the right.



**Properties Tab:** This tab provides a [View Section Properties] button that when clicked displays all of the design values for the AISC section you have selected.



**Bracing Tab:** This tab allows you to select how your beam is braced against lateral-torsional buckling. Defined brace points are automatically assumed to brace both the top and the bottom flanges.

Steel Section : W14X30

Quick-List | Properties | **Bracing**

Unbraced | Full

Mid Span | 1/3 Points | 1/4 Points | 1/5 Points

Defined

Locations

All Spans Minor Axis (y-y) Bending

Max. Allow LL Defl. Ratio : 360.0 | Max. Allow Total Defl. Ratio : 180.0

The first line offers the most basic options.....fully unbraced or fully braced.

The next line offers uniform brace spacing options.

The last two buttons offer the ability to specify brace spacings from a starting point or enable you to specify selected brace points, as shown below:

Steel Section : W14X30

Quick-List | Properties | **Bracing**

Unbraced | Full

Mid Span | 1/3 Points | 1/4 Points | 1/5 Points

**Defined**


Locations

Starting at : 1 ft

and occurring every : 3 ft


All Spans Minor Axis (y-y) Bending

Max. Allow LL Defl. Ratio : 360.0 | Max. Allow Total Defl. Ratio : 180.0




### Wood Specific Tab Items

**Design Values:** This area enables you to specify the design values for the wood

species & grade you want to use. Click the  button to access the built-in NDS allowable stresses database.

**Quick-List Tab:** This tab provides quick access to the database of wood sections. Clicking a section type button like **[Sawn-General]** or **[TJ: Microllam]** in the Select Type category will display all the sections of that type in the list to the right.



**Properties Tab:** This tab provides the values for the wood section you have chosen. You can enter different numbers here to modify the section.

Wood Section : 4x12 Design

Quick-List **Properties** Bracing

Member Width	=	3.5 in	Area	39.375 in <sup>2</sup>
Member Depth	=	11.25 in	Ix	415.28 in <sup>4</sup>
			Iy	40.195 in <sup>4</sup>
Wood Grading/Manuf. : Graded Lumber				
Wood Member Type : Sawn				
Wood Type selected on "General Data" tab				
Cm : Wet Use Factor		1.0	Cf or Cv for Bending	(See table)
Ct : Temperature Factor		1.0	Cf or Cv for Compression	(See table)
Cfu : Flat Use Factor		1.0		
			Use Cr : Repetitive ?	<input type="checkbox"/> (non-glb only)

Max. Allow LL Defl. Ratio : 360.0    Max. Allow Total Defl. Ratio : 180.0

**Bracing Tab:** See information provided above in the Steel section for a summary of bracing options.

### Concrete Specific Tab Items

**Design Values:** This area enables you to enter concrete and reinforcing strengths for the beam. In addition you can specify the stirrup size and Phi values.

Description for this Beam : --None--

Beam Material : Wood    Steel    **C**oncrete


Design Values

f <sub>c</sub>	3.0 ksi	f <sub>y</sub> :	60.0 ksi	Stirrups	60.0 ksi
f <sub>r</sub> = f <sub>c</sub> *	7.50	E <sub>s</sub> :	29,000.0		29,000.0 ksi
ψ Density	145.0 pcf	<small>ASTM A615 Bars Used</small>			
E <sub>c</sub> =	3,122.0 ksi	Stirrup Bar Size #	3		
φ : Phi		Num of Bars Crossing Inclined Crack	2		
Flexure :	0.90				
Shear :	0.750	β <sub>1</sub> =	0.850		



Use **Span Data** for concrete beam size & reinforcing



### Span Data

When a concrete beam is chosen, a new tab named **Span Data** will be added to the user interface (see below). This tab is where you specify the beam cross section and reinforcing. This tab will only be shown when the material is set to concrete.



**Beam Shape:** You can select between 4 beam shapes:





On the right side of the tab you can specify up to 6 bars set (quantity, size, vertical location and start/stop endpoints). Each bar set is referenced on the sketch with a color shown as a dot to the left of the set description.

The column highlighted in light blue titled "Dist of bar center....from...." is how you set the vertical position of the bars set in the beam.

When you look at the top one you can read it as "The top bar set is 3 inches from the bottom of the beam". Note that the module will know whether the bars are in tension or compression and handle the calculations properly.

The item named Bar Position This Span defines the starting and ending location of the bar's ends with respect to this span's left support.



The data in the screen capture below shows that bar set #1 runs from the left end (0.0 ft) to 10.0 ft from the left support.

Using these starting and ending locations you can fine tune the bar layout and end cutoffs.

Bar Set	# Bars	Size #	Dist. of bar center...from..	Bar Position This Span Start (ft)	Bar Position This Span End (ft)
Bar Set #1	2	6	3	0	10.0
Bar Set #2					
Bar Set #3					
Bar Set #4					
Bar Set #5					
Bar Set #6					

### Results Tabs

**Design OK**

Maximum Bending Stress Ratio = **0.809** : 1  
 Section used for this span: **W14X30**  
 Mu : Applied 41.328 k-ft Mn / Omega : 51.064 k-ft  
 Load Combination +D+0.750Lr+0.750L+0.750W+H  
 Location of maximum on span 11.500 ft  
 Span # where maximum occurs Span # 1

Maximum Shear Stress Ratio = **0.096** : 1  
 Section used for this span: **W14X30**  
 Vu : Applied 7.188 k Vn/Omega : 74.520 k  
 Load Combination +D+0.750Lr+0.750L+0.750W+H  
 Location of maximum on span 0.000 ft  
 Span # where maximum occurs Span # 1

Deflections for Min. Defl. Ratios  
 Max Downward (L+Lr) or (L+S) Deflection 0.300 in  
 Max Upward (L+Lr) or (L+S) Deflection 0.000 in  
 Live Load Deflection Ratio 919

Maximum Support Reactions (kips)

	D	Lr	L	S	W	E	H
Support #1	2.88	2.30	2.30	1.15	1.15		
Support #2	2.88	2.30	2.30	1.15	1.15		
Support #3							
Support #4							

Total Deflection Ratio 566

Load Combination - ASD	Span	Max. Stress Ratios	Summary of Moment Values (k-ft)				Summary of Shear Values (k)						
Beam Segment		M	V	Mmax+	Mmax-	Ma-max	Mnx	Mnx/Omega	Cb	Rm	Va max	Vnx	Vn/Omega
Overall MAXimum Envelo													
+D													
+D+L+H													
+D+Lr+H													
+D+S+H													
-Dsgn. L = 1.00 ft	1	0.033	0.054	3.838		3.838	197.083	118.014	1.733	1.00	4.025	111.780	74.520
-Dsgn. L = 1.00 ft	1	0.062	0.049	7.328	3.838	7.328	197.083	118.014	1.252	1.00	3.676	111.780	74.520
-Dsgn. L = 1.00 ft	1	0.089	0.045	10.470	7.328	10.470	197.083	118.014	1.145	1.00	3.327	111.780	74.520
-Dsgn. L = 20.01 ft	1	0.453	0.054	23.144		23.144	85.278	51.064	1.115	1.00	4.025	111.780	74.520
+D+0.750Lr+0.750L+H													
-Dsgn. L = 1.00 ft	1	0.051	0.085	6.031		6.031	197.083	118.014	1.733	1.00	6.325	111.780	74.520
-Dsgn. L = 1.00 ft	1	0.098	0.078	11.515	6.031	11.515	197.083	118.014	1.252	1.00	5.777	111.780	74.520

Summary Results | Max. Combinations | M-V-D Summary | Support Reactions | Design OK

ASD/Service Stress Combinations | Service Load Deflections | Compress Incremental Results

Load Combination - ASD	Span	Distance	Shear : Va	Moment : Ma	Lu
Span Name	#	(ft)	(k)	(k-ft)	(ft)
Overall MAXimum Envelope					
+D					
+D+L+H					
+D+Lr+H					
+D+S+H					
+D+0.750Lr+0.750L+H					
+D+0.750L+0.750S+H					
+D+W+H					
+D+0.750Lr+0.750L+0.750W+H					
+D+0.750L+0.750S+0.750W+H					
+D+0.750Lr+0.750L+0.5250E+H					
+D+0.750L+0.750S+0.5250E+H					

Summary Results | Max. Combinations | M-V-D Summary | Support Reactions | Design OK

ASD/Service Stress Combinations | Service Load Deflections | Compress Incremental Results

Load Combination - Service	Span	Distance	Deflection	I-effective
Span Name	#	(ft)	(in)	(in <sup>4</sup> )
Overall MAXimum Envelope				
D Only				
L Only				
Lr Only				
L+Lr				
S Only				
L+S				
Lr+S				
W Only				
D+Lr				
D+L				

And for concrete beams these two additional sub-tabs are also visible:

Summary Results | Max. Combinations | M-V-D Summary | Support Reactions | Design OK

LRFD/Strength Stress Combinations | Service Load Deflections | Cross Section Values | Design Shear

Section	Span #	Bar Layout Description	Phi*Mn (k-ft)		Inertia (in <sup>4</sup> )		
			Btm Tens	Top Tens	Igross	Icr-Btm Tens	Icr-Top Tens
Section 1	1	2- #6 @ d=15"	55.38	9.12	5,994.00	1,207.39	34.48

Program identifies all unique cross sections for length of beam. These cross sections may occur at more than one location.


Summary Results | Max. Combinations | M-V-D Summary | Support Reactions | Design OK

LRFD/Strength Stress Combinations | Service Load Deflections | Cross Section Values | Design Shear


Load Combination - MAX Envelope	Span #	Distance	'd'	Vu (k)		d*Vu/Mu	Phi Vc	Capacity & Stirrup Spacing (s), (in)		
				Actual	Design			Comment	Req'd Vs	Bar Spac.
+1.20D+1.60Lr+0.50L	1	0.128	15.000	8.880	8.880	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	0.256	15.000	8.188	8.188	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	0.383	15.000	8.096	8.096	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	0.511	15.000	8.004	8.004	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	0.639	15.000	7.912	7.912	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	0.767	15.000	7.820	7.820	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	0.894	15.000	7.728	7.728	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	1.022	15.000	7.636	7.636	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	1.150	15.000	7.544	7.544	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00
+1.20D+1.60Lr+0.50L	1	1.278	15.000	7.452	7.452	1.000	19.211	Vu < PhiVc/2	Not Req'd	0.00

Load Combination - Service	Support Force (k)
Span Name	
Overall MAXimum	
- Support 1, (D+L+Lr)	7.475
- Support 2, (D+L+Lr)	7.475
D Only	
- Support 1	2.875
- Support 2	2.875
L Only	
- Support 1	2.300
- Support 2	2.300
Lr Only	
- Support 1	2.300
- Support 2	2.300
L+Lr	

Sketch



Diagrams



## 10.2.2 General Beam Analysis


[Need more? Ask Us a Question](#)

The General Beam Analysis module offers beam analysis functionality but does not incorporate any design processes. In this way, it can be a useful tool for situations where only analysis results are desired, such as shear, moment, reactions, and deflections.

### General Data tab:

The General Data tab allows you to set the span conditions, span lengths, and support conditions in much the same way that this information is provided in the other beam

modules. Refer to the [Beams](#) topic for additional explanation. In addition to these pieces of data, the General Data tab also provides input fields for the elastic modulus for bending, and the cross sectional area and moment of inertia of each span of the beam, as shown below:



### Span Loads tab:

The Span Loads tab allows you to specify loads on one span at a time. The behavior of the tools on this tab is identical to the tools described for use in the other beam modules.

Refer to the [Beams](#) topic for additional explanation.

### Loads All Spans tab:

The Loads All Spans tab allows you to specify loads on all spans at the same time. The behavior of the tools on this tab is identical to the tools described for use in the other beam

modules. Refer to the [Beams](#) topic for additional explanation.

### Load Combinations tab:

The Load Combinations tab provides a view of the load combinations that will be analyzed. It also offers the ability to:

- Select a different set of load combinations,
- Modify the values used as load factors, and
- Turn certain combinations on and off.

Refer to the Beams topic for additional explanation.

The General Beam Analysis module offers output options that are analogous to the output options provided by the other beam modules, with the exception that no design results are provided.

The lower half of the screen is dedicated to the display of results. The vertical strip of tabs on the left side of the display allow you to choose between Calculations, Sketch, and Diagram as explained below:

**Calculations:**

The Calculations tab offers four sub-tabs:

**Summary Results:** Displays extreme moments, maximum shear, extreme deflections and extreme reactions.

Maximum Moment =				Maximum Shear =						
568.372 k-ft				135.45 k						
Load Combination +D+0.750L+0.750S+0.750W+H				Load Combination +D+0.750L+0.750S+0.750W+H						
Location of maximum on span 11.487				Location of maximum on span 27.500 ft						
Span # where maximum occurs Span # 1				Span # where maximum occurs Span # 1						
ft										
Deflections for Min. Defl. Ratios (L+Lr) or (L+S) Deflection				Extreme Reactions ( service, kips )						
			Ratio =	D	Lr	L	S	W	E	H
Max Downward	0.020 in		16334	Support #1	43.10	12.27	24.53	24.53	24.53	24.53
Max Upward	-0.017 in		39366	Support #2	97.30	16.20	32.40	32.40	32.40	32.40
Total Deflection				Support #3	44.44	-1.42	-2.84	-2.84	-2.84	-2.84
Max Downward	0.034 in		9841	Support #4	7.66	0.45	0.90	0.90	0.90	0.90
Max Upward	-0.017 in		39366							

**Maximum Combinations:** Displays extreme moments and shears, on a span-by-span basis, for all load combinations.

Load Combination - ASD	Span	Summary of Moment Values			Shear Va max
		Mmax+	Mmax-	Ma-max	
<b>Beam Segment</b>					
Overall MAXimum Envelope					
-Dsgn. L = 27.50 ft	1	568.372	-510.830	568.372	135.451
-Dsgn. L = 55.00 ft	2	134.962	-510.830	510.830	34.757
-Dsgn. L = 27.50 ft	3	46.939	-167.518	167.518	19.842
+D					
-Dsgn. L = 27.50 ft	1	232.227	-327.182	327.182	66.898
-Dsgn. L = 55.00 ft	2	134.962	-327.182	327.182	30.403
-Dsgn. L = 27.50 ft	3	29.326	-167.518	167.518	19.842
+D+L+H					
-Dsgn. L = 27.50 ft	1	381.148	-408.804	408.804	97.366
-Dsgn. L = 55.00 ft	2	114.031	-408.804	408.804	32.338
-Dsgn. L = 27.50 ft	3	36.636	-142.696	142.696	18.939
+D+Lr+H					
-Dsgn. L = 27.50 ft	1	306.556	-367.993	367.993	82.132

M-V-D: Summary: Displays moment, shear, and deflections at small increments along all spans. Moment and shear are displayed for all load combinations. Deflection is displayed for service load combinations only.

Load Combination - ASD	Span	Distance (ft)	Shear : Va (k)	Moment : Ma (k-ft)
<b>ASD/Service Stress Combinations</b>				
<b>Service Load Deflections</b>				
Compress Incremental Results				
Span Name	#			
Overall MAXimum Envelope				
+D				
+D+L+H				
+D+Lr+H				
+D+S+H				
+D+0.750Lr+0.750L+H				
+D+0.750L+0.750S+H				
+D+W+H				
+D+0.70E+H				
+D+0.750Lr+0.750L+0.750W+H				
+D+0.750L+0.750S+0.750W+H				
+D+0.750Lr+0.750L+0.5250E+H				
+D+0.750L+0.750S+0.5250E+H				
+0.60D+W+H				


Load Combination - Service	Span	Distance (ft)	Deflection (in)
<b>ASD/Service Stress Combinations</b>			
<b>Service Load Deflections</b>			
Compress Incremental Results			
Span Name	#		
Overall MAXimum Envelope			
D Only			
L Only			
Lr Only			
L+Lr			
S Only			
L+S			
span 1	1		
span 1	1	0.348	0.001
span 1	1	0.696	0.002
span 1	1	1.044	0.003
span 1	1	1.392	0.003
span 1	1	1.741	0.004
span 1	1	2.089	0.005

Support Reactions: Displays support reactions for all supports, for all load combinations.

Load Combination - Service	Support Force (k)
<b>ASD/Service Stress Combinations</b>	
<b>Support Reactions</b>	
Overall MAXimum	
-Support 1, (D+L+E)	92.166
-Support 2, (D+L+E)	162.107
-Support 3, (D Only)	44.439
-Support 4, (D+L+E)	9.464
D Only	
-Support 1	43.102
-Support 2	97.301
-Support 3	44.439
-Support 4	7.658
L Only	
-Support 1	24.532
-Support 2	32.403
-Support 3	-2.838
-Support 4	0.903
Lr Only	


**Sketch:**

Displays a sketch of the beam, indicating span lengths, support conditions, and applied loads.



**Diagram:**

Displays a graphic depiction of the beam with superimposed graphs of Moment, Shear, or Deflection for a selected load combination, or for an envelope of all load combinations.



## 10.2.3 Wood Beam

[Need more? Ask Us a Question](#)

In this section, for each input tab we will review only the items that are unique to the WOOD material type. Click here for a video: [Wood Beam](#)

For general information on the typical data input for all beams see the [Beams](#)<sup>[245]</sup> topic.

This module offers complete design of single and multi-span wood members. Among its capabilities are:

- Single or multi-span beams.
- End fixity can be pinned, fixed, free or a combination thereof.
- Analysis is according to 2005 NDS.
- ASD or LRFD design methods can be selected. Values of  $K_F$  and  $\phi$  are automatically determined and applied for the LRFD method.
- A complete wood section database is provided. This includes sawn, glued-laminated and selected manufactured sections.
- A complete wood species database is provided. All values are per 2005 NDS.
- Unbraced compression edge lengths can be specified in a variety of ways.
- Automatic member selection is provided.
- You can specify values for  $C_M$ ,  $C_t$  and  $C_r$ .  $C_F$  or  $C_V$  is automatically provided. In the case of  $C_F$ , the value is also based on species stress grade.

### General Data

The screenshot shows the 'General Data' tab of a software interface. The description is 'Sample Two-Span Wood Beam'. The design method is set to 'LRFD'. The wood species is 'Douglas Fir - Larch' and the wood grade is 'No.1'. The beam material is set to 'Wood'. The compression edge lateral bracing is set to 'Define Bracing Span-by-Span'. The design values are: Fb - Tension (1000 psi), Fb - Compression (1000 psi), Fc - Prill (1500 psi), Fc - Perp (625 psi), Fv (180 psi), Ft (675 psi), Density (32.21 pcf), Ebend - xx (1700 ksi), Eminbend - xx (620 ksi). The 'Calc Shear at 'd' from support?' and 'Force Le = 1.0 Lu?' checkboxes are checked. The 'Use Inflection Points as Brace Points' checkbox is unchecked.

#### Beam Material

Clicking one of these buttons changes the material type used for the beam.

#### Design Method

For wood & steel you can select ASD or LRFD design methods. Concrete design always uses ultimate strength design (LRFD).

#### Design Values





This section is used to specify the type of wood that will be used. Use the button to access the standard wood reference design values database and select a material.

These values can be edited right on the screen. HOWEVER there are other pieces of information, such as size factors for certain sizes of members, that are stored separately.

Wood Stress Database

**NDS 2005 Supplement Base Design Values**

Size Classes to Show: 2"->4" Thick, 2" & Wider 5" x 5" & Larger Glulam Table 5A - Beams Manufactured User Defined

Show Favorites Only Toggle Favorite ON-OFF Expand/Contract Trees: [+] [-]

Wood Species	Size/Group	Fb (psi)	Fv	Fc (psi)	Ft	E - Modu				
Common Name	Classification	Tension	Compr.	psi	Perp.	Prll	psi	E Bend	E Min Bend	E Ber
<input type="checkbox"/> Baldcypress	5"x5" & Lrgr									
- Select structural	5"x5" & Lrgr	1,150	1,150	200	615	1,050	750	1,300	470	
No. 1	5"x5" & Lrgr	1,000	1,000	200	615	925	675	1,300	470	
No. 2	5"x5" & Lrgr	625	625	175	615	600	425	1,000	370	
<input type="checkbox"/> Mixed Southern Pine	5"x5" & Lrgr									
- Select structural SR	5"x5" & Lrgr	1,500	1,500	165	375	900	1,000	1,300	470	
No. 1	5"x5" & Lrgr	1,350	1,350	165	375	800	900	1,300	470	
No. 2	5"x5" & Lrgr	850	850	165	375	525	550	1,000	370	
<input type="checkbox"/> Redwood	5"x5" & Lrgr									
- Clear Strutral	5"x5" & Lrgr	1,850	1,850	145	650	1,650	1,250	1,300	470	
- Select structural	5"x5" & Lrgr	1,400	1,400	145	650	1,200	950	1,300	470	
- Select structural OG	5"x5" & Lrgr	1,100	1,100	145	420	900	750	1,000	370	
No. 1	5"x5" & Lrgr	1,200	1,200	145	650	1,050	800	1,300	470	
No. 1 OG	5"x5" & Lrgr	950	950	145	420	800	650	1,000	370	
No. 2	5"x5" & Lrgr	1,000	1,000	145	650	900	525	1,100	400	
No. 2 OG	5"x5" & Lrgr	750	750	145	420	650	400	900	330	
<input type="checkbox"/> Southern Pine	5"x5" & Lrgr									
- Dense select structural	5"x5" & Lrgr	1,750	1,750	165	440	1,100	1,200	1,600	580	
- Select structural SR	5"x5" & Lrgr	1,500	1,500	165	375	950	1,000	1,500	550	

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\WDS\_2005.TPS

### Beam Span Data

This tab is used to define span length and section information for the beam:

**Wood Beam**

Span Length: 14.0 ft

Member: 2x12

Click on +/- to Add, Delete Spans | Click on Span To Select | Click on Support to Modify

General Data | **Beam Span Data** | Span Loads | Loads All Spans | D+L? Load Combinations

Select Span : 1

Span Length = 14 ft

Use Cr : Repetitive ?  (non-gb only)

Cm : Wet Use Factor : Fb: 1 Fv: 1 E: 1

Ct : Temperature Factor 1

Apply Incising Factors  (sawn only)

See Max Combinations tab for CF & Cv

Wood Section Name : 2x12 Auto Select

Database or Selected section used for :

Member Width = 1.50 in Sawn - General

Member Depth = 11.250 in Sawn - So. Pine

Area = 16.875 in<sup>2</sup> Glu-Lam - Western

Ix = 177.979 in<sup>4</sup> Glu-Lam - So. Pine

Iy = 3.164 in<sup>4</sup> TJ : Microllam


Wood Grading/Manuf. : Graded Lumber

Wood Member Type : Sawn


Select Section ...

- 2x12
- 2x14
- 3x4
- 3x6
- 3x8
- 3x10
- 3x12
- 3x14
- 3x16
- 4x4
- 4x6
- 4x8
- 4x10
- 4x12


The button shown bubbled in the screen capture below is used to display the Wood Section Database.




The Wood Section Database contains an extensive number of solid-sawn members, glulam members, and manufactured members commonly used in the USA.



The button shown bubbled in the screen capture below is used to display the Wood Member Design dialog.



The Wood Member Design dialog allows you to choose the type of member to be selected and to specify limits on the permissible stress ratio, deflection ratio and selected member size.



Note: The factor named Maximum Stress Ratio does not act as a multiplier on the specified deflection ratios.

### Span Loads

No differences from other materials.

### Loads All Spans

No differences from other materials.

### Load Combinations

For wood members you will see entries for load duration factors. When ASD is used, the Load Duration Factor is referred to as  $C_D$ . When LRFD is used, the Load Duration Factor is referred to as  $\lambda$ .

Note that  $C_D$  and  $\lambda$  actually appear on the button at the top of the column of values. When that button is clicked, the program will automatically determine the proper value for  $C_D$  or  $\lambda$  according to the NDS based on the shortest duration load type included in each of the load combinations.

ASD/Service Combinations		2009 IBC 8
Load Combination	Run?	$C_D$
+D	<input checked="" type="checkbox"/>	0.9
+D+L+H	<input checked="" type="checkbox"/>	1
+D+Lr+H	<input checked="" type="checkbox"/>	1.25
+D+S+H	<input checked="" type="checkbox"/>	1.15
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1.25
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1.15
+D+W+H	<input checked="" type="checkbox"/>	1.6
+D+0.70E+H	<input checked="" type="checkbox"/>	1.6
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1.6
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1.6
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1.6
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1.6
+0.60D+W+H	<input checked="" type="checkbox"/>	1.6
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	1.6

LRFD/Strength Combinations		2009 IBC 8
Load Combination	Run?	$\lambda$
+1.40D	<input checked="" type="checkbox"/>	0.6
+1.20D+0.50Lr+1.60L+1.60H	<input checked="" type="checkbox"/>	0.8
+1.20D+1.60L+0.50S+1.60H	<input checked="" type="checkbox"/>	0.8
+1.20D+1.60Lr+0.50L	<input checked="" type="checkbox"/>	0.8
+1.20D+1.60Lr+0.80W	<input checked="" type="checkbox"/>	1
+1.20D+0.50L+1.60S	<input checked="" type="checkbox"/>	0.8
+1.20D+1.60S+0.80W	<input checked="" type="checkbox"/>	1
+1.20D+0.50Lr+0.50L+1.60W	<input checked="" type="checkbox"/>	1
+1.20D+0.50L+0.50S+1.60W	<input checked="" type="checkbox"/>	1
+1.20D+0.50L+0.20S+E	<input checked="" type="checkbox"/>	1
+0.90D+1.60W+1.60H	<input checked="" type="checkbox"/>	1
+0.90D+E+1.60H	<input checked="" type="checkbox"/>	1

**Results Tabs:** This set of tabs provides detailed results for the current calculation. The vertical tabs on the left edge of the screen allow you to select the three major areas available for review: Calculations, Sketch, and Diagram.

The Calculations tab offers the following results options:

**Summary Results** provides details for shear, moment and deflection for the governing load combinations.

The Summary Results window displays the following data:

- Maximum Bending Stress Ratio:** 0.951 : 1. Section used for this span: 2x14. fb : Actual: 1,478.22 psi. FB : Allowable: 1,555.20 psi.
- Maximum Shear Stress Ratio:** 0.543 : 1. Section used for this span: 2x14. fv : Actual: 168.87 psi. Fv : Allowable: 311.04 psi.
- Deflections for Min. Defl. Ratios (L+R) or (L+S) Deflection:**
  - Max Downward: 0.078 in, Ratio = 1542
  - Max Upward: -0.034 in, Ratio = 3497
  - Total Deflection:
    - Max Downward: 0.085 in, Ratio = 1404
    - Max Upward: -0.034 in, Ratio = 3497
- Extreme Reactions ( service, kips ):
 

	D	Lr	L	S	W	E	H
Support #1	3.18			3.87			
Support #2		0.51			3.00		
Support #3			0.15			1.05	

**Max. Combinations** provides detailed results for each beam segment for each load combination. The leftmost column lists the load combinations and the unbraced length being considered.

These results are a consolidation of the highly detailed incremental results presented on the M-V-D Summary tab.

Load Combination	Span	Applied	Final Stress Ratios	Format Conversion Factor	Resistance Factor			Actual Stress (psi)					
Beam Segment	#	Moment (k-ft)	Shear (k)	Moment	Shear	KF-Bend	KF-Shear	KF-E	Phi-Bend	Phi-Shear	Phi-E	fb - Design	fv - Des
+1.40D													
-Length = 10.0 ft	1	-0.71	0.29	0.166	0.095	2.541	2.880	1.765	0.85	0.750	0.850	193.5	2
-Length = 10.0 ft	2	-0.71	0.29	0.166	0.095	2.541	2.880	1.765	0.85	0.750	0.850	193.5	2
+1.20D+0.50Lr+1.60L+													
-Length = 10.0 ft	1	-3.01	2.00	0.529	0.485	2.541	2.880	1.765	0.85	0.750	0.850	822.0	15
-Length = 10.0 ft	2	4.01	2.00	0.705	0.485	2.541	2.880	1.765	0.85	0.750	0.850	1,095.8	15
+1.20D+0.50Lr+1.60L+													
-Length = 10.0 ft	1	4.01	2.00	0.705	0.485	2.541	2.880	1.765	0.85	0.750	0.850	1,095.8	15
-Length = 10.0 ft	2	-3.01	0.49	0.529	0.485	2.541	2.880	1.765	0.85	0.750	0.850	822.0	15
+1.20D+0.50Lr+1.60L+													
-Length = 10.0 ft	1	-5.41	2.24	0.951	0.543	2.541	2.880	1.765	0.85	0.750	0.850	1,478.2	16
-Length = 10.0 ft	2	-5.41	2.24	0.951	0.543	2.541	2.880	1.765	0.85	0.750	0.850	1,478.2	16
+1.20D+1.60L+0.50S+													
-Length = 10.0 ft	1	-3.01	2.00	0.529	0.485	2.541	2.880	1.765	0.85	0.750	0.850	822.0	15

**M-V-D Summary- Stresses** shows highly detailed moment and shear information for each beam and for each load combination. For multi-span beams using Automatic Unbalanced Live Load Placement there may be thousands of lines of results.

Load Combination - LRFD	Span	Distance (ft)	Shear : Vu (k)	Moment : Mu (KFT)	Lu (k-ft)
+1.40D					
+1.20D+0.50Lr+1.60L+1.60H, LL Comb Ru					
+1.20D+0.50Lr+1.60L+1.60H, LL Comb Ru					
+1.20D+0.50Lr+1.60L+1.60H, LL Comb Ru					
+1.20D+1.60L+0.50S+1.60H, LL Comb Ru					
+1.20D+1.60L+0.50S+1.60H, LL Comb Ru					
+1.20D+1.60L+0.50S+1.60H, LL Comb Ru					
+1.20D+1.60Lr+0.50L, LL Comb Run ("L")					
-Span 1	1		0.107		Support Brace
-Span 1	1	0.077	0.103	0.008	L = 10.00
-Span 1	1	0.154	0.100	0.016	L = 10.00
-Span 1	1	0.231	0.096	0.023	L = 10.00
-Span 1	1	0.308	0.092	0.031	L = 10.00
-Span 1	1	0.385	0.088	0.038	L = 10.00

**M-V-D Summary - Deflections** shows highly detailed deflection results for all load combinations.

Summary Results | Max. Combinations | M-V-D Summary | Support Reactions | Design OK

LRFD/Strength Stress Combinations | Service Load Deflections | Compress Incremental Results


Load Combination - Service	Span	Distance (ft)	Deflection (in)	I-effective (in <sup>4</sup> )
Overall MAXimum Envelope				
D Only				
L Only, LL Comb Run (L*)				
L Only, LL Comb Run (L*)				
L Only, LL Comb Run (LL)				
D+L, LL Comb Run (L*)				
-Span 1	1			290.775
-Span 1	1	0.077	-0.000	290.775
-Span 1	1	0.154	-0.001	290.775
-Span 1	1	0.231	-0.001	290.775
-Span 1	1	0.308	-0.002	290.775
-Span 1	1	0.385	-0.002	290.775
-Span 1	1	0.462	-0.003	290.775
-Span 1	1	0.538	-0.003	290.775

Support Reactions shows reactions for each support for each load condition.


Summary Results | Max. Combinations | M-V-D Summary | Support Reactions | Design OK

Load Combination - Service	Support Force (k)
Overall MAXimum	
D Only	
L Only, LL Comb Run (L*)	
L Only, LL Comb Run (L*)	
L Only, LL Comb Run (LL)	
D+L, LL Comb Run (L*)	
-Support 1	3.032
-Support 2	2.006
-Support 3	1.202
D+L, LL Comb Run (L*)	
D+L, LL Comb Run (LL)	

The Sketch tab provides a graphic representation of the beam currently being designed:




The Diagram tab offers the ability to view shear, moment, and deflection diagrams for selected load combinations:



## REPORTS


Below is a typical Wood Beam printed report:

	Joseph P. Engineer GREAT ENGINEERING UNLIMITED 1234 Main Street, 1st Floor Anytown, USA, 99221 jpe@GreatEngineering.com Phone : (800) 111-2222	Title : Dsgnr: Project Desc :  Project Notes :	Job #
	Printed: 11 OCT 2009, 5:55PM		
	File: c:\EC6AA_TECH_EC6_FILES\examples.ec6 ENERCALC, INC. 1983-2009, Ver: 6.0.225, N:00661		
	License Owner : Licensed ENERCALC User		

**Wood Beam Design**  
 Lic. #: KW-06000215  
 Description : Sample Two-Span Wood Beam

<b>Material Properties</b>		<b>Calculations per IBC 2006, CBC 2007, 2005 NDS</b>	
Analysis Method : Load Resistance Factor D	Fb - Tension	2,600.0 psi	<i>E : Modulus of Elasticity</i>
Load Combination 2006 IBC & ASCE 7-05	Fb - Compr	2,600.0 psi	Ebend- xx 1,900.0 ksi
Wood Species : SP/SP	Fc - Prll	1,600.0 psi	Eminbend - xx 980.0 ksi
Wood Grade : 26F-V4	Fc - Perp	740.0 psi	Ebend- yy 1,800.0 ksi
Beam Bracing : Beam bracing is defined Beam-by-Beam	Fv	300.0 psi	Eminbend - yy 930.0 ksi
	Ft	1,200.0 psi	Density 35.440 pcf

**Unbraced Lengths**  
 Span # 1, Braced @ Mid Span



**Applied Loads** Service loads entered. Load Factors will be applied for calculations.

Beam self weight calculated and added to loads  
 Load for Span Number 1  
 Uniform Load : D = 0.350, L = 0.50 k/ft, Tributary Width = 1.0 ft

<b>DESIGN SUMMARY</b>				<b>Design OK</b>	
Maximum Bending Stress Ratio	=	0.470 : 1	Maximum Shear Stress Ratio	=	0.345 : 1
Section used for this span	=	5.125x26.5	Section used for this span	=	5.125x26.5
fb : Actual	=	2,082.12psi	fv : Actual	=	178.77 psi
FB : Allowable	=	4,434.33psi	Fv : Allowable	=	518.40 psi
Load Combination	=	+1.20D+0.50Lr+1.60L+1.60H	Load Combination	=	+1.20D+0.50Lr+1.60L+1.60H
Location of maximum on span	=	12.375ft	Location of maximum on span	=	0.000ft
Span # where maximum occurs	=	Span # 1	Span # where maximum occurs	=	Span # 1
<b>Maximum Deflection</b>					
Max Downward L+Lr+S Deflection		0.316 in	Ratio =		939
Max Upward L+Lr+S Deflection		0.000 in	Ratio =		0 <180
Max Downward Total Deflection		0.558 in	Ratio =		532
Max Upward Total Deflection		0.000 in	Ratio =		0 <360

**Maximum Forces & Stresses for Load Combinations**

Load Combination	Segment Length	Span #	Max Stress Ratios			Summary of Moment Values			Summary of Shear Values		
			M	V	λ	Mu	fb-design	Fb-allow	Vu	fv-design	Fv-allow
+1.40D	Length = 12.375 ft	1	0.266	0.195	0.600	40.97	885.11	3,325.75	6.62	75.99	388.80
+1.20D+0.50Lr+1.60L+1.60H	Length = 12.375 ft	1	0.470	0.345	0.800	96.37	2,082.12	4,434.33	15.58	178.77	518.40
+1.20D+0.50L+0.50Sr+1.60H	Length = 12.375 ft	1	0.264	0.194	0.800	54.26	1,172.24	4,434.33	8.77	100.65	518.40
+1.20D+1.60Lr+0.50L	Length = 12.375 ft	1	0.264	0.194	0.800	54.26	1,172.24	4,434.33	8.77	100.65	518.40



Joseph P. Engineer  
 GREAT ENGINEERING UNLIMITED  
 1234 Main Street, 1st Floor  
 Anytown, USA 99221  
 jpe@GreatEngineering.com  
 Phone : (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:  
 Project Notes :

Job #

Printed: 11 OCT 2009, 5:55PM

**Wood Beam Design**

File: c:\EC6\AA\_TECH\_EC6\_FILES\examples.ec6  
 ENERCALC, INC. 1983-2009, Ver: 6.0.225, N:00661

Lic. #: KW-0600215

License Owner : Licensed ENERCALC User

Description : Sample Two-Span Wood Beam

Load Combination	Segment Length	Span #	Max Stress Ratios			Summary of Moment Values			Summary of Shear Values		
			M	V	$\lambda$	Mu	fb-design	Fb-allow	Vu	fv-design	Fv-allow
+1.20D+1.60Lr+0.50L+0.80W	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
+1.20D+0.50L+1.60S	Length = 12.375 ft	1	0.264	0.194	0.800	54.26	1,172.24	4,434.33	8.77	100.65	518.40
	Length = 12.375 ft	1	0.264	0.194	0.800	54.26	1,172.24	4,434.33	8.77	100.65	518.40
+1.20D+0.50L+1.60S+0.80W	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
+1.20D+0.50Lr+0.50L+1.60W	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
+1.20D+0.50L+0.50S+1.60W	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
+1.20D+0.50L+0.20S+E	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
	Length = 12.375 ft	1	0.211	0.155	1.000	54.26	1,172.24	5,542.92	8.77	100.65	648.00
+0.90D+1.60W+1.60H	Length = 12.375 ft	1	0.103	0.075	1.000	26.34	569.00	5,542.92	4.26	48.85	648.00
	Length = 12.375 ft	1	0.103	0.075	1.000	26.34	569.00	5,542.92	4.26	48.85	648.00
+0.90D+E+1.60H	Length = 12.375 ft	1	0.103	0.075	1.000	26.34	569.00	5,542.92	4.26	48.85	648.00
	Length = 12.375 ft	1	0.103	0.075	1.000	26.34	569.00	5,542.92	4.26	48.85	648.00

**Overall Maximum Deflections - Unfactored Loads**

Load Combination	Span	Max. "+" Defl	Location in Span	Load Combination	Max. "+" Defl	Location in Span
D+L+Lr	1	0.5580	12.499		0.0000	0.000

**Maximum Deflections for Load Combinations - Unfactored Loads**


Load Combination	Span	Max. Downward Defl	Location in Span	Max. Upward Defl	Location in Span
D Only	1	0.2417	12.499	0.0000	0.000
L Only	1	0.3162	12.499	0.0000	0.000
D+L+S	1	0.5580	12.499	0.0000	0.000
D+L+Lr	1	0.5580	12.499	0.0000	0.000

**Vertical Reactions - Unfactored**

Support notation : Far left is #1

Values in KIPS

Load Combination	Support 1	Support 2
Overall MAXimum	10.917	10.917
D Only	4.729	4.729
L Only	6.188	6.188
D+L+S	10.917	10.917
D+L+Lr	10.917	10.917







Joseph P. Engineer  
 GREAT ENGINEERING UNLIMITED  
 1234 Main Street, 1st Floor  
 Anytown, USA 99221  
 joe@GreatEngineering.com  
 Phone: (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:  
 Project Notes :

Job #

Printed: 11 OCT 2009, 5:55PM


**Wood Beam Design**

Lic. # : KW-06000215

File: c:\EC6\AA\_TECH\_EC6\_FILES\examples.ec6  
 ENERCALC, INC. 1983-2009, Ver: 6.0.225, N:00661

License Owner : Licensed ENERCALC User

Description : Sample Two-Span Wood Beam



## 10.2.4 Steel Beam

### [Need more? Ask Us a Question](#)

In this section, for each input tab we will review only the items that are unique to the STEEL material type. Click here for a video: [Steel Beam](#)


For general information on the typical data input for all beams see the [Beams](#)<sup>[245]</sup> topic.

This module offers complete design of single and multi-span steel members. Among its capabilities are:

- Single or multi-span beams.
- End fixity can be pinned, fixed, free or a combination.
- Steel member analysis and design are according to AISC 360-05.
- ASD or LRFD design methods can be selected.
- A complete steel section database is provided.
- Unbraced compression edge lengths can be specified in a variety of ways.
- Automatic member selection is provided.


### General Data

When steel is used, this tab includes input fields to set the values for yield stress and elastic modulus, as well as an option to set the  $C_b$  factor equal to 1, as shown in the screen capture below:



If  $C_b$  is not forced to 1, the program automatically calculates  $C_b$  based on the moment and direction of curvature at various locations along the beam.



For convenience the module includes a built-in steel database. Click the  button to the right of the  $F_y$  entry and you will see the following table, which offers a number of commonly used steel grades:

Steel Fy Selections

Click Item To Select . . .

Selection Steel Section Shape

W M S HP C MC L

W, HP, HSS-Rect Only

HSS - Rectangular

HSS - Round

Pipe Sections

Selected Fy = 50.00 ksi

Select

Cancel

Select ASTM Steel Designation

A-992, High Strength, Low Alloy : W

Fy = 50 ksi

Fy = 55 ksi

Fy = 60 ksi

Fy = 65 ksi

A-36, Carbon Steel . . . .

Fy = 36 ksi

A-529, Carbon Steel . . . .

Fy = 50 ksi

Fy = 55 ksi

A-572, High Strength, Low Alloy . . .

Fy = 42 ksi

Fy = 50 ksi

Fy = 55 ksi

Fy = 60 ksi

Fy = 65 ksi

A-913, High Strength, Low Alloy . . . .

Fy = 50 ksi

Fy = 60 ksi

Fy = 65 ksi

Fy = 70 ksi

A-242, Fy = 50 ksi, Corrosion Resistant, High Strength, Low Alloy

A-588, Fy = 50 ksi, Corrosion Resistant, High Strength, Low Alloy

### Beam Span Data

When steel is selected, the beam size selection is specifically for steel. You can select a section in 4 ways:


1 - Simply type the AISC name into the Steel Section Name field and press **[Tab]**.



2 - Click the database access button and select from the built-in AISC section database.

3 - Click the **[Design]** button to have the module evaluate steel sections from the database according to your criteria.

4 - Select a steel section from the Quick-List tab as shown below:



### Span Loads

No differences from other materials.

### Loads All Spans

No differences from other materials.

### Load Combinations

No differences from other materials.

### Results Tab

This set of tabs provides detailed results for the current calculation. The vertical tabs on the left edge of the screen allow you to select the three major areas available for review: Calculations, Sketch, and Diagram.

The Calculations tab offers the following results options:

**Summary Results** provides details for shear, moment and deflection for the governing load combinations.

Summary Results		Max. Combinations	M-V-D Summary	Support Reactions	Design OK					
✓ Extreme Bending Stress Ratio =	0.563 : 1			✓ Extreme Shear Stress Ratio =	0.180 : 1					
Section used for this span	W24X55			Section used for this span	W24X55					
Mu : Applied	282.881 k-ft			Vu : Applied	45.380 k					
Mn * Phi : Allowable	502.500 k-ft			Vn * Phi : Allowable	251.69 k					
Load Combination	+1.20D+0.50Lr+1.60L+1.60H			Load Combination	+1.20D+0.50Lr+1.60L+1.60H					
Location of maximum on span	12.500 ft			Location of maximum on span	25.000 ft					
Span # where maximum occurs	Span # 1			Span # where maximum occurs	Span # 1					
✓ Deflections for Min. Defl. Ratios (L+Lr) or (L+S) Deflection				Extreme Reactions ( service, kips )						
Max Downward	0.455 in Ratio = 660			D	Lr	L	S	W	E	H
Max Upward	-0.287 in Ratio = 416			Support #1	4.41		25.00			
Total Deflection				Support #2	4.74		25.00			
Max Downward	0.534 in Ratio = 561									
Max Upward	-0.337 in Ratio = 356									

**Max. Combinations** provides detailed results for each beam segment for each load combination. The leftmost column lists the load combinations and the unbraced length being considered.

These results are a consolidation of the highly detailed incremental results on the M-V-D Summary tab.

Load Combination - LRFD	Span	Max. Stress Ratios		Summary of Moment Values (k-ft)						Summary of Shear Values (k)			
		M	V	max Mu+	max Mu-	Mu max	Mnx	Phi*Mnx	Cb	Rm	Vu max	Vnx	Phi*Vnx
Overall MAXimum Envelope													
- Dsgn. L = 25.00 ft	1	0.563	0.180	282.881	-0.965	282.881	558.333	502.500	1.000	1.00	45.360	279.660	251.694
- Dsgn. L = 5.00 ft	2	0.002	0.002		-0.965	0.965	558.333	502.500	1.000	1.00	0.386	279.660	251.694
+1.40D													
- Dsgn. L = 25.00 ft	1	0.076	0.025	38.361	-0.965	38.361	558.333	502.500	1.000	1.00	6.254	279.660	251.694
- Dsgn. L = 5.00 ft	2	0.002	0.002		-0.965	0.965	558.333	502.500	1.000	1.00	0.386	279.660	251.694
+1.20D+0.50Lr+1.60L+													
- Dsgn. L = 25.00 ft	1	0.563	0.180	282.881	-0.827	282.881	558.333	502.500	1.000	1.00	45.360	279.660	251.694
- Dsgn. L = 5.00 ft	2	0.002	0.001		-0.827	0.827	558.333	502.500	1.000	1.00	0.331	279.660	251.694
+1.20D+1.60L+0.50S+													
- Dsgn. L = 25.00 ft	1	0.563	0.180	282.881	-0.827	282.881	558.333	502.500	1.000	1.00	45.360	279.660	251.694
- Dsgn. L = 5.00 ft	2	0.002	0.001		-0.827	0.827	558.333	502.500	1.000	1.00	0.331	279.660	251.694
+1.20D+1.60Lr+0.50L													
- Dsgn. L = 25.00 ft	1	0.221	0.071	111.006	-0.827	111.006	558.333	502.500	1.000	1.00	17.860	279.660	251.694

**M-V-D Summary- Stresses** shows highly detailed moment and shear information for each beam and for each load combination. For multi-span beams using Automatic Unbalanced Live Load Placement there may be thousands of lines of results.

LRFD/Strength Stress Combinations	Service Load Deflections	Compress Incremental Results			
Load Combination - LRFD	Span #	Distance (ft)	Shear : Vu (k)	Moment : Mu (k-ft)	Lu (ft)
Overall MAXimum Envelope					
+1.40D					
+1.20D+0.50Lr+1.60L+1.60H					
+1.20D+1.60L+0.50S+1.60H					
+1.20D+1.60Lr+0.50L					
+1.20D+0.50L+1.60S					
- span 1	1		17.794		Support Brace
- span 1	1	0.192	17.520	3.396	L = 25.00
- span 1	1	0.385	17.246	6.738	L = 25.00
- span 1	1	0.577	16.971	10.028	L = 25.00
- span 1	1	0.769	16.697	13.266	L = 25.00
- span 1	1	0.962	16.423	16.450	L = 25.00
- span 1	1	1.154	16.149	19.582	L = 25.00
- span 1	1	1.346	15.874	22.661	L = 25.00


**M-V-D Summary - Deflections** shows highly detailed deflection results for all load combinations.

LRFD/Strength Stress Combinations	Service Load Deflections	Compress Incremental Results		
Load Combination - Service	Span #	Distance (ft)	Deflection (in)	I-effective (in^4)
Overall MAXimum Envelope				
D Only				
- span 1	1			1,350.000
- span 1	1	0.192	0.011	1,350.000
- span 1	1	0.385	0.022	1,350.000
- span 1	1	0.577	0.033	1,350.000
- span 1	1	0.769	0.044	1,350.000
- span 1	1	0.962	0.055	1,350.000
- span 1	1	1.154	0.066	1,350.000
- span 1	1	1.346	0.077	1,350.000
- span 1	1	1.538	0.088	1,350.000
- span 1	1	1.731	0.099	1,350.000
- span 1	1	1.923	0.109	1,350.000


**Support Reactions** shows reactions for each support for each load condition.

Load Combination - Service		Support Force (k)
Overall Maximum		
Support 1, (D+L)		29,412
Support 2, (D+L)		29,743
Support 3, (D+L+S)		
D Only		
Support 1		4,412
Support 2		4,743
Support 3		
L Only		
Support 1		25,000
Support 2		25,000
Support 3		
D+L		
Support 1		29,412
Support 2		29,743
Support 3		

The Sketch tab provides a graphic representation of the beam currently being designed:



The Diagram tab offers the ability to view shear, moment, and deflection diagrams for selected load combinations:



## 10.2.5 Concrete Beam

[Need more? Ask Us a Question](#)

In this section, for each input tab we will review only the items that are unique to the CONCRETE material type. Click here for a video: [Concrete Beam](#)

### General Data

The concrete beam module handles single- and multiple-span beams using ONE cross section shape. That shape can have up to six groups of reinforcing per span, and the reinforcing can vary on a span-by-span basis.

This module also has a beam on elastic foundation option for single-span beams. In the screen capture below you can see the two large selection boxes. Selecting Single Span Beam on Elastic Foundation will remove the ability to select end support conditions, and it will provide an entry for the Modulus of Subgrade Reaction of the supporting soil.

On the right side of this tab are all the required rebar, concrete strength and elastic modulus entries, shear stirrup data, strength reduction factors and deflection criteria to check.

**NOTE:** It is important to know how this module operates with regard to beam stiffness along the span, and how this affects multi-span beams. This module divides each span into a series of segments. The effective moment of inertia for each segment (for each load combination) is calculated using the actual unfactored moment on that segment. Thus the module creates a very accurate variable stiffness model of the beam based on actual moments. For multiple-span beams, this will affect the relative stiffness of each beam span. Thus the moment distribution across multiple spans will be properly performed. This will affect factored load moments and shears and service load level deflections and reactions.

The screenshot shows the 'General Data' tab of a software application. The description is 'Sample Two-Span Concrete Beam'. The 'Beam Material' is set to 'Concrete'. The 'Support Type' is 'Single or Multi Span Beam with Varying Supports'. The 'Design Values' section includes the following inputs:

- $f_c$ : 3.0 ksi
- $f_r = f_c^{1/2}$ : 7.50
- $\Psi$  Density: 145.0 pcf
- $\lambda$  Lightweight Factor: 1.0
- E - Concrete: 3,122.0 ksi
- $E = 57000^* f_c^{1/2}$  and  $w^{1.5} * 33^* f_c^{1/2}$
- $\phi$ : Phi Values Flexure: 0.90
- Shear: 0.750
- $\beta_1$ : 0.850
- fy - Main Rebar: 60.0 ksi
- E - Main Rebar: 29,000.0 ksi
- fy - Stirrups: 60.0 ksi
- E - Stirrups: 29,000.0 ksi
- Stirrup Bar Size #: 3
- Number of Resisting Legs Per Stirrup: 2
- Max. Allow Live Load Deflection Ratio: 360.0
- Max. Allow Deflection Ratio: 180.0

### Beam Span Data

This tab has some pieces of input that are constant for all spans and some that can vary on a span-by-span basis.


The cross section shape and dimensions are the same for all spans.

When you click on a span (for multi-span beams) in the topmost section of the window, the span length and rebar layout will update to display the arrangement that is specific to that span.

On the right side of this tab you can specify up to 6 bar sets (quantity, size, vertical location and start/stop endpoints). Each bar set is referenced on the sketch with a color shown as a dot to the left of the set description.

The column highlighted in light blue titled "Dist of bar center....from...." is how you set the vertical position of the bar sets in the beam. When you look at the top one, you can read it as "*The top bar set is 3 inches from the bottom of the beam*". Note that the module will know whether the bars are in tension or compression and will handle the calculations properly.

The item labeled Bar Position This Span defines the starting and ending location of the bar ends with respect to the left end of each respective span. The data in the screen capture below shows that bar set #1 and #2 run from the left end (0.0 ft) to 25.0 ft from the left end of Span 1. Using these starting and ending locations you can fine tune the bar layout and end cutoffs.



	# Bars	Size #	Dist. of bar center....from...	Bar Position This Span Start (ft)	End
Bar Set #1	2	6	3	0.0	25.0 FL
Bar Set #2	2	6	4.25	0.0	25.0 FL
Bar Set #3					
Bar Set #4					
Bar Set #5					
Bar Set #6					

Note: The module will report an error message if any beam segments are found to be completely unreinforced. Therefore, it is imperative that the rebar be defined in such a way as to prevent completely unreinforced segments. This includes the short segments at the extreme ends of a beam, where rebar is typically terminated. Remember that this module is an analysis tool, not a detailing tool, so don't be tempted to define rebar as starting or ending short of the physical end of the beam. The button labeled "FL" adjacent to each rebar definition has been provided as a convenient way to indicate to the program that the selected rebar runs the Full Length of the span.

**Important:** Bars are assumed to be fully-effective at the locations where they are defined. This can be seen from the capacity diagram. So in situations where development must be considered, the user must understand this behavior and should define bar locations accordingly.

## Span Loads



No differences from other materials.

**All Span Loads**

No differences from other materials.

**Load Combinations**

No differences from other materials.

**Results Tabs**

This set of tabs provides detailed results for the current calculation. The vertical tabs on the left edge of the screen allow you to select the three major areas available for review: Calculations, Sketch, and Diagram.

The Calculations tab offers the following results options:

**Summary Results** provides details for shear, moment and deflection for the governing load combinations. Shear results are not shown here...they are summarized on a separate tab that gives the required stirrup layout.

Maximum Bending Stress Ratio = 0.909 : 1	
Section used for this span	Typical Section
Mu-x : Applied	-46.164 k-ft
Mn * Phi : Allowable	50.760 k-ft
Load Combination	+1.20D+0.50Lr+1.60L+1.60H
Location of maximum on span	0.000 ft
Span # where maximum occurs	Span # 2
Deflections for Min. Defl. Ratios (L+Lr) or (L+S) Deflection	
Max Downward	0.293 in Ratio = 1023
Max Upward	-0.013 in Ratio = 9012
Total Deflection	
Max Downward	0.424 in Ratio = 706
Max Upward	-0.024 in Ratio = 5027
Extreme Reactions ( service, kips )	
	D Lr L S W E H
Support #1	3.89 2.02
Support #2	9.73 5.17
Support #3	-0.28 -0.19

**Max. Combinations** provides detailed results for each beam segment for each load combination.

These results are a consolidation to the highly detailed incremental results on the M-V-D Summary tab.

Load Combination - LRFD	Length of this beam segment (ft)	Mu : Extreme	Phi*Minx	Stress Ratio
MAXIMUM BENDING Envelope				
- Span # 1	24.88	-44.793	50.760	0.882
- Span # 2	25.00	-46.164	50.760	0.909
+1.40D				
- Span # 1	24.88	-30.750	50.760	0.606
- Span # 2	25.00	-31.691	50.760	0.624
+1.20D+0.50Lr+1.60L+1.60H				
- Span # 1	24.88	-44.793	50.760	0.882
- Span # 2	25.00	-46.164	50.760	0.909
+1.20D+1.60L+0.50S+1.60H				
- Span # 1	24.88	-44.793	50.760	0.882
- Span # 2	25.00	-46.164	50.760	0.909
+1.20D+1.60Lr+0.50L				
- Span # 1	24.88	-32.118	50.760	0.633

**M-V-D Summary - LRFD/Strength Stress Combinations** shows highly detailed moment and shear results for each beam and for each load combination. For multi-

span beams using Automatic Unbalanced Live Load Placement there may be thousands of lines of results.

Load Combination - LRFD	Span #	Distance (ft)	Shear : Vu (k)	Moment (k-ft)	
				Mu	Mn * Phi
MAXIMUM BENDING Envelope					
MAXIMUM SHEAR Envelope					
+1.40D					
+1.20D+0.50Lr+1.60L+1.60H					
+1.20D+1.60L+0.50S+1.60H					
+1.20D+1.60Lr+0.50L					
+1.20D+0.50L+1.60S					
+1.20D+0.50Lr+0.50L+1.60W					
-span 1	1		5.645	0.000	57.995
-span 1	1	0.119	5.578	0.668	57.995
-span 1	1	0.238	5.512	1.328	57.995
-span 1	1	0.357	5.446	1.980	57.995
-span 1	1	0.476	5.379	2.625	57.995
-span 1	1	0.595	5.313	3.261	57.995

**M-V-D Summary - Service Load Deflections** shows highly detailed deflection results for all load combinations. When each load combination is expanded by clicking the [+] icon, you will see the deflections along the entire beam. You will also see the effective moment of inertia used in that region. (Remember that the effective moment of inertia is calculated based on service-level moments at many locations along the length of each span.)

Load Combination - Service	Span #	Distance (ft)	Deflection (in)	I-effective (in <sup>4</sup> )
Overall MAXIMUM Envelope				
D Only				
D Only				
L Only				
D+L				

"I-effective" is the "effective" moment of inertia used at this beam increment.

To calculate deflections an effective moment of inertia is calculated for the span increment using  $I_{cr}$  and  $I_{mactual}$  for that increment. The program also "knows" which side of the beam is in tension and uses the proper  $I_{cr}$  tracked for calculation of I-effective.

I-effective for the increment is calculated as  $I_g * (M_{cr} / M_u)^4 + I_{cr} * [1 - (M_{cr} / M_u)]^4$ .  $M_u$  is the service level moment at the beam increment. Note that research developed by Branson guided the ACI in creating their  $I_{eff}$  formula for an entire beam. Using the 4th power instead of a third power in the ACI equation is per Branson for calculating  $I_{eff}$  for detailed beam increments.

**M-V-D Summary - Cross Section Values** shows the moment capacities and moment of inertia for all of the identified cross sections. The module has examined all of the spans you defined and looked for identical reinforcing layouts. It has eliminated the duplicates, and for simplicity, it only lists the unique reinforced cross sections here.

Span #	Bar Layout Description	Phi*Mn (k-ft)		Inertia (in <sup>4</sup> )		
(from left)	('d' measured from top of beam down)	Btm Tens	Top Tens	Igross	Icr-Btm Tens	Icr-Top Tens
Section 1	2- #6 @ d=15", 2- #6 @ d=4.25",	58.00	50.76	4,860.00	1,200.43	996.65
Section 2	2- #6 @ d=15", 2- #6 @ d=4.25",	58.00	50.76	4,860.00	1,200.43	996.65

Program identifies all unique cross sections for length of beam. These cross sections may occur at more than one location.

**M-V-D Summary - Design Shear** shows the shear stirrup requirements along the span(s) as required by the governing load combinations that generate the highest shear at each section.


The column labeled Comment indicates the ACI code condition that governs the requirement for shear reinforcing at each design location.

Load Combination - MAX Envelope	Span #	Distance (ft)	d' (in)	Vu (k)	Actual	Design	Mu	d*Vu/Mu	Phi Vc	Capacity & Stirrup Spacing (k)	Comment	Req'd PhiVs	Code Req'd Spacing (in)	Suggested Spacing (in)
+1.20D+1.60L+0.50S+1.60H	1	15.000	15.000	7.872	7.872	7.872	0.00	1.000	15.008	PhiVc/2 < Vu <= PhiVc	Min 11.5.5.1	7.5	7.0	
+1.20D+1.60L+0.50S+1.60H	1	0.119	15.000	7.780	7.780	7.780	0.93	1.000	15.008	PhiVc/2 < Vu <= PhiVc	Min 11.5.5.1	7.5	7.0	
+1.20D+1.60L+0.50S+1.60H	1	0.238	15.000	7.687	7.687	7.687	1.85	1.000	15.008	PhiVc/2 < Vu <= PhiVc	Min 11.5.5.1	7.5	7.0	
+1.20D+1.60L+0.50S+1.60H	1	0.357	15.000	7.595	7.595	7.595	2.76	1.000	15.008	PhiVc/2 < Vu <= PhiVc	Min 11.5.5.1	7.5	7.0	
+1.20D+1.60L+0.50S+1.60H	1	0.476	15.000	7.502	7.502	7.502	3.66	1.000	15.008	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	0.595	15.000	7.409	7.409	7.409	4.55	1.000	15.008	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	0.714	15.000	7.317	7.317	7.317	5.42	1.000	15.008	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	0.833	15.000	7.224	7.224	7.224	6.29	1.000	15.008	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	0.952	15.000	7.132	7.132	7.132	7.14	1.000	15.008	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	1.071	15.000	7.039	7.039	7.039	7.99	1.000	15.008	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	1.190	15.000	6.947	6.947	6.947	8.82	0.984	14.956	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	1.310	15.000	6.854	6.854	6.854	9.64	0.889	14.640	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	1.429	15.000	6.761	6.761	6.761	10.45	0.809	14.376	Vu < PhiVc/2	Not Reqd	0.0	0.0	
+1.20D+1.60L+0.50S+1.60H	1	1.548	15.000	6.669	6.669	6.669	11.25	0.741	14.152	Vu < PhiVc/2	Not Reqd	0.0	0.0	


**Support Reactions** shows reactions for each support for each load condition.

Load Combination - Service	Support Force (k)
Span Name	
Overall MAXimum	
- Support 1, (D+L)	5,914
- Support 2, (D+L)	14,901
- Support 3, (D+L)	-0,472
D Only	
- Support 1	3,891
- Support 2	9,733
- Support 3	-0,280
L Only	
- Support 1	2,025
- Support 2	5,162
- Support 3	-0,187
D+L	
- Support 1	5,914
- Support 2	14,901
- Support 3	-0,472

The Sketch tab provides a graphic representation of the beam currently being designed:



The Diagram tab offers the ability to view shear, moment, and deflection diagrams for selected load combinations:



## 10.2.6 Beam on Elastic Foundation

[Need more? Ask Us a Question](#)

The Beam on Elastic Foundation module is a single-span version of the Concrete Beam module that provides special support conditions to represent an idealized, compression-only, continuous elastic support.

The significant variation between the Beam on Elastic Foundation module and the Concrete Beam module is the fact that the Beam on Elastic Foundation module collects a Soil Subgrade Modulus for use in modeling the spring support.

***Note: This module will stop if it finds any locations where the soil springs tend to go into tension, so be sure to use realistic load combinations. For instance, don't run +W Only or +Lr Only, without the corresponding dead load that would also be applied concurrently.***

Refer to the Concrete Beam module information in this document for other details.

## 10.2.7 Composite Steel Beam

### [Need more? Ask Us a Question](#)

This module provides analysis and design of AISC steel sections acting compositely with a concrete slab that is continuously connected to the compression flange of the beam with suitable shear connectors. Click here for a video: [Composite Steel Beam](#)

Features of the module include:

- The concrete slab can be either full depth or cast over formed steel decking, with rib orientation perpendicular or parallel to the beam.
- Stud capacity can be calculated by the module using standard AISC procedure.
- Normal or lightweight concrete may be used for both strength and deflection calculations.
- Both shored and unshored construction techniques can be analyzed by the module.
- ASD or LRFD design methods can be chosen.
- Flexible specification of shear studs is available.
- Very flexible loading specification, including the ability to specify construction loads (applied to pre-composite checks only), loads that apply to both the pre-composite and post-composite checks (always applied), and loads that are only applicable to the post-composite checks (applied after curing).
- Extensive load combination capability.
- Can use many sections from the AISC databases.


The screenshot displays the 'Composite Steel Beam' software interface. The main window shows a 30.0 ft span and a W14x26 steel section. The 'Composite Data' section includes: Total Slab Thickness (7.50 in), Effective Width (10.0 ft), Slab on Metal Deck (checked), Rib Measurements (Height: 2.0 in, Spacing: 12.0 in, Opening Width @ Top: 7.0 in, Opening Width @ Btm: 5.0 in), Stud Diameter (3/4"), Qn : Stud Capacity (17.24 k), Concrete Fc (4.0 ksi), and Concrete Density (145.0 pcf). The 'Design Values' section shows Fy : Steel Yield (50.0 ksi), E: Modulus (29,000.0 ksi), and Max. Allow Deflection Ratios (Total Loads = 180.0, Live Load = 360.0). The 'Partial Composite Action' section has 'Full Composite' selected. The 'Summary Results' section shows: Maximum Bending Stress Ratio = 0.463 : 1 (Section used for this span: W14x26, Percent Composite Action: 100%), Maximum Shear Stress Ratio = 0.233 : 1 (Section used for this span: W14x26), Vu : Applied (16.545 k), Vn/Omega : Allowable (70.890 k), Load Combination (span 1), Location of maximum on span (0.0 ft), and Span # where maximum occurs (Span # 1). Deflections for Min. Defl. Ratios are also listed: Max Downward Pre-Composite Deflection (0.267 in), Max Upward Pre-Composite Deflection (0.000 in), Pre-Composite Deflection Ratio (1348), Max Downward Composite Deflection (0.905 in), Max Upward Composite Deflection (0.000 in), and Composite Deflection Ratio (398).


### General Data Tab

This tab gathers all input except for the beam section size and loads.

The Analysis Method category offers an option of ASD or LRFD methods.

The Composite Data category offers all of the necessary input fields to completely specify the slab, its effective width, stud information and metal deck specification (if applicable).



For Qn you can enter the value directly or click the  button to display the stud capacity calculation dialog:

**Stud Capacity Calculation per AISC 360-05 B.2.d**

Stud Diameter 3/4"

$$Q_n = 0.5 A_{sc} \sqrt{f_c E_c} \leq R_g R_p A_{sc} F_u$$

A <sub>sc</sub> (from diameter)	=	0.442 in <sup>2</sup>
f <sub>c</sub> : Concrete Strength	=	4.00 ksi
E <sub>c</sub> : Concrete Modulus	=	3,492.06 ksi
F <sub>u</sub> : Stud Tensile Strength	=	<input type="text" value="65.0"/> ksi

R<sub>g</sub> :  ▼

R<sub>p</sub> : 0.60 : Perpendicular Deck

Q <sub>n</sub> Max = R <sub>g</sub> R <sub>p</sub> A <sub>sc</sub> F <sub>u</sub>	=	17.24 k
Q <sub>n</sub> = 0.5 A <sub>sc</sub> √f <sub>c</sub> E <sub>c</sub>	=	26.12


**Q<sub>n</sub>      17.24 k**


---

✗
Quit

✓
 Use Calc'd Q<sub>n</sub>

When you click the checkbox for Slab on Metal Deck, the associated input fields appear to allow the selection of a manufactured deck product, or the manual specification of the required deck properties.

Click the  button to display the metal deck selection window as shown below, or simply enter the deck cross section data in the dimension input fields:



### Partial Composite Action

This category provides three ways to have the module calculate stud requirements.

**Full Composite** tells the module to use the number of studs necessary to provide full  $V_h$  shear resistance for the slab to beam connection.

**Specify % Composite** allows the user to enter a percentage of maximum composite action. The module will then determine the number of studs needed for that  $V_h$  and complete the bending capacity calculations.

**Calc Min Studs** tells the module to calculate the minimum number of studs (greater than 25% composite per code recommendations) that will adequately supply the required moment capacity based on the applied moment.


### Beam Span Data Tab

This is basically the same tab used for a normal steel beam except that there is no ability to specify unbraced compression flange lengths. For regions of positive moment, the top



flange is considered to be continuously braced by its composite connection to the concrete slab.

Note: Use caution in situations where the applied loading may result in regions of negative moment, because this module considers the bottom flange to be continuously braced.



### Span Loads Tab

This tab is basically the same as the normal load entry for other beam design modules except for two differences:

- 1- There are two checkboxes that allow the user to indicate whether the module should automatically calculate and apply the beam self weight and slab self weight.
- 2- There are three "Load Application" options that allow the user to specify the sequencing of the specified loads as follows:

- **Non-Composite Only (Construction):** Dead Load and/or Live Load that will be considered in the pre-composite checks, but not in the post-composite checks.

Use this load application type to specify temporary Construction Live Load or Construction Dead Load that will be removed before the concrete cures. Do NOT use this load application type to specify permanent loads like the weight of the concrete fill on the metal deck. That type of load should be specified using the next option.

- **Pre & Post Composite (Always applied):** Dead Load that will be considered in the pre-composite AND the post-composite checks.

Use this option for loads that will be in place while the section is non-composite and will REMAIN in place after composite action is achieved. Examples might include the weight of the concrete fill on the metal deck or the self-weight of the steel beam.

- **Post Composite Only (Applied after curing):** Any type of load that will be superimposed on the cured composite section. These will only be considered in the post-composite checks.

Use this option for loads that will be placed on the structure only after composite action has developed. Some examples might include the weight of architectural floor finishes or the weight of permanent mechanical equipment.

Span #	Load Type	Trib. (ft)	D (ksf)	Lr (ksf)	L (ksf)	S (ksf)	W (ksf)	E (ksf)	H (ksf)	Load Application
1	Full Uniform	8.000	0.020							Non-Composite Only
1	Full Uniform	8.000	0.0540							Pre & Post Composite
1	Full Uniform	8.000	0.0260		0.080					Post Composite Only

## Load Combinations Tab

The function of the Load Combinations tab in the Composite Steel Beam module is the same as in other beam modules.

**Results Tabs:** This set of tabs provides detailed results for the current calculation. The vertical tabs on the left edge of the screen allow the user to select the three major areas available for review: Calculations, Sketch, and Diagram.

The Calculations tab offers the following results options:

**Summary Results** tab presents the maximum/governing ratio values from all of the results presented on the Max. Combinations tab. The module looks for the maximum bending stress ratio and presents the components that are calculated to create that ratio.

For the bending stress item the module reports the Construction bending ratio which considers all loads specified to be applied to the beam before curing. The resulting moment is compared to the capacity of the steel section acting alone (non-compositely).

For the item reported as Governing Values, the module considers all loads specified to be applied to the composite section. That moment is then compared to the full composite section moment capacity for the percentage of shear connection specified.

The results indicate the load combination that creates the governing values along with the span id and location at which the governing ratio was found to occur.

The module calculates the maximum total deflection as the sum of the deflection of the non-composite steel section resisting all of the loads that are specified as Pre & Post Composite (Always applied) plus the deflection of the composite section resisting all of the loads that are specified as Post Composite Only (Applied after curing).

Note! The screen shown below which gives information for Construction loads is only for unshored beams. For shored beams the Construction portion of moments is not applicable, so it is not shown.

**Summary Results** | Max. Combinations | Studs | M-V-D Summary | Deflections | Reactions | Properties | **Design OK**

**Maximum Bending Stress Ratio = 0.463 : 1**  
 Section used for this span: **W14x26**  
 Percent Composite Action: **100 %**

	Pre-Composite	Composite
Mu : Applied	11.588	124.088 k-ft
Mn / Omega : Allowable	100.299	268.206 k-ft

Load Combination: **Post Composite : +D+L+H**  
 Location of maximum on span: **15.0 ft**  
 Span # where maximum occurs: **Span # 1**

**Maximum Shear Stress Ratio = 0.233 : 1**  
 Section used for this span: **W14x26**

Vu : Applied	16.545k
Vn/Omega : Allowable	70.890k

Load Combination: **span 1**  
 Location of maximum on span: **0.0 ft**  
 Span # where maximum occurs: **Span # 1**

For Maximum Support Reactions ---> See tabular results

**Deflections for Min. Defl. Ratios**

Max Downward Pre-Composite Deflection	0.267 in
Max Upward Pre-Composite Deflection	0.000 in
Pre-Composite Deflection Ratio	1348
Max Downward Composite Deflection	0.905 in
Max Upward Composite Deflection	0.000 in
Composite Deflection Ratio	398

**Max Combinations** tab presents in more concise detail the bending and shear values for all load combinations. The display varies depending upon which Stress Method is selected.

Here is a view of the summary of unshored result values when "AISC 360-05" is selected in the Stress Method category:

**Summary Results** | **Max. Combinations** | Studs | M-V-D Summary | Deflections | Reactions | Properties | **Design OK**

Load Combination - ASD Unshored Beam Segment	Span	Max. Stress Ratios		Bending Summary (k-ft)		Shear Summary (k)	
		M	V	Ma Applied	Mn/Omega	Va Applied	Vn/Omega
Pre Composite : D + Const L Span L = 30 ft	1	0.116	0.022	11.588	100.299	1.545	70.890
Post Composite : +D Span L = 30 ft	1	0.043	0.022	11.588	268.206	1.545	70.890
Post Composite : +D+L+H Span L = 30 ft	1	0.463	0.233	124.088	268.206	16.545	70.890
Post Composite : +D+Lr+H Span L = 30 ft	1	0.043	0.022	11.588	268.206	1.545	70.890
Post Composite : +D+S+H Span L = 30 ft	1	0.043	0.022	11.588	268.206	1.545	70.890
Post Composite : +D+0.750Lr+0.750L Span L = 30 ft	1	0.358	0.180	95.963	268.206	12.795	70.890
Post Composite : +D+0.750L+0.750L Span L = 30 ft	1	0.358	0.180	95.963	268.206	12.795	70.890

Ma Applied is the moment demand on the section due to the referenced load combination.

Mn/Omega is the moment capacity of the section at the stage of loading indicated by the referenced load combination (either pre-composite or post-composite condition).

(When LRFD is used, the allowable nomenclature will change to the Mn value times Phi.)

Here is a view of the summary of shored result values when "AISC 360-05" is selected in the Stress Method category:

Load Combination - ASD Shored	Span	Max. Stress Ratios		Bending Summary (k-ft)		Shear Summary (k)	
Beam Segment		M	V	Ma Applied	Mn/Omega	Va Applied	Vn/Omega
Overall Maximums							
Span L = 30 ft	1	0.463	0.233	124.082	268.206	16.545	70.890
+D							
Span L = 30 ft	1	0.043	0.022	11.587	268.206	1.545	70.890
+D+L+H							
Span L = 30 ft	1	0.463	0.233	124.082	268.206	16.545	70.890
+D+Lr+H							
Span L = 30 ft	1	0.043	0.022	11.587	268.206	1.545	70.890
+D+S+H							
Span L = 30 ft	1	0.043	0.022	11.587	268.206	1.545	70.890
+D+0.750Lr+0.750L+H							
Span L = 30 ft	1	0.358	0.180	95.958	268.206	12.795	70.890
+D+0.750L+0.750S+H							
Span L = 30 ft	1	0.358	0.180	95.958	268.206	12.795	70.890

**Studs** tab presents the shear connector requirements for all span sections. When point loads are present, this chart may list more detailed spacing requirements because of the shear change between applied point loads.

Span	Studs
From Support 1 @ to 15.00 ft	use 16 studs.
From 15.00 ft to Support 2	use 16 studs.

**M-V-D Summary** presents moment, shear, and deflection results. Four screen captures of this tab are shown below. Depending upon the Analysis Method selection (ASD or LRFD) and the shoring selection (shored or unshored), these lists will present different values and headings.

Note: There will also be subtle differences in these displays depending on which option the user has selected for the Stress Method ("AISC 360-05" or "Prior Method"). Since the "Prior Method" is being offered as a transition aid for a limited time, the screen captures below are all based on the AISC 360-05 Stress Method:

ASD/Service Stress Combinations - SHORED:

Summary Results Max. Combinations Studs M-V-D Summary Deflections Reactions Properties Design OK

ASD/Service Stress Combinations Expand Incremental Results

Load Combination - ASD - Shored	Span #	Distance (ft)	Max Ratio	% Composite	Bending Summary (k-ft)						Shear Summary (k)	
Span Name			M	V	Ma	Mn	I3-2a Type	Omega	Mn/Omega	Va	Vn/Omega	
Overall Maximums												
+D												
+D+H												
span 1	1			0.35	100	187.34	Plastic	1.67	187.34	21.931	63.020	
span 1	1	0.20	0.02	0.34	100	4.39	187.34	1.67	187.34	21.637	63.020	
span 1	1	0.40	0.05	0.34	100	8.71	187.34	1.67	187.34	21.343	63.020	
span 1	1	0.60	0.07	0.33	100	12.98	187.34	1.67	187.34	21.048	63.020	
span 1	1	0.81	0.09	0.33	100	17.19	187.34	1.67	187.34	20.754	63.020	
span 1	1	1.01	0.11	0.32	100	21.34	187.34	1.67	187.34	20.459	63.020	
span 1	1	1.21	0.14	0.32	100	25.43	187.34	1.67	187.34	20.165	63.020	
span 1	1	1.41	0.16	0.32	100	29.46	187.34	1.67	187.34	19.871	63.020	
span 1	1	1.61	0.18	0.31	100	33.43	187.34	1.67	187.34	19.576	63.020	
span 1	1	1.81	0.20	0.31	100	37.34	187.34	1.67	187.34	19.282	63.020	
span 1	1	2.01	0.22	0.30	100	41.19	187.34	1.67	187.34	18.988	63.020	
span 1	1	2.21	0.24	0.30	100	44.99	187.34	1.67	187.34	18.693	63.020	
span 1	1	2.42	0.26	0.29	100	48.72	187.34	1.67	187.34	18.399	63.020	
span 1	1	2.62	0.28	0.29	100	52.40	187.34	1.67	187.34	18.104	63.020	
span 1	1	2.82	0.30	0.28	100	56.01	187.34	1.67	187.34	17.810	63.020	
span 1	1	3.02	0.32	0.28	100	59.57	187.34	1.67	187.34	17.516	63.020	
span 1	1	3.22	0.34	0.27	100	63.06	187.34	1.67	187.34	17.221	63.020	
span 1	1	3.42	0.35	0.27	100	66.50	187.34	1.67	187.34	16.927	63.020	

ASD/Service Stress Combinations - UNSHORED:

Summary Results Max. Combinations Studs M-V-D Summary Deflections Reactions Properties Design N.G.

ASD/Service Stress Combinations Expand Incremental Results

Load Combination - ASD - Unshored	Span #	Distance ft	Mu : Pre-Comp loads (ft-k)	Mu : Construction removed (ft-k)	Mu : Post-Comp loads (ft-k)	Mu : Final	Mn	I3-2a Type	% Comp	Omega	Mn/Omega	Ratio	Va
Overall Maximums													
Post Composite : +D													
Post Composite : +D+H+H													
span 1	1		1.83	-0.48	3.40	4.76	312.87	Plastic	100	1.67	187.34	0.418	26.342
span 1	1	0.200	3.64	-0.95	6.76	9.45	312.87	Plastic	100	1.67	187.34	0.412	25.992
span 1	1	0.600	5.42	-1.41	10.07	14.08	312.87	Plastic	100	1.67	187.34	0.407	25.642
span 1	1	1.000	7.17	-1.87	13.34	18.64	312.87	Plastic	100	1.67	187.34	0.401	25.292
span 1	1	1.400	8.90	-2.32	16.56	23.14	312.87	Plastic	100	1.67	187.34	0.396	24.938
span 1	1	1.800	10.61	-2.76	19.74	27.58	312.87	Plastic	100	1.67	187.34	0.390	24.587
span 1	1	2.200	12.29	-3.20	22.86	31.96	312.87	Plastic	100	1.67	187.34	0.385	24.233
span 1	1	2.600	13.95	-3.64	25.95	36.27	312.87	Plastic	100	1.67	187.34	0.379	23.884
span 1	1	3.000	15.59	-4.06	28.99	40.51	312.87	Plastic	100	1.67	187.34	0.373	23.535
span 1	1	2.000	17.19	-4.48	31.98	44.69	312.87	Plastic	100	1.67	187.34	0.368	23.182
span 1	1	2.200	18.78	-4.89	34.93	48.81	312.87	Plastic	100	1.67	187.34	0.362	22.830
span 1	1	2.400	20.34	-5.30	37.83	52.87	312.87	Plastic	100	1.67	187.34	0.357	22.475
span 1	1	2.600	21.87	-5.70	40.68	56.86	312.87	Plastic	100	1.67	187.34	0.351	22.122
span 1	1	2.800	23.38	-6.09	43.49	60.78	312.87	Plastic	100	1.67	187.34	0.346	21.777
span 1	1	3.000	24.87	-6.48	46.25	64.65	312.87	Plastic	100	1.67	187.34	0.340	21.425
span 1	1	3.200	26.33	-6.86	48.97	68.44	312.87	Plastic	100	1.67	187.34	0.334	21.074
span 1	1	3.400	27.78	-7.23	51.64	72.17	312.87	Plastic	100	1.67	187.34	0.328	20.722

LRFD/Strength Stress Combinations - SHORED:

Summary Results Max. Combinations Studs M-V-D Summary Deflections Reactions Properties Design OK

LRFD/Strength Stress Combinations Expand Incremental Results

Load Combination - LRFD - Shored	Span #	Distance (ft)	Max Ratio	% Composite	Bending Summary (k-ft)						Shear Summary (k)	
Span Name			M	V	Mu	Mn	I3-2a Type	Phi	Mn * Phi	Vu	Vn * Phi	
Overall Maximums												
+1.40D												
+1.20D+0.50Lr+1.60L+1.60H												
span 1	1		0.32	100	281.58	Plastic	0.90	281.58	30.158		94.530	
span 1	1	0.201	0.02	0.31	100	6.03	281.58	0.90	281.58	29.753	94.530	
span 1	1	0.403	0.04	0.31	100	11.98	281.58	0.90	281.58	29.348	94.530	
span 1	1	0.604	0.06	0.31	100	17.85	281.58	0.90	281.58	28.943	94.530	
span 1	1	0.805	0.08	0.30	100	23.64	281.58	0.90	281.58	28.538	94.530	
span 1	1	1.007	0.10	0.30	100	29.34	281.58	0.90	281.58	28.134	94.530	
span 1	1	1.208	0.12	0.29	100	34.97	281.58	0.90	281.58	27.729	94.530	
span 1	1	1.409	0.14	0.29	100	40.51	281.58	0.90	281.58	27.324	94.530	
span 1	1	1.611	0.16	0.28	100	45.97	281.58	0.90	281.58	26.919	94.530	
span 1	1	1.812	0.18	0.28	100	51.35	281.58	0.90	281.58	26.514	94.530	
span 1	1	2.013	0.20	0.28	100	56.64	281.58	0.90	281.58	26.110	94.530	
span 1	1	2.215	0.22	0.27	100	61.86	281.58	0.90	281.58	25.705	94.530	
span 1	1	2.416	0.24	0.27	100	67.00	281.58	0.90	281.58	25.300	94.530	
span 1	1	2.617	0.26	0.26	100	72.05	281.58	0.90	281.58	24.895	94.530	
span 1	1	2.819	0.27	0.26	100	77.02	281.58	0.90	281.58	24.490	94.530	
span 1	1	3.020	0.29	0.25	100	81.91	281.58	0.90	281.58	24.086	94.530	
span 1	1	3.221	0.31	0.25	100	86.72	281.58	0.90	281.58	23.681	94.530	

LRFD/Strength Stress Combinations - UNSHORED:

Load Combination - LRFD - Unshored	Span #	Distance ft	Mu : Pre-Comp loads (ft-k)	Mu : Construction removed (ft-k)	Mu : Post-Comp loads (ft-k)	Mu : Final	Mn	I3.2a Type	% Comp	Phi	Mn * Phi	Linear Summary (k)	Ratio	Value
Pre Composite : 1.40D														
Post Composite : 1.20D + 1.60Const L														
Post Composite : +1.40D														
Post Composite : +1.20D+0.50Lr+1.60L+														
Post Composite : +1.20D+1.60L+0.50S+														
-span 1	1		2.86	-0.69	4.73	6.91	312.87	Plastic	100	0.90	281.58	0.405	38.2	
-span 1	1	0.200	5.69	-1.36	9.40	13.73	312.87	Plastic	100	0.90	281.58	0.399	37.7	
-span 1	1	0.400	8.48	-2.03	14.01	20.45	312.87	Plastic	100	0.90	281.58	0.388	36.7	
-span 1	1	0.600	11.23	-2.69	18.55	27.08	312.87	Plastic	100	0.90	281.58	0.383	36.1	
-span 1	1	0.800	13.94	-3.34	23.03	33.62	312.87	Plastic	100	0.90	281.58	0.378	35.6	
-span 1	1	1.000	16.61	-3.98	27.44	40.07	312.87	Plastic	100	0.90	281.58	0.372	35.1	
-span 1	1	1.200	19.24	-4.61	31.79	46.42	312.87	Plastic	100	0.90	281.58	0.367	34.6	
-span 1	1	1.400	21.84	-5.23	36.08	52.68	312.87	Plastic	100	0.90	281.58	0.361	34.1	
-span 1	1	1.600	24.39	-5.85	40.31	58.85	312.87	Plastic	100	0.90	281.58	0.356	33.6	
-span 1	1	1.800	26.91	-6.45	44.47	64.93	312.87	Plastic	100	0.90	281.58	0.351	33.1	
-span 1	1	2.000	29.39	-7.05	48.56	70.91	312.87	Plastic	100	0.90	281.58	0.345	32.6	
-span 1	1	2.200	31.83	-7.63	52.60	76.80	312.87	Plastic	100	0.90	281.58	0.340	32.1	
-span 1	1	2.400	34.23	-8.21	56.57	82.60	312.87	Plastic	100	0.90	281.58	0.334	31.6	
-span 1	1	2.600	36.60	-8.77	60.48	88.30	312.87	Plastic	100	0.90	281.58	0.329	31.1	

Deflections tab has two versions, one for shored and one for unshored construction. The only differences are the load combinations and the explanations of load applications listed.

Service Deflections - SHORED:

Load Combination - Service - Shored	Span #	Distance (ft)	Deflection (in)	Ixx Used (in <sup>4</sup> )
Lr Only				
L Only				
S Only				
Lr+L+S				
-span 1	1	0.201	0.014	633.4
-span 1	1	0.403	0.027	633.4
-span 1	1	0.604	0.041	633.4
-span 1	1	0.805	0.055	633.4
-span 1	1	1.007	0.068	633.4
-span 1	1	1.208	0.082	633.4
-span 1	1	1.409	0.095	633.4
-span 1	1	1.611	0.109	633.4
-span 1	1	1.812	0.122	633.4
-span 1	1	2.013	0.135	633.4
-span 1	1	2.215	0.149	633.4
-span 1	1	2.416	0.162	633.4
-span 1	1	2.617	0.175	633.4
-span 1	1	2.818	0.188	633.4

Service Deflections - UNSHORED:

Load Combination - Service - Unshored	Span #	Distance (ft)	Deflections (in)				Ixx Used
			Pre-Composite	Const Loads Removed	Added Post Composite	Total	
Precomposite							
Precomposite minus Construction							
Postcomposite : D + Lr							
Postcomposite : D + L							
Postcomposite : D + Lr + L							
-span 1	1	0.200	0.041	-0.012	0.018	0.048	633.4
-span 1	1	0.400	0.083	-0.025	0.037	0.095	633.4
-span 1	1	0.600	0.124	-0.037	0.055	0.143	633.4
-span 1	1	0.800	0.165	-0.049	0.074	0.190	633.4
-span 1	1	1.000	0.207	-0.061	0.092	0.237	633.4
-span 1	1	1.200	0.248	-0.073	0.110	0.284	633.4
-span 1	1	1.400	0.289	-0.086	0.128	0.332	633.4
-span 1	1	1.600	0.329	-0.098	0.147	0.378	633.4
-span 1	1	1.800	0.370	-0.110	0.165	0.425	633.4
-span 1	1	2.000	0.411	-0.122	0.183	0.472	633.4
-span 1	1	2.200	0.451	-0.134	0.201	0.518	633.4
-span 1	1	2.400	0.491	-0.146	0.219	0.564	633.4

In the Unshored Service Deflections table, the columns warrant some detailed explanation:

The column labeled "Pre-Composite" shows the deflection of the bare steel beam subjected to all loads that are specified to act on the bare steel beam. This would include


all loads defined using the "Non-Composite (Construction)" option and all loads defined using the "Pre & Post Composite (Always Applied)" option on the Span Loads tab.

The column labeled "Construction Loads Removed" shows the deflection of the bare steel beam due all loads defined using the "Non-Composite (Construction)" option on the Span Loads tab. Since these loads are removed before the beam reaches its service condition, these construction load deflections are removed from the total deflection, so that the Total deflection represents a correct net total deflection in the service condition.

The column labeled "Added Post Composite" shows the deflection of the composite section due to the loads that are superimposed on the section after it has achieved composite action. This would include all loads defined using the "Post Composite Only (Applied after curing)" option on the Span Loads tab.

The column labeled "Total" is calculated by adding the value in the "Pre-Composite" column to the value in the "Added Post Composite" column and then netting out the value in the "Construction Loads Removed" column. This way, the "Total" deflection represents the full anticipated in-service deflection considering all permanent loads and properly accounting for their sequence of application.

**Reactions** tab has two versions, one for shored and one for unshored construction. The only differences are the load combinations and the explanations of load applications listed.



Load Combination - Service	Support Force (k)
Overall MAXimum	
Support 1, (Postcomposite : D + L)	15.783
Support 2, (Postcomposite : D + L)	15.783
Precomposite Loads	
Support 1	9.211
Support 2	9.211
Precomposite minus Construction	
Support 1	2.731
Support 2	2.731
Postcomposite : D + Lr	
Support 1	6.183
Support 2	6.183
Postcomposite : D + L	
Support 1	15.783
Support 2	15.783
Postcomposite : D + Lr + L	
Support 1	15.783
Support 2	15.783
Postcomposite : D + L + S	
Support 1	15.783
Support 2	15.783
Postcomposite : D + L + W + S/2	
Support 1	15.783

**Properties** tab shows the calculations for transformed section properties calculated in increments of 1% shear connection, from 100% down to the code minimum 25%. "I Lower Bound" and "I Constant Stiffness" are terms described in AISC 360-05.

Summary Results | Max. Combinations | Studs | M-V-D Summary | Deflections | Reactions | Properties | Design N.G.


Section Properties for 25% to 100% Composite Action

Span Number	Analysis Shear %	Type	Connection	Plastic N.A. from Bottom	Sum On Shear (k)	# Studs 1/2 Span	Mn - Capacity kft	I - Steel	I - Trans	I - Lwr Bound	Moment of Inertia I - Const Stiff **
Span 1											
-	PNA in Slab	Plastic	100	17.890	324.500	16	312.866	199.00	853.97	633.37	459.62
-	PNA in Flange	Plastic	99	13.694	321.255	16	321.935	199.00	853.97	631.59	458.55
-	PNA in Flange	Plastic	98	13.687	318.010	16	320.573	199.00	853.97	629.78	457.47
-	PNA in Flange	Plastic	97	13.681	314.765	15	319.210	199.00	853.97	627.94	456.36
-	PNA in Flange	Plastic	96	13.674	311.520	15	317.844	199.00	853.97	626.07	455.24
-	PNA in Flange	Plastic	95	13.668	308.275	15	316.478	199.00	853.97	624.18	454.11
-	PNA in Flange	Plastic	94	13.661	305.030	15	315.109	199.00	853.97	622.26	452.95
-	PNA in Flange	Plastic	93	13.655	301.785	15	313.740	199.00	853.97	620.31	451.79
-	PNA in Flange	Plastic	92	13.648	298.540	15	312.368	199.00	853.97	618.33	450.60
-	PNA in Flange	Plastic	91	13.642	295.295	15	310.995	199.00	853.97	616.33	449.40
-	PNA in Flange	Plastic	90	13.635	292.050	14	309.621	199.00	853.97	614.29	448.18
-	PNA in Flange	Plastic	89	13.629	288.805	14	308.245	199.00	853.97	612.23	446.94
-	PNA in Flange	Plastic	88	13.622	285.560	14	306.868	199.00	853.97	610.13	445.68
-	PNA in Flange	Plastic	87	13.616	282.315	14	305.489	199.00	853.97	608.01	444.40
-	PNA in Flange	Plastic	86	13.609	279.070	14	304.108	199.00	853.97	605.85	443.11
-	PNA in Flange	Plastic	85	13.603	275.825	14	302.726	199.00	853.97	603.66	441.80
-	PNA in Flange	Plastic	84	13.596	272.580	13	301.343	199.00	853.97	601.44	440.46
-	PNA in Flange	Plastic	83	13.590	269.335	13	299.958	199.00	853.97	599.19	439.11


\*\* Ref Equation AISC 360-05 (C-13-2) with a = 0.6 and b = 0.4

The Sketch tab provides two ways to view a graphic representation of the beam currently being designed:

Span & Loads tab:




Cross Section tab:



The Diagram tab offers the ability to view shear, moment, and deflection diagrams for selected load combinations:





## 10.2.8 Wood Ledger

### [Need more? Ask Us a Question](#)

The wood ledger module provides the ability to calculate moments and shears in the ledger, as well as actual and allowable bearing loads on the attaching bolts.

The module allows the ledger to be attached to concrete or another wood member, and it automatically calculates the proper allowable bolt values.

All calculations are according to 2005 NDS and either 2006 IBC or 2009 IBC. Allowable bolt capacity at an angle to the grain is calculated using Hankinson's formula.

**Wood Ledger**

General | Loads | D+L+? Load Combinations

Description: Sample Wood Ledger Calc

Design Method: ASD | LRFD

Wood Stress Grade: Douglas Fir - Larch (North), No. 1/No. Fb: 850.0 psi, Fv: 180.0 psi, CM - Wet Service Factor: 1.0, Ct - Temperature Factor: 1.0, Cf - Size Factor: 1.20, Cg - Group Action Factor: 1.0, Cdelta - Geometry Factor: 1.0

Bolting Data: Bolt Diameter: 5/8" in, Bolt Spacing: 24.0 in, Fyb: Bolt Bending Yield: 45,000 psi

Attached to Concrete? Yes | No

Concrete as "Main" Supporting Member: Using 6" anchor embedment length in equations. Using dowel bearing strength fixed at 7.5 ksi per NDS Table 11E

Results | M & V Details | Allowable Bolt Capacity | Design OK

Maximum Ledger Bending		Maximum Bolt Bearing Summary		Dowel Bearing Strengths (for specific gravity & bolt diameter)	
Load Combination . .		Load Combination . .			
Moment	+D 66.667 ft-lb	Max. Vertical Load	+D 400.0 lbs	Ledger, Perp to Grain	2,800.0 psi
fb : Actual Stress	26.091 psi	Bolt Allow Vertical Load	525.0 lbs	Ledger, Parallel to Grain	5,600.0 psi
F'b : Allowable Stress	1,020.0 psi	Max. Horizontal Load	0.0 lbs	Supporting Member, Perp to Grain	7,500.0 psi
Stress Ratio	0.02558 :1	Bolt Allow Horizontal Load	928.36 lbs	Supporting Member, Parallel to Grain	7,500.0 psi
Maximum Ledger Shear		Angle of Resultant			
Load Combination . .					
Shear	+D 200.0 lbs	Diagonal Applied Force	400.0 lbs		
Fv : Actual (per NDS 3.4-7)	55.172 psi	Allow Diagonal Bolt Force	525.0 lbs		
F'v : Allowable Stress	180.0 psi	Stress Ratio, Wood @ Bolt	0.7619 :1		
Stress Ratio	0.3065 :1				

### General Tab

This tab collects information on the ledger size and stress grade, and bolt information. If the ledger in

**Ledger Data:** Enter the actual dimensions (not nominal) and the wood species of the ledger. The specific gravity will be retrieved from the internal databases (you can also revise the specific gravity).

**Wood Stress Grade:** Use the [Browse] button to access the built-in NDS reference design values database and retrieve the Fb and Fv values. You can also edit these values separately.

**Bolting Data:** Enter the bolt diameter and spacing. The yield strength of the bolt is fixed at 45 ksi in this module to remain consistent with the assumptions in the NDS.

**ASD or LRFD:** Select the design method to be used. Load factoring and allowable stress calculations will applied accordingly. Values of  $K_F$  and  $\phi$  are automatically determined and applied for the LRFD method.

The screenshot shows the 'Wood Ledger' software window with the following sections:


- Description:** Sample Wood Ledger Calc
- Ledger (Side Member) Data:**
  - Is : Side member dowel bearing length: 1.50 in
  - Depth: 7.250 in
  - Wood Species: Douglas Fir-Larch
  - G : Specific Gravity: 0.5
- Attached to Concrete ?** Yes  No
- Wood as "Main" Supporting Member:**
  - Im : Main member dowel bearing length: 3.50 in
  - Wood Species: [Dropdown]
  - G : Specific Gravity: 0.450
- Design Method:** ASD (selected) | LRFD
- Wood Stress Grade:**
  - Browse: Douglas Fir - Larch (North), No. 1/No. Fb: 850.0 psi
  - CM - Wet Service Factor: 1.0 Fv: 180.0 psi
  - Ct - Temperature Factor: 1.0 Cg - Group Action Factor: 1.0
  - Cf - Size Factor: 1.20 Cdelta - Geometry Factor: 1.0
- Bolting Data:**
  - Bolt Diameter: 5/8" in Bolt Spacing: 24.0 in
  - Fyb : Bolt Bending Yield: 45,000 psi
  - \*\* Bolt assumed to be mid-depth in side member for shear calcs.*
- Footer:** \*\*\*\*\* Main & Side member must both have grain direction parallel

### When "Attached to Concrete" is set to [No]

When the user specifies that the ledger is not attached to concrete, this implies that the ledger is attached to a supporting wood member. The display will change to allow the width and species of the supporting member to be entered.

This close-up shows the 'Attached to Concrete ?' section with 'Yes' and 'No' buttons, where 'No' is selected. Below it, the 'Wood as "Main" Supporting Member' section is active, showing input fields for 'Im : Main member dowel bearing length' (3.50 in), 'Wood Species' (dropdown), and 'G : Specific Gravity' (0.450).

The following sketch clarifies the width dimension required for a wood supporting member:



### Loads Tab

This tab allows you to apply vertical and horizontal loads to the ledger. All loads are assumed to act in the plane of the wall. Vertical loads might come from gravity loading on supported members. Horizontal loading might come from diaphragm action, such as the floor system dragging lateral wind or seismic load into the ledger. When both vertical and horizontal loads are applied, the resulting load will be at an angle to the bolt that is somewhere between 0 degrees (for purely horizontal loading) and 90 degrees (for purely vertical loading).

One set of uniform load values can be specified, and it will be considered to act consistently along all areas of the ledger. For calculations purposes, this module considers the ledger a continuous beam over multiple supports.

One set of repeating point loads can be specified, where the input collects the magnitude, the starting location, and the spacing between subsequent loads. The module will consider all locations of the point loads over enough ledger spans between bolts to determine the governing case. For example, say your ledger bolting is set to 36" and the point load is set to 15". There will be multiple point loads between bolts, and on the NEXT span, the point loads will be in different relative positions with respect to the bolts. The module analyzes all conditions of that bolt pattern over enough ledger spans to determine the governing point load offset.

One set of horizontal (lateral) shear loads is allowed, in order to simulate wind or seismic load applied to the ledger and acting in the plane of the supporting wall.

General Loads Load Combinations

Uniform Load... *Applied perpendicular to grain*

Dead  Roof Live  Floor Live  Snow  Wind  Seismic  Earth  plf

Point Load... *Applied perpendicular to grain*

Spacing  in

Offset  in

Horizontal Shear *Applied parallel to grain*

Wind  Seismic  Earth  plf

### Load Combinations Tab

This is the typical load combination tab with entries for load duration factors  $C_D$  (ASD) and  $\lambda$  (LRFD).

Selecting the **[Auto Reverse Wind Factors]** and/or **[Auto Reverse Seismic Factors]** buttons creates additional load combinations that insert "-W" and "-E" whenever W and E are used.

Load Combinations IBC 2009 Change Load Combination Set Auto-Minimize Combinations to Run

Load Combination	Run	$C_D$	D	Lr	L	S	W	E	H
+D	<input checked="" type="checkbox"/>	0.9	1.0						0
+D+L+H	<input checked="" type="checkbox"/>	1	1.0		1				1.0
+D+Lr+H	<input checked="" type="checkbox"/>	1	1.0	1.0					1.0
+D+S+H	<input checked="" type="checkbox"/>	1.15	1.0			1.0			1.0
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1	1.0	0.750	0.750				1.0
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1.15	1.0		0.750	0.750			1.0
+D+W+H	<input checked="" type="checkbox"/>	1.6	1.0				1.0		1.0
+D+0.70E+H	<input checked="" type="checkbox"/>	1.6	1.0					0.70	1.0
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1.6	1.0	0.750	0.750		0.750		1.0
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1.6	1.0		0.750	0.750	0.750		1.0
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1.6	1.0	0.750	0.750			0.5250	1.0
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1.6	1.0		0.750	0.750		0.5250	1.0
+0.60D+W+H	<input checked="" type="checkbox"/>	1.6	0.60				1.0		1.0
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	1.6	0.60					0.70	1.0

Auto Reverse Wind Factors   
Auto Reverse Seismic Factors

$\lambda$

### Results Tabs

This set of tabs provides detailed results for the current calculation. The vertical tabs on the left edge of the screen allow you to select the two major areas available for review: Calculations and Sketch.

The Calculations tab offers the following results options:

**Results** tab presents a summary of the design for the current member by reporting the following:

**Maximum Ledger Bending** shows the load combination, applied moment and actual and allowable bending stresses. Note that no slenderness is considered for the flexural design of the ledger.

**Maximum Ledger Shear** shows the load combination, applied shear and actual and allowable shear stresses for vertical loads only. These stresses are taken at the point of bolt support of the ledger and no subtraction of uniform loads within a distance "ledger depth" from that support is considered.

**Maximum Bolt Bearing Summary** Shows the vertical and horizontal components of force acting on the bolt for the governing condition. "Allow Diagonal Bolt Force" is the result of allowable parallel to grain and perpendicular to grain bolt capacities used for the "Angle of Resultant" in a Hankinson formula calculation.

**Dowel Bearing Strengths** give the allowable stress and resulting allowable bolt bearing stress considering NDS procedures and strengths and bolt size the user has entered.

Category	Load Combination	Value	Unit
<b>Maximum Ledger Bending</b>	Load Combination	+1.40D	
	Moment	23.333 ft-lb	
	fb : Actual Stress	9.132 psi	
	F'b : Allowable Stress	612.0 psi	
	Stress Ratio	0.01492 :1	
<b>Maximum Ledger Shear</b>	Load Combination	+1.40D	
	Shear	140.0 lbs	
	f <sub>v</sub> : Actual (per NDS 3.4-7)	38.621 psi	
	F'v : Allowable Stress	108.0 psi	
	Stress Ratio	0.3576 :1	
<b>Maximum Bolt Bearing Summary</b>	Load Combination	+1.40D	
	Max. Vertical Load	315.0 lbs	
	Bolt Allow Vertical Load	315.0 lbs	
	Max. Horizontal Load	0.0 lbs	
	Bolt Allow Horizontal Load	557.01 lbs	
<b>Dowel Bearing Strengths</b> (for specific gravity & bolt diameter)	Ledger, Perp to Grain	2,800.0 psi	
	Ledger, Parallel to Grain	5,600.0 psi	
	Supporting Member, Perp to Grain	7,500.0 psi	
	Supporting Member, Parallel to Grain	7,500.0 psi	
		Angle of Resultant	90.0 deg
		Diagonal Applied Force	280.0 lbs
		Allow Diagonal Bolt Force	315.0 lbs
		Stress Ratio, Wood @ Bolt	0.8889 :1

**M & V Details** tab summarizes the design values according to load combination for moment, shear and bolt forces.


Load Combination	Max. Moment Results				Max. Shear Results				Bolt Force Results			Dowel Bearing @ Angle			
	Moment	fb	Fb	fb/Fb	Shear	f <sub>v</sub>	F <sub>v</sub>	f <sub>v</sub> /F <sub>v</sub>	Vert	Allow	Horz	Allow	Angle	Force	Allow
+1.40D	280.000	9	612	0.015	140.0	38.6	108.0	0.358	280.0	315.0	557.0	90.0	280.0	315.0	0.89
+1.20D+0.50Lr+1.60L+1.60H	240.000	8	816	0.010	120.0	33.1	144.0	0.230	240.0	420.0	742.7	90.0	240.0	420.0	0.57
+1.20D+1.60Lr+0.50L	240.000	8	816	0.010	120.0	33.1	144.0	0.230	240.0	420.0	742.7	90.0	240.0	420.0	0.57
+1.20D+1.60Lr+0.80W	240.000	8	1,020	0.008	120.0	33.1	180.0	0.184	240.0	525.0	928.4	90.0	240.0	525.0	0.46
+1.20D+0.50Lr+0.50L+1.60W	240.000	8	1,020	0.008	120.0	33.1	180.0	0.184	240.0	525.0	928.4	90.0	240.0	525.0	0.46

**Allowable Bolt Capacity** tab provides the details of the bolt capacities according to the chosen NDS calculation method.

Results		M & V Details		Allowable Bolt Capacity		Design OK	
Governing Load Combination . . . +1.40D							
Resutant Load Angle : Theta = 90.0 deg Ktheta = 1.250 Fe theta = 315.0							
<b>Bolt Capacity - Load Perpendicular to Grain</b>				<b>Bolt Capacity - Load Parallel to Grain</b>			
Fem	7,500.0	Fes	2,800.0	Fyb	45,000.0	Fem	7,500.0
Re	2.679	Rt	4.0			Fes	5,600.0
k1	3.082	k2	1.763	k3	1.449	Fyb	45,000.0
Im : Eq 11.3-1	Rd = 5.0	Z = 0.0	lbs	Im : Eq 11.3-1	Rd = 4.0	Z = 0.0	lbs
Is : Eq 11.3-2	Rd = 5.0	Z = 525.0	lbs	Is : Eq 11.3-2	Rd = 4.0	Z = 1,312.50	lbs
II : Eq 11.3-3	Rd = 4.50	Z = 1,797.59	lbs	II : Eq 11.3-3	Rd = 3.60	Z = 2,513.91	lbs
IIIIm : Eq 11.3-4	Rd = 4.0	Z = 1,949.73	lbs	IIIIm : Eq 11.3-4	Rd = 3.20	Z = 2,866.15	lbs
IIIIs : Eq 11.3-5	Rd = 4.0	Z = 544.26	lbs	IIIIs : Eq 11.3-5	Rd = 3.20	Z = 928.36	lbs
IV : Eq 11.3-6	Rd = 4.0	Z = 763.75	lbs	IV : Eq 11.3-6	Rd = 3.20	Z = 1,197.18	lbs
Zmin : Basic Design Value		525.0	lbs	Z : Basic Design Value		928.36	lbs
<b>Reference design value - Perpendicular to Grain :</b>				<b>Reference design value - Parallel to Grain :</b>			
Z * CM * CD * Ct * Cg * Cdelta = 315.0 lbs				Z * CM * CD * Ct * Cg * Cdelta = 557.01 lbs			

[Note !](#)  
Refer to 2005 NDS Section 11.3 for Bolt Capacity calculation method.

The Sketch tab provides a graphic representation of the ledger currently being designed:



## 10.2.9 Masonry Beam

### [Need more? Ask Us a Question](#)

This module provides design analysis for concrete masonry beams and lintels subject to vertical and lateral loads. Beams can have fixed or pinned ends for most typical conditions, and the user can specify rebar sets within the depth of the beam.

Vertical loads can be dead and live uniform and concentrated loads. You can have up to four loads of each type, and the uniform loads can be full or partial length.

The module provides analysis for both seismic and wind loads for each recalculation. You can specify seismic factors that apply to the beam's weight and a wind load.

To allow the module to model different concrete block types, you can specify either lightweight or medium weight block, and additionally enter a self-weight multiplication factor.

For both the vertical and lateral bending and shear directions, the module calculates allowable bending moments and shear stresses. Also, for both directions, actual moments and shears due to all entered loads are calculated. Final results consist of combined stress ratio calculations for all combinations or dead, live, seismic, and wind vertical and lateral moments and shears.

The screenshot displays the 'Masonry Beam' software interface. The top menu bar includes 'General & Materials', 'Reinforcing', 'Vertical Loads', and 'D+L? Load Combinations'. The 'Description' field contains 'Sample Masonry Beam'. Input parameters include: Clear Span (8.0 ft), Beam Depth (2.0 ft), Thickness (8 in), and End Fixity (Pin-Pin). Material Data includes:  $F_s$  (32,000.0 psi),  $f_m$  (1,500.0 psi),  $E_m = f_m *$  (750.0), Wall Wt Mult. (1.0), Block Type (Normal Wt), and Modulus of Rupture (100.0). Lateral Loads include Lateral Wind Loads and Lateral Wall Weight Seismic Factor. The 'Load Combination to Use' is set to ASD. The bottom section shows design results for Maximum Stress Ratios, Maximum Moment, and Maximum Shear, with a 'Design OK' status.

Maximum Stress Ratios...	Vertical	Lateral	Combined
$f_b/F_b$	0.130	0.0	<b>0.130</b> : 1.00
$f_v/F_v$	0.3564	0.0	<b>0.3564</b> : 1.00

Maximum Moment	Actual	Allowable	Actual	Allowable
Vertical Loads for Load Combination : +D+H	4.0 k-ft	30.774 k-ft	<b>Minimum <math>M_n = 1.3 * F_{cr} * S =</math></b> 6.10 k-ft	
Lateral Loads for Load Combination :	0.0 k-ft	0.0 k-ft		

Maximum Shear	Actual	Allowable
Vertical Loads for Load Combination : +D+H	13.115 psi	36.794 psi
Lateral Loads for Load Combination :	0.0 psi	0.0 psi

### Unique Features



- This module calculates all vertical and lateral moments and shears and combines them for all possible stress ratios. This provides a thorough evaluation of combined stresses for seismic and wind design.
- The module also provides the ability to modify the material weight, automatically reverse seismic and/or wind loadings, and model both fix-fix and pin-pin end fixity conditions.

### Assumptions & Limitations

When the beam's fixity is set to Fixed, both vertical and lateral bending are considered fixed.

### General Tab

This tab provides data entry for the lintel dimensions, material properties and lateral loads.

**Clear Span** and **Lintel Depth** are used to calculate the beam bending and shears.

**Thickness** is the nominal masonry thickness. The true thickness is determined from internal tables.

**End Fixity** controls whether the analysis will consider the lintel to be pinned or fixed.

**Calculate & Include Vertical Lintel Weight** tells the module to calculate the lintel self-weight and add it as a uniform vertical load across the full span.

**Material Data** defines the allowable stresses for masonry and reinforcing steel.

**Wall Weight Multiplier** allows the user to factor the lintel self-weight that is pulled from internal tables.

**Block Type** selects the density of the CMU used for self-weight.

**Lateral Loads** allows you to specify wind and seismic loads that are applied horizontally, perpendicular to the span of the lintel. Seismic Weight factor is a multiplier applied to the lintel self-weight to create a laterally applied uniform load.

## Reinforcing Tab

This tab allows you to specify the longitudinal reinforcing in the beam.

**Note: All longitudinal reinforcing bars are assumed to be fully developed. No attempt is made to compare the moment diagram with a longitudinal rebar development diagram, so engineering judgment should be applied in situations where end fixity is assumed and/or where heavy concentrated loads cause significant moments at locations close to the development zone of the provided reinforcement.**

**Bending Reinforcement**

Rebar Size: 6.0

Bars each face?

# Bars Each Face: 1.0  
*Min one Bar E/F shown*

Rebar Distance from Top and Bottom of Lintel to Centerline of rebar group

At Top: 4.0 in

At Bottom: 4.0 in

# Bar Sets: 1  
*1 Bar Set Places rebar at bottom*  
*This is the number of "sets" spaced evenly vertically in the lintel.*

Bar Spacing: 3.0 in

**Shear Reinforcement**

Use Shear Reinf.?  No  Yes

Bar Size: 3

Bar Spacing: 18.0

# Shear legs: 1

Vertical Load

Lateral Wind & Seismic Load

### Rebar Size



Enter the rebar size used for all longitudinal bar sets to be used in the lintel.

### Bars Each Face

Selected implies that the lintel is reinforced with two layers of reinforcing separated by the value specified in the "Bar Spacing" input.

Deselected implies that the lintel is reinforced with one layer of reinforcing located at the middle of the width of the lintel.



The lintel below **DOES** have bars each face:  
does **NOT** have bars each face:



**# Bars Each Location**

Enter the number of individual rebars to consider at each reinforced location.

The lintel below has **one** bar at each reinforced location:    The lintel below has **three** bars at each reinforced location:




**Rebar Distance from Top & Bottom of Lintel to Centerline of rebar group**

Distance from the top and bottom of the lintel to the center of area of the respective bar set. These distances will be used as "d" for vertical bending strength calculations.

**# Bar Sets**

Enter the number of bar sets in the lintel. A value of one indicates that the lintel has bottom reinforcing only.

The lintel below has **one** bar set:    The lintel below has **two** bar sets:    The lintel below has **three** bar sets:

**Bar Spacing**

This is the clear distance between the bars on each face in a bar set. It is assumed that the bar set is centered within the width of the lintel. The value of "d" used for lateral bending strength calculations is calculated as:  $\text{Spacing Between Bars} + (\text{Actual Thickness} - \text{Spacing Between Bars}) / 2$

**Shear Reinforcement**

When you click **[Yes]** you can specify the vertical shear reinforcement used in the lintel. The results will then reflect the allowable & actual shear stress ratios.

**Vertical Load Tab**

This tab allows you to specify point loads and distributed loads applied to the lintel.

**Point Loads...**

	Distance	Dead Load	Lf: Floor Live	Lr: Roof Live	S: Snow	W: Wind	E: Earthquake
#1	ft						k
#2	ft						k
#3	ft						k
#4	ft						k

**Distributed Loads...**

	Start X	End X	Dead Load	Lf: Floor Live	Lr: Roof Live	S: Snow	W: Wind	E: Earthquake
#1	ft	12.0 ft	0.920			0.450		k/ft
#2	ft	ft						k/ft
#3	ft	ft						k/ft
#4	ft	ft						k/ft

### Load Combinations Tab

This is the typical load combination tab used throughout the **SEL**. "LDF" is a Load Duration Factor that will be applied to allowable stresses and is only available for the ASD design method.

**Service Combinations** | IBC 2009 | Change Load Combination Set | Auto-Minimize Combinations to Run

Load Combination	Run	LDF	D	Lr	L	S	W	E	H
+D	<input checked="" type="checkbox"/>	1.0	1.0						
+D+L+H	<input checked="" type="checkbox"/>	1.0	1.0		1.0				1.0
+D+Lr+H	<input checked="" type="checkbox"/>	1.0	1.0	1.0					1.0
+D+S+H	<input checked="" type="checkbox"/>	1.0	1.0			1.0			1.0
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1.0	1.0	0.750	0.750				1.0
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1.0	1.0		0.750	0.750			1.0
+D+W+H	<input checked="" type="checkbox"/>	1.0	1.0				1.0		1.0
+D+0.70E+H	<input checked="" type="checkbox"/>	1.0	1.0					0.70	1.0
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1.0	1.0	0.750	0.750		0.750		1.0
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1.0	1.0		0.750	0.750	0.750		1.0
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1.0	1.0	0.750	0.750			0.5250	1.0
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1.0	1.0		0.750	0.750		0.5250	1.0
+0.60D+W+H	<input checked="" type="checkbox"/>	1.0	0.60				1.0		1.0
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	1.0	0.60					0.70	1.0

Auto Reverse Wind   
Auto Reverse Seismic

### Output & Graphics Tabs

#### Results Tab

This tab summarizes the calculated moments, shears and combined stress ratios for the lintel.

Ratios for bending and shear are provided for both vertical and lateral load applications. There are no calculations for combined vertical & lateral stresses.

Results			M & V Results			Design Values			Design OK		
<b>Maximum Stress Ratios...</b>											
	<u>Vertical</u>	<u>Lateral</u>	<u>Combined</u>								
fb/Fb	0.3026	0.0	0.3026 : 1.00								
Fv/Fv	0.7764	0.0	0.7764 : 1.00								
<b>Maximum Moment</b>											
	<u>Actual</u>	<u>Allowable</u>									
Vertical Loads	6.829 k-ft	22.568 k-ft	<b>Maximum Tension As</b>								
for Load Combination : +D+S+H			0.880 in <sup>2</sup>								
Lateral Loads	0.0 k-ft	0.0 k-ft	<b>Minimum Mn = 1.3 * Fcr * S =</b>								
for Load Combination :			6.10 k-ft								
<b>Maximum Shear</b>											
	<u>Actual</u>	<u>Allowable</u>									
Vertical Loads	22.40 psi	28.852 psi									
for Load Combination : +D+S+H											
Lateral Loads	0.0 psi	0.0 psi									
for Load Combination :											

### M & V Results Tab

This tab provides full details for all actual and allowable stresses for all load combinations.

Results			M & V Results			Design Values			Design OK					
Load Combination	Vertical Moments			Vertical Shear				Lateral Moment			Lateral Shear			
	Mactual	Mallow	Ratio	V Actual	Fv	Fv	Fv/Fv	Mactual	Mallow	Mact/Mallow	V actual	Fv	Fv	Fv/Fv
+D	12.00	47.39	0.253	6.00	18.74	52.46	0.357		10.46				38.73	
+D+L+H	24.00	47.39	0.506	12.00	37.47	52.46	0.714		10.46				38.73	
+D+Lr+H	24.00	47.39	0.506	12.00	37.47	52.46	0.714		10.46				38.73	
+D+S+H	24.00	47.39	0.506	12.00	37.47	52.46	0.714		10.46				38.73	
+D+0.750Lr+0.750L+H	30.00	47.39	0.633	15.00	46.84	52.46	0.893		10.46				38.73	
+D+0.750L+0.750S+H	30.00	47.39	0.633	15.00	46.84	52.46	0.893		10.46				38.73	
+D+W+H	12.00	47.39	0.253	6.00	18.74	52.46	0.357	0.96	10.46	0.092	0.48	1.58	38.73	0.041
+D-1.0W+H	12.00	47.39	0.253	6.00	18.74	52.46	0.357	0.96	10.46	0.092	0.48	1.58	38.73	0.041
+D+0.70E+H	12.00	47.39	0.253	6.00	18.74	52.46	0.357	0.93	10.46	0.089	0.47	1.54	38.73	0.040
+D-0.70E+H	12.00	47.39	0.253	6.00	18.74	52.46	0.357	0.93	10.46	0.089	0.47	1.54	38.73	0.040
+D+0.750Lr+0.750L+0.75	30.00	47.39	0.633	15.00	46.84	52.46	0.893	0.72	10.46	0.069	0.36	1.19	38.73	0.031
+D+0.750Lr+0.750L-0.75	30.00	47.39	0.633	15.00	46.84	52.46	0.893	0.72	10.46	0.069	0.36	1.19	38.73	0.031
+D+0.750L+0.750S+0.75	30.00	47.39	0.633	15.00	46.84	52.46	0.893	0.72	10.46	0.069	0.36	1.19	38.73	0.031
+D+0.750L+0.750S-0.75	30.00	47.39	0.633	15.00	46.84	52.46	0.893	0.72	10.46	0.069	0.36	1.19	38.73	0.031

### Design Values Tab

This tab summarizes allowable stress calculations. When ASD is used, the tab looks like this:

Results			M & V Results			Design Values			Design OK		
<b>Vertical Strength</b>											
As	0.620 in <sup>2</sup>		Equiv. Solid Thickness	7.60 in							
rho	0.001936		Wall Weight	84.0 psf							
np	0.04991		E	1,125.0 ksi							
k : ((np) <sup>2</sup> +2np) <sup>0.5</sup> -np	0.2699		n	25.778							
j = 1 - k/3	0.910										
M:mas=Fb k j b d <sup>2</sup> /2	68,148 k-ft										
M:Stl = Fs As j d	47,394 k-ft										
<b>Lateral Strength</b> (Checking lateral bending for span)											
As	0.930 in <sup>2</sup>										
rho	0.003069										
np	0.07912										
k : (np <sup>2</sup> +2np) <sup>0.5</sup> -np	0.3265										
j = 1 - k/3	0.8912										
M:mas=Fb k j b d <sup>2</sup> /2	11,477 k-ft										
M:Stl = Fs As j d	10,464 k-ft										

And when LRFD is used, the tab looks like this:

Results M & V Results Design Values Design OK

**Vertical Strength**

As - (per bar set at one side of lintel)	0.620 in <sup>2</sup>	Equiv. Solid Thickness	7.60 in
Phi * Mn	88.028 k-ft	Wall Weight	84.0 psf
		E	1,125.0 ksi
		n	25.778


*Note! Strength uses two bottom bar sets.*

**Lateral Strength** (Checking lateral bending for span)

As - (all bar sets at one side of lintel)	0.930 in <sup>2</sup>
Phi * Mn	21.202 k-ft

*Note! Strength uses bar set on each side of lintel.*

Sketch Tab




## 10.2.10 Steel Beam with Torsional Loads

The Steel Beam with Torsional Loads module offers the ability to analyze and design a single-span steel beam for applied loads that create shear, bending, and torsion. It can be a useful tool for situations where beams have concentrated or distributed loads that are applied eccentrically, or where beams are subjected to torsional moments.

### General Data tab:


The General Data tab allows you to set the span length, and support conditions in much the same way that this information is provided in the other beam modules. Refer to the [Beams](#) topic for additional explanation, but remember that this particular module is limited to single-span conditions. In addition to these pieces of data, the General Data tab also provides input fields for the compression edge lateral bracing condition, the design method, material properties, and an option to force the  $C_b$  value to 1.0, as shown below:



### Beam Span Data tab:

The Beam Span Data tab is used to specify the span length, the allowable deflection ratios, and to select the steel section under consideration.






**Span Loads tab:**

The Span Loads tab allows you to specify loads on one span at a time. The behavior of the tools on this tab is very similar to the tools described for use in the other beam modules, except that it introduces the ability to specify load eccentricities and the ability to indicate that concentrated moments should be considered as torsional moments. Refer to the

Beams

topic for additional explanation.



**Load Combinations tab:**

The Load Combinations tab provides a view of the load combinations that will be analyzed. It also offers the ability to:

- Select a different set of load combinations,
- Modify the values used as load factors, and
- Turn certain combinations on and off.

Refer to the **Beams** topic for additional explanation.

The Steel Beam with Torsional Loads module offers output options that are analogous to the output options provided by the other beam modules, with the exception that the results include torsional design considerations.

The lower half of the screen is dedicated to the display of results. The vertical strip of tabs on the left side of the display allow you to choose between Calculations, Sketch, and Diagram as explained below:

### Calculations:

The Calculations tab offers four sub-tabs:

**Summary Results:** Displays extreme flange normal stress, extreme flange and web shear stress, extreme deflections, extreme rotations, and extreme reactions.

Sub-tab	Value
Max. Flange Normal Stress Ratio	0.857 : 1
vu : Flange Normal Stress	30.31 ksi
vn/Omega : Flange Normal Stress (Phi Mn/Sxx)	35.35 ksi
Max Mu : Applied Steel Section Load Combination	62.89 k-ft HSS8x8x3/8 +D+L+H
Max. Flange or Web Shear Stress Ratio	0.203 : 1
vu : Flange Shear Stress	0.00 ksi
vu : Web Shear Stress	3.65 ksi
vn/Omega : Shear Stress	17.96 ksi
Section used for this span Load Combination	HSS8x8x3/8 +D+L+H
Maximum Deflection (L+R) or (L+S) Deflection	
Max Downward	0.160 in Ratio = 747
Max Upward	0.000 in Ratio = 0
Total Deflection	
Max Downward	0.301 in Ratio = 398
Max Upward	0.000 in Ratio = 0
Maximum Rotation	0.1430 deg at 3.013 ft
Maximum Support Reactions (kips)	
	D Lr L S W E H
Support #1	9.80 11.20
Support #2	4.20 4.80

**Maximum Combinations:** Displays maximum stress ratio, extreme moments and shears, flange normal stresses due to bending and due to torsion, flange shear stress due to torsion, web shear stress due to bending and due to torsion, for all load combinations.

Load Combination	Max. Strs Ratio	Bending Max		Flange Normal (ksi)		Flange Shear (ksi)		Web Shear (ksi)							
		Mu (k-ft)	Vu (k)	Bend	Tors	Allow	Ratio	Tors	Allow	Ratio	Bend	Tors	Allow	Ratio	
Overall MAXimum Envelope															
-Dsgn. L = 10.00 ft	0.066	54.06	21.69	1.958		35.351	0.055		17.964			1.177	17.964	0.066	
+D															
+D+L+H	0.066	4.06	1.69	1.958		35.351	0.055		17.964			1.177	17.964	0.066	
+D+0.750Lr+0.750L+H	0.939	54.06	21.69	26.055		35.351	0.737		17.964			16.873	17.964	0.939	
+D+0.750L+0.750S+H	0.721	41.56	16.69	20.031		35.351	0.567		17.964			12.949	17.964	0.721	
+D+0.750Lr+0.750L+0.750W	0.721	41.56	16.69	20.031		35.351	0.567		17.964			12.949	17.964	0.721	
+D+0.750L+0.750S+0.750W	0.721	41.56	16.69	20.031		35.351	0.567		17.964			12.949	17.964	0.721	
+D+0.750Lr+0.750L+0.5250	0.721	41.56	16.69	20.031		35.351	0.567		17.964			12.949	17.964	0.721	

**M-V-D: Summary:** Displays moment, shear, unbraced length, flange normal stress, flange shear stress, web shear stress, and deflections at small increments along all spans. Moment, shear, and stresses are displayed for all load combinations. Deflection is displayed for service load combinations only.


ASD/Service Stress Combinations									
Load Combination - ASD	Distance	Shear : Va	ments : Ma	(k-ft)	Lu	Flange	Flange	Web	
Span Name	ft	(k)	Bending		ft	(ft)	Normal (ksi)	Shear (ksi)	
Overall MAXimum Envelope									
+D									
+D+L+H									
+D+0.750Lr+0.750L+H									
span_1		18.200		Support Brace					
span_1	0.042	18.200	0.762	Lu = 10.00	0.367			0.044	
span_1	0.084	18.200	1.523	Lu = 10.00	0.734			0.088	
span_1	0.126	18.200	2.285	Lu = 10.00	1.101			0.133	
span_1	0.167	18.200	3.046	Lu = 10.00	1.468			0.177	
span_1	0.209	18.200	3.808	Lu = 10.00	1.835			0.221	
span_1	0.251	18.200	4.569	Lu = 10.00	2.202			0.265	
span_1	0.293	18.200	5.331	Lu = 10.00	2.569			0.310	
span_1	0.335	18.200	6.092	Lu = 10.00	2.936			0.354	
span_1	0.377	18.200	6.854	Lu = 10.00	3.303			0.398	

Support Reactions: Displays support reactions for all supports, for all load combinations.

Load Combination - Service	Support Force (k)
Overall MAXimum	
Support 1, (D+L+Lr)	21.688
Support 2, (D+L+Lr)	21.688
D Only	
Support 1	1.688
Support 2	1.688
L Only	
Support 1	20.000
Support 2	20.000
D+L+S	
Support 1	21.688
Support 2	21.688
D+L+Lr	
Support 1	21.688
Support 2	21.688


**Sketch:**

Displays a sketch of the beam, indicating span lengths, support conditions, and applied loads.



**Diagram:**

Displays a graphic depiction of the beam with superimposed graphs of Moment, Shear, Deflection or Rotation for a selected load combination, or for an envelope of all load combinations.



## 10.3 Columns


**Structural Engineering Library** has a single basic column design module that supports Wood, Steel, Concrete and Masonry material types.

There are some portions of the graphical user interface that remain consistent for all materials, and this topic will focus on those items. For detailed information about each of the material-specific calculation modules, please review the respective topics below.

Note: The Column modules are not intended for the design of tension members. Column modules should not be applied in situations where the member experiences net tension.

### General Information

The screen capture below shows the portions of the General tab that remain constant for all four material types.



You can easily select a different column material by clicking one of the four material buttons. When you do, the program will load the user interface that is specific to the chosen material.

**Overall Column Height** is the total height of the column and does not have anything to do with slenderness lengths. This length is used for three things:

- to describe the overall height of the column for the purpose of calculating self weight (if specified),
- to locate the topmost point of load application, and
- to perform the bending analysis when lateral loads are applied.

**Rotational End Fixities** let you specify how the ends of the columns are or are not attached to boundary conditions. Each condition explicitly describes the translational and rotational boundary conditions at both the top and bottom of the column.

### Vertical Loads

Vertical loads can be applied to any location along the height of the column. You use this tab to build a table of applied loads with the **[Add]**, **[Copy]** and **[Delete]** buttons.

**Include Self Weight** option tells the module to automatically calculate the weight of the column and add it as an additional dead load (which will be factored per "D" load combination factor and applied at the top of the column).

**Description** lets you describe each load you are applying.

**Load Eccentricity** has "X" and "Y" eccentricity locations so the loads can create Y-Y and X-X axis moments respectively.

**Location from Base** is where you specify the vertical location of the axial load with respect to the bottom of the column.

X-Ecc (in)	Y-Ecc (in)	+Z from base (ft)	D (k)	Lr (k)	L (k)	S (k)	W (k)	E (k)	H (k)
		10.00							

Applied Axial Loads . . .

Description:

Include Self-weight?  Yes  No

Load Eccentricity . . . (from geometric center)

X-Ecc:  in

Y-Ecc:  in

Location from base . . .

Top of Column = 10.0 ft

Specify Height =

D: Dead  k

Lr: Live, Roof  k

L: Live  k

S: Snow  k

W: Wind  k

E: Seismic\*  k

H: Earth  k

## Lateral Loads

On this tab you can specify loads that will be applied along the X or Y axes of the column (non-axial loads).

**Note! Moments applied at fixed ends have no effect on column design, and will be ignored, producing no effect on the column, and will also NOT appear as reactions.**

**Applied Load Type & Values** has a drop-down list box where you can choose Full Uniform, Partial Uniform, Point Load and Moment load types.

**Description** lets you describe each load you are applying.

**Moment Axis** is where you specify about which column axis the load creates its applied moment.

**Location from Base** is where you specify the vertical location of the lateral load with respect to the bottom of the column.

Load Type	Moment Axis	Location (ft)	D	Lr (k-ft)	L (k-ft)	S (k-ft)	W (k-ft)	E (k-ft)	H (k-ft)
Moment	X-X	11.000	24.700		24.400				
Point Load	Y-Y	5.500	56.900		56.600				

Applied Load Type & Values: **Moment**

Description:

D: Dead  k-ft    W: Wind  k-ft

Lr: Live, Roof  k-ft    E: Seismic\*  k-ft

L: Live  k-ft    H: Earth  k-ft

S: Snow  k-ft

Moment Axis:  X-X  Y-Y  
*(Point & uniform loads act along Y-Y Axis)*

Location:  ft  
*(measured upward from base)*

### Load Combination Tab

This tab allows you to specify the load combinations to use for the analysis. The tabs change appearance slightly between ASD and LRFD selections. There are also optional load duration factor entries for wood and masonry design.

Please see the screen captures below for variations based on the selected material.

### Steel ASD

Load Combination	Run?	D	Lr	L	S	W	E	H
+D	<input checked="" type="checkbox"/>	1.0						
+D+L	<input checked="" type="checkbox"/>	1.0		1.0				
+D+Lr	<input checked="" type="checkbox"/>	1.0	1.0					
+D+S	<input checked="" type="checkbox"/>	1.0			1.0			
+D+0.750Lr+0.750L	<input checked="" type="checkbox"/>	1.0	0.750	0.750				
+D+0.750Lr+0.750S	<input checked="" type="checkbox"/>	1.0		0.750	0.750			
+D+W	<input checked="" type="checkbox"/>	1.0				1.0		
+D+0.70E	<input checked="" type="checkbox"/>	1.0					0.70	
+D+0.750Lr+0.750L+0.750W	<input checked="" type="checkbox"/>	1.0	0.750	0.750		0.750		
+D+0.750Lr+0.750S+0.750W	<input checked="" type="checkbox"/>	1.0		0.750	0.750	0.750		
+D+0.750Lr+0.750L+0.5250E	<input checked="" type="checkbox"/>	1.0	0.750	0.750			0.5250	
+D+0.750Lr+0.750S+0.5250E	<input checked="" type="checkbox"/>	1.0		0.750	0.750		0.5250	
+0.60D+W	<input checked="" type="checkbox"/>	0.60				1.0		
+0.60D+0.70E	<input checked="" type="checkbox"/>	0.60					0.70	

2009 IBC & ASCE 7-05    Auto-Minimize Combinations to Run

Use add'l SDS factors per ASCE 12.4.2.3?

Auto Reverse Wind Factors?

Auto Reverse Seismic Factors?

### Steel LRFD

General | Column Size | Loads | Slenderness | D+L+? Load Combinations

LRFD/Strength Combinations | 2009 IBC & ASCE 7-05 | Auto-Minimize Combinations to Run

Load Combination	Run?	D	Lr	L	S	W	E	H
+1.40D	<input checked="" type="checkbox"/>	1.40						
+1.20D+0.50Lr+1.60L+1.60H	<input checked="" type="checkbox"/>	1.20	0.50	1.60				1.60
+1.20D+1.60L+0.50S+1.60H	<input checked="" type="checkbox"/>	1.20		1.60	0.50			1.60
+1.20D+1.60Lr+0.50L	<input checked="" type="checkbox"/>	1.20	1.60	0.50				
+1.20D+1.60Lr+0.80W	<input checked="" type="checkbox"/>	1.20	1.60			0.80		
+1.20D+0.50L+1.60S	<input checked="" type="checkbox"/>	1.20		0.50	1.60			
+1.20D+1.60S+0.80W	<input checked="" type="checkbox"/>	1.20			1.60	0.80		
+1.20D+0.50Lr+0.50L+1.60W	<input checked="" type="checkbox"/>	1.20	0.50	0.50		1.60		
+1.20D+0.50L+0.50S+1.60W	<input checked="" type="checkbox"/>	1.20		0.50	0.50	1.60		
+1.20D+0.50L+0.20S+E	<input checked="" type="checkbox"/>	1.20		0.50	0.20		1.0	
+0.90D+1.60W+1.60H	<input checked="" type="checkbox"/>	0.90				1.60		1.60
+0.90D+E+1.60H	<input checked="" type="checkbox"/>	0.90					1.0	1.60

Use add'l SDS factors per ASCE 12.4.2.3?

Auto Reverse Wind Factors?

Auto Reverse Seismic Factors?

### Concrete LRFD

General | Concrete Shape | Loads | Slenderness | D+L+? Load Combinations | Auto Calculate

LRFD/Strength Combinations | 2009 IBC & ASCE 7-05 | Auto-Minimize Combinations to Run

Load Combination	Run?	D	Lr	L	S	W	E	H
+1.40D	<input checked="" type="checkbox"/>	1.4						
+1.20D+0.50Lr+1.60L+1.60H	<input checked="" type="checkbox"/>	1.2	0.5	1.6				1.6
+1.20D+1.60L+0.50S+1.60H	<input checked="" type="checkbox"/>	1.2		1.6	0.5			1.6
+1.20D+1.60Lr+0.50L	<input checked="" type="checkbox"/>	1.2	1.6	0.50				
+1.20D+1.60Lr+0.80W	<input checked="" type="checkbox"/>	1.2	1.6			0.8		
+1.20D+0.50L+1.60S	<input checked="" type="checkbox"/>	1.2		0.50	1.6			
+1.20D+1.60S+0.80W	<input checked="" type="checkbox"/>	1.2			1.6	0.8		
+1.20D+0.50Lr+0.50L+1.60W	<input checked="" type="checkbox"/>	1.2	0.5	0.50		1.6		
+1.20D+0.50L+0.50S+1.60W	<input checked="" type="checkbox"/>	1.2		0.50	0.5	1.6		
+1.20D+0.50L+0.20S+E	<input checked="" type="checkbox"/>	1.2		0.50	0.2		1	
+0.90D+1.60W+1.60H	<input checked="" type="checkbox"/>	0.9				1.6		1.6
+0.90D+E+1.60H	<input checked="" type="checkbox"/>	0.9					1	1.6

Use add'l SDS factors per ASCE 12.4.2.3?

Auto Reverse Wind Factors?

Auto Reverse Seismic Factors?

### Wood ASD

General | Column Size | Loads | Slenderness | D+L+? Load Combinations

Load Combinations | 2009 IBC & ASCE 7-05 | Auto-Minimize Combinations to Run

Load Combination	Run?	C <sub>p</sub>	D	Lr	L	S	W	E	H
+D	<input checked="" type="checkbox"/>	0.9	1	0	0	0	0	0	0
+D+L+H	<input checked="" type="checkbox"/>	1	1	0	1	0	0	0	1
+D+Lr+H	<input checked="" type="checkbox"/>	1.25	1	1	0	0	0	0	1
+D+S+H	<input checked="" type="checkbox"/>	1.15	1	0	0	1	0	0	1
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1.25	1	0.75	0.75	0	0	0	1
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1.15	1	0	0.75	0.75	0	0	1
+D+W+H	<input checked="" type="checkbox"/>	1.6	1	0	0	0	1	0	1
+D+0.70E+H	<input checked="" type="checkbox"/>	1.6	1	0	0	0	0	0.7	1
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1.6	1	0.75	0.75	0	0.75	0	1
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1.6	1	0	0.75	0.75	0.75	0	1
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1.6	1	0.75	0.75	0	0	0.525	1
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1.6	1	0	0.75	0.75	0	0.525	1
+0.60D+W+H	<input checked="" type="checkbox"/>	1.6	0.6	0	0	0	1	0	1
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	1.6	0.6	0	0	0	0	0.7	1

Use add'l SDS factors per ASCE 12.4.2.3?

Auto Reverse Wind Factors?

Auto Reverse Seismic Factors?

### Wood LRFD



General Column Size Loads Slenderness **D+L+?** Load Combinations

LRFD/Strength Combinations 2009 IBC & ASCE 7-05  Auto-Minimize Combinations to Run

Load Combination	Run?	$\gamma$	D	Lr	L	S	W	E	H
+1.40D	<input checked="" type="checkbox"/>	0.6	1.4	0	0	0	0	0	0
+1.20D+0.50Lr+1.60L+1.60H	<input checked="" type="checkbox"/>	0.8	1.2	0.5	1.6	0	0	0	1.6
+1.20D+1.60L+0.50S+1.60H	<input checked="" type="checkbox"/>	0.8	1.2	0	1.6	0.5	0	0	1.6
+1.20D+1.60Lr+0.50L	<input checked="" type="checkbox"/>	0.8	1.2	1.6	0.50	0	0	0	0
+1.20D+1.60Lr+0.80W	<input checked="" type="checkbox"/>	1	1.2	1.6	0	0	0.8	0	0
+1.20D+0.50L+1.60S	<input checked="" type="checkbox"/>	0.8	1.2	0	0.50	1.6	0	0	0
+1.20D+1.60S+0.80W	<input checked="" type="checkbox"/>	1	1.2	0	0	1.6	0.8	0	0
+1.20D+0.50Lr+0.50L+1.60W	<input checked="" type="checkbox"/>	1	1.2	0.5	0.50	0	1.6	0	0
+1.20D+0.50L+0.50S+1.60W	<input checked="" type="checkbox"/>	1	1.2	0	0.50	0.5	1.6	0	0
+1.20D+0.50L+0.20S+E	<input checked="" type="checkbox"/>	1	1.2	0	0.50	0.2	0	1	0
+0.90D+1.60W+1.60H	<input checked="" type="checkbox"/>	1	0.9	0	0	0	1.6	0	1.6
+0.90D+E+1.60H	<input checked="" type="checkbox"/>	1	0.9	0	0	0	0	1	1.6

Use add'l SDS factors per ASCE 12.4.2.3?

Auto Reverse Wind Factors?

Auto Reverse Seismic Factors?

### Masonry ASD

General **Masonry** Loads Slenderness **D+L+?** Load Combinations Code Ref : ACI 530-08, & ASCE 7-05

Load Combinations 2009 IBC & ASCE 7-05  Auto-Minimize Combinations to Run

Load Combination	Run?	Stress Increase	D	Lr	L	S	W	E	H
+D	<input checked="" type="checkbox"/>	1	1						
+D+L+H	<input checked="" type="checkbox"/>	1	1		1				1
+D+Lr+H	<input checked="" type="checkbox"/>	1	1	1					1
+D+S+H	<input checked="" type="checkbox"/>	1	1			1			1
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1	1	0.75	0.75				1
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1	1		0.75	0.75			1
+D+W+H	<input checked="" type="checkbox"/>	1	1				1		1
+D+0.70E+H	<input checked="" type="checkbox"/>	1	1					0.7	1
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1	1	0.75	0.75		0.75		1
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1	1		0.75	0.75	0.75		1
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1	1	0.75	0.75			0.525	1
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1	1		0.75	0.75		0.525	1
+0.60D+W+H	<input checked="" type="checkbox"/>	1	0.6				1		1
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	1	0.6					0.7	1

Use add'l SDS factors per ASCE 12.4.2.3?

Auto Reverse Wind Factors?

Auto Reverse Seismic Factors?

### Masonry LRFD

General **Masonry** Loads Slenderness **D+L+?** Load Combinations Code Ref : ACI 530-08, & ASCE 7-05

LRFD/Strength Combinations 2009 IBC & ASCE 7-05  Auto-Minimize Combinations to Run

Load Combination	Run?	D	Lr	L	S	W	E	H
+1.40D	<input checked="" type="checkbox"/>	1.4						
+1.20D+0.50Lr+1.60L+1.60H	<input checked="" type="checkbox"/>	1.2	0.5	1.6				1.6
+1.20D+1.60L+0.50S+1.60H	<input checked="" type="checkbox"/>	1.2		1.6	0.5			1.6
+1.20D+1.60Lr+0.50L	<input checked="" type="checkbox"/>	1.2	1.6	0.50				
+1.20D+1.60Lr+0.80W	<input checked="" type="checkbox"/>	1.2	1.6			0.8		
+1.20D+0.50L+1.60S	<input checked="" type="checkbox"/>	1.2		0.50	1.6			
+1.20D+1.60S+0.80W	<input checked="" type="checkbox"/>	1.2			1.6	0.8		
+1.20D+0.50Lr+0.50L+1.60W	<input checked="" type="checkbox"/>	1.2	0.5	0.50		1.6		
+1.20D+0.50L+0.50S+1.60W	<input checked="" type="checkbox"/>	1.2		0.50	0.5	1.6		
+1.20D+0.50L+0.20S+E	<input checked="" type="checkbox"/>	1.2		0.50	0.2		1	
+0.90D+1.60W+1.60H	<input checked="" type="checkbox"/>	0.9				1.6		1.6
+0.90D+E+1.60H	<input checked="" type="checkbox"/>	0.9					1	1.6

Use add'l SDS factors per ASCE 12.4.2.3?

Auto Reverse Wind Factors?

Auto Reverse Seismic Factors?

### 10.3.1 Column Slenderness

[Need more? Ask Us a Question](#)

The Slenderness tab allows you to specify the column bracing, which will be considered in axial capacity calculations. Click here for a video: [Column Slenderness](#)

It is **important** to understand that the settings on the Slenderness tab serve double-duty. When the column has applied bending forces, these slenderness settings also define the unbraced compression edge lengths, and therefore they affect the calculation of allowable bending stresses.

In most of the column modules there are two tabs: "X-X" and "Y-Y Axis Column Slenderness". Let's start with the all-important definition of the axis reference for slenderness.

Buckling failure of a column can be thought of as an uncontrolled and excessive deflection in the direction of a particular axis. When defining slenderness, one of the important values is the distance between points that brace the column against movement (or failure) along a particular axis.

The column modules ask you to specify the distance between points of bracing that prevent buckling along the column's local X-X or Y-Y axis.

The **X-X axis** is always parallel to the "**width**" dimension of the column. The **Y-Y axis** is always parallel to the "**depth**" dimension of the column.


For example, the "X-X" axis of a steel W14 section is parallel to the flanges. The "X-X Axis Column Slenderness" defines the distance between points that prevent the column from buckling along its "X-X" axis.

**In Structural Engineering Library, slenderness is entered as the distance between points bracing a member against buckling in the direction of the specified axis.**

In the screen capture immediately below, we have selected [**Fully braced "X" Axis**]. This means that the column is fully braced against buckling along its X-X axis, which is parallel to the width dimension. If this was a steel "W" section, then the column is fully braced against buckling parallel to the flanges.

#### **All materials, column fully braced**


This selection sets the column as fully braced, and no slenderness effects will be evaluated.



**All materials, typical simple slenderness specification**

This selection allows you to enter the unbraced height to use for the column slenderness calculation. Also available are selections for the typical slenderness multipliers ("K" factors) for various end conditions.

Note! End fixity is specified on a different tab in the column modules. These slenderness factors do not alter the end fixity you specified for the column, nor do they get determined automatically by the end fixities that you specified.



**All materials, typical slenderness with user-defined slenderness factor "K"**

This selection allows you to enter the unbraced height and the slenderness "K" factor to use for the column slenderness calculation.

Note! End fixity is specified on a different tab in the column modules. These slenderness factors do not alter the end fixity you specified for the column, nor do they get determined automatically by the end fixities that you specified.

X-X Axis COLUMN Slenderness | Y-Y Axis COLUMN Slenderness

Fully braced "X" "X" Axis

Select "Kx" "factor

Input "Kx" "factor

Compute "Kx" "using adjacent members

Enter Bracing Locations

Unbraced height = 10.0 ft

K = 1.0

Brace Direction Resisting X-X Axis Movement

### Concrete & Steel Only

For concrete and steel you will see an option to Compute K using adjacent members.

This advanced selection lets you select the framing condition above and below the column, and using the entered lengths and EI values, it will use standard equations for Non-Sway columns to calculate the effective "K" factor.

Keep in mind that this option is used to define the relative stiffnesses of the framing in the plane of buckling that is being considered. For example, when using the X-X Axis Column Slenderness tab, the plane under consideration is the plane in which the column's X-X axis lies.

X-X Axis COLUMN Slenderness | Y-Y Axis COLUMN Slenderness

Fully braced "X" "X" Axis

Select "Kx" "factor

Input "Kx" "factor

Compute "Kx" "using adjacent members

Enter Bracing Locations

Unbraced height = 10.00 ft

K = 0.9939

$$\Psi = \frac{\sum (EI/L)_{\text{Columns}}}{\sum (0.5 EI/L)_{\text{Beams}}}$$

$\Psi_{\text{top}} = 2.877$

$\Psi_{\text{bot}} = 3.018$

$kh = 0.7 + 0.05 (\Psi_{\text{t}} + \Psi_{\text{b}}) \leq 1.0$

$kh = 0.85 + 0.05 \Psi_{\text{min}} \leq 1.0$

24.0 24.0

12.0 EI 100.0

EI 160.0 EI 125.0

12.0 EI 105.0

EI 160.0 EI 125.0

12.0 EI 110.0

24.0 24.0

### Wood & Steel Only.....

For wood and steel columns only, there is an option to **[Enter Bracing Location]**, which allows you to divide the column up into several segments with different unbraced lengths.

X-X Axis COLUMN Slenderness
Y-Y Axis COLUMN Slenderness

Fully braced "X" Axis

Select "Kx" factor

Input "Kx" factor

Compute "Kx" using adjacent members

Enter Bracing Locations

Bracing member deflections along "x-x" local axis

Total Column Height = 10.0 ft

K =

*The following brace locations are measured FROM THE BASE of the column.*


Brace #1 Location =  ft

Brace #2 Location =  ft

Brace #3 Location =  ft

Brace #4 Location =  ft

Local Axis Reference :



## 10.3.2 Wood Column

[Need more? Ask Us a Question](#)

This module designs wood columns that are subject to axial loads and lateral bending loads about both axes. Click here for a video: [Wood Column](#)

The user can select ASD or LRFD design methods and has access to a large built-in database of wood sizes and NDS species stress grades. Values of  $K_F$  and  $\phi$  are automatically determined and applied for the LRFD method.

All calculations are according to the NDS code.

The screen capture below shows the full screen for wood column design. See items below for descriptions of items that are specific to the Wood Column module.

For general description of the module, end fixity, loads, and load combinations [click here](#)<sup>326</sup>. For slenderness description [click here](#)<sup>331</sup>.

The screenshot displays the 'Wood Column' software interface. The main window is titled 'Wood Column' and features a menu bar with options like 'Cancel', 'New', 'Save Only', and 'Save & Exit'. Below the menu bar are several tabs: 'General', 'Column Data', 'Loads', 'Slenderness', and 'D+L? Load Combs'. The 'General' tab is active, showing a 'Description' field with 'Sample Wood Column Calc'. The 'Column Material' section has 'Wood' selected. The 'End Fixities' section shows 'Top : Free to Rotate, No Translation' and 'Bottom : Free to Rotate, No Translation' selected. The 'Overall Column Height' is set to 12.0 ft. The 'Design Stresses' section shows 'Analysis Method' set to 'ASD'. The 'Wood Species' is 'Douglas Fir - Larch' and 'Wood Grade' is 'No.2'. The 'Fb - Tension' is 900.0 psi, 'Fv' is 180.0 psi, 'Fb - Compression' is 900.0 psi, 'Ft' is 575.0 psi, 'Fc - Prill' is 1,350.0 psi, and 'Density' is 31.20 pcf. The 'Fc - Perp' is 625.0 psi. The 'E : Modulus of Elasticity' section shows 'Basic' values of 1,600.0 ksi for x-x Bending, y-y Bending, and Axial, with 'Minimum' values of 580.0 ksi. The 'Results' tab is active, showing 'Bending & Shear Check Results' for a '12x14' column. The 'Maximum Axial + Bending Stress Ratio' is 0.1733 : 1, and the 'Maximum Shear Stress Ratio' is 0.01193 : 1. The 'Reactions' section shows 'Maximum SERVICE Lateral Load Reactions' and 'Maximum SERVICE Load Lateral Deflections'.


### General Tab

The Design Stresses area bubbled in the screen capture below is unique to the wood column selection. This area enables you to specify the base design values for the wood species and grade of interest.

The screenshot shows the 'Wood Column' software interface. The 'Design Stresses' section is highlighted with a red bubble. It includes the following fields and values:


- Analysis Method: ASD (selected), LRFD
- Wood Species: Douglas Fir - Larch
- Wood Grade: No. 2
- Fb - Tension: 900.0 psi
- Fb - Compression: 900.0 psi
- Fc - Prill: 1,350.0 psi
- Fc - Perp: 625.0 psi
- Fv: 180.0 psi
- Ft: 575.0 psi
- Density: 31.20 pcf
- E : Modulus of Elasticity:
 

	x-x Bending	y-y Bending	Axial
Basic	1,600.0	1,600.0	1,600.0
Minimum	580.0	580.0	

You can either enter these values manually, or you can click the  button to display the Wood Stress Database.


### Column Data Tab

All of the information on this tab is unique to a wood column.

The area bubbled in **red** is where you specify the column cross section. Use the  button to display the built-in database of wood sections (solid-sawn, glulam, and manufactured sections are available). You can also enter the values manually.

The area bubbled in **blue** provides allowable stress modification factors that you can specify. Please note that  $C_F$  or  $C_V$  values are automatically filled in.  $C_F$  values are determined from the size and stress grade of the member (No. 1 and Utility grades have different values).  $C_V$  values are calculated when a glu-lam section is specified. Note that this section allows for the specification of the Repetitive Member factor. If the Repetitive Member factor option is selected, the program then offers the option to specify a value for the Wall Stud Repetitive Member Factor as defined by the NDS Special Design Provisions for Wind and Seismic (SDPWS). If the option is selected to specify a Wall Stud Repetitive Member Factor, it will only be applied to load combinations that include wind. Be sure to review the appropriate section of SDPWS for requirements on the use of this factor, as well as the values to be used for various sizes of dimension lumber.

The area in **green** provides quick access to the built-in wood section database. Simply click the button of the section type and the list on the right will be populated automatically from the appropriate database. Then just click on a section to have its data loaded into the entries in the **red** area.



Note: The flat use factor will only be applied if it is specified by the user. In addition, it is important to understand how the factor will be applied in situations where built-up columns are designed. The flat use factor is supposed to be applied when bending occurs about the weak axis of the **individual laminations**. But the program does not actually understand the orientation of individual laminations in a built-up column as of July 2018. So for consistency, the program is set up to look at the **overall dimensions** of a built-up column cross section, and then to apply the flat use factor only when considering bending about the overall weak axis. This requires the designer's consideration, because the weak axis of the overall built-up section may or may not correspond to the weak axis of the individual laminations.

## Results Tab

This tab provides a summary of the stress ratios, reactions and deflections for the column.

**Max Axial + Bending Stress Ratio** is the governing load combination for the column. Listed is the governing load combination, the NDS formulas that is used and the location of the maximum stress ratio above the base of the column. Please note maximum stress ratio is what is being reported because it governs the design.....not necessarily the highest axial or bending stress.

**Max Shear Stress Ratio** will probably never govern for a column design but is presented here with the governing load combination, location and allowable/actual stress values.

**Lateral Load Reactions and Deflections** are the result of applied lateral loads.



**Results** | Design Maximum Combinations | Detailed Axial, Moment, Shear Results | End Reactions

**Bending & Shear Check Results** 6x8

✓ Maximum Axial + Bending Stress Ratio = **0.003544** : 1

Load Combination: +D+L

Governing NDS Formula: Comp Only,  $f_c/F_c'$

Location of max. above base: 0.0 ft

For Max Load Comb & Location values are . . .

Applied Axial: 0.09453 k

Applied Mx: 0.0 k-ft

Applied My: 0.0 k-ft

Fc : Allowable: 646.56 psi

Maximum SERVICE Lateral Load Reactions . . . (see tab for all)

Top along Y-Y: 0.0 k

Top along X-X: 0.0 k

Bottom along Y-Y: 0.0 k

Bottom along X-X: 0.0 k

Maximum SERVICE Load Lateral Deflections . . . (see tab for all)

Along Y-Y: 0.0 in at 0.0 ft above base

for load combination : n/a

Along X-X: 0.0 in at 0.0 ft above base

for load combination : n/a

Other Factors used to calculate allowable stresses . . .

	Bending	Compression	Tension
Cf or Cv : Size based factors	1.000	1.000	

✓ Maximum Shear Stress Ratio = **0.0** : 1

Load Combination: +D+Lr

Location of max. above base: 10.0 ft

Applied Design Shear: 0.0 psi

Allowable Shear: 150.0 psi

### Design Maximum Combinations Tab

This tab lists the resulting maximum stress ratios for each load combination. This list is created by examining the detailed list (on the next tab) and determining the governing stress ratios for each load combination.

**Results** | Design Maximum Combinations | Detailed Axial, Moment, Shear Results | End Reactions

Load Combination Name	Max. Axial+Bending Stress Ratios			Max Shear Ratios		
	Stress Ratio	Status	Location	Stress Ratio	Status	Location
+D	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+L+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+Lr+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+S+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+0.750L+0.750S+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+W+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+0.70E+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+0.750Lr+0.750L+0.750W+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+0.750L+0.750S+0.750W+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+0.750Lr+0.750L+0.5250E+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+D+0.750L+0.750S+0.5250E+H	0.7323	PASS	0.0000	0.0000	PASS	5.0000
+0.60D+W+H	0.4394	PASS	0.0000	0.0000	PASS	5.0000
+0.60D+0.70E+H	0.4394	PASS	0.0000	0.0000	PASS	5.0000

These values represent the governing Axial, M-x and M-y values calculated from applied axial loads & eccentricities, applied moments, and end conditions.

### Detailed Results Tab - Stress

This tab lists the detailed results at small increments along the height of the column for each load combination. For consistency, all of the column headings use labels directly from the NDS code.

Note! This list scrolls to the right to display more information. See the successive screen captures below:



Service Load Deflections											Compress List
Bending Stress Variables											es
Cr	Cd	Lex	Rbx	FbEx	Clx	Lev	Rby	FbEy	Clx		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		
1.00	1.000	60.000	5.071	23,866.8	0.997	60.000	2.760	80,550.6	1.000		

And then the final data column.....

Service Load Deflections				Compress List
Column Stress Variables				
Fce - X	Fce - Y	C-D	Cp	
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299
729.9	324.4	1.000		0.299

### Detailed Results Tab - Deflections

This tab reports the deflections at incremental locations along the height of the column, for each service load condition (i.e. for individual load cases and for a set of built-in service load combinations), along each axis. It is important to understand that the deflection values indicated on this tab represent RELATIVE deflections. That is, they represent the distance from the deflected shape of the column to a straight-line chord drawn between the deflected locations of the top and bottom nodes of the column. This has significance when viewing the deflection data for a column that is fixed at the bottom and free to deflect at the top. If lateral loads are applied to this type of cantilevered column, it is reasonable to expect that the free top will deflect laterally. However, when viewing the results on the Service Load Deflections tab, the deflection at both the bottom AND the top will always be reported as zero, because this tab is reporting RELATIVE deflections, and by definition, the relative deflection of either endpoint of a member is zero. Do not interpret the results on the Service Load Deflections tab as ABSOLUTE deflections.


SERVICE LOADS		Deflections (in)	
Load Combination, Distance		xx Defl	yy Defl
+ D Only			
- L Only			
0.000 ft			
0.067 ft		-0.0066	
0.134 ft		-0.0133	
0.201 ft		-0.0199	
0.268 ft		-0.0265	
0.336 ft		-0.0331	
0.403 ft		-0.0397	
0.470 ft		-0.0463	
0.537 ft		-0.0529	
0.604 ft		-0.0595	
0.671 ft		-0.0660	
0.738 ft		-0.0726	
0.805 ft		-0.0791	
0.872 ft		-0.0856	
0.940 ft		-0.0921	
1.007 ft		-0.0985	
1.074 ft		-0.1049	
1.141 ft		-0.1113	
1.208 ft		-0.1177	

### End Reactions Tab

This tab provides the sideways (non-axial) reactions for individual load cases and for a set of built-in service load combinations, along each axis.


SERVICE LOADS Load Combination	X-X Reaction (k)		Y-Y Reaction (k)		Axial Reaction (k)
	@ Base	@ Top	@ Base	@ Top	@ Base
D Only	-0.025	0.025			1.020
L Only	-0.025	0.025			1.000
Lr Only	-0.100	0.100			4.000
L+Lr	-0.125	0.125			5.000
D+Lr	-0.125	0.125			5.020
D+L	-0.050	0.050			2.020
D+L+Lr	-0.150	0.150			6.020

### Sketch Tab



### Axial-Shear-Moment Diagrams

This tab provides comprehensive charting capability to view graphs of Axial load, Shear, Moment, and Deflection along the length of the member. Note that the graphs are oriented such that the right end of the graph represents the column base, and the left end of the graph represents the column top. This was done to maximize the scale of the graph based on the screen area available.



### Pn-Pnx-Mny Diagrams

This tab allows you to see the moment capacities about each axis given a certain allowable axial load.

This is mostly for reference and can be considered a reverse application of the load capacity calculations.

In the screen capture below we have selected a 30 degree angle. For a 1.1 kip axial load you can see the moment capacity values, Mnx and Mny.

A-V-M Diagrams Pn-Mnx-Mny Diagrams

Column P-Mx-My Capacity Envelope Data . . .

Rotation Angle from Mx -> My

	Pn (k)	Mnx (k-ft)	Mny (k-ft)	Rotation Angle
0	0.00	1.27	0.49	30
5	0.14	1.26	0.48	30
10	0.27	1.24	0.47	30
15	0.41	1.22	0.45	30
20	0.55	1.14	0.42	30
25	0.69	1.06	0.38	30
30	0.82	1.00	0.35	30
35	0.96	0.94	0.33	30
40	1.10	0.88	0.30	30
45	1.24	0.83	0.28	30
50	1.37	0.78	0.26	30
55	1.51	0.73	0.24	30
60	1.65	0.69	0.22	30
65	1.78	0.65	0.20	30
70	1.92	0.61	0.19	30
75	2.06	0.57	0.17	30
80	2.20	0.53	0.16	30
85	2.33	0.50	0.14	30
90	2.47	0.47	0.13	30
	2.61	0.43	0.12	30
	2.75	0.40	0.11	30

### 10.3.3 Steel Column

[Need more? Ask Us a Question](#)


This module designs steel columns that are subject to axial loads and lateral bending loads about both axes. Click here for a video: Steel Column

The user can select ASD or LRFD methods and has access to a complete database of steel section sizes.

All calculations are according to AISC 360-05.

The screen capture below shows the full screen for steel column design. See items below for descriptions of items that are specific to the steel column design module.


For general description of the module, end fixity, loads, and load combinations [click here](#)<sup>326</sup>. For slenderness description [click here](#)<sup>331</sup>.



## General Tab

The area shown bubbled in the screen capture below is specific to the steel column selection. Here you can specify ASD or LRFD design procedure and specify the yield strength and elastic modulus of the steel member to be used.

Click the  button to display the Steel Fy Selections dialog to select a standard grade.



**Steel Column**

General | Column Size | Loads | Slenderness | D-L? | Load Combinations

Description  
Steel Column

Column Material . . .  
Steel Concrete Wood Masonry

End Fixities . . .  
 Top : Free to Rotate, No Translation Bottom : Free to Rotate, No Translation  
 Top : Free to Rotate, No Translation Bottom : End entirely Fixed  
 Top : End entirely Fixed Bottom : End entirely Fixed  
 Top : End entirely Fixed Bottom : Free to Rotate, No Translation  
 Top : Rotation & Translation Allowed Bottom : End entirely Fixed  
*Move cursor over item for info*

Overall Column Height 12.0 ft  
*( Used for bending analysis, not slenderness )*

**Design Stresses**

Analysis Method ASD LRFD

Fy : Steel Yield 50.0 ksi  
*A-992, High Strength, Low Alloy, Fy = 50 ksi*

E : Elastic Bending Modulus 29,000.0 ksi

## Column Size Tab

All items on this tab are specific to a steel column.

The item circled in **red** is where you can type in the typical section name, press [Tab], and the section will be searched and retrieved from our built-in database. Or you can click the




button, and you can select a section from the built-in AISC database.


The items circled in **blue** are the section properties for the section you have chosen.

The item circled in **green** is the Quick-List". Click on one of the many buttons with a section letter and the full list of those sections will be displayed to the right. Simply click on a section and it will be assigned to the red and blue areas.





The button circled in pink will display the Steel Member Design dialog (see below).



This tool checks all of the steel sections for the selected type (W is selected in this case). A section will be judged to pass if the maximum stress ratio entered is not exceeded and the depth measurements and depth class are not exceeded.

We use the term "Depth Class" to refer to the nominal dimension of the family to which the section belongs (ex: W14). It does refer to the actual depth of the section. All sections starting with "W14" are of the "14" depth class.

### Results Tab

This tab provides a summary of the stress ratios, reactions and deflections for the column.

**Max Axial + Bending Stress Ratio** is the governing load combination for the column. Listed is the governing load combination, the AISC formulas that are used, and the location of the maximum stress ratio above the base of the column. Please note that the maximum stress ratio is being reported (along with its location) because it governs the overall design, even though it may not necessarily be the highest axial stress or the highest bending stress experienced anywhere in the column.

**Max Shear Stress Ratio** will probably never govern for a normally loaded column design. But it is presented here with the governing load combination, location and allowable/actual stress values.

**Lateral Load Reactions and Deflections** are the result of applied lateral loads.

**Bending & Shear Check Results** **W14X90**

✓ Maximum Axial + Bending Stress Ratio = **0.3489** : 1  
 Load Combination: +D+L  
 Location of max. above base: 11.919 ft  
 At maximum location values are . . .  
 Pu : Axial: 30.0 k  
 Pn / Omega : Allowable: 734.56 k  
 Mu-x : Applied: 0.0 k-ft  
 Mn-x / Omega : Allowable: 381.64 k-ft  
 Mu-y : Applied: 59.597 k-ft  
 Mn-y / Omega : Allowable: 181.42 k-ft

✓ Maximum Shear Stress Ratio = **0.01214** : 1  
 Load Combination: +D+L  
 Location of max. above base: 0.0 ft  
 Vu : Applied: 5.0 k  
 Vn / Omega : Allowable: 411.80 k

Maximum SERVICE Load Reactions . . . (see Reactions tab for all)  
 Top along Y-Y: 0.0 k Bottom along Y-Y: 0.0 k  
 Top along X-X: 5.0 k Bottom along X-X: 5.0 k

Maximum SERVICE Load Deflections . . . (see A-M-V-D tab for all)  
 Along Y-Y: 0.0 in at 0.0 ft above base  
 for load combination :  
 Along X-X: 0.09203 in at 7.007 ft above base  
 for load combination : D+L

## Design Maximum Combinations Tab

This tab lists the resulting maximum stress ratios for each load combination. This list is created by examining the detailed list (on the next tab) and determining the governing stress ratios for each load combination.

Load Combination Name	Max. Axial+Bending Stress Ratios			Max Shear Ratios		
	Stress Ratio	Status	Location (ft)	Stress Ratio	Status	Location (ft)
+D	0.2326	PASS	11.9195	0.0081	PASS	0.0000
+D+L	0.3489	PASS	11.9195	0.0121	PASS	0.0000
+D+0.750Lr+0.750L	0.3198	PASS	11.9195	0.0111	PASS	0.0000
+D+0.750Lr+0.750S	0.3198	PASS	11.9195	0.0111	PASS	0.0000
+D+0.750Lr+0.750L+0.750W	0.3198	PASS	11.9195	0.0111	PASS	0.0000
+D+0.750Lr+0.750S+0.750W	0.3198	PASS	11.9195	0.0111	PASS	0.0000
+D+0.750Lr+0.750L+0.5250E	0.3198	PASS	11.9195	0.0111	PASS	0.0000
+D+0.750Lr+0.750S+0.5250E	0.3198	PASS	11.9195	0.0111	PASS	0.0000

These values represent the governing Axial, M-x and M-y values calculated from applied axial loads & eccentricities, applied moments, and end conditions.

## Detailed A-M-V-D Results Tab - Stresses

This tab lists the detailed results at small increments along the height of the column, for each load combination.

For consistency, all of the column headings are taken directly from AISC.

Note! This list scrolls to the right to display more information.

The screenshot shows a software interface with a table titled "Service Load Deflections". The table has columns for "ASD/Service Loads", "Axial (k)", "Moment (k-ft)", and "Shear (k)". The "ASD/Service Loads" column includes "Load Combination, Distance" and "Pu". The "Axial (k)" column includes "Pn-C/Omega", "Pn-T/Omega", "Mu : x", and "Mnx / Omega". The "Moment (k-ft)" column includes "Mu : y", "Mny / Omega", "Vu : X", and "VnX / Omega". The "Shear (k)" column includes "Vu : Y". The table contains 13 rows of data for various distances from 0.000 ft to 1.047 ft.

ASD/Service Loads	Axial (k)		Moment (k-ft)				Shear (k)			
Load Combination, Distance	Pu	Pn-C/Omega	Pn-T/Omega	Mu : x	Mnx / Omega	Mu : y	Mny / Omega	Vu : X	VnX / Omega	Vu : Y
+D										
0.000 ft	20.000	734.557	793.413		381.642		181.422	-3.333	411.800	
0.081 ft	20.000	734.557	793.413		381.642	0.268	181.422	-3.333	411.800	
0.161 ft	20.000	734.557	793.413		381.642	0.537	181.422	-3.333	411.800	
0.242 ft	20.000	734.557	793.413		381.642	0.805	181.422	-3.333	411.800	
0.322 ft	20.000	734.557	793.413		381.642	1.074	181.422	-3.333	411.800	
0.403 ft	20.000	734.557	793.413		381.642	1.342	181.422	-3.333	411.800	
0.483 ft	20.000	734.557	793.413		381.642	1.611	181.422	-3.333	411.800	
0.564 ft	20.000	734.557	793.413		381.642	1.879	181.422	-3.333	411.800	
0.644 ft	20.000	734.557	793.413		381.642	2.148	181.422	-3.333	411.800	
0.725 ft	20.000	734.557	793.413		381.642	2.416	181.422	-3.333	411.800	
0.805 ft	20.000	734.557	793.413		381.642	2.685	181.422	-3.333	411.800	
0.886 ft	20.000	734.557	793.413		381.642	2.953	181.422	-3.333	411.800	
0.966 ft	20.000	734.557	793.413		381.642	3.221	181.422	-3.333	411.800	
1.047 ft	20.000	734.557	793.413		381.642	3.490	181.422	-3.333	411.800	

### Detailed A-M-V-D Results Tab - Service Load Deflections

This tab reports the deflections at incremental locations along the height of the column, for each service load condition (i.e. for individual load cases and for a set of built-in service load combinations), along each axis.

The screenshot shows a zoomed-in view of the "Service Load Deflections" table. It has columns for "Unfactored Service Loads" and "Deflection (in)". The "Unfactored Service Loads" column includes "Load Combination, Distance". The "Deflection (in)" column includes "xx Defl" and "yy Defl". The table shows deflection values for various distances from 0.000 ft to 1.047 ft.

Unfactored Service Loads	Deflection (in)	
Load Combination, Distance	xx Defl	yy Defl
+D Only		
- L Only		
0.000 ft	0.0005	
0.081 ft	0.0011	
0.161 ft	0.0016	
0.242 ft	0.0021	
0.322 ft	0.0026	
0.403 ft	0.0032	
0.483 ft	0.0037	
0.564 ft	0.0042	
0.644 ft	0.0048	
0.725 ft	0.0053	
0.805 ft	0.0058	
0.886 ft	0.0063	
0.966 ft	0.0068	
1.047 ft		

### Reactions Tab


This tab provides the sideways (non-axial) reactions for individual load cases and for a set of built-in service load combinations, along each axis.

Results Design Maximum Combinations Detailed A-M-V-D Results Reactions

Reactions from LATERAL Loads along direction noted . . .


SERVICE LOADS Load Combination	X-X Reaction (k)		Y-Y Reaction (k)		Axial Reaction (k)
	@ Base	@ Top	@ Base	@ Top	@ Base
D Only		-5.000	9.000		20.000
L Only		-5.000	6.000		10.000
W Only		-5.000	6.000		
E Only		-5.000	9.000		
D+L		-5.000	9.000		30.000
D+W		-5.000	6.000		20.000
D+L+W		-5.000	15.000		30.000
D+E		-5.000	6.000		20.000
D+L+E		-5.000	15.000		30.000

### Sketch Tab



### Axial-Shear-Moment Diagrams

This tab provides comprehensive charting capability to view graphs of Axial load, Shear, Moment, and Deflection along the length of the member. Note that the graphs are oriented such that the right end of the graph represents the column base, and the left end of the graph represents the column top. This was done to maximize the scale of the graph based on the screen area available.



### 10.3.4 Concrete Column

[Need more? Ask Us a Question](#)

This module designs concrete columns that are subject to axial loads and lateral bending loads about both axes. Click here for a video: Concrete Column

The module only uses strength design for concrete.

All calculations are according to the referenced version of ACI 318 based on the selected governing building code.

The screen capture below shows the full screen for concrete column design. See items below for descriptions of items that are specific to the concrete column design module.

For general description of the module, end fixity, loads, and load combinations [click here](#)<sup>326</sup>. For slenderness description [click here](#)<sup>331</sup>.

The screenshot displays the 'Concrete Column' software interface. The top menu bar includes 'General', 'Concrete Shape', 'Loads', 'Slenderness', and 'D+L+?' Load Combinations. The 'Description' field contains 'Sample Concrete Column'. The 'Column Material' is set to 'Concrete'. The 'Overall Column Height' is 10.0 ft. Material values include  $f_c = 3.0$  ksi,  $f_y$  - Main Rebar = 60.0 ksi, Density = 145.0 pcf, and  $E = 3,122.02$  ksi. End fixities are set to 'Top: Free to Rotate, No Translation' and 'Bottom: Free to Rotate, No Translation'. The 'Results' tab is active, showing a Maximum Stress Ratio of 0.2811. Governing Load Combination is +1.20D+1.60L+0.50S+1.60H. Maximum SERVICE Load Reactions and Deflections are also displayed.

Pnmax : Nominal Max. Compressive Axial Capacity	1,608.60 k
$\phi$ Pn, max : Usable Compressive Axial Capacity	1,025.48 k

$\phi$	= 0.750	$\beta$	= 0.850	$\theta$	= 0.850 (ACI-318 10.3.6)
P	: % Reinforcing	1.7510 %	Rebar	% Ok	
	Reinforcing Area	7.920 in <sup>2</sup>			
	Concrete Area	452.39 in <sup>2</sup>			

## General Tab

The area circled in red in the screen capture below is specific to the concrete column selection.

The screenshot shows the 'General' tab for a 'Sample Concrete Column'. The 'Material Values' section is circled in red. It contains the following fields and values:

- $f_c$ : 3.0 ksi
- Density: 145.0 pcf
- $f_y$  - Main Rebar: 60.0 ksi
- E - Main Rebar: 29,000.0 ksi
- E - Concrete: 3,122.02 ksi
- Buttons for E - Concrete:
  - Set to:  $57,000 * \sqrt{f_c}$
  - Set to:  $(w^{1.5}) * 33 * f_c^{0.5}$
- Allow. Reinforcing Limits:
  - Min. Reinf.: 1.0 %
  - Max. Reinf.: 8.0 %

The two buttons and immediately set the value for elastic modulus "E" to the values as described on the button.

## Concrete Shape

This tab is specific to the concrete column selection. It allows you to select from 12 different column shapes. Simply click the button surrounding the column shape icon and the screen below will change to allow specific data input for measurements and reinforcing layout.

Following the screen capture below we will show ALL the data input areas for ALL the column shapes with descriptions as needed.

Note that this module does a very detailed biaxial analysis of the column cross section using exact numerical methods.


### Circular Column

**Circular Column**

**Dimensions** Diameter . . . . . 18.0 in

**Reinforcing**  Hollow Inside Diameter . . . . .

Column Edge to Rebar Edge Cover . . . . . 2.0 in




**Circular Column**

**Dimensions** **Rebar Layout:**

**Reinforcing**  Bar Size . . . . . # 5

Bar Count . . . . . 8.0



*Note: Exact bar counts not shown here...see full graphics.*


**Circular Column**

**Dimensions** **Rebar Layout:**

**Reinforcing**  Corner Bar Size . . . . . 5

Middle bars at top & bottom . . . . .  
Bar Count 2.0 Bar Size 5

Middle bars at left & right . . . . .  
Bar Count 2.0 Bar Size 5



*Note: For bars, exact counts not shown here...see full graphics.*

**Circular Column**

**Dimensions** **Rebar Layout:**

**Reinforcing** Bar Size Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	4.729	4.729
2	5	-4.729	4.729
3	5	-4.729	-4.729
4	5	4.729	-4.729
5	5	-1.576	4.729
6	5	-1.576	-4.729
7	5	1.576	4.729
8	5	1.576	-4.729
9	5	-4.729	-1.576
10	5	4.729	-1.576

#3 #4 #5 #6 #7

#8 #9 #10 #11 #18

X Location 4.729 in

Y Location 4.729 in

### Square Column

**Square Column**

**Dimensions** Square Dimension  in

**Reinforcing** Column Edge to Rebar Edge Cover  in

**Square Column**

**Dimensions**

**Reinforcing** Rebar Layout: **Square Cage** Circular Cage General

Corner Bar Size

Middle bars at top & bottom . . .  
Bar Count  Bar Size

Middle bars at left & right . . .  
Bar Count  Bar Size

*Note: For ● ● bars, exact counts not shown...see graphics.*

**Square Column**

**Dimensions**

**Reinforcing** Rebar Layout: Square Cage **Circular Cage** General

Bar Size

Bar Count

*Note: Exact bar counts not shown...see graphics.*

**Square Column**

**Dimensions**

**Reinforcing** Rebar Layout: Square Cage Circular Cage **General**

Bar Size  Use Buttons & List to Define Rebar

#3 #4 **#5** #6 #7

#8 #9 #10 #11 #18

X Location  in

Y Location  in

*Dimensions from lower-left corner.*

Bar ID #	Bar Size	X	Y
1	5	15.375	8.688
2	5	12.031	14.479
3	5	5.344	14.479
4	5	2.000	8.688
5	5	5.344	2.896
6	5	12.031	2.896

## Rectangular Column



**Rectangular Column**

**Dimensions**  
 Height: 12.0 in  
 Width: 12.0 in  
 Column Edge to Rebar Edge Cover: 2.0 in

**Reinforcing**

**Rectangular Column**

**Dimensions**

**Reinforcing**

Rebar Layout: **Rectangular Cage** | General

Corner Bar Size: 5

Middle bars at top & bottom: Bar Count 2.0, Bar Size 5

Middle bars at left & right: Bar Count 2.0, Bar Size 5

Note: For ● ● bars, exact counts not shown...see graphics.

**Rectangular Column**

**Dimensions**

**Reinforcing**

Rebar Layout: Rectangular Cage | **General**

Bar Size: Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	2.313	2.313
2	5	2.313	9.688
3	5	9.688	9.688
4	5	9.688	2.000
5	5	4.771	9.688
6	5	4.771	2.313
7	5	7.229	9.688
8	5	7.229	2.313
9	5	2.313	4.771
10	5	9.688	4.771

X Location: 2.313 in  
 Y Location: 2.313 in

Dimensions from lower-left corner:

Buttons: Delete, Add, Delete All

### Trapezoidal Column

**Trapezoidal Column**

**Dimensions**  
 Top Width: 12.0 in  
 Offset: 2.0 in  
 Bottom Width: 12.0 in  
 Height: 10.0 in

**Reinforcing**

Column Edge to Rebar Edge Cover: 2.0 in

Buttons: Set Column Symmetrical


**Trapezoidal Column**

Rebar Layout: **Perimeter Cage** **General**

Corner Bar Size: 5

Middle bars at top & bottom: Bar Count 2.0, Bar Size 5

Middle bars at left & right: Bar Count 2.0, Bar Size 5



Note: For bars, exact counts not shown...see graphics.

**Trapezoidal Column**

Rebar Layout: **Perimeter Cage** **General**

Bar Size: #3 #4 #5 #6 #7 #8 #9 #10 #11 #18

X Location: 2.313 in

Y Location: 2.313 in

Dimensions from lower-left corner.

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	2.313	2.313
2	5	4.313	7.688
3	5	11.688	7.688
4	5	9.688	2.000
5	5	6.771	7.688
6	5	9.229	7.688
7	5	4.563	2.313
8	5	7.125	2.313
9	5	2.979	4.104
10	5	3.646	5.806

Buttons: Delete, Add, Delete All

### "L" Shaped Column

**L Shaped Column**

Dimensions


Height: 12.0 in

Width: 12.0 in

Vert. Section Width: 6.0 in

Horiz. Section Height: 6.0 in

Column Edge to Rebar Edge Cover (Dbl Row only): 2.0 in




**L Shaped Column**

Rebar Layout: **Single Row** **Double Row** **General**

Bar Size: 5

Vertical middle bars: Bar Count 3.0, Bar Size 5

Horizontal middle bars: Bar Count 3.0, Bar Size 5



Note: Exact bar count not shown...see graphics.

**L Shaped Column**

Rebar Layout: **Single Row** Double Row General

Reinforcing

- Bar Size & Number . . . . . Bar Count: 6.0 Bar Size: 5
- Bar Size & Number . . . . . Bar Count: 6.0 Bar Size: 5
- Bar Size & Number . . . . . Bar Count: 3.0 Bar Size: 5
- Bar Size & Number . . . . . Bar Count: 3.0 Bar Size: 5

Note: Exact bar count not shown.

**L Shaped Column**

Rebar Layout: Single Row **Double Row** General

Reinforcing

Bar Size: #3 #4 #5 #6 #7 #8 #9 #10 #11 #18

X Location: 2.313 in

Y Location: 2.313 in

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	2.313	2.313
2	5	2.313	9.688
3	5	3.688	9.688
4	5	3.688	2.313
5	5	9.688	3.688
6	5	9.688	2.313
7	5	2.313	3.600
8	5	2.313	5.200
9	5	2.313	6.800
10	5	2.313	8.400

Buttons: Delete Add Delete All

**"Z" Shaped Column**

**Z Shaped Column**

Dimensions

- Top Height: 6.0 in
- Overall Height: 18.0 in
- Vertical Width: 6.0 in
- Left Offset: 6.0 in
- Bottom Width: 12.0 in
- Bottom Height: 6.0 in

Column Edge to Rebar Edge Cover (Dbl Row only): 2.0 in

**Z Shaped Column**

Rebar Layout: **Single Row** Double Row General

Reinforcing

- Bar Size . . . . . Bar Size: 5
- Bar Size & Count . . . . . Bar Count: 2.0 Bar Size: 5
- Bar Size & Count . . . . . Bar Count: 3.0 Bar Size: 5
- Bar Size & Count . . . . . Bar Count: 2.0 Bar Size: 5

Note: Exact bar count not shown...see graphics.

**Z Shaped Column**

**Rebar Layout:** **Single Row** **Double Row** **General**

**Reinforcing**

- Bar Size & Number . . . . . Bar Size: 5
- Bar Size & Number . . . . . Bar Count: 4.0 Bar Size: 5
- Bar Size & Number . . . . . Bar Count: 4.0 Bar Size: 5
- Bar Size & Number . . . . . Bar Count: 4.0 Bar Size: 5

*Note: Exact bar count not shown.*

**Z Shaped Column**

**Rebar Layout:** **Single Row** **Double Row** **General**

**Reinforcing**

Bar Size: #3 #4 #5 #6 #7 #8 #9 #10 #11 #18

X Location: 2.313 in

Y Location: 15.688 in

*Dimensions from lower-left corner.*

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	2.313	15.688
1	5	2.313	14.313
1	5	9.688	15.688
1	5	9.688	14.313
2	5	8.313	2.313
3	5	8.313	3.688
4	5	15.688	2.313
5	5	15.688	3.688
6	5	4.771	15.688
7	5	4.771	14.313

Buttons: Delete, Add, Delete All

**Six Sided Column**

**Six Sided Column**

**Dimensions**

- Top Width: 6.0 in
- Bottom Width: 18.0 in
- Left Offset: 6.0 in
- Base Height: 6.0 in
- Total Height: 18.0 in
- Column Edge to Rebar Edge Cover: 2.0 in

**Six Sided Column**

**Rebar Layout:** **Perimeter Pattern** **General**

**Reinforcing**

- Bar Size . . . . . 5
- Maximum Bar Spacing: 3.0 in

*Note: Exact bar count not shown here...see full graphics.*

**Six Sided Column**

Rebar Layout: **Perimeter Pattern** **General**

Bar Size: #3 #4 **#5** #6 #7  
 #8 #9 #10 #11 #18

X Location: 2.313 in  
 Y Location: 2.313 in  
*Dimensions from lower-left corner.*

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	2.313	2.313
2	5	15.688	2.313
3	5	2.251	5.469
4	5	15.749	5.469
5	5	6.531	15.749
6	5	11.469	15.749
7	5	4.988	2.313
8	5	7.663	2.313
9	5	10.338	2.313
10	5	13.013	2.313

Buttons: Delete Add Delete All

**"T" Shaped Column**

**T ShapedColumn**

Dimensions: Total Height: 18 in  
 Top Flange Width: 18 in  
 Top Flange Thickness: 6 in  
 Web Thickness: 8 in  
 Column Edge to Rebar Edge Cover: 2 in

**T ShapedColumn**

Rebar Layout: **Perimeter Pattern** **General**

Bar Size: 5  
 Maximum Bar Spacing: 5 in

Note: Exact bar count not shown here...see full graphics.

**T ShapedColumn**

Rebar Layout: **Perimeter Pattern** **General**

Bar Size: #3 #4 **#5** #6 #7  
 #8 #9 #10 #11 #18

X Location: -2.688 in  
 Y Location: 15.688 in  
*Dimensions from lower-left corner.*

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	-2.688	15.688
2	5	-2.688	14.313
3	5	10.688	15.688
4	5	10.688	14.313
5	5	1.771	15.688
6	5	1.771	14.313
7	5	6.229	15.688
8	5	6.229	14.313
9	5	10.688	15.688
10	5	10.688	14.313

Buttons: Delete Add Delete All

**"I" Shaped Column**

**I ShapedColumn**

**Dimensions**

Top Flange Width: 12.0 in

Top Flange Thickness: 4.0 in

Web Thickness: 4.0 in

Bottom Flange Width: 10.0 in

Bottom Flange Thickness: 4.0 in

Total Height: 18.0 in

Column Edge to Rebar Edge Cover: 2.0 in

**I ShapedColumn**

**Reinforcing**

Rebar Layout: **Perimeter Pattern** | General

Bar Size: 5

Maximum Bar Spacing: 5.0 in

Note: Exact bar count not shown here...see full graphics.

**I ShapedColumn**

**Reinforcing**

Rebar Layout: Perimeter Pattern | **General**

Bar Size: #5

X Location: 2.313 in

Y Location: 2.313 in

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	2.313	2.313
2	5	2.313	1.688
3	5	7.688	2.313
4	5	7.688	1.688
5	5	1.313	15.688
6	5	1.313	16.313
7	5	8.688	15.688
8	5	8.688	16.313
9	5	5.000	15.688
10	5	5.000	16.313

Buttons: Delete, Add, Delete All

### Cross Shaped Column

**Cross Shaped Column**

**Dimensions**

Overall Height: 18.0 in

Overall Width: 18.0 in

Width: 6.0 in

Height: 6.0 in

Vert. Offset: 6.0 in

Horiz. Offset: 6.0 in


Column Edge to Rebar Edge Cover: 2.0 in

**Cross Shaped Column**

Dimensions | Rebar Layout: **Perimeter Pattern** | General

Reinforcing

Bar Size: 5  
Maximum Bar Spacing: 2.0



Note: Exact bar count not shown here...see full graphics.

**Cross Shaped Column**

Dimensions | Rebar Layout: **Perimeter Pattern** | General

Reinforcing

Bar Size: #3 #4 #5 #6 #7 #8 #9 #10 #11 #18

X Location: 8.313 in  
Y Location: 2.313 in

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	8.313	2.313
2	5	9.688	2.313
1	5	8.313	15.688
2	5	9.688	15.688
1	5	2.313	8.313
2	5	2.313	3.688
1	5	15.688	8.313
2	5	15.688	3.688
1	5	8.313	8.313
1	5	8.313	3.688

Delete + Add Delete All


### Octagon Column

**Octagon Column**

Dimensions | Select Entry Method: **Max. Height/Width** | Edge Dimension

Reinforcing

Max. Height/Width: 18.0 in  
Edge Dimension: 4.000 in  
Column Edge to Rebar Edge Cover: 2.0 in




Max. Height/Width  
Edge Dimension  
Cover  
Edge Dimension

**Octagon Column**

Dimensions | Rebar Layout: **Perimeter Pattern** | General

Reinforcing

Bar Size: 5  
Maximum Bar Spacing: 2.0 in



Note: Exact bar count not shown here...see full graphics.

**Octagon Column**

**Dimensions** | **Rebar Layout:** **Perimeter Pattern** | **General**

**Reinforcing**

Bar Size: #3 #4 #5 #6 #7 #8 #9 #10 #11 #18

X Location: 1.414 in  
Y Location: -0.700 in  
*Dimensions from lower-left corner.*

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y
1	5	1.414	-0.700
2	5	1.414	-3.300
3	5	3.528	-5.414
4	5	6.128	-5.414
5	5	16.586	-3.300
6	5	16.586	-0.700
7	5	6.128	1.414
8	5	3.528	1.414
9	5	1.414	-2.000
10	5	1.414	-3.300

Buttons: Delete, Add, Delete All

### Rectangular Tube Column

**Rectangular Tube Column**

**Dimensions** | **Reinforcing**

Height: 18.0 in  
Width: 18.0 in  
X1: 6.0 in  
X2: 4.0 in  
Y1: 8.0 in  
Y2: 6.0 in

**Rectangular Tube Column**

**Dimensions** | **Reinforcing**

Bar Size: #3 #4 #5 #6 #7 #8 #9 #10 #11 #18

X Location: 0.000 in  
Y Location: 0.000 in  
*Dimensions from same datum as edges!*

Use Buttons & List to Define Rebar

Bar ID #	Bar Size	X	Y

Buttons: Delete, Add, Delete All

### Results Tab

Results | Design Results | A-M-V-D Results | Pn-Mnx-Mny Capacities | Section Props | Reactions

Governing Load Combination: +1.20D+1.60L+0.50S+1.60H  
Location of max. above base: 9.933 ft

Maximum Stress Ratio = 0.2811 : 1  
Ratio =  $(P_u^2 + M_u^2)^{.5} / (\Phi P_n^2 + \Phi M_n^2)^{.5}$

Pu = 285.47 k, Pn = 1,025.48 k  
Mu-x = 14.279 k-ft, Mn-x = 0.0 k-ft  
Mu-y = 28.110 k-ft, Mn-y = 0.0 k-ft  
Mu Angle = 63.0 deg, Mn @ Angle = 111.50 k-ft  
Mu @ Angle = 31.529 k-ft

Pn & Mn values located at Pu-Mu vector intersection with capacity curve

Column Capacities . . .  
Pnmax : Nominal Max. Compressive Axial Capacity: 1,608.60 k  
Phi Pn, max : Usable Compressive Axial Capacity: 1,025.48 k

Maximum SERVICE Load Reactions . . .  
Top along Y-Y: k, Bottom along Y-Y: k  
Top along X-X: k, Bottom along X-X: k

Maximum SERVICE Load Deflections . . .  
Along Y-Y: -0.000832 in at 2.953 ft above base  
for load combination : D+L+Lr  
Along X-X: -0.001123 in at 2.953 ft above base  
for load combination : D+L

General Section Information . . .  
phi = 0.750, beta = 0.850, theta = 0.850 (ACI-318 10.3.6)  
rho : % Reinforcing: 1.7510 % Rebar % Ok  
Reinforcing Area: 7.920 in^2  
Concrete Area: 452.39 in^2



### Design Results Tab - Load Combination Summary

Load Combination	Base Dist (ft)	Pu (kips)	Phi * Pn (kips)	X-Slenderness Delta	Delta*Mux	Y-Slenderness Delta	Delta*Muy	Alpha (deg)	Moments @ Alpha (k-ft)	Utilization Ratio	
+1.40D	9.93	146.38	1,025.48	1.00	6.95	1.00	14.25	64.00	15.86	111.53	0.142
+1.20D+0.50Lr+1.60L+1.60H	9.93	285.47	1,025.48	1.00	16.39	1.00	28.11	60.00	32.54	115.73	0.280
+1.20D+1.60L+0.50S+1.60H	9.93	285.47	1,025.48	1.00	14.28	1.00	28.11	63.00	31.53	111.50	0.281
+1.20D+1.60Lr+0.50L	9.93	175.47	1,002.52	1.00	16.39	1.00	17.18	46.00	23.75	136.80	0.174
+1.20D+1.60Lr+0.80W	9.93	125.47	989.96	1.00	13.91	1.00	12.22	41.00	18.51	144.35	0.128
+1.20D+0.50L+1.60S	9.93	175.47	1,025.48	1.00	9.63	1.00	17.18	61.00	19.70	115.73	0.171
+1.20D+1.60S+0.80W	9.93	125.47	1,025.48	1.00	7.15	1.00	12.22	60.00	14.16	115.73	0.122
+1.20D+0.50Lr+0.50L+1.60W	9.93	175.47	1,025.47	1.00	10.93	1.00	17.18	58.00	20.36	119.64	0.171
+1.20D+0.50L+0.50S+1.60W	9.93	175.47	1,025.48	1.00	8.82	1.00	17.18	63.00	19.31	111.50	0.172
+1.20D+0.50L+0.20S+E	9.93	175.47	1,025.48	1.00	8.59	1.00	17.18	63.00	19.21	111.50	0.172

### Design Results Tab - Load Combination Detailed Results

Load Combination Name	Dist. From Base (ft)	Factored Applied Pu (k)	Alpha (deg)	Factored Applied Mu@Alpha (k & k-ft)	Delta Mag. Factors X-X	Y-Y	Magnified Moments (k-ft) Delta*X*Mux	Delta*Muy	Cm X	Y	k*Lu/r X	Y	Pc: Euler Buckling X	Y
+1.40D	9.93	146.38	64.0	15.86	1.000	1.000	6.95	14.25	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+0.50Lr+1.60L+1	9.93	285.47	60.0	32.54	1.000	1.000	16.39	28.11	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+1.60L+0.50S+1	9.93	285.47	63.0	31.53	1.000	1.000	14.28	28.11	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+1.60Lr+0.50L	9.93	175.47	46.0	23.75	1.000	1.000	16.39	17.18	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+1.60Lr+0.80W	9.93	125.47	41.0	18.51	1.000	1.000	13.91	12.22	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+0.50L+1.60S	9.93	175.47	61.0	19.70	1.000	1.000	9.63	17.18	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+1.60S+0.80W	9.93	125.47	60.0	14.16	1.000	1.000	7.15	12.22	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+0.50Lr+0.50L+1	9.93	175.47	58.0	20.36	1.000	1.000	10.93	17.18	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+0.50L+0.50S+1	9.93	175.47	63.0	19.31	1.000	1.000	8.82	17.18	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55
+1.20D+0.50L+0.20S+E	9.93	175.47	63.0	19.21	1.000	1.000	8.59	17.18	1.00	1.00	1.7	1.7	1,254,556.72	1,254.55

Note: The value of Euler Buckling load (Pc) is calculated using the following formula from ACI 318-11 Section R10.10.6.2:  $EI = 0.25E_c I_g$ .

### A-M-V-D Results - Strength Design Results

FACTORED LOADS Load Combination, Distance	Pu (k)	Moment (k-ft) Mu - xx	Mu - yy	Shear (k) Vu - xx	Vu - yy
+1.40D 0.000 ft	146.377			2.870	1.400
0.067 ft	146.377	-0.094	-0.193	2.870	1.400
0.134 ft	146.377	-0.188	-0.385	2.870	1.400
0.201 ft	146.377	-0.282	-0.578	2.870	1.400
0.268 ft	146.377	-0.376	-0.770	2.870	1.400
0.336 ft	146.377	-0.470	-0.963	2.870	1.400
0.403 ft	146.377	-0.564	-1.156	2.870	1.400
0.470 ft	146.377	-0.658	-1.348	2.870	1.400
0.537 ft	146.059	-0.752	-1.541	2.870	1.400
0.604 ft	146.059	-0.846	-1.734	2.870	1.400
0.671 ft	146.059	-0.940	-1.926	2.870	1.400
0.738 ft	146.059	-1.034	-2.119	2.870	1.400
0.805 ft	146.059	-1.128	-2.311	2.870	1.400
0.872 ft	146.059	-1.221	-2.504	2.870	1.400
0.940 ft	146.059	-1.315	-2.697	2.870	1.400
1.007 ft	145.740	-1.409	-2.889	2.870	1.400
1.074 ft	145.740	-1.503	-3.082	2.870	1.400

### A-M-V-D Results - Service Load Deflections

SERVICE LOADS		Deflections (in)	
Load Combination, Distance	xx Defl	yy Defl	
D Only			
L Only			
Lr Only			
L+Lr			
0.000 ft			
0.067 ft	-0.0000	-0.0000	
0.134 ft	-0.0000	-0.0000	
0.201 ft	-0.0001	-0.0001	
0.268 ft	-0.0001	-0.0001	
0.336 ft	-0.0001	-0.0001	
0.403 ft	-0.0001	-0.0001	
0.470 ft	-0.0001	-0.0001	
0.537 ft	-0.0002	-0.0002	
0.604 ft	-0.0002	-0.0002	
0.671 ft	-0.0002	-0.0002	
0.738 ft	-0.0002	-0.0002	
0.805 ft	-0.0002	-0.0002	
0.872 ft	-0.0002	-0.0002	

Note: Deflections are based on Ig.

### P-Mx-My Capacities

Alpha : Mux-Mux	Load	Stress Block	Max Tension	Phi	Pn	Mn @ Alpha	Phi Pn : Allow	Phi Mn @ Alpha
Result Angle (deg)	Combination	(in)	Steel Strain		(k)	(k-ft)	(k)	(k-ft)
64.00	+1.40D	70.650	0.750	0.750	1,608.52	0.75	1,025.48	0.57
60.00	+1.20D+0.50Lr+1.60L+1.60H	70.575	0.750	0.750	1,608.53	0.71	1,025.48	0.53
63.00	+1.20D+1.60L+0.50S+1.60H	70.725	0.750	0.750	1,608.54	0.53	1,025.48	0.40
46.00	+1.20D+1.60Lr+0.50L	70.668	0.750	0.750	1,608.51	0.85	1,025.48	0.64
41.00	+1.20D+1.60Lr+0.80W	58.575	0.750	0.750	1,600.20	78.42	1,025.48	58.81
41.00	+1.20D+1.60Lr+0.80W	52.875	0.750	0.750	1,591.94	148.78	1,025.48	111.59
41.00	+1.20D+1.60Lr+0.80W	48.375	0.750	0.750	1,583.36	218.45	1,025.48	163.84
41.00	+1.20D+1.60Lr+0.80W	45.225	0.750	0.750	1,575.26	279.15	1,025.48	209.36
41.00	+1.20D+1.60Lr+0.80W	42.375	0.750	0.750	1,566.90	341.85	1,025.48	256.39
41.00	+1.20D+1.60Lr+0.80W	39.825	0.750	0.750	1,558.40	405.56	1,025.48	304.17
41.00	+1.20D+1.60Lr+0.80W	37.725	0.750	0.750	1,549.98	464.55	1,025.48	348.41
41.00	+1.20D+1.60Lr+0.80W	36.000	0.750	0.750	1,541.72	518.10	1,025.48	388.57
41.00	+1.20D+1.60Lr+0.80W	34.425	0.750	0.750	1,533.45	571.68	1,025.48	428.76
41.00	+1.20D+1.60Lr+0.80W	32.925	0.750	0.750	1,524.85	627.48	1,025.48	470.61
41.00	+1.20D+1.60Lr+0.80W	31.575	0.750	0.750	1,516.40	682.23	1,025.48	511.67
41.00	+1.20D+1.60Lr+0.80W	30.375	0.750	0.750	1,508.27	734.98	1,025.48	551.24
41.00	+1.20D+1.60Lr+0.80W	29.213	0.750	0.750	1,499.75	790.22	1,025.48	592.67
41.00	+1.20D+1.60Lr+0.80W	28.181	0.750	0.750	1,491.44	845.00	1,025.48	633.75
41.00	+1.20D+1.60Lr+0.80W	27.731	0.750	0.750	1,483.08	921.45	1,025.48	691.09
41.00	+1.20D+1.60Lr+0.80W	27.394	0.750	0.750	1,474.71	1,000.71	1,025.48	750.53
41.00	+1.20D+1.60Lr+0.80W	27.094	0.750	0.750	1,466.21	1,081.35	1,025.48	811.01

### Section Properties


Alpha	Sxx	Syy	Ixx	Iyy	Ixy	rxx	ryy	Cracked Section
deg	in <sup>3</sup>	in <sup>3</sup>	in <sup>4</sup>	in <sup>4</sup>	in <sup>4</sup>	in	in	Theta (deg)
0	2,304.000	2,304.000	27,648.000	27,648.000	0.000	6.928	6.928	9,238.258
15	1,881.208	1,881.208	27,648.000	27,648.000	0.000	6.928	6.928	9,382.950
30	1,686.645	1,686.645	27,648.000	27,648.000	0.000	6.928	6.928	9,726.975
45	1,629.174	1,629.174	27,648.000	27,648.000	0.000	6.928	6.928	9,905.826
60	1,686.645	1,686.645	27,648.000	27,648.000	-0.000	6.928	6.928	9,755.344
75	1,881.208	1,881.208	27,648.000	27,648.000	0.000	6.928	6.928	9,419.546
90	2,304.000	2,304.000	27,648.000	27,648.000	-0.000	6.928	6.928	9,248.395
105	1,881.208	1,881.208	27,648.000	27,648.000	0.000	6.928	6.928	9,388.442
120	1,686.645	1,686.645	27,648.000	27,648.000	0.000	6.928	6.928	9,699.923
135	1,629.174	1,629.174	27,648.000	27,648.000	0.000	6.928	6.928	9,840.371
150	1,686.645	1,686.645	27,648.000	27,648.000	-0.000	6.928	6.928	9,669.435
165	1,881.208	1,881.208	27,648.000	27,648.000	0.000	6.928	6.928	9,349.280
180	2,304.000	2,304.000	27,648.000	27,648.000	-0.000	6.928	6.928	9,238.258
195	1,881.208	1,881.208	27,648.000	27,648.000	0.000	6.928	6.928	9,475.436
210	1,686.645	1,686.645	27,648.000	27,648.000	0.000	6.928	6.928	9,906.392
225	1,629.174	1,629.174	27,648.000	27,648.000	0.000	6.928	6.928	10,161.343
240	1,686.645	1,686.645	27,648.000	27,648.000	-0.000	6.928	6.928	10,066.295
255	1,881.208	1,881.208	27,648.000	27,648.000	0.000	6.928	6.928	9,765.014
270	2,304.000	2,304.000	27,648.000	27,648.000	-0.000	6.928	6.928	9,605.652
285	1,881.208	1,881.208	27,648.000	27,648.000	0.000	6.928	6.928	9,730.168

### Reactions


Service Load Reactions . . .

SERVICE LOADS Load Combination	X-X Reaction (k)		Y-Y Reaction (k)		Axial reaction (k)
	@ Base	@ Top	@ Base	@ Top	@ Base
D Only	2.050	2.050	1.000	1.000	105.800
L Only	2.000	2.000	1.000	1.000	100.000
Lr Only			1.000	1.000	
L+Lr	2.000	2.000	2.000	2.000	100.000
S Only			0.150	0.150	
D+Lr	2.050	2.050	2.000	2.000	105.800
D+L	4.050	4.050	2.000	2.000	205.800
D+L+Lr	4.050	4.050	3.000	3.000	205.800
D+S	2.050	2.050	1.150	1.150	105.800
D+L+S	4.050	4.050	2.150	2.150	205.800
D+Lr+S	2.050	2.050	2.150	2.150	105.800


### Sketch



### P-M Diagrams



### A-V-M-D Diagrams



## Theoretical Basis

[Click here to view Concrete Column Module Theoretical Basis](#)

### 10.3.5 Masonry Column

[Need more? Ask Us a Question](#)

This module designs masonry columns that are subject to axial loads and lateral bending loads about one axis. Click here for a video: Masonry Column

The user can select ASD or LRFD methods.

All calculations are according to the ACI 530-05 or ACI 530-08 code, depending upon whether IBC 06 or IBC 09 has been selected as the governing building code.

The screen capture below shows the full screen for masonry column design. See items below for descriptions of items that are specific to the masonry column design module.

For general description of the module, end fixity, loads, and load combinations [click here](#)<sup>326</sup>. For slenderness description [click here](#)<sup>331</sup>.


The screenshot shows the 'Masonry Column' software interface. The top menu bar includes 'General', 'Masonry', 'Loads', 'Slenderness', and 'D+L? Load Combinations'. The 'Description' field contains 'Sample Masonry Column'. The 'Column Material' section has buttons for 'Steel', 'Concrete', 'Wood', and 'Masonry' (which is selected). The 'End Fixities' section has radio buttons for different top and bottom conditions. The 'Overall Column Height' is set to 10.0 ft. The 'Analysis Method' section has 'Allowable Stress Design' and 'Strength Design' (which is selected). The 'Phi' value is set to 0.90. The bottom section shows calculation results for 'Bending & Shear Check Results' and 'Reinforcing Area Check'.

Check	Value	Code Reference
Maximum Axial + Bending Stress Ratio	0.109 : 1	
Load Combination	+1.40D	
Location of max. above base	0.000 ft	
At maximum location values are . . .		
Pu	15.506 k	
0.9 * Pn	139.840 k	
Mu-x	0.000 k-ft	
0.9 * Mn-x	28.026 k-ft	
Phi * Pb	46.0 k	
Phi * Mb	50.9 k-ft	
Reinforcing Area Check		(ACI 530-05, Sec 3.3.4.4.1)
As : Actual Reinforcement	1.240	
Min: 0.0025 * An	0.298	
Max: 0.04 * An	4.766	
Dimensional Checks		
Min. (Width or Depth) must be >= 8"		(ACI 530-08, Sec 3.3.4.4.2(b))
Overall Height / Min Dim must be <= 30		(ACI 530-08, Sec 3.3.4.4.2(a))
Maximum SERVICE Load Reactions		(see Reactions tab for all)
Top along Y-Y	0.000 k	
Bottom along Y-Y	0.000 k	
Maximum SERVICE Load Deflections		(see A-M-V-D tab for all)
Along Y-Y	0.000 in at 0.000 ft above base	
for load combination :		
Compressive Strength		(ACI 530-08, Sec 3.3.4.1.1)
Pa = 0.80*[0.80*fm*(An-Ast)+FyAst] * [1-(f1/(140*f1))^2]		
	= 139.891 k	
Check Column Ties		(ACI 530-08, Sec 1.14.1.3)
Min. Tie Dia. = 1/4", # 3 bar provided		
Max Tie Spacing = 7.63 in, Provided = 10.00 in		


## General Tab

The area circled in red below is specific to the masonry column selection. You have the choice of using Working Stress or Strength Design methods.

The column capacity is determined by creating a P-M interaction diagram, so that the effect of compressive force is included in the calculation of allowable moment capacity. For working stress this will result in significantly higher capacities than the older methods that calculated an actual stress ratio using  $(f_a/F_a + f_b/F_b)$ .



Here is the description when the Strength Design method is selected...



## Masonry Tab

All of the information on this tab is specific to masonry column design.


The input items in the **red** bubble define the material properties of the column and reinforcing used.

The input items in the **blue** bubble let you define the cross section size, reinforcing, and orientation of the column.


Under **Specify Column Dimensions** we've made it easy by providing buttons for the common nominal dimensions of a masonry column. Click the Width and Depth buttons and you will see the actual dimension appear in the bottom of the area. Note that "Width" is parallel to the "x-x" axis and "Depth" is parallel to the "y-y" axis.

In the lower right you can specify the bar size and bar count to be used on each face of the column.

The graphic will change accordingly as your input changes.



## Results Tab



## Design Maximum Combinations

This tab summarizes the maximum stress ratios for each load combination.

Load Combination Name	Stress Ratio	Max. Bending Ratios		Axial Values (k)		Moment Values (k-ft)	
		Status	Location (ft)	Actual	Allowable	Actual	Allowable
+1.40D	0.0877	PASS	9.93	15.708	179.207	2.318	26.433
+1.20D+0.50Lr+1.60L+1.60H	0.1689	PASS	9.93	29.464	174.443	4.635	27.402
+1.20D+1.60L+0.50S+1.60H	0.1982	PASS	9.93	34.464	173.876	5.463	27.530
+1.20D+1.60Lr+0.50L	0.1043	PASS	9.93	18.464	176.978	2.814	26.915
+1.20D+1.60Lr+0.80W	0.1221	PASS	9.93	21.464	175.855	3.311	27.111
+1.20D+0.50L+1.60S	0.1982	PASS	9.93	34.464	173.876	5.463	27.530
+1.20D+1.60S+0.80W	0.2158	PASS	9.93	37.464	173.592	5.960	27.558
+1.20D+0.50Lr+0.50L+1.60W	0.1982	PASS	9.93	34.464	173.876	5.463	27.530
+1.20D+0.50L+0.50S+1.60W	0.2274	PASS	9.93	39.464	173.592	6.291	27.558
+1.20D+0.50L+0.20S+E	0.1160	PASS	9.93	20.464	176.417	3.145	27.051
+0.90D+1.60W+1.60H	0.1501	PASS	9.93	26.098	173.876	4.139	27.530

## A-M-V-D Results: Strength Combinations

This tab presents the very detailed allowable and actual values for each load combination.

LRFD/Strength Loads Load Combination, Distance	Maximum Stress Ratio	Axial (k)		Moment (k-ft)	
		Pu	Phi Pn	Mu	Phi Mn
+1.40D					
+1.20D+0.50Lr+1.60L+1.60H					
+1.20D+1.60L+0.50S+1.60H					
+1.20D+1.60Lr+0.50L					
+1.20D+1.60Lr+0.80W					
+1.20D+0.50L+1.60S					
0.000 ft	0.185	33.000	175.855		27.111
0.067 ft	0.172	34.464	199.474	0.037	21.360
0.134 ft	0.172	34.464	199.474	0.074	21.360
0.201 ft	0.172	34.464	199.474	0.111	21.360
0.268 ft	0.172	34.464	199.474	0.148	21.360
0.336 ft	0.172	34.464	199.474	0.185	21.360
0.403 ft	0.172	34.464	199.474	0.221	21.360
0.470 ft	0.172	34.464	199.474	0.258	21.360
0.537 ft	0.172	34.464	199.474	0.295	21.360

## A-M-V-D Results: Service Load Deflections

This tab summarizes the lateral deflections of the column at increments along its height. These values will be nonzero only if lateral loads are applied or the axial load is applied with an eccentricity.

SERVICE LOADS Load Combination, Distance	Deflections (in)	
	xx	Defl
D Only		
L Only		
S Only		
W Only		
D+L		
0.000 ft		
0.067 ft		0.0003
0.134 ft		0.0006
0.201 ft		0.0009
0.268 ft		0.0013
0.336 ft		0.0016
0.403 ft		0.0019
0.470 ft		0.0022
0.537 ft		0.0025
0.604 ft		0.0028
0.671 ft		0.0031



### P-M Surface Data

This tab lists the full analysis results for the column.

Strength Design	P-M Interaction Curve Values		
	Phi*Pn Allow. (k)	Phi*Mn Allow. (k-ft)	Neutral Axis (in)
1: P-M Diagram Point		34.036	2.965
2: P-M Diagram Point	0.066	34.036	2.965
3: P-M Diagram Point	0.298	34.146	2.980
4: P-M Diagram Point	0.529	34.255	2.995
5: P-M Diagram Point	0.758	34.364	3.010
6: P-M Diagram Point	0.986	34.471	3.025
7: P-M Diagram Point	1.212	34.578	3.040
8: P-M Diagram Point	1.438	34.685	3.055
9: P-M Diagram Point	1.662	34.790	3.070
10: P-M Diagram Point	1.885	34.895	3.085
11: P-M Diagram Point	2.107	34.999	3.100
12: P-M Diagram Point	2.328	35.103	3.115
13: P-M Diagram Point	2.547	35.206	3.130
14: P-M Diagram Point	2.765	35.309	3.145
15: P-M Diagram Point	2.982	35.410	3.160
16: P-M Diagram Point	3.198	35.510	3.175
17: P-M Diagram Point	3.412	35.611	3.190


NOTE! These values have been adjusted for Slenderness & Phi.

### Reactions


This tab reports axial reactions and lateral reactions due to lateral loads or due to axial loads that have an eccentricity.

SERVICE LOADS	Lateral Load Reaction		Axial Reaction (k)
	@ Base	@ Top	@ Base
D Only	0.563	-0.563	45.000
L Only	0.038	-0.038	3.000
Lr Only	0.050	-0.050	4.000
L+Lr	0.088	-0.088	7.000
S Only	0.013	-0.013	1.000
W Only	0.013	-0.013	1.000
E Only	0.013	-0.013	1.000
D+Lr	0.613	-0.613	49.000
D+L	0.600	-0.600	48.000
D+L+Lr	0.650	-0.650	52.000
D+S	0.575	-0.575	46.000
D+W	0.575	-0.575	46.000
D+L+S	0.613	-0.613	49.000
D+Lr+S	0.625	-0.625	50.000
D+L+W	0.613	-0.613	49.000
D+Lr+W	0.625	-0.625	50.000


### Sketch



### A-V-M Diagrams



### Pn-Mnx-Mny Diagrams



## 10.4 General Walls

### General Introductory Video:

[Click Here for Video](#)

## 10.4.1 Concrete Slender Wall

[Need more? Ask Us a Question](#)

This program provides analysis of concrete wall panels that stand vertically and have applied vertical and out-of-plane lateral loads. Click here for a video: [Concrete Slender Wall](#)

The wall panel is analyzed using strength design procedures. Out-of-plane moments within the wall are created by eccentric axial loads, applied lateral loads, lateral self weight loads and moments induced due to the wall weight acting at an eccentricity when it deflects (P-Delta moments).

The ACI slender wall procedure, introduced in ACI 318-99, was first adopted by the IBC 2000 and subsequent code editions. As quoted in ACI 318R-05 Commentary, Section 14.8 is based on the corresponding requirements in 1997 UBC and experimental research presented in the 1982 "Test Report by SCCACI-SEAOSC". Analytical study of the current IBC/ACI provisions for concrete wall panels showed the ACI procedure does not correspond to a bilinear load-deflection characteristic observed in the SEAOSC tests and significantly underestimates the service load deflection.

The ENERCALC Concrete Slender Wall program uses basic principles of structural mechanics to model the wall as a series of beam segments. For each segment the actual moment is used to calculate member stiffness using the  $I_{\text{effective}}$  equations developed by Peter H. Bischoff. Since these changes to wall stiffness affect the wall deflection profile, the program performs an iterative analysis of calculating moments (including P-Delta effects). The results are deflection curves almost exactly matching the SCCACI-SEAOSC test results. This makes this program far more accurate at calculating wall deflections and P-Delta effects than the simple equations in the ACI code.

### Capabilities

This module provides these capabilities:

- One or two story slender tilt-up concrete walls
- Iterative process accounts for P-delta
- Optional parapet
- Axial loads with optional eccentricities
- Wind, seismic and user defined lateral loads creating bending on the wall panel
- Variable strip width to model the wall panel
- Temperature differential can be specified across thickness of wall to add curvature
- Rebar location at center of wall or two layers of reinforcing at each side
- Bottom of wall can be fixed or pinned for moment resistance
- Top of wall can be pinned or free
- A reveal can be defined and cross section properties modified for reduced thickness and optionally add rebar

- The effects of wall openings can be addressed by modeling the solid panel between or adjacent to openings and then using superposition to apply the loads above and below openings.

The screenshot displays the 'Concrete Slender Wall' software interface. The 'Material Properties' section shows concrete strength  $f_c = 3.0$  ksi and yield strength  $f_y = 60.0$  ksi. The 'Thickness & Rebar' section shows a wall thickness of 6.50 in and rebar spacing of 16.0 in. The 'Analysis Settings' section shows 'Ieff based on Mu @ Element' selected. The 'Calculations' section shows a maximum bending stress ratio of 0.3947 and a minimum deflection ratio of 616.11. The 'Results reported for "Strip Width" of 12.0 in' section shows a governing load combination of +0.90D+E with a maximum moment of 1.488 k-ft and a maximum deflection of 0.2922 in.

Check	Actual Values	Allowable Values
Maximum Bending Stress Ratio	0.3947 : 1	
Minimum Deflection Ratio	L / 616.11	
Moment Capacity Check	+0.90D+E	Max Mu = 1.488 k-ft, Phi * Mn = 3.769 k-ft
Service Deflection Check	D + L + S + E/1.4	Min. Defl. Ratio = 616.11, Allow. Deflection Ratio = 150.0
Axial Load Check	+0.90D+E	Max. Deflection = 0.2922 in, Allow Deflection = 2.0
Reinforcing Limit Check	D Only	Max Pu / Ag = 41.750 psi, .060 * f_c = 180.0 psi
Minimum Moment Check	D Only	Actual As/bd = 0.005962, Max Allow As/bd = 0.01355
Maximum Reactions		Mcracking = 1.928 k-ft, Minimum Phi Mn = 3.162 k-ft

## General Tab

The screenshot displays the 'Concrete Slender Wall' software interface, specifically the 'General' tab. The 'Material Properties' section shows concrete strength  $f_c = 3.0$  ksi and yield strength  $f_y = 60.0$  ksi. The 'Thickness & Rebar' section shows a wall thickness of 6.50 in and rebar spacing of 16.0 in. The 'Analysis Settings' section shows 'Ieff based on Mu @ Element' selected.

## Material Properties

$f_c$

28-day compressive strength of the concrete.

$F_y$

Yield point stress of reinforcing

**Fr: Rupture Modulus**

Multiplier used in the expression to define the modulus of rupture for the concrete. 5.0 is the original recommended multiplier that was developed as a result of the SEAOSC slender wall tests of the early 1980s. 7.5 is the multiplier provided by ACI 318-05, -08, and -11.

**Lambda**

Factor to account for lightweight concrete.

**Ec**

Modulus of elasticity of concrete. You can enter the value or click the ["57"] button to set  $E_c = 57000 * \sqrt{f'c}$ , or click the ["33"] button to set  $E_c = 33 * \sqrt{f'c} * \text{ConcWeight}^{1.5}$ .

**Concrete Wt**

Weight of concrete in pounds per cubic foot.

**Max Pu/Ag = f'c \* <entry>**

Enter a multiplier less than 1.0 which will be applied to f'c to determine the maximum allowable factored axial stress.

**Thickness & Rebar****Wall Thickness**

Total wall thickness

**Bar Location**

You can select bar placement at the center of the wall thickness or at each face. When selecting "Bar Each Face" the module performs calculations considering both bars.

**Rebar "d" Distance**

Enter the distance between the outside surface of the wall to the centerline of the rebar. For bars each face this measurement can be from either face.

**Wall Weight**

The internally calculated wall weight considering the concrete weight and wall thickness entered.

**Rebar [Spacing] / [# in Width]**

These two options indicate how you will specify the rebar quantity in your design strip.

[Spacing] will change the entry so that you can enter a spacing in inches for the rebar.

[# in Width] changes the entry so you can enter the number of bars in your design strip, where the width of the design strip is entered on the Dimensions tab.

Note: When using the "Bars Each Face" option, the "# Bars in Width" specifies the number of bars **on each face** within the design strip width.

### Bar Size

Enter the US customary rebar size number.

## Analysis Settings

### leff used for Deflection

The module offers the option to use  $I_{\text{effective}}$  based on the moment in the individual wall elements or to use  $I_{\text{cracked}}$  for the full height of the wall.

### Temperature Differential across thickness

This input is used to describe the temperature change between each face of the wall. A temperature change induces a slight curvature into the wall because the hotter side expands, resulting in a slightly higher out-of-plane deflection.

### Minimum Vertical Steel: %/100

Minimum steel as a percentage of the gross wall area.

### Minimum Allowed (Span/Deflection) Ratio

This setting establishes the minimum allowable ratio of span length to service load deflection. If a lower actual Span/Deflection ratio occurs (meaning greater deflection), a warning message will be displayed.


### Apply 0.75 Factor used in ACI Eq. 14-5 & 14-6

Please see the code reference for an explanation of this factor. It is typically not used in this module because it is a calibration factor used to curve fit deflection calculations with ACI approximate formulas.

### Number of wall elements for FE solver to use

This module divides the wall design strip into segments from the base to the top for analysis purposes. Use this entry to define the number of segments to use. Experience demonstrates that approximately 30 segments gives a good balance between the iterative P-Delta analysis reaching convergence and excessive calculation time.

## Dimensions Tab



### Fixity Conditions

Controls how the top and bottom of the wall are restrained for moments and lateral movement.

#### [Top & Bottom Pinned]

Base of wall is restrained against movement out of plane and vertically, rotates freely. Top of wall restrained against out of plane movement and can move vertically and rotate freely.

#### [Top Pinned, Bottom Fixed]

Base of wall is restrained against movement about all three axes. Top of wall restrained against out of plane movement and can move vertically and rotate freely.

#### [Top Free, Bottom Fixed]

Base of wall is restrained against movement about all three axes. Top of wall is completely free making this a cantilevered wall.

### Clear Height

Span of the wall between the base and the first lateral support. For one story walls this is the top support. For 2 story walls this prompt will change to be "1st story height".

### Parapet Height

Distance the wall extends (without a topmost lateral support) above the topmost lateral support (i.e. extension above the clear height for one story wall, extension above the 2nd story height for 2 story walls).

### Reveal Data

A reveal is a portion of the wall that is recessed from the rest of the surface. It is formed by placing thin blockout material (typically styrofoam) in the forms prior to concrete placement. It is used to create architectural effects. The reveal reduces the structural thickness of the wall. This module calculates section properties for this reduced section in the portion of the wall where the reveal has been formed.

### Reveal Depth



Depth of reveal measured from outside face of wall. A 1" reveal in a 6" wall gives a net structural thickness of 5".

### Reveal Start Location, Reveal End Location

Distances measured upwards from bottom of wall that define the start and end points of the reveal.

### Reveal Rebar

This selection defines how the module should consider the reveal area to be reinforced.

**No Change** means that the reinforcing stays where it is as defined by the "Rebar 'd' Distance" entered on the General tab. This option results in an offset rebar location within the remaining structural thickness, because the reveal takes away part of the concrete.

**Drape Bars** tells the module to move the rebar inward to give the same dimension between the rebar and face of wall. For walls with bars at "Center" this moves the bar to the center of the remaining structural thickness. When bars are specified on each face, this option moves only one of the bars inwards.

**Add Bars** enables you to add additional reinforcing in the area of the reveal. The location of the main rebar is as described in the "No Change" option above.


### Strip Width: Width of wall portion for analysis

This module performs its analysis for this width. Results are for either this width or a 12" width as noted where the results are provided.

Note that applied loads either are applied to the entire strip width (as for concentrated vertical and lateral loads) or are entered on a per-foot basis when they are uniform loads.

### Two Story...

When a two story wall is selected, this tab changes slightly to provide the 2nd story height and remove the Fixed-Free support option.



## 1st Story Height

Distance from the bottom of the wall to the first lateral support.

## 2nd Story Height

Distance from the first lateral support to the top lateral support.

## Loads Tab - Vertical Loads

A variety of vertical loads are available. Note the hint in green describing whether the load is per foot or on the entire strip width.

All loads that are entered on this tab will be multiplied by the load factors specified on the Load Combination sub-tabs. So these magnitudes should be specified with those load factors in mind.

**Concrete Slender Wall**

Code Ref: ACI 318-05, Sec. 14.8

\*\*\* "+" Vertical loads act downwards and should be entered as unfactored loads. \*\*\*

**Uniform Loads @ Top of Wall** (*Applied per foot of Strip Width*)

	Eccentricity	D	Lr	L	S	W
Ledger Load	6.750 in	1.0				k/ft
Concentric Load						k/ft

**Mid-Height Uniform Loads** (*Applied per foot of Strip Width*)

	Eccentricity	D	Lr	L	S	W
Ledger Load	6.0 in					k/ft
Concentric Load						k/ft

**Concentrated Loads** (*Applied to full "Strip Width"*)

	Eccentricity	Dist. from Base	D	Lr	L	S	W
Load #1							k
<i>Note! Wall Bottom = 0.0</i>			Load distributed over "Strip Width" specified on the Dimensions tab				
Load #2							k
<i>Note! Wall Bottom = 0.0</i>			Load distributed over "Strip Width" specified on the Dimensions tab				

## Ledger Load

This is a per-foot vertical load applied to the wall at an optional eccentricity. So if you have a 48" strip width and specify a 1 k/ft dead load then the strip will have a total of 4 kip applied due to the 1 k/ft entry.

## Eccentricity

Describes an offset from the mid-thickness of the wall panel, which is the default location of application of a vertical load. Enter this value as a positive number when the load is shifted toward the inside of the wall.

## Concentric Load

This is a per-foot vertical load applied concentrically to the wall. So if you have a 48" strip width and specify a 1 k/ft dead load then the strip will have a total of 4 kip applied due to the 1 k/ft entry.

## Mid-Height Vertical Uniform Load

This load entry is only shown for 2-story walls. It allows you to specify two uniform loads applied at the "1st Story" height, one of which can have an eccentricity from the wall center.

### Concentrated Loads

This is a single concentrated vertical load applied to the wall "strip width" with an optional eccentricity.

**Distance from Base** is the height at which the load is applied.

### Loads Tab - Lateral Loads

Lateral loads are applied perpendicular to the plane of the wall and are almost always seismic or wind. These loads create out of plane deflection of the wall, which the module will use to develop P-Delta effects to calculate secondary moments in the wall. Recall that this module divides the wall into small segments and calculates the allowable and actual forces and deflections for each small segment. In this way the lateral loads are properly modeled on what is effectively a beam with variable stiffness due to the state of cracking in each segment.

All loads that are entered on this tab will be multiplied by the load factors specified on the Load Combination sub-tabs. So these magnitudes should be specified with those load factors in mind.

The screenshot shows the 'Concrete Slender Wall' software interface. The 'Loads' tab is active, and the 'Lateral' sub-tab is selected. The interface includes the following elements:

- Full area WIND load:** 15.0 psf
- Select method of calculating wall weight E load:** Enter Lat Load, Enter Wall Weight Factor, Enter SDS per ASCE-05
- Wall Weight SEISMIC Load:** Fp = 25.0 psf
- Enter Seismic Wall Lateral Load:** 25.0 psf
- Concentrated Lateral Loads (Applied to full "STRIP Width"):**
  - Load #1: D: Dead Load, Lr: Roof Live Load, L: Live Load, E: Seismic Load?, W: Wind Load, Height above base
  - Load #2: D: Dead Load, Lr: Roof Live Load, L: Live Load, E: Seismic Load?, W: Wind Load, Height above base
- Distributed Lateral Loads (Applied to full "STRIP Width"):**
  - Load #1: D: Dead Load, Lr: Roof Live Load, L: Live Load, E: Seismic Load?, W: Wind Load, Location of start & end of load above base (Dist. to TOP, Dist. to BOTTOM)
  - Load #2: D: Dead Load, Lr: Roof Live Load, L: Live Load, E: Seismic Load?, W: Wind Load, Location of start & end of load above base (Dist. to TOP, Dist. to BOTTOM)

### Full area WIND Load

Enter the wind load that will be applied to the wall in the out-of-plane direction. This load will only be applied to one surface of the wall, and as such, the magnitude must take into consideration both the internal and external pressures.

For the purpose of defining the direction of applied wind pressures, consider that pressure will only be applied to the exterior surface of the wall. A net pressure that acts TOWARD the exterior surface of the wall should be entered as a positive value. A net pressure that acts AWAY FROM the exterior surface of the wall should be entered as a negative value.

### Wall Weight SEISMIC Load

This section offers three options to specify the seismic load that will be applied to the wall in the out-of-plane direction:

**Enter Lateral Load:** This entry is a simple net load applied to the wall (but will still be factored by the load combination factors for "E").

Select method of calculating wall weight E load :	Enter Lat Load	Enter Seismic Wall Lateral Load	25.0 psf
Wall Weight SEISMIC Load	Enter Wall Weight Factor		
Fp = 25.0 psf	Enter SDS per ASCE-05		

**Enter Wall Weight Factor:** Enter a number that will be multiplied by the self-weight of the wall. For example, if you enter 0.25 and the wall weighs 80 psf, then a 20.00 psf out-of-plane load will be calculated and applied to the wall using the load combination factors for "E".

Select method of calculating wall weight E load :	Enter Lat Load	Enter Seismic factor to be applied to wall weight =	0.250
Wall Weight SEISMIC Load	Enter Wall Weight Factor		
Fp = Wall Wt. * 0.250 = 18.125 psf	Enter SDS per ASCE-05		

**Enter  $S_{DS}$  per ASCE-05:** Enter the ( $S_{DS} * I$ ) value as prescribed by the ASCE code for the building location. The minimum calculated load value of 10 psf or ( $0.4 * \text{Value Entered} * \text{Wall Weight}$ ) will be applied to the wall using the load combination factors for "E".

Select method of calculating wall weight E load :	Enter Lat Load	Enter $I * S_{DS}$ per ASCE 12.11.1	
Wall Weight SEISMIC Load	Enter Wall Weight Factor	$S_{DS} * I =$	0.850
Fp = Wall Wt. * 0.340 = 24.650 psf	Enter SDS per ASCE-05	<i>Fp = 0.40 * I * SDS * WallWt; Check that (0.40 * I * SDS) &gt; 0.10</i>	

## Fp

This is the actual seismic load applied perpendicular to the plane of the wall, which represents the wall's seismic self weight load.

## Concentrated Lateral Loads

This is an added lateral load applied perpendicular to the plane of the wall. It acts on the full "Strip Width" and is factored by the load combination factors corresponding to the type of load.

## Distributed Lateral Loads

This is an added lateral uniform load applied out-of-plane to the wall. It acts on the full "Strip Width" and is factored by the load combination factors corresponding to the type of load. You also enter the start and end distance of the load extent above the base of the wall.

## Load Combinations Tab

Typical load combination information as used throughout **Structural Engineering Library**.

Concrete Slender Wall									
Code Ref: ACI 318-05, Sec. 14.8									
Factored Combinations IBC 2009									
Load Combinations for Moments	Run	D	Lr	L	S	W	E		
+1.40D	<input checked="" type="checkbox"/>	1.40							L ≤ 100, f1=0.5
+1.20D+0.50Lr+1.60L	<input checked="" type="checkbox"/>	1.20	0.50	1.60					L > 100, f1=1.0
+1.20D+1.60L+0.50S	<input checked="" type="checkbox"/>	1.20		0.50	0.50				
+1.20D+1.60Lr+0.50L	<input checked="" type="checkbox"/>	1.20	1.60	0.50					
+1.20D+1.60Lr+0.80W	<input checked="" type="checkbox"/>	1.20	1.60	0.50		0.80			
+1.20D+0.50L+1.60S	<input checked="" type="checkbox"/>	1.20		0.50	1.60				
+1.20D+1.60S+0.80W	<input checked="" type="checkbox"/>	1.20		0.50	1.60	0.80			
+1.20D+0.50Lr+0.50L+1.60W	<input checked="" type="checkbox"/>	1.20	0.50	0.50		1.60			
+1.20D+0.50L+0.50S+1.60W	<input checked="" type="checkbox"/>	1.20		0.50	0.50	1.60			
+1.20D+0.50L+0.20S+E	<input checked="" type="checkbox"/>	1.20		0.50	0.20		1.0		
+0.90D+1.60W	<input checked="" type="checkbox"/>	0.90				1.60			
+0.90D+E	<input checked="" type="checkbox"/>	0.90					1.0		

### Summary Tab

This tab presents the critical results as calculated by the module.

Summary									
Results reported for "Strip Width" of 12.0 in									
Governing Load Combination . . .		Actual Values . . .				Allowable Values . . .			
✓ Maximum Bending Stress Ratio	L /	0.3947 : 1							
✓ Minimum Deflection Ratio	L /	616.11							
✓ Moment Capacity Check	+0.90D+E	Max Mu	=	1.488 k-ft	Phi * Mn	=	3.769 k-ft		
		...location	:	Btwn : 10.83 to 11.67 ft above base					
✓ Service Deflection Check	D + L + S + E/1.4	Min. Defl. Ratio	=	616.11	Allow. Deflection Ratio	=	150.0		
		Max. Deflection	=	0.2922 in	Allow Deflection	=	2.0		
✓ Axial Load Check	+0.90D+E	Max Pu / Ag	=	41,750 psi	.060 * Fc =	=	180.0 psi		
		...location	=	10.417 ft	(Max Mu location)				
✓ Reinforcing Limit Check		Actual As/bd	=	0.005962	Max Allow As/bd	=	0.1877		
Minimum Moment Check	+1.40D	Mcracking	=	1.928 k-ft	Minimum Phi Mn	=	3.162 k-ft		
Maximum Reactions . . .									
	Top Horizontal	E Only		0.1330 k					
	Base Horizontal	E Only		0.2798 k					
	Mid-Ht Horizontal	E Only		0.5873 k					
	Vertical Reaction	D Only		4.120 k					

### Maximum Bending Stress Ratio

The module looks at the detailed results for ALL strength design load combinations at all "segments" in the wall and pulls out the maximum factored load bending stress ratio to present here as the governing condition.

### Minimum Deflection Ratio

The module looks at the detailed results for ALL service load combinations at all "segments" in the wall and pulls out the minimum service load deflection ratio (meaning maximum deflection) to present here as the governing condition.

### Moment Capacity Check

For the condition of maximum bending stress ratio, the actual applied and allowable bending moments are given along with the governing load combination.

### Service Deflection Check

For the condition of minimum deflection ratio (meaning maximum deflection) the ratio, deflection, allowable minimum ratio, allowable deflection (based on allowable ratio) and governing load combination are reported.

### Axial Load Check

The module checks the actual axial stress in all segments for all load combinations and gives the maximum actual stress  $P_u/Ag$ . The allowable value is the result of the user's entry for maximum percentage of  $f'_c$  to use.

### Reinforcing Limit Check

The module checks all portions of the wall for reinforcing (including differently reinforced first and second stories and reveal areas). It reports the maximum reinforcing ratio and compares it with the maximum percentage of balanced section analysis  $A_s$  allowed.

### Minimum Moment Check

ACI specifies that a wall section in bending shall have a minimum strength  $M_n$  that is greater than the cracking strength  $M_{cr} = S_{gross} * F_r$ .

### Maximum Reactions

This gives a summary of the maximum reactions (both out-of-plane and vertical) along with the load combination that creates them.

## Maximum Combinations Tab

This tab provides a summary of the governing values for each load combination for both factored load axial & bending and service load deflections.

**Factored Load Maximum Moments for Load Combinations:** The module looks through the result set for each load combination and identifies the location above the base of the wall at which the maximum condition is found. Note that "Aseff" is the effective area of steel and is influenced by the axial compression in that segment.

**Service Load Maximum Deflections for Load Combinations:** The module looks through the result set for each load combination and identifies the location above the base of the wall at which the maximum out-of-plane deflection is found. The value for "Ieff" is specific to the segment at that location and is based on the actual moment and Bischoff's equation for calculating effective moment of inertia.

Factored Load Maximum Moments for Load Combinations									
Load Combination	Axial Load (k)		Moment Values (k-ft)				Steel Area (in <sup>2</sup> /strip width)		
	$P_u$	$0.06f'_c b t$	$M_{cr}$	$M_u$	$\Phi$	$\Phi M_n$	As Actual	As Ratio	$0.6^* \rho_{bal}$
+1.40D at 39.50 to 40.00		14.04		0.79	0.90	3.16	0.233	0.0060	0.1877
+1.20D+0.50Lr+1.60L at 39.50 to 40.00		14.04		0.67	0.90	3.16	0.233	0.0060	0.1877
+1.20D+1.60Lr+0.50S at 39.50 to 40.00		14.04		0.67	0.90	3.16	0.233	0.0060	0.1877
+1.20D+1.60Lr+0.50L at 39.50 to 40.00		14.04		0.67	0.90	3.16	0.233	0.0060	0.1877
+1.20D+1.60Lr+0.80W at 25.00 to 25.50	2.604	14.04		-0.70	0.90	3.70	0.233	0.0060	0.1877
+1.20D+0.50L+1.60S at 39.50 to 40.00		14.04		0.67	0.90	3.16	0.233	0.0060	0.1877
+1.20D+1.60Lr+0.80W at 25.00 to 25.50	2.604	14.04		-0.70	0.90	3.70	0.233	0.0060	0.1877

Service Load Maximum Deflections for Load Combinations									
Load Combination	Axial Load (k)	Moment (k-ft)		Inertia (in <sup>4</sup> )			Defl. (in)		
		$M_{cr}$	Mactual	$I_{gross}$	$I_{cr}$	$I_{eff}$	Deflection	Defl Ratio	
D + L + Lr at 34.50 to 35.00	1.429		0.292	274.63	17.19	17.19	0.1693	1,063.4	
D + L + W at 34.50 to 35.00	1.429		0.509	274.63	17.19	17.19	0.2724	660.8	
D + L + S + W/2 at 34.50 to 35.00	1.429		0.509	274.63	17.19	17.19	0.2724	660.8	
D + L + S + W/2 at 34.50 to 35.00	1.429		0.400	274.63	17.19	17.19	0.2208	815.1	
D + L + S + E/1.4 at 34.00 to 34.50	1.468		0.520	274.63	17.24	17.24	0.2922	616.1	
D + 0.5(L+Lr) + 0.7W at 34.50 to 35.00	1.429		0.444	274.63	17.19	17.19	0.2415	745.5	
D + 0.5(L+Lr) + 0.7E at 34.00 to 34.50	1.468		0.515	274.63	17.24	17.24	0.2897	621.4	

### Strength Design Results Tab

This tab provides an extremely detailed summary of the factored axial load, moments, effective steel area and moment of inertia at each wall analysis segment for each load combination.

Factored Load Calculations for Strength Analysis		Note! All values for user defined Strip Width						Expand Load Cases			
Load Combination	Wall Segment	Axial Load (k)	Mcr	Moment Values (k-ft)		Steel Area (in <sup>2</sup> /strip width)		Inertia (in <sup>4</sup> )			
		Pu	0.06Fcbt	Iterated Mu	Phi	Phi Mn	As Actual	As Ratio 0.6*rhoBal	Igross	Icr	
Overall MAXimum Envelope											
+1.40D											
+1.20D+0.50Lr+1.60L											
+1.20D+1.60L+0.50S											
+1.20D+1.60Lr+0.50L											
+1.20D+1.60Lr+0.80W											
+1.20D+0.50L+1.60S											
+1.20D+1.60S+0.80W											
+1.20D+0.50Lr+0.50L+1.60W											
	-39.50 to 40.00			0.675	0.90	3.162	0.233	0.0060	0.1877	274.63	16.1
	-39.00 to 39.50	1.293	14.040	0.721	0.90	3.431	0.233	0.0060	0.1877	274.63	17.1
	-38.50 to 39.00	1.340	14.040	0.745	0.90	3.440	0.233	0.0060	0.1877	274.63	17.1
	-38.00 to 38.50	1.387	14.040	0.762	0.90	3.450	0.233	0.0060	0.1877	274.63	17.1
	-37.50 to 38.00	1.434	14.040	0.772	0.90	3.460	0.233	0.0060	0.1877	274.63	17.1
	-37.00 to 37.50	1.481	14.040	0.776	0.90	3.469	0.233	0.0060	0.1877	274.63	17.1

### Service Load Deflections Tab

This tab provides an extremely detailed summary of the service axial load, moments, effective moment of inertia and calculated deflection at each wall analysis segment for each load combination.

Service Load Calculations for Deflection Analysis		Note! All values adjusted to a 12" analysis width						Expand Load Cases	
Load Combination	Wall Segment	Axial Load (k)	Mcr	Mactual	Inertia (in <sup>4</sup> )		Iterated Defl. (in)		
					Igross	Icr	Ieff	Deflection	Defl Ratio
Overall MAXimum Envelope									
D + L + Lr									
D + L + W									
	-39.50 to 40.00			0.563	274.63	16.68	16.68	0.0244	999.0
	-39.00 to 39.50	1.078		0.582	274.63	16.73	16.73	0.0708	999.0
	-38.50 to 39.00	1.117		0.590	274.63	16.78	16.78	0.1124	999.0
	-38.00 to 38.50	1.156		0.595	274.63	16.83	16.83	0.1491	999.0
	-37.50 to 38.00	1.195		0.595	274.63	16.88	16.88	0.1809	994.8
	-37.00 to 37.50	1.234		0.591	274.63	16.94	16.94	0.2079	865.8
	-36.50 to 37.00	1.273		0.583	274.63	16.99	16.99	0.2300	782.5
	-36.00 to 36.50	1.312		0.571	274.63	17.04	17.04	0.2474	727.5
	-35.50 to 36.00	1.351		0.554	274.63	17.09	17.09	0.2602	691.9
	-35.00 to 35.50	1.390		0.534	274.63	17.14	17.14	0.2684	670.6
	-34.50 to 35.00	1.429		0.509	274.63	17.19	17.19	0.2724	660.8
	-34.00 to 34.50	1.468		0.479	274.63	17.24	17.24	0.2723	661.1
	-33.50 to 34.00	1.507		0.446	274.63	17.30	17.30	0.2683	670.9
	-33.00 to 33.50	1.546		0.409	274.63	17.35	17.35	0.2608	690.3

### Reactions Tab

This tab gives a summary of out-of-plane and vertical base reactions for each service load combination.

Summary 
  Maximum Combinations 
  Strength Design Results 
  Service Load Deflections 
  Reactions 
  Notes

**NOTE! All reactions given for the specified strip width. They are NOT per foot.**

Load Combination	Base Horizontal Reaction (k)	Mid Horizontal Reaction (k)	Top Horizontal Reaction (k)	Vertical Reaction at bottom (k)
Unfactored Service Loads				
D Only	0.000	0.000	0.000	4.068
S Only	0.000	0.000	0.000	0.000
W Only	0.060	0.248	0.157	0.000
E Only	0.099	0.408	0.257	0.000
D + L + Lr	0.000	0.000	0.000	4.068
D + L + S	0.000	0.000	0.000	4.068
D + L + W + S/2	0.062	0.245	0.158	4.068
D + L + S + W/2	0.031	0.123	0.079	4.068
D + L + S + E/1.4	0.072	0.288	0.186	4.068

### Notes Tab

Included are some excerpts from ACI regarding slender concrete wall design.

Summary 
  Maximum Combinations 
  Strength Design Results 
  Service Load Deflections 
  Reactions 
  Notes

ACI 318-05/08 Code references for Concrete Slender Wall Panel design - Out of Plane Loading

ACI 14.8.1 Method satisfies requirements of 10.10 when flexural tension controls.

ACI 14.8.2.1 ACI method is only for simply supported, axially loaded walls with moments at mid-span. ENERCALC method uses ACI principles but cannot use the exact equations because max moments are rarely at mid-height.

ACI 14.8.2.2 ACI Equations for constant cross section. ENERCALC allows for variable cross section.

ACI 14.8.2.4  $M_{cr} \leq \Phi * M_n$


ACI 14.8.3 States that iteration of moments and deflections is allowed

See chapter 14 and R10.12.3 for usage of a "stiffness reduction factor" of 0.75 to increase deflections.

ACI 318-08 Code references


ACI 14.8.4 This program uses more accurate numerical methods for moment of inertia at wall increments using Bischoff's equation which yield numerical results that closely match test results.

### Sketch Tab



### Diagram Tab





## 10.4.2 Masonry Slender Wall

[Need more? Ask Us a Question](#)

This module provides design and analysis according to the new provisions for design of masonry walls, using the P-Delta deflection considerations now included in the IBC. Click

here for a video:

Masonry Slender Wall

This method lifts the restriction on H/t ratios, and performs wall analysis using the principles of ultimate strength design. The design method is very similar to that of the Concrete Slender Wall module.

This module uses a variable width strip of wall section to represent a typical section of wall. The module has the ability to apply a lateral wind load, seismic load, partial length uniform lateral load, and a lateral point load to the clear span of the wall section. This variety of loadings should take care of almost every lateral loading case possible.

The user may specify masonry and reinforcing strengths, seismic factor, wind load, vertical and lateral loads, vertical load eccentricities, and wall construction. The module determines the wall capacity, actual deflections considering P-Delta effects, and solves for the final moments obtained through iteration of the P-Delta effects. Deflection analysis is provided for both service and factored load cases.

The user reaches a final design by modifying wall thickness, rebar size, and rebar spacing until no overstress condition exists and the deflection limits prescribed in the code are satisfied.

This module uses basic principles of structural mechanics to model the wall as a series of beam segments. For each segment the actual moment is used to calculate member stiffness using the  $I_{\text{effective}}$  equations developed by Peter H. Bischoff. Since these changes to wall stiffness affect the wall deflection profile, the program performs an iterative analysis of calculating moments (including P-Delta effects). The results are deflection curves almost exactly matching the SCCACI-SEAOSC test results. This makes this module far more accurate at calculating wall deflections and P-Delta effects than the simple equations in the ACI code.

### Capabilities

This module provides these capabilities:

- One or two story slender masonry walls
- Iterative process accounts for P-delta
- Optional parapet
- Axial loads with optional eccentricities
- Wind, seismic and user defined lateral loads creating bending on the wall panel
- Variable strip width to model the wall panel
- Temperature differential can be specified across thickness of wall to add curvature

**Masonry Slender Wall**

Code Ref: ACI 530-08/MSJC 2009 Sec. 3.3.5

Sample Masonry Slender Wall

Wall Material: Concrete, **Masonry**

Material Properties  
 Construction Type: Partial Grouted Hollow Concrete Masonry  
 f<sub>m</sub>: 1.50 ksi, f<sub>y</sub> - Yield: 60.0 ksi  
 f<sub>r</sub> - Rupture: 61.0 psi, f<sub>r</sub> Table:   
 E<sub>m</sub> = f<sub>m</sub> \* 900.0, Max % of ρ bal.: 0.50  
 Grout Density: 105 pcf, **140 pcf**  
 Block Weight: Light, Medium, **Normal**

Thickness & Rebar  
 Nominal Thickness in: 6, **8**, 10, 12, 14, 16  
 Actual Thickness: 7.625  
 Rebar "d" Distance: 3.80 in  
 Solid Grouted:   
 Wall Weight: 66.0 psf

Analysis Settings  
 I<sub>eff</sub> used for deflection: **I<sub>eff</sub> based on Mu @ Element**, Cracked Full Height  
 Number of wall elements for FE solver to use: 30.0  
 Minimum Vertical Steel: (your entry) \* bd: 0.0020  
 Minimum allowed (Span/Deflection) ratio: 150.0

**Summary** | Maximum Combinations | Strength Design Results | Service Load Deflections | Reactions | Notes

Results reported for "Strip Width" of 12.0 in

Check	Governing Load Combination	Actual Values	Allowable Values
Maximum Bending Stress Ratio		0.3146	1
Minimum Deflection Ratio	L /	262.31	
Moment Capacity Check	+0.90D+1.60W	Max Mu = 1.229 k-ft	Phi * Mn = 3.908 k-ft
Service Deflection Check	D + L + S + E/1.4	Min. Defl. Ratio = 262.31 Max. Deflection = 0.9149 in	Allow. Deflection Ratio = 150.0 Allow Deflection = 1.60
Axial Load Check	+0.90D+1.60W at 8.67 to 9.33	Max Pu / Ag = 13.939 psi	0.2 * f <sub>m</sub> = 300.0 psi
Reinforcing Limit Check	+0.90D+1.60W	Max As/bd = 0.005082	As/bd <= 0.5 * ρ bal = 0.005345
Minimum Moment Check	+0.90D+1.60W	Mcracking = 0.5013 k-ft	Minimum Phi Mn = 3.512 k-ft

Maximum Reactions

Top Horizontal	E Only	0.3906 k
Base Horizontal	E Only	0.2344 k
Vertical Reaction	D + L + S + E/1.4	1.650 k

## General Tab

**Masonry Slender Wall**

Code Ref: ACI 530-08/MSJC 2009 Sec. 3.3.5

Sample Masonry Slender Wall

Wall Material: Concrete, **Masonry**

Material Properties  
 Construction Type: Partial Grouted Hollow Concrete Masonry  
 f<sub>m</sub>: 1.50 ksi, f<sub>y</sub> - Yield: 60.0 ksi  
 f<sub>r</sub> - Rupture: 61.0 psi, f<sub>r</sub> Table:   
 E<sub>m</sub> = f<sub>m</sub> \* 900.0, Max % of ρ bal.: 0.50  
 Grout Density: 105 pcf, **140 pcf**  
 Block Weight: Light, Medium, **Normal**

Thickness & Rebar  
 Nominal Thickness in: 6, **8**, 10, 12, 14, 16  
 Actual Thickness: 7.625  
 Rebar "d" Distance: 3.80 in  
 Solid Grouted:   
 Wall Weight: 66.0 psf

Analysis Settings  
 I<sub>eff</sub> used for deflection: **I<sub>eff</sub> based on Mu @ Element**, Cracked Full Height  
 Number of wall elements for FE solver to use: 30.0  
 Minimum Vertical Steel: (your entry) \* bd: 0.0020  
 Minimum allowed (Span/Deflection) ratio: 150.0

## Material Properties

**f<sub>m</sub>**

Enter the allowable masonry strength to be used in the analysis. The allowable bending and axial stresses calculated from f<sub>m</sub> are outlined in a later section.

**f<sub>y</sub>**

Yield point stress of reinforcing.

**f<sub>r</sub> - Rupture & Fr-Table**

Modulus of rupture for the masonry wall system.

### **$E_m = f'_m * [\text{value}]$**

The modulus of elasticity of the masonry wall system is specified by this value acting as a multiplier to  $f'_m$ .

### **Max % of Rho Balanced**

This value sets the maximum percentage of reinforcing the module will allow without giving a warning message. Enter this as a value less than 1.0 which will be applied to the reinforcing area calculated for a balanced section to determine the maximum allowable reinforcing ratio.

### **Grout Density**

Choose from two different options for the density of the grout.

### **Block Weight**

Select light, medium and normal weight block. The weight of a completed wall is determined from the masonry database, depending on the block weight, grout density, and grouted cell spacing. To view the database values click **Databases > Concrete Masonry Unit Data** from the main menu. Here is what you will see:

Concrete Masonry Unit Information

Select List to View . . .

Select Code Ref for Masonry Values

ASTM C90-06 and TEK 14-1b

Section Properties . . .

Equiv. Solid Thick Face Shell Only    I Net

Completed wall weights using 140pcf grout . . .

Light Weight Block    Medium Weight Block    **Normal Weight Block**

Completed wall weights using 105pcf grout . . .

Light Weight Block    Medium Weight Block    Normal Weight Block

Nominal Block Thickness (in)	Wall Weight - Normal Weight Block, 140 pcf Grout					
	8"	16"	24"	32"	40"	48"
6	64.000	47.000	41.000	39.000	37.000	36.000
8	86.000	63.000	55.000	51.000	48.000	47.000
10	109.000	77.000	66.000	61.000	58.000	55.000
12	132.000	90.000	77.000	70.000	66.000	63.000
14	154.000	104.000	87.000	79.000	74.000	70.000
16	177.000	118.000	98.000	88.000	82.000	78.000

Change    Close

## **Thickness & Rebar**

### **Nominal Thickness**

Select the nominal thickness for the concrete masonry units used in the wall construction. This selection will pull the values for wall weight, equivalent solid thickness and Igross from the masonry database (see above).

### **Actual Thickness**

The actual wall thickness for the nominal selection.

### **Rebar Size & Spacing**

Enter the rebar size and spacing.

**Rebar "d" Distance**

Enter the distance from the extreme compression fiber to the center of the rebar.

**Solid Grouted**

Select this checkbox if the wall is to be grouted solid . If unchecked the module will calculate the wall weight considering that grouted cells only occur at the spacing of the reinforcing.

**Wall Weight**

Weight of wall as retrieved from the masonry database. Value is based on specified wall thickness, grout density, block type, and grouting frequency.

**Analysis Settings****P-Delta Deflection Method**

The module always performs an iterative analysis for moments and deflections using progressively greater wall deflections due to increasing P-Delta effects.

**Temperature Differential across thickness**

This input is used to describe the temperature change between each face of the wall. A temperature change induces a slight curvature into the wall because the hotter side expands, resulting in a slightly higher out-of-plane deflection.

Enter temperature differentials as positive values. The effects of a specified temperature differential are always additive with the bending and deflection resulting from other applied loads.

**Minimum Vertical Steel: %/100**

Minimum steel percentage as a portion of the gross wall area.


**Minimum Out-of-Plane Deflection Ratio**

This setting establishes the minimum allowable ratio of span length to service load deflection. If a lower actual Span/Deflection ratio occurs (meaning greater deflection), a warning message will be displayed.

**Number of wall elements for FE solver to use**

This module divides the wall design strip into segments from the base to the top for analysis purposes. Use this entry to define the number of segments to use. Experience demonstrates that approximately 30 segments gives a good balance between the iterative P-Delta analysis reaching convergence and excessive calculation time.

**Dimensions Tab**



### Fixity Conditions

Controls how the top and bottom of the wall are restrained for moments and lateral movement.

#### [Top & Bottom Pinned]

Base of wall is restrained against movement out of plane and vertically, rotates freely. Top of wall restrained against out of plane movement and can move vertically and rotate freely.

#### [Top Pinned, Bottom Fixed]

Base of wall is restrained against movement about all three axes. Top of wall restrained against out of plane movement and can move vertically and rotate freely.

#### [Top Free, Bottom Fixed]

Base of wall is restrained against movement about all three axes. Top of wall is completely free making this a cantilevered wall.

### Clear Height

Span of the wall between the base and the first lateral support. For one story walls this is the top support. For 2 story walls this is this prompt will change to be "1st story height".

### Parapet Height

Distance the wall extends (without a topmost lateral support) above the topmost lateral support (clear height for one story wall, 2nd story height for 2 story walls)


### Strip Width: Width of wall portion for analysis

This module performs its analysis for this width. Results are for either for this width or a 12" width as noted where the results are provided.

Note that applied loads either are applied to the entire strip width (as for concentrated vertical and lateral loads) or are entered on a per-foot basis when they are uniform loads.

### Two Story...

When a two story wall is selected this tab changes slightly to provide the 2nd story height and remove the Fixed-Free support option.



### 1st Story Height

Distance from the bottom of the wall to the first lateral support.


### 2nd Story Height

Distance from the first lateral support to the top lateral support.

## Loads Tab - Vertical Loads

A variety of vertical loads are available. Note the hint in green describing whether the load is per foot or on the entire strip width.

All loads that are entered on this tab will be multiplied by the load factors specified on the Load Combination sub-tabs. So these magnitudes should be specified with those load factors in mind.



### Ledger Load

This is a per-foot vertical load applied to the wall at an optional eccentricity. So if you have a 48" strip width and specify a 1 k/ft dead load then the strip will have a total of 4 kip applied due to the 1 k/ft entry.

### Concentric Load

This is a per-foot vertical load applied concentrically to the wall. So if you have a 48" strip width and specify a 1 k/ft dead load then the strip will have a total of 4 kip applied due to the 1 k/ft entry.

### Mid-Height Vertical Uniform Load

This load entry is only shown for 2-story walls. It allows you to specify two uniform loads applied at the "1st Story" height, one of which can have an eccentricity from the wall center.

### Concentrated Loads

These are single concentrated vertical loads applied to the wall "strip width" with an optional eccentricity.

**Distance from Base** is the height at which the load is applied.

### Eccentricity

Describes an offset from the mid-thickness of the wall panel, which is the default location of application of a vertical load. Enter this value as a positive number when the load is shifted toward the inside of the wall.

## Loads Tab - Lateral Loads

Lateral loads are applied perpendicular to the plane of the wall and are almost always seismic or wind. These loads create out-of-plane deflection of the wall, which the module will use to develop P-Delta effects to calculate secondary moments in the wall. Recall from other explanations that the module divides the wall into small segments and calculates the allowable and actual forces and deflections for each small segment. In this way the lateral loads are properly modeled on what is a beam with variable stiffness due to the state of cracking in each segment.

All loads that are entered on this tab will be multiplied by the load factors specified on the Load Combination sub-tabs. So these magnitudes should be specified with those load factors in mind.

Masonry Slender Wall

General | Dimensions | **Loads** | Load Combinations | Code Ref: ACI 318-05, Sec. 14.8

Vertical | **Lateral** | \*\*\* Enter D, L, Lr as Unfactored. Consult code for W and E for use in load combinations \*\*\*

Full area WIND load: 15 psf

Select method of calculating wall weight E load: Enter Lat Load

Wall Weight SEISMIC Load: Enter Wall Weight Factor

Fp = Wall Wt. \* 0.340 = 24.480 psf

Enter I\*SDS per ASCE 12.11.1: SDS \* I = 0.85

Enter SDS per ASCE-05: Fp = 0.40 \* I \* SDS \* WallWt; Check that (0.40 \* I \* SDS) > 0.10

**Concentrated Lateral Loads** (Applied to full "STRIP Width")

	Load #1	Load #2
D : Dead Load	[ ] k	[ ] k
Lr : Roof Live Load	[ ] k	[ ] k
L : Live Load	[ ] k	[ ] k
E : Seismic Load ?	[ ] k	[ ] k
W : Wind Load	[ ] k	[ ] k
Height above base	[ ] ft	[ ] ft

**Distributed Lateral Loads** (Applied to full "STRIP Width")

	Load #1	Load #2
D : Dead Load	[ ] k/ft	[ ] k/ft
Lr : Roof Live Load	[ ] k/ft	[ ] k/ft
L : Live Load	[ ] k/ft	[ ] k/ft
E : Seismic Load ?	[ ] k/ft	[ ] k/ft
W : Wind Load	[ ] k/ft	[ ] k/ft
Location of start & end of load above base . . .		
Dist. to TOP	[ ] ft	[ ] ft
Dist. to BOTTOM	[ ] ft	[ ] ft



### Full area WIND Load

Enter the wind load that will be applied to the wall in the out-of-plane direction. This load will only be applied to one surface of the wall, and as such, the magnitude must take into consideration both the internal and external pressures.

For the purpose of defining the direction of applied wind pressures, consider that pressure will only be applied to the exterior surface of the wall. A net pressure that acts TOWARD the exterior surface of the wall should be entered as a positive value. A net pressure that acts AWAY FROM the exterior surface of the wall should be entered as a negative value.

### Wall weight seismic load

This section offers three options to specify the seismic load that will be internally applied to the wall in the out-of-plane direction:

**Enter Lateral Load:** This entry is a simple net load applied to the wall (but will still be factored by the load combination factors for "E").

Select method of calculating wall weight E load :	Enter Lat Load	Enter Seismic Wall Lateral Load	<input type="text" value="25.0"/> psf
Wall Weight SEISMIC Load	Enter Wall Weight Factor		
Fp =			25.0 psf

**Enter Wall Weight Factor:** Enter a number that will be multiplied by the self-weight of the wall. For example, if you enter 0.25 and the wall weighs 80 psf, then a 20.00 psf out-of-plane load will be calculated and applied to the wall using the load combination factors for "E".

Select method of calculating wall weight E load :	Enter Lat Load	Enter Seismic factor to be applied to wall weight =	<input type="text" value="0.250"/>
Wall Weight SEISMIC Load	Enter Wall Weight Factor		
Fp = Wall Wt. * 0.250			= 18.125 psf

**Enter S<sub>DS</sub> per ASCE-05:** Enter the (S<sub>DS</sub> \* I) value as prescribed by the ASCE code for the building location. The minimum calculated load value of 10 psf or (0.4 \* Value Entered \* Wall Weight) will be applied to the wall using the load combination factors for "E".

Select method of calculating wall weight E load :	Enter Lat Load	Enter I*SDS per ASCE 12.11.1	<input type="text" value="0.850"/>
Wall Weight SEISMIC Load	Enter Wall Weight Factor	S <sub>DS</sub> * I =	
Fp = Wall Wt. * 0.340	Enter SDS per ASCE-05	Fp = 0.40*I*SDS*WallWt; Check that (0.40*I*SDS) > 0.10	

### Fp

This is the actual seismic load applied perpendicular to the plane of the wall, which represents the wall's seismic self weight load.

### Concentrated Lateral Loads

This is an added lateral load applied perpendicular to the plane of the wall. It acts on the full "Strip Width" and is factored by the load combination factors corresponding to the type of load.


### Distributed Lateral Loads

This is an added lateral uniform load applied perpendicular to the plane of the wall. It acts on the full "Strip Width" and is factored by the load combination factors corresponding to the type of load.

You also enter the start and end distance of the load extent above the base of the wall.

## Load Combination Tab

Typical load combination information as used throughout **Structural Engineering Library**.



## Results Summary Tab

This tab presents the critical results as calculated by the module.

Check	Governing Load Combination	Actual Values	Allowable Values
Maximum Bending Stress Ratio		0.4795 : 1	
Minimum Deflection Ratio		L / 203.573	
Moment Capacity Check	+1.20D+0.50L+0.20S+E	Max Mu = -1.978 k-ft ...location : Btwn : 25.00 to 25.50 ft above base	Phi * Mn = 4.125 k-ft
Service Deflection Check	D + L + S + E/1.4	Min. Def. Ratio = 203.573 Max. Deflection = 1.474 in	Allow. Deflection Ratio = 150.0 Allow Deflection = 2.0
Axial Load Check	+0.90D+E	Max Pu / Ag = 37.231 psi ...location = 25.250 ft (Max Mu location)	0.05 * fm = 75.0 psi
Reinforcing Limit Check		Actual As/bd = 0.0050	Max Allow As/bd = 0.1182
Minimum Moment Check	+1.40D	Mcracking = 0.5013 k-ft	1.3 * Min. Phi Mn = 4.650 k-ft
Maximum Reactions			
Top Horizontal	D + L + S + E/1.4	0.1322 k	
Base Horizontal	E Only	0.1553 k	
Mid-Ht Horizontal	D + L + S + E/1.4	0.4540 k	
Vertical Reaction	D + L + S + W/2	7.640 k	

### Maximum Bending Stress Ratio

The module looks at the detailed results for ALL strength design load combinations at all "segments" in the wall and pulls out the maximum factored load bending stress ratio to present here as the governing condition.

**Minimum Deflection Ratio**

The module looks at the detailed results for ALL service load combinations at all "segments" in the wall and pulls out the minimum service load deflection ratio (meaning maximum deflection) to present here as the governing condition.

**Moment Capacity Check**

For the condition of maximum bending stress ratio, the actual applied and allowable bending moments are given along with the governing load combination.

**Service Deflection Check**

For the condition of minimum deflection ratio (meaning maximum deflection) the ratio, deflection, allowable minimum ratio, allowable deflection (based on allowable ratio) and governing load combination are reported.

**Axial Load Check**

The module checks the factored axial stress in all segments for all load combinations and gives the maximum actual stress  $P_u/Ag$ . The allowable value is the result of the wall slenderness. If the slenderness is less than or equal to 30, the allowable value of factored axial stress is  $0.20f'_m$ . If the slenderness is greater than 30, the allowable value of factored axial stress is  $0.05f'_m$ .

**Reinforcing Limit Check**

The module checks all portions of the wall for reinforcing (including differently reinforced first and second stories) and reports the maximum reinforcing ratio and compares it with the maximum percentage of balanced section analysis  $A_s$  allowed.

**Minimum Moment Check**

ACI specifies that a wall section in bending shall have a minimum strength  $M_n$  that is greater than the cracking strength  $M_{cr} = S_{gross} * f_r$ .

**Maximum Reactions**

This gives a summary of the maximum reactions (both out-of-plane and vertical) along with the load combination that creates them.

**Maximum Combinations**

This tab provides a summary of the governing values for each load combination for both factored load axial & bending and service load deflections.

**Factored Load Maximum Moments for Load Combinations:** The module looks through the result set for each load combination and identifies the location above the base of the wall at which the maximum condition is found. Note that " $A_{seff}$ " is the effective area of steel and is influenced by the axial compression in that segment.

**Service Load Maximum Deflections for Load Combinations:** The module looks through the result set for each load combination and identifies the location above the base of the wall at which the maximum out-of-plane deflection is found. The value for

"I<sub>eff</sub>" is specific to the segment at that location and is based on the actual moment and Bischoff's equation for calculating effective moment of inertia.

Factored Load Maximum Moments for Load Combinations											
Load Combination	Axial Load (k)		Moment Values (k-ft)				Steel Area (in <sup>2</sup> /strip width)				
	Pu	0.05f <sub>cb</sub> t	Mcr	Mu	Phi	Phi Mn	As Actual	As Ratio	0.6* $\rho$ oBal		
+1.40D at 39.50 to 40.00	1.447	20.880	0.50	0.79	0.90	3.89	0.233	0.0050	0.1182		
+1.20D+0.50Lr+1.60L at 25.00 to 25.50	2.889	20.880	0.50	-1.42	0.90	4.19	0.233	0.0050	0.1182		
+1.20D+1.60Lr+0.50S at 25.00 to 25.50	2.889	20.880	0.50	-1.42	0.90	4.19	0.233	0.0050	0.1182		
+1.20D+1.60Lr+0.50L at 39.50 to 40.00	2.841	20.880	0.50	1.57	0.90	4.18	0.233	0.0050	0.1182		
+1.20D+1.60Lr+0.80W at 39.50 to 40.00	2.841	20.880	0.50	1.58	0.90	4.18	0.233	0.0050	0.1182		
+1.20D+0.50Lr+1.60S at 39.50 to 40.00	2.841	20.880	0.50	1.57	0.90	4.18	0.233	0.0050	0.1182		
+1.20D+1.60S+0.80W at 39.50 to 40.00	2.841	20.880	0.50	1.58	0.90	4.18	0.233	0.0050	0.1182		

Service Load Maximum Deflections for Load Combinations											
Load Combination	Axial Load (k)	Moment (k-ft)		Inertia (in <sup>4</sup> )		Defl. (in)					
		Mcr	Mactual	Igross	Icr	Ieff	Deflection	Defl Ratio			
D + L + Lr at 35.50 to 36.00	2.297	0.501	0.608	376.00	54.19	67.65	0.1361	1,322.7			
D + L + W at 12.50 to 13.33	5.815	0.501	0.926	376.00	52.99	55.23	0.6861	437.3			
D + L + W + S/2 at 12.50 to 13.33	6.315	0.501	0.898	376.00	53.89	56.43	0.6306	475.7			
D + L + S + W/2 at 13.33 to 14.17	6.760	0.501	0.719	376.00	54.67	60.99	0.1664	1,803.2			
D + L + S + E/1.4 at 11.67 to 12.50	6.870	0.501	1.404	376.00	54.87	55.41	1.4737	203.6			
D + 0.5(L+Lr) + 0.7W at 12.50 to 13.33	5.315	0.501	0.465	376.00	52.08	376.00	0.1084	2,768.3			
D + 0.5(L+Lr) + 0.7E at 11.67 to 12.50	5.370	0.501	1.016	376.00	52.18	53.76	0.9058	331.2			

### Strength Design Results

This tab provides an extremely detailed summary of the factored axial load, moments, effective steel area and moment of inertia at each wall analysis segment for each load combination.

Factored Load Calculations for Strength Analysis												
Load Combination	Wall Segment	Axial Load (k)		Moment Values (k-ft)			Steel Area (in <sup>2</sup> /strip width)			Inertia (in <sup>4</sup> )		
		Pu	0.05f <sub>mb</sub> t	Mcr	Iterated Mu	Phi	Phi Mn	As Actual	As Ratio	0.6* $\rho$ oBal	Igross	Icr
+1.40D +1.20D+0.50Lr+1.60L	-39.50 to 40.00	1.740	20.880	0.501	0.956	0.90	3.948	0.233	0.0050	0.1182	376.00	55.0
	-39.00 to 39.50	1.779	20.880	0.501	0.836	0.90	3.957	0.233	0.0050	0.1182	376.00	55.0
	-38.50 to 39.00	1.819	20.880	0.501	0.755	0.90	3.965	0.233	0.0050	0.1182	376.00	55.0
	-38.00 to 38.50	1.858	20.880	0.501	0.674	0.90	3.973	0.233	0.0050	0.1182	376.00	56.0
	-37.50 to 38.00	1.898	20.880	0.501	0.592	0.90	3.981	0.233	0.0050	0.1182	376.00	56.0
	-37.00 to 37.50	1.937	20.880	0.501	0.510	0.90	3.990	0.233	0.0050	0.1182	376.00	56.0
	-36.50 to 37.00	1.977	20.880	0.501	0.427	0.90	3.998	0.233	0.0050	0.1182	376.00	56.0
	-36.00 to 36.50	2.016	20.880	0.501	0.344	0.90	4.006	0.233	0.0050	0.1182	376.00	56.0
	-35.50 to 36.00	2.056	20.880	0.501	0.261	0.90	4.014	0.233	0.0050	0.1182	376.00	56.0
	-35.00 to 35.50	2.096	20.880	0.501	0.178	0.90	4.022	0.233	0.0050	0.1182	376.00	56.0
	-34.50 to 35.00	2.135	20.880	0.501	0.094	0.90	4.031	0.233	0.0050	0.1182	376.00	56.0
	-34.00 to 34.50	2.175	20.880	0.501	0.011	0.90	4.039	0.233	0.0050	0.1182	376.00	56.0

### Service Load Deflections

This tab provides an extremely detailed summary of the service axial load, moments, effective moment of inertia and calculated deflection at each wall analysis segment for each load combination.

Service Load Calculations for Deflection Analysis											
Load Combination	Wall Segment	Axial Load (k)	Moment (k-ft)		Inertia (in <sup>4</sup> )		Iterated Defl. (in)				
			Mcr	Mactual	Igross	Icr	Ieff	Deflection	Defl Ratio		
D + L + Lr D + L + W	-34.50 to 35.00	2.363	0.501	1.125	376.00	51.97	53.07	0.0090	999.0		
	-34.00 to 34.50	2.396	0.501	1.003	376.00	53.68	53.61	0.0240	999.0		
	-33.50 to 34.00	2.429	0.501	0.921	376.00	53.70	54.21	0.0332	999.0		
	-33.00 to 33.50	2.462	0.501	0.837	376.00	53.72	55.19	0.0371	999.0		
	-32.50 to 33.00	2.495	0.501	0.752	376.00	53.74	56.92	0.0363	999.0		
	-32.00 to 32.50	2.528	0.501	0.667	376.00	53.77	60.46	0.0314	999.0		
	-31.50 to 32.00	2.561	0.501	0.581	376.00	53.79	70.41	0.0232	999.0		
	-31.00 to 31.50	2.594	0.501	0.494	376.00	53.81	376.00	0.0127	999.0		
	-30.50 to 31.00	2.627	0.501	0.407	376.00	53.84	376.00	0.0011	999.0		
	-30.00 to 30.50	2.660	0.501	0.320	376.00	53.86	376.00	-0.0115	999.0		
	-29.50 to 30.00	2.693	0.501	0.233	376.00	53.88	376.00	-0.0252	999.0		
	-29.00 to 29.50	2.726	0.501	0.145	376.00	53.90	376.00	-0.0400	999.0		
	-28.50 to 29.00	2.759	0.501	0.057	376.00	53.93	376.00	-0.0556	999.0		
	-28.00 to 28.50	2.792	0.501	-0.031	376.00	53.95	376.00	-0.0716	999.0		

### Reactions

This tab gives a summary of out-of-plane and vertical base reactions for each service load combination.

Load Combination	Base Horizontal Reaction (k)	Mid Horizontal Reaction (k)	Top Horizontal Reaction (k)	Vertical Reaction at bottom (k)
Unfactored Service Loads				
D Only	0.003	0.065	0.067	4.640
S Only	0.005	0.048	0.044	1.000
W Only	0.123	0.312	0.164	0.000
E Only	0.181	0.474	0.242	0.000
D + L + Lr	0.029	0.140	0.169	7.761
D + L + S	0.029	0.140	0.169	7.761
D + L + W + S/2	0.138	0.467	0.004	7.261
D + L + S + W/2	0.081	0.319	0.100	7.761
D + L + S + E/1.4	0.142	0.516	0.017	7.761

### Notes

Included are some excerpts from ACI regarding slender masonry wall design.

ACI 530-05/08 Code references for Slender Masonry Wall Design - Out of Plane Loading

ACI 3.3.5.3 says method is only for simply supported, axially loaded walls with moments at mid-span. OK to use established principles

ACI 3.3.5.4 -  $P_u / A_g \leq 0.20 f_m$  when slenderness  $< 30$   
 $P_u / A_g \leq 0.05 f_m$  when slenderness  $> 30$


ACI 3.1.8.2.1 Fr per table 3.1.8.2

ACI 3.3.2 - Masonry stress of  $0.80 f_m$  over a block =  $0.80 * C$


ACI 3.3.3.1 Bars  $\leq \#9$

ACI 3.1.8.1.1 -  $1,500 \leq f_m \leq 4000$

### Sketch



### Diagram



## 10.5 Shear Walls

Please select a material chapter.

## 10.5.1 Concrete Shear Wall

[Need more? Ask Us a Question](#)

This module allows the design of concrete shear walls including multi-story walls with no openings but with up to five levels of differing length, height and thickness.

**Concrete Shear Wall**

General | Story Data | Loads | Footing | Load Combs

Description: Sample Concrete Shear Wall Calc

Concrete Wall Data

Height: 44.0 ft | Sds: 0.30  
R : Resp. Mod Factor: 5.0

Material Properties

f<sub>c</sub>: 3.0 ksi | Density: 150.0 pcf  
f<sub>y</sub>: 60.0 ksi | Phi - Shear: 0.650  
E<sub>c</sub>: 3,120.0 ksi |  Use Mu & Nu for Vc Calc  
E<sub>v</sub>: 1,248.0 ksi | Min. Bending As: 0.00180

Multi-Story Wall Summary

	Bottom Level	2nd Level	3rd Level	4th Level	5th Level
Vu : Story Shear	434.0 +1.20D+0.50Lr+0.50L+W+1.6I	324.0 +1.20D+0.50Lr+0.50L+W+1.6I	240.0 +1.20D+0.50Lr+0.50L+W+1.6I	167.50 +1.20D+0.50Lr+0.50L+W+1.6I	85.0 +1.20D+0.50Lr+0.50L+W+1.6I
Mu : Story Moment	1,447.82 +1.20D+0.50L+0.7C	1,228.01 +1.20D+0.50L+1.6	70.804 +1.20D+0.50L+0.7C	36.079 +1.20D+0.50L+0.7C	22.547 +1.20D+0.50L+0.7C
Nu : Axial	257.880 +1.20D+0.50Lr+1.6	210.360 +1.20D+0.50Lr+1.6	41.30 +1.40D+1.60H	31.404 +1.40D+1.60H	21.875 k
Uplift @ Left End	115.247 +0.90D+E+0.90H	5.267 +0.90D+E+0.90H	9.123 +1.20D+0.50L+0.7C	5.616 +1.20D+0.50L+0.7C	0.0 k
Uplift @ Right End	115.247 +0.90D+E+0.90H	5.267 +0.90D+E+0.90H	9.123 +1.20D+0.50L+0.7C	5.616 +1.20D+0.50L+0.7C	0.0 k
<b>vu : Applied</b>	602.78 psi > vn:max	409.091 psi > vn:max	303.030 psi	264.362psi	245.949 psi
vc = Phi	71.204 psi	71.204 psi	71.204 psi	71.204psi	71.204 psi
vn:max=Phi*10*sqrt(f <sub>c</sub> )	356.020 psi	356.020 psi	356.020 psi	356.020psi	356.020 psi
<b>Horizontal As Req'd</b>	0.8922 in <sup>2</sup> / ft	1.372 in <sup>2</sup> / ft	0.7243 in <sup>2</sup> / ft	0.5706 in <sup>2</sup> / ft	0.5162 in <sup>2</sup> / ft
<b>Vertical As Req'd</b>	0.1728 in <sup>2</sup> / ft	0.1728 in <sup>2</sup> / ft	0.1728 in <sup>2</sup> / ft	0.1728 in <sup>2</sup> / ft	0.1699 in <sup>2</sup> / ft
<b>Bending As Req'd</b>	5.939 in <sup>2</sup>	4.426 in <sup>2</sup>	1.426 in <sup>2</sup>	1.140 in <sup>2</sup>	0.6221 in <sup>2</sup>

*Bending As to be located at EACH end of wall section. See "Effective Depth" on "Multi-Story" input tab above for As centroid location.*

### General Tab

**Concrete Shear Wall**

General | Story Data | Loads | Footing | Load Combs

Description: Sample Concrete Shear Wall Calc

Concrete Wall Data

Height: 44.0 ft | Sds: 0.30  
R : Resp. Mod Factor: 5.0

Material Properties

f<sub>c</sub>: 3.0 ksi | Density: 150.0 pcf  
f<sub>y</sub>: 60.0 ksi | Phi - Shear: 0.650  
E<sub>c</sub>: 3,120.0 ksi |  Use Mu & Nu for Vc Calc  
E<sub>v</sub>: 1,248.0 ksi | Min. Bending As: 0.00180

**Height** specifies the total height of the wall. On the next tab you can divide that total height into up to five different wall portions.



$E_c$  is the bending modulus of elasticity and  $E_v$  is the shear modulus of elasticity.

$S_{DS}$  and  $R$  are used to calculate the in-plane portion of the wall weight to be applied as a seismic load.

$E_c$  is the bending modulus of elasticity, and  $E_v$  is the shear modulus of elasticity.

## Story Data Tab

This tab is where you specify the distinct wall levels for the wall.

	Bottom	2nd Level	3rd Level	4th Level	5th Level
Analysis HT	Datum = 0.00	11.0 ft	16.0 ft	23.250 ft	31.50 ft
Wall Offset	Datum = 0.00	4.50 ft	7.250 ft	7.750 ft	9.50 ft
Wall Length	24.0 ft	12.0 ft	6.50 ft	5.50 ft	3.0 ft
Wall Thickness	12.0 in	12.0 in	12.0 in	12.0 in	12.0 in
Effective Depth	5.0 ft	5.50 ft	5.50 ft	5.50 ft	5.50 ft

Reference Color :

**Analysis Height** locates the bottom edge of the wall section and is where the maximum shear and bending stress will be calculated. This is the user-defined height at which the analysis of a particular wall section will be performed. All moments, shears, and vertical loads at this height will be calculated using all applied lateral and vertical loads and the wall self weight above this point. The other wall data items specified in the same column will be used between this analysis height and the next higher level indicated in the column to the right.

ALWAYS WORK WITH THE HIGHER ANALYSIS HEIGHT IN THE COLUMN TO THE RIGHT OF A LOWER HEIGHT. This is needed due to the manner in which the module calculates the heights by comparing heights of adjacent sections.

**Wall Offset** is the distance that this wall section is offset from the left-most edge of the bottom-most wall section. Please refer to the diagram to further understand this item. Because this module can be used with a walls that have their length changes with height, you must enter the offset from the bottom wall section to the LEFT EDGE of the wall section. This enables the module to calculate the actual X-Distance to the center of gravity of the wall.

**Wall Length** is the length of the wall section. Maximum length is the overall wall length - offset. Enter the length to be used in the analysis of the particular wall section. Please note that if the Wall length + Offset is greater than the Wall Length + Offset for

the level below, this indicates that the section OVERHANGS the section below it. This is not allowed.

**Wall thickness** is the thickness of this wall section. Enter the thickness to be used in the analysis of a particular wall section. This thickness will be used only between the Analysis Height for that section up to the analysis of the next higher section (or Total Wall Height if it is the highest section).

**Effective Depth** locates the tension rebar in the panel, and is used to calculate "shear depth" for calculation of actual shear stresses. As with beams, the Effective Depth in a shear wall is measured from the compression edge of the wall to the centroid of the tension chord rebar.

### Loads Tab

This main tab has four sub-tabs that allow you to enter four types of loads.

**Vertical loads** can be of dead, live, roof live and snow types.


**Lateral loads** can be of seismic and wind types.

**Add wall weight to dead loads** will tell the module to calculate the weight of the wall above each analysis height and include it in the vertical dead loads to calculate applied axial stress. It also is used for footing design when that option is selected.


**Add wall weight as SEISMIC load** will calculate the wall self weight, apply the lateral weight seismic factor and "E" load combination factor. The resulting load will be applied at the wall center to calculate shear and overturning due to that portion of the wall. This is used for values at the analysis height, for the effect of that level's seismic weight on the levels below, and for footing overturning and sliding calculations.

#### Vertical Point Loads

Use this tab to apply point loads to the wall. You can specify an "X" and "Y" distance from the lower-left corner of the lower wall so that the load can be located anywhere on the defined walls.




Use the [Add] and [Edit] buttons to change the values of applied loads. Clicking either button displays this window:



### Vertical Uniform Loads

Use this tab to apply uniform loads to the wall. You can specify a "Y" distance from the bottom of the lower wall so that the load can be located at any height.



Use the **[Add]** and **[Edit]** buttons to change the values of applied loads. Clicking either button displays this window:

**Edit Distributed Load**

**Vertical Distributed Load Location . . .**

START Distance from Left Edge of wall  ft

END Distance from Left Edge of wall

"Y" - Distance ABOVE of Base of wall  ft

**Distributed Load Magnitudes . . .**

Dead Load  k/ft

Live - Roof  k/ft


Live - Floor  k/ft

Snow  k/ft


Earth

### Lateral Point Loads

Use this tab to apply point lateral loads to the wall. You can specify a "Y" distance from the bottom of the lower wall so that the load can be located at any height.




Use the **[Add]** and **[Edit]** buttons to change the values of applied loads. Clicking either button displays this window:



### Lateral Uniform Loads

Use this tab to apply uniform lateral loads to the wall. You can specify a Start and End location to define the extent of the lateral load.



Use the [**Add**] and [**Edit**] buttons to change the values of applied loads. Clicking either button displays this window:

**Edit Distributed Load**

**Lateral Point Load Location . . .**

START Distance ABOVE of Base of wall  ft

END Distance ABOVE of Base of wall  ft

**Distributed Loads Magnitudes . . .**

Dead  k/ft

Roof Live  k/ft

Floor Live  k/ft


Seismic  k/ft

Wind  k/ft

Earth  k/ft

### Footing Tab

You also have the option to specify a footing under a shear wall by selecting the Specify a



Footing checkbox.

The dimensions of the footing are specified using Distance @ Left and Distance @ Right.

**Distance @ Left** is the distance that the footing projects past the left edge of the wall (meaning the lower wall level for a multi-story type wall).

**Distance @ Right** is the distance that the footing projects past the right edge of the wall (meaning the lower wall level for a multi-story type wall).

Rebar is assumed to exist only at the bottom of the footing to resist tensile forces from the vertical loads and increased pressure due to overturning forces. Tension in the top of the footing in cases where no upward soil pressure exists and the footing weight creates a downward net force IS IGNORED.

### Load Combination Tab

The typical load combination tab for strength design of concrete is provided.

Run	Load Combination	Dead Load Factor	0.2*SDS* Seismic Factor	Roof Live	Floor Live	Snow	Wind	Seismic Factor	Seismic Rho	Earth
Yes	+1.40D+1.60H	1.400								1.600
Yes	+1.20D+0.50Lr+1.60L+1.60H	1.200		0.500	1.600					1.600
Yes	+1.20D+1.60L+0.50S+1.60H	1.200			1.600					1.600
Yes	+1.20D+1.60Lr+0.50L+1.60H	1.200		1.600	0.500					1.600
Yes	+1.20D+1.60Lr+0.50W+1.60H	1.200		1.600		0.500	0.500			1.600
Yes	+1.20D+0.50L+1.60S+1.60H	1.200			0.500	0.500	0.500			1.600
Yes	+1.20D+1.60S+0.50W+1.60H	1.200				0.500	0.500			1.600
Yes	+1.20D+0.50Lr+0.50L+W+1.60H	1.200		0.500	0.500	1.000	1.000			1.600
Yes	+1.20D+0.50L+0.50S+W+1.60H	1.200			0.500	1.000	1.000			1.600
Yes	+1.20D+0.50L+0.70S+E+1.60H	1.200			0.500			1.000		1.600
Yes	+0.90D+W+0.90H	0.900				1.000	1.000			0.900
Yes	+0.90D+E+0.90H	0.900						1.000		0.900

### Wall Summary - Stresses Tab

Provides a summary of each level.

In the top portion you will see the calculated shear, moment and axial loads at the analysis height you have specified. These values are due to wall self weight and applied vertical and lateral loads from that analysis height and above.

In the bottom portion of the screen, the unit shear stresses, shear steel required and end reinforcing for bending tension in that wall section are reported. All calculations are per ACI.

	Bottom Level	2nd Level	3rd Level	4th Level	5th Level
Vu : Story Shear	434.0 +1.20D+0.50Lr+0.50L+W+1	324.0 +1.20D+0.50Lr+0.50L+W+1	240.0 +1.20D+0.50Lr+0.50L+W+1	167.50 +1.20D+0.50Lr+0.50L+W+1	85.0 +1.20D+0.50Lr+
Mu : Story Moment	844.10 +1.20D+0.50L+0.;	229.309 +1.20D+0.50L+0.;	70.804 +1.20D+0.50L+0.;	36.079 +1.20D+0.50L+0.;	22.547 +1.20D-
Nu : Axial	203.160 +1.20D+0.50Lr+1.	155.640 +1.20D+0.50Lr+1.	41.30 +1.40D+1.60H	31.404 +1.40D+1.60H	21.875 k
Uplift @ Left End	102.167 +1.20D+0.50L+0.;	22.814 +0.90D+E+0.90H	9.123 +1.20D+0.50L+0.;	5.616 +1.20D+0.50L+0.;	0.0 k
Uplift @ Right End	102.167 +1.20D+0.50L+0.;	22.814 +0.90D+E+0.90H	9.123 +1.20D+0.50L+0.;	5.616 +1.20D+0.50L+0.;	0.0 k
<b>vu : Applied</b>	602.78 psi > vn: max	409.091 psi > vn: max	303.030 psi	264.362 psi	245.949 psi
vc * Phi	71.204 psi	71.204 psi	71.204 psi	71.204 psi	71.204 psi
vn: max=Phi*10*sqrt(f'c)	356.020 psi	356.020 psi	356.020 psi	356.020 psi	356.020 psi
<b>Horizontal As Req'd</b>	0.8922 in <sup>2</sup> / ft	1.372 in <sup>2</sup> / ft	0.7243 in <sup>2</sup> / ft	0.5706 in <sup>2</sup> / ft	0.5162 in <sup>2</sup> / ft
<b>Vertical As Req'd</b>	0.1728 in <sup>2</sup> / ft	0.1728 in <sup>2</sup> / ft	0.1728 in <sup>2</sup> / ft	0.1728 in <sup>2</sup> / ft	0.1699 in <sup>2</sup> / ft
<b>Bending As Req'd</b>	3.305 in <sup>2</sup>	1.426 in <sup>2</sup>	1.426 in <sup>2</sup>	1.140 in <sup>2</sup>	0.6221 in <sup>2</sup>

*Bending As to be located at EACH end of wall section. See "Effective Depth" on "Multi-Story" input tab above for As centroid location.*

### Wall Summary - Forces Tab

This tab provides the detailed force values for each wall level and for each load combination.

Load Combination	Wall Level	Values for Wall Section			Resultant Ecc. (ft)	Overturning Ratio	Uplift (k)	
		Vu (k)	Mu (ft-k)	Pu (k)			Left	Right
+1.40D+1.60H	Level 5		-14.000	21.875	-0.640	None		
	Level 4		-4.188	31.404	-0.133	None		
	Level 3		-4.188	41.300	-0.101	None		
	Level 2		66.373	100.940	0.658	None		
	Level 1		125.773	156.380	0.804	None		
+1.20D+0.50Lr+1.60L+1.60H	Level 5		-12.000	18.750	-0.640	None		
	Level 4		-3.188	26.918	-0.118	None		
	Level 3		-3.188	35.400	-0.090	None		
	Level 2		160.973	155.640	1.034	None		
	Level 1		220.373	203.160	1.085	None		
+1.20D+1.60L+0.50S+1.60H	Level 5		-12.000	18.750	-0.640	None		
	Level 4		-3.188	26.918	-0.118	None		


### Footing & Stability Tab

This tab provides the calculated service and factored load soil pressure, one-way shear and bending at the end of the wall.

<b>Max Factored Soil Pressures</b>		<b>Max Unfactored Soil Pressures</b>	
@ Left Side of Footing .... governing load comb	2,012.64 psf +1.20D+0.50L+0.70S-E+1.60H	@ Left Side of Footing .... governing load comb	1,216.60 psf +D+L+H
@ Right Side of Footing .... governing load comb	2,572.45 psf +1.20D+0.50L+0.70S+E+1.60H	@ Right Side of Footing .... governing load comb	2,100.91 psf +D+0.750L+0.750S+0.5250E+H
<b>Footing One-Way Shear Check...</b>		<b>Overturning Stability...</b>	
vu @ Left End of Footing	35.508 psi	.... governing load comb	With resisting moment calc'd about..... +0.60D+0.70E+0.60H
vu @ Right End of Footing	44.705 psi	Overturning Moment	545.76 k-ft
vn * phi : Allowable	93.113 psi	Resisting Moment	1,244.44 k-ft
<b>Footing Bending Design...</b>		Stability Ratio	<b>2.280 : 1</b>
@ Left Wall End		@ Right Wall End	
Mu	63.252 k-ft		Right End of Ftg.
Ru	78.089 psi		.... governing load comb
As % Req'd	0.00180 in <sup>2</sup>	0.002230 in <sup>2</sup>	Overturning Moment
As Req'd in Ftg Width	<b>1.555 in<sup>2</sup></b>	<b>1.605 in<sup>2</sup></b>	Resisting Moment
			Stability Ratio
			<b>2.663 : 1</b>

### Sketch Tab





## 10.5.2 Masonry Shear Wall

### General

This module allows the design of masonry shear walls including multi-story walls with no openings but with up to five levels of differing length, height, thickness, grouting and reinforcing patterns.

The wall will be composed of two zones:

**Chord Zone:** The areas at both ends of each level that contain chord rebar in every cell. (Always solid grouted.)

**Field of Wall:** The area between chord zones that may have a different reinforcing/grouting pattern. (May be partially-grouted or solid-grouted.)

### Convenience Features

The module collects data on a level-by-level basis to allow the user to account for varying reinforcing and grouting patterns. It also allows some convenience features such as the ability to specify:


- reinforcing and grouting that can vary from one story to the next,
- wall offsets to account for conditions where the length of wall at one story is shorter than the length of the wall below,
- a continuous footing,
- solid grouting,
- chord rebar that is different from the rebar in the field of the wall,
- bond beams and/or horizontal joint reinforcing for shear reinforcing.

### Limitations

Masonry Shear Wall does not allow for the design of openings. It also does not allow for the design of special boundary elements, but it does incorporate the checks to verify that special boundary elements are or are not required.


### Input Parameters

#### General tab



Collects overall wall length and height, material properties, and strength reduction factors.

### Story Data tab



Select checkboxes as necessary to specify the number of stories. Shear wall is assumed to be laterally braced at each defined story level.

**Analysis Height:** The heights at which the story framing is assumed to brace the shear wall.

**Wall Offset:** A lateral offset dimension that can be used to shift the left edge of the wall at the selected level.

**Wall Length:** The distance from the left end of the wall to the right end, at the selected level. This can be used to shift the right edge of the wall.

**Effective Depth:** The dimension from the compression edge of the wall to the centroid of the chord steel.

**Nominal Block Width:** Use the dropdown to select the block width.

**# Chord Cells @ each End:** Specify the number of solid-grouted reinforced chord cells at each end of the selected level.

**Solid Grout:** Reinforced cells will always be assumed to be grouted, but this option provides a way to tell the program that ALL cells in the selected level will be grouted, regardless of whether they contain rebar or not.

**Vertical Bar Size:** Use the dropdown to select the size of the vertical rebar that will be used in the field of the wall.

**Vertical Bar Spacing:** Specify the spacing of vertical rebar in the field of the wall.

**Horizontal Joint Reinforcing (HJR) Area:** Specify the effective cross-sectional area of one piece of horizontal joint reinforcing, if it is to be considered as shear reinforcing.


**Horizontal Joint Reinforcing (HJR) Spacing:** Specify the vertical spacing of horizontal joint reinforcing, if it is to be considered as shear reinforcing.

**Bond Beam Reinforcing Area:** Specify the effective cross-sectional area of rebar in one bond beam, if it is to be considered as shear reinforcing.

**Spacing of Bond Beams:** Specify the vertical spacing of bond beam reinforcing, if it is to be considered as shear reinforcing.

**Vertical Rebar Size (Chords):** Use the dropdown to select the size of the vertical rebar that will be used in each solid-grouted chord cell.

## Loads




Use the tabs to specify magnitude and location of:

- Vertical Point Loads
- Vertical Uniform Loads
- Lateral Point Loads, and
- Lateral Uniform Loads.

Also offers the option to automatically consider wall weight as vertical dead load and/or automatically calculate seismic load due to wall weight.


### Footing



Optional tab to design a footing that behaves as a continuous grade beam that cantilevers past the end of the wall.

Specify geometry, allowable soil pressure, and material properties to arrive at checks for soil pressure and footing flexure.

## Load Combinations



Collects settings that control how load combinations will be generated and applied to the analysis/design of:

- Masonry and reinforcing
- Footing and reinforcing
- Stability
- Soil Pressure

## Output

### Shear Design

Calculations	Shear Design	Axial Design	Flexural Design	Force Summary Tables	Footing & Stability
Sketch	<b>Shear Analysis</b>				
	Special Boundary Elements Req'd?	Bottom Level		2nd Level	3rd Level
	Vu : Story Shear	Not Req'd	11.10 k	6.90 k	3.40 k
	for Load Combination	+1.20D+0.50L+0.70S+E+1.60H	+1.20D+0.50L+0.70S+E+1.60H	+1.20D+0.50L+0.50L+W+1.60H	
	Vn Masonry	27.885 k	28.505 k	28.031 k	
	Controlling Mu/(Vu*d)	1.217	0.871	0.442	
	Vn Steel	55.80 k	55.80 k	55.80 k	
	Vn Max	27.885 k	40.773 k	28.031 k	
	Vn * Phi	22.308 k	32.618 k	22.425 k	
	Ratio: Vu/PhiVn (controlling)	<b>0.4976</b>	<b>0.2115</b>	<b>0.1516</b>	
Vertical As >= Av/3	OK	OK	OK		
Vertical Bar Spacing <= 96"	OK	OK	OK		

Reports:

- Factored shear force and controlling load combination
- Shear strength from masonry
- Shear strength from reinforcing

- Limiting shear strength
- Design shear strength
- Design ratio
- Need for special boundary elements
- Code requirements for area and spacing of vertical rebar.

### Axial Design

		Bottom Level	2nd Level	3rd Level
Calculations	<b>Axial Analysis</b>			
	H / d Ratio	1.06	1.03	1.03
	Pu	49.872 k	40.368 k	22.224 k
	for Load Combination	+1.20D+0.50L+1.60L+1.60H	+1.20D+0.50L+1.60L+1.60H	+1.20D+0.50L+1.60L+1.60H
	Phi Pn	283.561 k	225.310 k	225.310 k
Ratio: Pu/PhiPn (controlling)		<b>0.1759</b>	<b>0.1792</b>	<b>0.09864</b>

### Reports:

- H/d ratio
- Factored axial load and controlling load combination
- Design axial load
- Design ratio

### Flexural Design

		Bottom Level	2nd Level	3rd Level	
Calculations	<b>Flexural Analysis</b>				
	"a" : Flexural compression	2.623 in	1.311 in	1.311 in	
	Length of defined chord zone is >= the "a" dimension of the masonry (the compression zone)	OK	OK	OK	
	"d" : Eff depth to tension reinf	136.0 in	140.0 in	140.0 in	
	As-flex < As-max ?	OK: 0.400 <= 9.189	OK: 0.200 <= 9.460	OK: 0.200 <= 9.460	
	Mu	162.150 k-ft	72.10 k-ft	18.050 k-ft	
	for Load Combination	+1.20D+0.50L+0.70S+E+1.60H	+1.20D+0.50L+0.70S+E+1.60H	+1.20D+0.50L+0.70S+E+1.60H	
	Phi Mn	242.439 k-ft	125.410 k-ft	125.410 k-ft	
	Ratio: Mu/PhiMn (controlling)		<b>0.6688</b>	<b>0.5749</b>	<b>0.1439</b>

### Reports:

- Length of chord zone
- Comparison of As flex to As max
- Factored moment and controlling load combination
- Design moment
- Design ratio

### Force Summary Table

Load Combination	Values for Wall Section			Resultant Ecc. (ft)	Overturning Ratio	Uplift (k)	
	Wall Level	Vu (k)	Mu (ft-k)			Pu (k)	Left
[-] D Only							
[-] Level 3				12.720	None		
[-] Level 2				23.040	None		
[-] Level 1				30.960	None		
[+] +1.20D+0.50Lr+1.60L+1.60H							
[-] Level 3				22.224	None		
[-] Level 2				40.368	None		
[-] Level 1				49.872	None		
[+] +1.20D+1.60L+0.50S+1.60H							
[-] Level 3				21.024	None		
[-] Level 2				39.168	None		
[-] Level 1				48.672	None		

For each load combination, this table reports:

- Vu
- Mu
- Pu
- Eccentricity
- Overturning Ratio
- Uplift

## Footing & Stability

Shear Design	Axial Design	Flexural Design	Force Summary Tables	Footing & Stability																				
<b>Max Factored Soil Pressures</b>																								
<table border="0"> <tr> <td> <ul style="list-style-type: none"> <li>@ Left Side of Footing .... governing load comb</li> <li>@ Right Side of Footing .... governing load comb</li> </ul> </td> <td> <ul style="list-style-type: none"> <li>1,684.29 psf +1.20D+0.50Lr+1.60L+1.60H</li> <li>2,596.47 psf +1.20D+0.50L+0.70S+E+1.60H</li> </ul> </td> <td> <ul style="list-style-type: none"> <li>Max Unfactored Soil Pressures</li> <li>@ Left Side of Footing .... governing load comb</li> <li>@ Right Side of Footing .... governing load comb</li> </ul> </td> <td> <ul style="list-style-type: none"> <li>1,270.25 psf +D+L+H</li> <li>1,873.26 psf +D+0.750L+0.750S+0.5250E+H</li> </ul> </td> </tr> </table>					<ul style="list-style-type: none"> <li>@ Left Side of Footing .... governing load comb</li> <li>@ Right Side of Footing .... governing load comb</li> </ul>	<ul style="list-style-type: none"> <li>1,684.29 psf +1.20D+0.50Lr+1.60L+1.60H</li> <li>2,596.47 psf +1.20D+0.50L+0.70S+E+1.60H</li> </ul>	<ul style="list-style-type: none"> <li>Max Unfactored Soil Pressures</li> <li>@ Left Side of Footing .... governing load comb</li> <li>@ Right Side of Footing .... governing load comb</li> </ul>	<ul style="list-style-type: none"> <li>1,270.25 psf +D+L+H</li> <li>1,873.26 psf +D+0.750L+0.750S+0.5250E+H</li> </ul>																
<ul style="list-style-type: none"> <li>@ Left Side of Footing .... governing load comb</li> <li>@ Right Side of Footing .... governing load comb</li> </ul>	<ul style="list-style-type: none"> <li>1,684.29 psf +1.20D+0.50Lr+1.60L+1.60H</li> <li>2,596.47 psf +1.20D+0.50L+0.70S+E+1.60H</li> </ul>	<ul style="list-style-type: none"> <li>Max Unfactored Soil Pressures</li> <li>@ Left Side of Footing .... governing load comb</li> <li>@ Right Side of Footing .... governing load comb</li> </ul>	<ul style="list-style-type: none"> <li>1,270.25 psf +D+L+H</li> <li>1,873.26 psf +D+0.750L+0.750S+0.5250E+H</li> </ul>																					
<b>Footing One-Way Shear Check...</b>																								
<table border="0"> <tr> <td>vu @ Left End of Footing</td> <td>5.293 psi</td> <td></td> <td></td> <td></td> </tr> <tr> <td>vu @ Right End of Footing</td> <td>8.044 psi</td> <td></td> <td></td> <td></td> </tr> <tr> <td>vn * phi : Allowable</td> <td>93.113 psi</td> <td></td> <td></td> <td></td> </tr> </table>					vu @ Left End of Footing	5.293 psi				vu @ Right End of Footing	8.044 psi				vn * phi : Allowable	93.113 psi								
vu @ Left End of Footing	5.293 psi																							
vu @ Right End of Footing	8.044 psi																							
vn * phi : Allowable	93.113 psi																							
<b>Footing Bending Design...</b>																								
<table border="0"> <tr> <td>Mu</td> <td>6.632 k-ft</td> <td>9.879 k-ft</td> <td></td> <td></td> </tr> <tr> <td>Ru</td> <td>12.458 psi</td> <td>18.558 psi</td> <td></td> <td></td> </tr> <tr> <td>As % Req'd</td> <td>0.00180 in<sup>2</sup></td> <td>0.00180 in<sup>2</sup></td> <td></td> <td></td> </tr> <tr> <td>As Req'd in Ftg Width</td> <td>1.210 in<sup>2</sup></td> <td>1.210 in<sup>2</sup></td> <td></td> <td></td> </tr> </table>					Mu	6.632 k-ft	9.879 k-ft			Ru	12.458 psi	18.558 psi			As % Req'd	0.00180 in <sup>2</sup>	0.00180 in <sup>2</sup>			As Req'd in Ftg Width	1.210 in <sup>2</sup>	1.210 in <sup>2</sup>		
Mu	6.632 k-ft	9.879 k-ft																						
Ru	12.458 psi	18.558 psi																						
As % Req'd	0.00180 in <sup>2</sup>	0.00180 in <sup>2</sup>																						
As Req'd in Ftg Width	1.210 in <sup>2</sup>	1.210 in <sup>2</sup>																						
<b>Overturning Stability...</b>																								
<table border="0"> <tr> <td>.... governing load comb</td> <td>+0.60D+0.70E+0.60H</td> <td>With resisting moment calc'd about....</td> <td></td> <td></td> </tr> <tr> <td>Overturning Moment</td> <td>120.738 k-ft</td> <td>Left End of Ftg.</td> <td></td> <td></td> </tr> <tr> <td>Resisting Moment</td> <td>162.864 k-ft</td> <td>Right End of Ftg.</td> <td></td> <td></td> </tr> <tr> <td>Stability Ratio</td> <td>1.349 : 1</td> <td>+0.60D+0.70E+0.60H</td> <td></td> <td>+0.60D+0.70E+0.60H</td> </tr> </table>					.... governing load comb	+0.60D+0.70E+0.60H	With resisting moment calc'd about....			Overturning Moment	120.738 k-ft	Left End of Ftg.			Resisting Moment	162.864 k-ft	Right End of Ftg.			Stability Ratio	1.349 : 1	+0.60D+0.70E+0.60H		+0.60D+0.70E+0.60H
.... governing load comb	+0.60D+0.70E+0.60H	With resisting moment calc'd about....																						
Overturning Moment	120.738 k-ft	Left End of Ftg.																						
Resisting Moment	162.864 k-ft	Right End of Ftg.																						
Stability Ratio	1.349 : 1	+0.60D+0.70E+0.60H		+0.60D+0.70E+0.60H																				

Reports:

- Maximum Factored Soil Pressures and controlling load combinations
- Maximum Unfactored Soil Pressures and controlling load combinations
- Footing One-Way Shear Check
- Footing Bending Design Values
- Overturning Stability Results and controlling load combinations



### 10.5.3 Wood Shear Wall

#### Basis

The NDS Special Design Provisions for Wind & Seismic allows for three approaches to wood shear wall design:


1. Force Transfer Shear Walls
2. Perforated Shear Walls
3. Individual Full-Height Wall Segment Shear Walls.

Force Transfer Shear Walls and Perforated Shear Walls allow the designer to use more favorable analysis assumptions, and offers some benefits in terms of construction details. But it comes at a cost of the designer having to perform more calculations and designs to follow the load path through all of the headers, jambs, sills, etc., and their connections.

At present, the Wood Shear Wall module implements the Individual Full-Height Wall Segment Shear Walls method. This is the most straightforward method from the design standpoint. This method still requires the evaluation of  $h/b$  ratios to decide whether to eliminate slender segments or suffer the imposed reduction on the nominal shear capacity based on the slenderness of each panel in the wall. (Section 4.3.5.1 refers back to Section 4.3.4, which includes this reduction.) But this method does not require consideration of the reduction factor ( $C_o$ ) that applies to Perforated Shear Walls.

The implementation within Structural Engineering Library goes a little further by allowing the user to specify openings. The module then takes the defined openings and considers only the solid stacked portions of remaining wall as being effective at resisting lateral loads.

Section 4.3.3.4 provides the justification for summing the resistance of multiple Individual Full-Height Wall Segments because, by our definition within the module, all segments will be “sheathed with the same materials and construction”.



## Overview

The Wood Shear Wall module allows the user to define overall geometry, openings (if any), sheathing type, chord member species, grade, and size, applied loads, and a footing (if desired). The module then evaluates the resulting shear panels, chords, and footing (if defined).

Sheathing is evaluated for aspect ratio and unit shear due to load combinations that include either wind or seismic. The module considers the selected sheathing type, sheathing thickness, fastener size, blocking condition, and the species of the supporting framing. It then automatically incorporates any necessary adjustments to the nominal unit shear values from the 2008 Special Design Provisions for Wind and Seismic on the basis of sheathing type, aspect ratio, and the species of the supporting framing. The result is a required fastener spacing for each panel in the wall.

Chords are evaluated for tension and compression due to load combinations that include either wind or seismic. The moment in a given shear panel is assumed to be coupled out at the location of the chords, resulting in tension and compression forces. Any applied vertical loads that may be present are combined with the wind or seismic chord forces, and the resulting loads on the chords are evaluated as per the requirements of the NDS.

Footings (if defined) are evaluated for soil bearing pressure, overturning, and one-way shear and flexure of the cantilevered end projection.

There are certain items that are not explicitly evaluated by this module, and the user should be aware of the following exclusions: bending or shear in the top plate, bearing on the top plate, out of plane design of the wall sheathing or framing, gravity-only loading on the common studs or chords, bearing on the bottom plate, design of anchorage hardware or connections.

### Workflow Process

The general workflow proceeds as follows:

1. The overall height and length of the shear wall are defined on the General tab, along with selections such as the Seismic Design Category, the Design Method, and the Framing and Chord Species and Grade.
2. The sheathing type, thickness, fastener size and blocking conditions is selected on the Sheathing tab. This tab also allows for the specification of sheathing on the second side of the framing when necessary.
3. The chord size is specified on a level-by-level basis on the Chords tab. This tab also allows for the specification of the bracing assumption to be applied in the compression design of the chords.
4. If openings are present in the wall, they can be defined on the Openings tab.
5. Loads of many types can be defined and applied on the Loads tab.
6. If a continuous footing design is desired, the footing geometry and material properties can be entered on the Footing tab.
7. The Load Combinations tab allows for the definition of the load combinations that will be used for the design.
8. The results for the shear panels, chords, and footing (if designed) can be reviewed in the Results panel in the lower portion of the screen.

### General tab

**Description:** Enter a freeform description of the current wall design for reference.

**Total Wall Length:** Enter the overall length of the shear wall in units of feet.

**Story Heights:** Enter the heights of up to five stories in units of feet. Whenever a value is entered, the input field for the next story height is displayed in case it is needed. The total accumulated height is automatically reported.

**Seismic Design Category:** Enter the appropriate Seismic Design Category for the wall being designed. This is used to check the selected sheathing type to be sure it is permissible for use in that SDS according to the Special Design Provisions for Wind and Seismic.

**Design Method:** Select ASD or LRFD to dictate which method will be applied when designing shear panels and chords. Footing design (when requested) is always by LRFD methods.

**Framing & Chord Material:** Use the icon to access the Wood Reference Design Values database in order to select the species and grade of wood used for the chords and common framing in the wall.

### Sheathing tab

**Select SDPWS Construction Table:** Choose the table from which the sheathing will be selected.

**Select Main Sheathing:** Select a tabular entry to represent the sheathing type, sheathing thickness, fastener size/penetration, and in some cases the blocking condition.

**Nominal Shear Capacities:** The program displays the nominal shear capacities for seismic design and for wind design directly from the selected table. These are nominal values which still need to be modified for use in design, such as with a phi factor or factor of safety and with any applicable adjustments such as for aspect ratio or specific gravity of the supporting framing.

**Sheathing is Blocked:** (Only visible for some tabular selections) Use this checkbox to indicate if the sheathing is blocked or not. This setting has an effect on some of the allowable aspect ratios.

**Table 4.3A Footnote 2 is applicable:** (Only visible for some tabular selections) Use this checkbox to indicate if a specific condition exists as described in detail in the referenced footnote in Table 4.3A of the 2008 Special Design Provisions for Wind and Seismic.

**Sheathing on 2nd Side:** Use this checkbox to indicate that there is a sheathing of some sort on the other side of the framing.

**Use Same as Main Sheathing:** A convenience option that automatically sets the Sheathing on 2nd Side to be identical to the sheathing on the Main side.

**Note:** If sheathing is specified on the second side, and if the sheathing comes from the same Construction Table as the Main Sheathing, then the blocking setting for the 2nd side will automatically be assumed to be the same as the blocking setting for the Main side.

### Chords tab

The Chords tab will automatically display one row of chord definition data for each story that was defined on the General tab.

**Chord Size:** Use the drop-down list box to select the size of the sawn lumber member(s) that will be used at the chord locations for the given level. Note that the program will automatically determine the number of chord members required at each location. So for example, if the wall was generally going to be constructed of 2x4 framing, then this input should be set to "2x4". Once the analysis and design has been completed, the program will report how many 2x4s should be ganged together to safely resist the imposed chord forces at each location.

**CF: Size Factor:** Enter the appropriate Size Factor for the chord member size, species, and grade being entered.

**Area per Chord:** The program reports that cross sectional area of one member of the selected size for reference.

**Maximum Chord Stress Ratio:** Enter the maximum permissible chord stress ratio. Typically 1.0 using current design methods and load combinations.

**Chord Strength Calculation:** This setting offers two options for defining the bracing of chord members when the allowable compression stress is calculated.

- The option named *Treat all chords as fully braced about both axes* implies that all chords are braced against column buckling. The physical model for this option might be a situation where chord members always occur at "L" or "T" shaped intersections, such that the sheathing prevents buckling in the plane of the shear wall, and the intersecting wall prevents buckling out of the plane of the shear wall. (These conditions are probably not common.)
- The option named *Assume all chords unbraced out of plane of wall for story height* implies that the sheathing prevents buckling in the plane of the shear wall, but nothing prohibits column buckling of the chord member out of the plane of the wall. This is the condition for the chords at the end of an isolated straight panel of wall where no perpendicular walls intersect the shear wall at the chord locations.

## Openings tab

The Openings tab allows openings to be defined in the shear wall.

**Add:** The Add button opens the Add Opening dialog. The dialog automatically numbers the openings that are added, and it collects the geometric information necessary to locate and size the opening. The Add Opening dialog also checks the alignment of defined openings to ensure that all jambs are aligned.

**Edit:** By selecting an existing opening in the list, the Edit button allows the selected opening to be revised.

**Delete:** By selecting an existing opening in the list, the Delete button allows the selected opening to be removed.

Renumber: The Renumber button allows existing openings to be renumbered in a logical order by working from left to right and then from bottom to top.


The graphic display offers checkboxes to independently display or hide:

- Openings
- Shear Panel callouts
- Chord graphics and callouts
- Panel and opening dimensions
- All loads


Note: This module is predicated on the design assumptions of the Individual Full-Height Wall Segment Shear Walls method. This method disregards the shear resistance of portions of shear walls above and below openings. This leads to two **important** considerations regarding the use of openings:

1. In multi-story models, any opening in one story must not partially overlap an opening in a different story. Envision vertical lines at the jambs of an opening, and project them to the top and bottom of the entire wall. Those jamb reference lines must not cross any other opening. The Add Opening dialog will warn if this condition is being violated by having partially-overlapping openings in any story. This may require enlarging some openings so that they respect the jamb locations of adjacent openings, or it may require applying the module only to the solid portions of the wall that remain after the openings have been omitted.
2. The presence of an opening within a given story, creates a panel that is ineffective at resisting shear. The ineffective panel is defined by the width of the opening and it extends for the full height of that story. This means that it is not necessary to model stacked openings within a given story. In fact, doing so will cause an error.

See the following diagrams for some acceptable and unacceptable opening geometries:




**NG - Jambs of openings do NOT align --> Here is how to fix it -->**  
**OK - Jambs of openings align properly**



it --> **NG - Opening crosses top of story** --> Here is how to fix  
**OK - Large opening modeled as 2 separate openings**





**NG - Stacked openings within a story --> Here is how to fix it -->**  
**OK - One opening accomplishes the task**

Note: When using the self-weight functions for Dead Load and for seismic load, the program does not deduct any weight for openings. In other words, the program assumes that the unit weight of the window, door, buver, etc. in the opening, is approximately the same as the unit weight of the wood-framed construction it is replacing.

### Footing tab

**Specify a Footing:** If this checkbox is selected, then the input fields for defining a footing are displayed. Note: This checkbox also causes some footing-related input to be shown or hidden as appropriate on the Loads tab.

**Allowable Soil Pressure:** Specify the allowable soil bearing pressure in units of ksf.

**f'c:** Specify the compressive stress of concrete in units of ksi.

**Fy:** Specify the yield stress of rebar in units of ksi.

**Rebar Cover:** Specify the cover over rebar in units of inches. The program will use this value and an allowance for the rebar size to calculate the effective depth of the concrete section.

**Minimum Steel Reinforcing Percentage Based on Thickness:** Specify the minimum permissible ratio of rebar area to gross area of concrete.

**Concrete Density:** Specify the density of concrete in units of pcf.

**Footing Width:** Specify the width of the footing in units of ft. This is the dimension perpendicular to the wall length.

**Footing Thickness:** Enter the thickness of the footing in units of inches.

**Projection @ Left:** Enter the projection of the footing beyond the left end of the wall in units of ft.

**Wall Length:** The program reports the shear wall length in units of ft for reference.

**Projection @ Right:** Enter the projection of the footing beyond the right end of the wall in units of ft.

**Footing Length:** The program reports the footing length in units of ft for reference.

## Loads tab

The Loads tab provides several sub-tabs for the convenient definition of many different types of loads that could potentially act on a shear wall system.

### General sub-tab

The Wall Self Weight category offers inputs for the following:

**Consider Wall Weight:** This category provides options to automatically consider the wall self-weight:

- As vertical Dead load - a way to request that the program use the unit weight described above to calculate a dead load

- As Seismic load - a way to request that the program use the unit weight described above to calculate a lateral seismic load using the value of  $C_s$  described below

Weight: (Only displayed when one of the options above has been selected.) Enter the unit weight of shear wall construction in psf.

$C_s$ : Seismic Response Coefficient: (Only displayed when the "As Seismic load" option above has been selected.) Collects the value of  $C_s$  by which the unit weight would be multiplied to determine the seismic load due to the self-weight of the wall if that option is selected.

The Soil over Footing category is only displayed if the "Specify a Footing" option is selected on the Footing tab. This category offers inputs for the following:

Soil depth over footing: Enter the depth of soil above the top of the footing in units of inches. This value is used to determine loading on concrete footings when one is designed. This value will affect the reinforced concrete design, the soil bearing pressure, and the overturning ratio.

Soil density: Enter the density of soil above the top of the footing in units of pcf. This value is used to determine loading on concrete footings when one is designed. This value will affect the reinforced concrete design, the soil bearing pressure, and the overturning ratio. If no footing design is requested, this value has no influence on the remaining calculations.

The Added Overburden Load over Footing category is only displayed if the "Specify a Footing" option is selected on the Footing tab. This category allows the user to specify superimposed load on the top of the footing for all of the common load cases. This value will affect the reinforced concrete design, the soil bearing pressure, and the overturning ratio.

#### **Vertical Point sub-tab**

Add: The Add button opens the Add Point Load dialog. The dialog allows vertical point loads of all load cases to be defined and located with respect to the lower left corner of the wall. Note: Positive magnitudes are assumed to act downward.

Edit: By selecting an existing load in the list, the Edit button allows the selected load to be revised.

Delete: By selecting an existing load in the list, the Delete button allows the load opening to be removed.

#### **Vertical Uniform sub-tab**

Add: The Add button opens the Add Uniform Load dialog. The dialog allows vertical uniform loads of all load cases to be defined and located with respect to the lower left corner of the wall. Note: Uniform loads can be specified as partial-length loads by

specifying the start and end locations of the load with respect to the left edge of the wall. Positive magnitudes are assumed to act downward.

Edit: By selecting an existing load in the list, the Edit button allows the selected load to be revised.

Delete: By selecting an existing load in the list, the Delete button allows the load opening to be removed.

#### **Lateral Point sub-tab**

Add: The Add button opens the Add Point Load dialog. The dialog allows lateral point loads of all load cases to be defined and located with respect to the lower edge of the wall. Note: Positive magnitudes are assumed to act to the right.

Edit: By selecting an existing load in the list, the Edit button allows the selected load to be revised.

Delete: By selecting an existing load in the list, the Delete button allows the load opening to be removed.

#### **Lateral Uniform sub-tab**

Add: The Add button opens the Add Uniform Load dialog. The dialog allows lateral uniform loads of all load cases to be defined and located with respect to the lower edge of the wall. Note: Uniform loads can be specified as partial-height loads by specifying the start and end locations of the load with respect to the bottom edge of the wall. Positive magnitudes are assumed to act to the right.

Edit: By selecting an existing load in the list, the Edit button allows the selected load to be revised.

Delete: By selecting an existing load in the list, the Delete button allows the load opening to be removed.

The graphic display offers checkboxes to independently display or hide:

- Openings
- Shear Panel callouts
- Chord graphics and callouts
- Panel and opening dimensions
- All loads - otherwise only the loads associated with the selected tab are displayed

#### **Load Combinations tab**

The Load Combinations tab indicates the currently selected load combination set.

The load combination set can be changed by clicking the Change Load Combination Set button.

The padlock icon can be used to unlock the individual load factors so they can be edited.

Note: Editing load factors in this way will not alter the load factors that are stored in the selected load combination set. The edits will only affect the currently active calculation.

The Load Combinations tab has two sub-tabs: Service Combinations and Factored Combinations.

### **Service Combinations sub-tab**

The Service Combinations tab offers the service-level combinations from the selected load combination set. These load combinations will be used for wood design when the ASD Design Method is selected. They will also be used to determine soil bearing pressures when the option is selected to design a footing.

A selected checkbox in the "Run" column indicates that the associated load combination will be considered. The "Run" button offers quick convenience options for changing the selection status of many load combinations at one time.

The  $C_D$  column is only visible when the ASD Design Method is selected. It indicates the value of the Load Duration Factor for each load combination. Click the  $C_D$  button to quickly set the values of  $C_D$  for all load combinations based on the load case with the shortest duration.

Use additional factors per ASCE 12.4.2.3: Select this button to instruct the module to consider the additional contribution to the Dead Load due to the vertical component of seismic load prescribed in ASCE 12.4.2.3.

Auto Reverse Wind: Select this button to instruct the module to also consider the algebraic negative of the defined Wind loads. (This may be useful for quickly creating a load combinations that reverse the direction of application of applied wind loads by creating a "sister" load combination that uses the negative version of the wind component for each load combo that normally incorporates +W.)

Auto Reverse Seismic: Select this button to instruct the module to also consider the algebraic negative of the defined Seismic loads. (This may be useful for quickly creating a load combinations that reverse the direction of application of applied seismic loads by creating a "sister" load combination that uses the negative version of the seismic component for each load combo that normally incorporates +E.)

### **Factored Combinations sub-tab**

The Factored Combinations tab offers the factored- or ultimate-level combinations from the selected load combination set. These load combinations will be used for wood design when the LRFD Design Method is selected. They will also be used for reinforced concrete design when the option is selected to design a footing.

A selected checkbox in the "Run" column indicates that the associated load combination will be considered. The "Run" button offers quick convenience options for changing the selection status of many load combinations at one time.

The Lambda column is only visible when the LRFD Design Method is selected. It indicates the value of the Time Effect Factor for each load combination. Click the Lambda button to quickly set the values of Lambda for all load combinations based on Table N3.

$L \leq 100, f_1=0.5$ : Select this option to set appropriate load factors on Live Load when the specified Live Load is less than or equal to 100 psf.

$L > 100, f_1=1.0$ : Select this option to set appropriate load factors on Live Load when the specified Live Load is greater than 100 psf.

Use additional factors per ASCE 12.4.2.3: Select this button to instruct the module to consider the additional contribution to the Dead Load due to the vertical component of seismic load prescribed in ASCE 12.4.2.3.

Auto Reverse Wind: Select this button to instruct the module to also consider the algebraic negative of the defined Wind loads. (This may be useful for quickly creating a load combinations that reverse the direction of application of applied wind loads by creating a "sister" load combination that uses the negative version of the wind component for each load combo that normally incorporates +W.)

Auto Reverse Seismic: Select this button to instruct the module to also consider the algebraic negative of the defined Seismic loads. (This may be useful for quickly creating a load combinations that reverse the direction of application of applied seismic loads by creating a "sister" load combination that uses the negative version of the seismic component for each load combo that normally incorporates +E.)

The lower portion of the screen offers the following options for reviewing results:

### Shear Panel Design

#### Summary

On a panel-by-panel, level-by-level basis, the Summary tab presents the following information:

Max Shear: Reports the maximum shear force and the load combination associated with that maximum shear force.

# of Sides: Indicates the number of sides to which sheathing has been applied. Will either be 1 or 2.

**Shear Summary & Attachment:** Reports the actual unit shear, the allowable unit shear, the design status, and the required attachment pattern.

**Height/Width Ratio:** Reports the actual height-to-width ratio, the allowable height-to-width ratio for Side 1 (Main Sheathing), the allowable height-to-width ratio for Side 2 (2nd Side Sheathing), and notes regarding the status of the height-to-width ratio and any necessary adjustments.

### **Detail by Panel ID**

On a panel-by-panel, load combination-by-load combination basis, the Detail by Panel ID tab presents the following information:

**Panel Data:** Reports the story in which the panel exists, the distance from the left edge of the overall wall to the left edge of the panel, the width of the panel, the distance from the bottom edge of the overall wall to the bottom edge of the panel, the height of the panel, and the height-to-width ratio of the panel.

**Shear Forces:** Reports the "Tributary Width" =  $(\text{Panel Width} / \sum \text{Panel Widths}) * \text{Overall Wall Length}$ , Tributary % =  $\text{Panel Width} / \sum \text{Panel Widths}$ , Shear tributary to each panel, panel width, and the maximum unit shear.

**Capacity Factors:** Reports phi for LRFD designs or the reciprocal of the Factor of Safety for ASD designs, a capacity adjustment factor due to aspect ratio of the sheathing on the Main Sheathing side of the wall, a capacity adjustment factor due to aspect ratio of the sheathing on the 2nd Side of the wall, and a capacity adjustment factor due to the specific gravity of the framing.

**Adjusted Allowable Shear:** Reports the allowable unit shears for all relevant fastener spacings incorporating any applicable capacity adjustment factors. In situations where two sides of sheathing are being considered, this table will correctly determine the capacity considering both sides of sheathing by applying the rules of 4.3.3.3 and 4.3.3.3.2.

**Panel Moment:** Reports the moment in the panel.

**Chord ID:** Reports the identifying labels for the chords at the left and at the right end of each panel.

### **Detail by Load Combination**

On a load combination-by-load combination, panel-by-panel basis, the Detail by Load Combination tab presents the following information:

"Tributary Width" =  $(\text{Panel Width} / \sum \text{Panel Widths}) * \text{Overall Wall Length}$

Tributary % =  $\text{Panel Width} / \sum \text{Panel Widths}$

Shear Force = shear tributary to each panel

A convenient nomenclature key is presented on this tab as well.

## Chord Design

### Chord Data

For each chord in the wall, the Chord Data tab presents the following information:

**Location:** Reports the Level in which the chord occurs and the distance from the left edge of the overall wall to the chord.

**Chord Design:** Reports the chord force associated with the controlling design ratio, the load combination responsible for producing the controlling design ratio, then number of chord members required to resist the applied load, the size of the chord member indicated by the user, the governing design ratio, the governing design consideration (tension or compression), and the design status.

**Chord Compression Stress:** Reports the maximum chord compression force, the load combination responsible for producing the maximum chord compression force, the maximum compressive stress, and the allowable compressive stress.

**Chord Tension Stress:** Reports the maximum chord tension force, the load combination responsible for producing the maximum chord tension force, the maximum tensile stress, and the allowable tensile stress.

### Chord Forces by Chord ID

For each chord in the wall, on a load combination-by-load combination basis the Chord Forces by Chord ID tab presents the following information:

**Story:** The story in which the chord occurs.

**ID:** The identification label assigned to the chord.

**Axial:** Reports the load in the chord due to the sum of applied vertical loads, the load in the chord that can be added or subtracted due to the overturning moment in the panel, the force with the largest (tendency for) tension, and the force with the largest (tendency for) compression.

**Chord Location:** Reports the distance from the left edge of the overall shear wall to the chord location, the distance from the bottom edge of the overall shear wall to the bottom of the chord, and the distance from the bottom edge of the overall shear wall to the top of the chord.



## Footing & Stability

**Max Factored Pressures:** Reports the maximum factored soil pressures at the left and right sides of the footing, along with the load combination responsible for producing each of those pressures. Note: Factored soil pressures are reported for reference, as they are used in the reinforced concrete design calculation for the footing.

**Footing One-Way Shear Check:** Reports the results of the one-way shear calculation for both ends of the footing.

**Footing Bending Design:** Reports the results of the flexural analysis and design including recommended reinforcing options to satisfy the required area of steel.

**Max Unfactored Soil Pressures:** Reports the maximum unfactored soil pressures at the left and right sides of the footing, along with the load combination responsible for producing each of those pressures. Unfactored soil pressures are compared to the allowable soil bearing pressure provided by the user.

**Overtuning Stability:** Reports the overturning analysis performed about each end of the footing including the overturning moment, the resisting moment, the stability ratio, and the governing load combination.

## Sketch

The sketch tab provides a convenient graphical view of the shear wall with options to selectively view or hide the following:

- Openings
- Shear Panel callouts
- Chord graphics and callouts
- Panel and opening dimensions
- All loads

## 10.6 Retaining Walls

Please select a subtopic.

## 10.6.1 Cantilevered Retaining Wall

### [Need more? Ask Us a Question](#)

Here is a listing of design capabilities contained in this Cantilevered Retaining Wall module:

- Cantilevered stem wall can have up to five different stem sections, of either masonry or concrete, each with a different thickness and/or reinforcing size and spacing. You may also include a weightless fence on top of the wall for the purpose of collecting additional wind load.
- Surcharges on either side of the wall.
- Sloped backfill.
- Axial dead and live load applied to the top of the wall, with eccentricity.
- Wind acting on a wall projection above grade.
- Add lateral loads against the stem -- uniform or concentrated (impact) loads.
- Effect of an adjacent footing behind the wall, line or point loading.
- Option to use user-defined active and passive pressure or input angle of internal friction and module will compute pressures using the Rankine or Coulomb formulas.
- Specify percent passive and frictional resistance to be used to prevent sliding.
- Option to specify sliding resistance using cohesion, in lieu of friction.

### Window Layout

The retaining wall module divides the screen into a left and right portion. The left portion contains all of the input data (and in some cases intermediate calculated values). The right portion contains the calculated results and sketches.

**Cantilevered Retaining Wall**

General | Loads | Stem | Footing | Options

Results | Sketch | Loading | Print Sketch & Loading separately.

Summary | RSM | OTM | Sliding | Stem

Description  
Sample Retaining Wall

General

Retained Height: 11.000 ft  
 Wall height above retained soil: 0.000 ft  
 Height of Soil over Toe: 12.000 in  
 Water table height over heel: 0.000 ft  
 Soil Slope: Set to: Level 0.00 : 1

Soil Values

Allow Soil Bearing: 3,000.0 psf  
 Soil Density (heel side): 110.00 pcf  
 Soil Density (toe side): 0.00 pcf  
 Lateral Pressure Method: E.F.P. | Coulomb | Rankine  
 Active Soil Pressure - Heel Side: 45.00 psf/ft  
 Active Soil Pressure - Toe Side: 30.00 psf/ft  
 Passive Pressure: 389.00 psf/ft

Stability Ratios

OTM Ratio: 2.624 : 1.00  
 Sliding Ratio: 1.619 : 1.00

Soil Loading Results (Service loads)

	Actual	Allowable
Soil Pressure @ Toe	2,160.5 psf	3,000.0 psf
Soil Pressure @ Heel	231.5 psf	
Total Bearing Load	8,970.0 lbs	
...resultant ecc	12.10 in	

Eccentricity within middle third

Footing Results

ACI Factored Pressure @ Toe	2,592.6 psf
ACI Factored Pressure @ Heel	277.8 psf
Mu:Design @ Toe	3,909.7 ft-lb
Mu:Design @ Heel	15,964.0 ft-lb

Stem Base Moment Governs HEEL Moment

One-Way Footing Shears...

Shear @ Toe (vu)	6.377 psi
Shear @ Heel (vu)	37.543 psi
Allow. Footing Shear (phi*vn)	88.741 psi

Design Notes . . . (visible when needed)

## GENERAL WALL INFORMATION

This tab allows you to enter the general information affecting the retaining wall. More specific data will be entered on other tabs dedicated specifically to the stem, footing and loads.

**General** | Loads | Stem | Footing | Options

**Description**  
Sample Retaining Wall

**General**

Retained Height: 11.000 ft

Wall height above retained soil: 0.000 ft

Height of Soil over Toe: 12.000 in

Water table height over heel: 0.000 ft

Soil Slope: Set to: Level 0.00 : 1

**Soil Values**

Allow Soil Bearing: 3,000.0 psf

Soil Density (heel side): 110.00 pcf

Soil Density (toe side): 0.00 pcf

Lateral Pressure Method: E.F.P. | Coulomb | Rankine

Active Soil Pressure - Heel Side: 45.00 psf/ft

Active Soil Pressure - Toe Side: 30.00 psf/ft

Passive Pressure: 389.00 psf/ft

### Retained Height

This is the height of retained earth measured from top of footing to the top of soil behind the stem (over the heel). When the backfill is sloped, the soil will slope away and upwards from this height. The actual retained height used for overturning and soil pressure calculations will be the retained height projected at the vertical plane of the back of the heel, but for stem moments, no such increase will be made.

Using the spin-buttons you can vary the retained height in 3-inch increments. You can also type in any number. After each entry, you can press **[Tab]** to advance to the next entry, or use your mouse to reposition the cursor.

### Wall Height above Retained Soil

Use this entry to specify if the wall extends above the retained height. This entry is typically used to define a "screen wall" projection above the retained soil. This

extension can be used as a weightless "Fence", or it can be defined as a concrete or masonry stem section without any soil retained behind it. You can enter wind load on this projection using the entry labeled "Load @ stem above soil" on the Loads tab. We'll handle the fence when we get to the Stem design screen. The total height of the wall (above the footing) will be equal to the Retained Height plus the Wall Height Above Retained Soil.

### **Height of Soil over Toe**

Measured from top of footing to top of soil on the toe side, this may vary from a few inches to a few feet depending upon site conditions. (Note that it is specified in inches.) It is used to calculate passive soil resistance (but its effective depth can be modified by the "Soil over toe to Neglect" entry in the Sliding Resistance category on the Footing tab). This depth of soil is also used to calculate the resisting moment, and to reduce the net lateral sliding force. You can negate the latter effects on the Options screen if desired.

### **Water table height over heel**

If a portion of the retained height is below a water table, the active pressure of the saturated soil will increase below that level. This additional pressure for the saturated soil is equal to the pressure of water, plus the submerged weight of the soil (its saturated weight - 62.4), plus the surcharge of the soil above the water table. The submerged weight of a soil can be approximated as 62% of its dry unit weight.

If you want to design for a water table condition, enter the maximum height from top of footing to water table level. The module will then compute the added pressures for saturated soil on the heel side of the footing, including buoyancy effect. It will also calculate increased moments and shears on the stem, and an increased overturning moment. Don't enter a height more than the retained height, nor a liquid other than water. If the water table is near the top of the retained height, it may be advisable to enter the saturated soil density and specify the resulting active pressure for the full retained height.

### **Soil Slope**

You may enter any backfill slope behind the wall. Use the drop-down list box or type the slope ratio as Horiz/Vert. The soil must be level or slope upward. Negative backfill slopes (grade sloping downward, away from the wall) are not allowed.

The module will use this slope to:

1. include the weight of a triangular wedge of soil over the heel as vertical load, and
2. compute overturning based upon an assumed vertical plane at the back face of the footing extending from the bottom of the footing to the ground surface – a steeper slope will result in a higher overturning moment.

When the Rankine or Coulomb method is used, the final calculated pressures do include the effect of the slope on those Rankine or Coulomb equations.

The module will not accept a backfill slope steeper than the angle of internal friction.

### **Allow Soil Bearing**

The maximum allowable soil bearing pressure for static conditions. Using the spin buttons you can increment in 50 psf steps. Typical values vary from 1,000 psf to 4,000 psf or more.

**Soil Density (heel side)**

Enter the soil density for all earth (or water if applicable) above the heel of the footing. This weight is used to calculate overturning resistance forces and soil pressures using the weight of the soil block over the projecting heel of the footing. When surcharges are applied over the soil, the surcharges are transformed to equivalent uniform lateral loads acting on the wall by the ratio  $\text{force} = (\text{Surcharge} / \text{Density})$

\*Lateral Load. Input this value in lbs. per cubic foot. Usual values are 110 pcf to 120 pcf. More if saturated soil. Water is usually assumed to be 64 pcf.

**Soil Density (toe side)**

Enter the soil density on the toe side, which may be different than the heel side. When surcharges are applied over the soil on the toe side, the surcharge is transformed to equivalent uniform lateral loads acting on the wall by the ratio  $\text{force} = (\text{Surcharge} / \text{Density})$ \*Lateral Load. Input this value in lbs. per cubic foot. Typical values are 110 pcf to 120 pcf.

**Lateral Pressure Method**

Here you can choose between E.F.P. (Equivalent Fluid Pressure), Rankine formula or Coulomb formula. Based on your choice for Lateral Pressure Method, you will be offered the following input fields to fully define the lateral forces acting on the wall and footing.

**When the EFP Method is selected:****Active Soil Pressure - Heel Side**

Enter the equivalent fluid pressure (EFP) for the soil being retained that acts to overturn and slide the wall toward the toe side. This pressure acts on the stem for stem section calculations, and on the total footing+wall+slope height for overturning, sliding, and soil pressure calculations.

Commonly used values, assuming an angle of internal friction of 34°, are 30 pcf for a level backfill; 35 pcf for a 4:1 slope; 38 pcf for a 3:1 slope; 43 pcf for a 2:1 slope; and 55 pcf for a 1.5:1 slope. These values are usually provided by the geotechnical engineer.

When the retained soil is sloped, a vertical component of the lateral earth pressure over the heel can be applied vertically downward in the plane of the back of the footing. You can choose to apply this force for overturning resistance, sliding resistance, and/or for soil pressure calculations, by checking the boxes on the Options tab.

**Active Soil Pressure - Toe Side**

Enter the active pressure to be used on the toe side of the wall. This active pressure is used along with the "Soil Height over Toe" value (entered on the Sliding tab) to calculate a stabilizing soil force on the wall. This front side of the wall is assumed to

be level. The active pressure from soil over the toe counteracts the heel-side active pressure to reduce net overturning and net sliding force.

This action is arguable, therefore the default is set to not use this counteracting force.

### Passive Pressure

This is the resistance of the soil in front of the wall and footing to being pushed against to resist sliding. Its value is in psf per foot of depth (pcf). This value is usually obtained from the geotechnical engineer. Its value usually varies from 100 pcf to about 350 pcf.

### When the Rankine or Coulomb Method is selected:

#### Soil Friction Angle

This value is entered in degrees and is the angle of internal friction of the soil. This value is usually provided by a geotechnical engineer from soils tests, but can also be found in reference books or building codes for various typical soil classifications. This value is used along with Soil Density within the standard Rankine and Coulomb equations to determine "Ka" and "Kp" multipliers of density to give active and passive soil pressure values.

#### Active Soil Pressure

This value will be computed using the Rankine or Coulomb formulas. This represents the lateral earth pressure acting to slide and overturn the wall toward the toe side. The result will be presented in units of psf/ft. This pressure acts on the stem for stem section calculations, and on the total footing+wall+slope height for overturning, sliding, and soil pressure calculations.

When the retained soil is sloped, a vertical component of the lateral earth pressure over the heel can be applied vertically downward in the plane of the back of the footing. You can choose to apply this force for overturning resistance, sliding resistance, and/or for soil pressure calculations, by checking the boxes on the Options tab.

#### Passive Soil Pressure

This value will also be computed using the Rankine or Coulomb formulas. This is the resistance of the soil in front of the wall to being pushed against to resist sliding. Its value is in psf per foot of depth (pcf). Common values usually vary from 100 pcf to about 350 pcf.

Lateral Pressure Method	E.F.P.	Coulomb	Rankine
Soil Friction Angle		30.000	deg
Active Soil Pressure - $K_a * \text{Gamma (Horiz.)}$		55.298	psf/ft
Passive Soil Pressure - $K_p * \text{Gamma (Horiz.)}$		330.000	psf/ft



## APPLIED LOADS

This tab allows you to enter all the loads that will be applied to your retaining wall in addition to lateral earth pressure.

General	Loads	Stem	Footing	Options
Wind Load on exposed stem above soil		0.00 psf		
<b>Vertical Surcharge</b>				
Surcharge over Toe		0.00 psf		
Use TOE Surcharge To Resist Sliding & Overturning		<input type="checkbox"/>		
Surcharge Over Heel		0.00 psf		
Use HEEL Surcharge To Resist Sliding & Overturning		<input type="checkbox"/>		
<b>Vertical Load Applied to Top of Stem</b>				
Axial Dead Load		0.0 plf		
Axial Live Load		0.0 plf		
Axial Load Ecc		0.00 in		
<b>Vertical Adjacent Footing Load</b>				
Adjacent Footing Load		0.00 plf		
Back of Wall to CL of Footing		0.00 ft		
Footing Width perpendicular to wall		0.000 ft		
Ht. of Base above (+) or below (-) soil below retained ht.		0.00 ft		
Load eccentricity from CL adjacent footing		0.00 in		
Footing Type		Line Load		
Poisson's Ratio		0.300		
<b>Lateral Load on Stem</b>				
Load Magnitude (load applied horizontally)		0.00 psf		
...Distance from top of footing to top of load		0.00 ft		
...Distance from top of footing to bottom of load		0.00 ft		

### Wind Load on exposed stem above soil

This wind force will be applied to that part of the stem projecting above the retained height defined by the entry "Wall height above retained soil." It is used to calculate overturning moment and sliding, stem design moment and shear, and soil pressures. Only positive values of wind load should be specified. This will ensure that the wind load acts in the direction of the active soil pressure, increasing the overturning moment, the sliding force, the soil bearing pressure, and shear and moment in the stem.

**Vertical Surcharge (Surcharges will be factored as Earth Load, H for LRFD designs.)****Surcharge over Toe**

This surcharge is treated as additional soil weight – if the surcharge is 240 psf and the density is 120 pcf, then the module uses two feet of additional soil. Similarly, if 50 psf is added for the weight of a slab over the footing, this will be equivalent to 0.41 feet of soil (50 / 120). This surcharge will affect sliding resistance and active toe pressure. Keep this in mind if modeling a point load toe surcharge.

**Use TOE Surcharge to resist sliding & overturning**

Checking this box will include the weight of soil overburden on the toe to resist overturning and add to its weight for frictional resistance.

**Surcharge over Heel**

This surcharge is considered uniformly applied to the top surface of the soil over the heel. It may be entered whether or not the ground surface is sloped, but it is unlikely a surcharge could apply to a sloped backfill. This surcharge is always taken as a vertical force. This surcharge is divided by the soil density and multiplied by the Active Pressure to create a uniform lateral load applied to the wall. You can choose to use this surcharge to resist sliding and overturning by clicking the box on the Options tab. Typical live load surcharges are 100 psf for light traffic and parking, and 250 psf for highway traffic.

**Use HEEL Surcharge to resist sliding & overturning**

Checking this box will include heel surcharge. If the surcharge includes live load, then using it to resist sliding and overturning could be non-conservative. In this situation, it might be advisable to deselect this checkbox.

**Vertical Load Applied to Top of Stem**

These loads are considered uniform load along the length of the wall. They are applied to the top of the topmost stem section and affect the design of masonry stems only. The dead and live loads are used to calculate stem design values and factored soil reaction pressures used for footing design. Only the dead load is used to resist overturning and sliding of the retaining wall.

If a wall is subjected to a high axial load (say more than 3 kips/ft) it could cause a reversal of the bending moment in the heel. Under these conditions, it might be advisable to investigate the design with and without the high axial load, to be sure that an acceptable design is found for all conditions.

Since slenderness ratios ( $h/t$ ) for retaining walls are generally small, usually less than 10, and axial stresses are low, slenderness effects are checked but usually have a small effect.

If a point load is applied to the top of a wall, such as a beam reaction, the point load is typically assumed to distribute itself laterally at a rate that is based on engineering judgment for the materials under consideration. As a result of this distribution, the point load will result in a uniformly distributed load of some relatively low magnitude by

the time it reaches the base of the stem. This module does not have an explicit input field for point loads, so they must be represented as uniformly distributed loads. To properly account for the lateral distribution that is characteristic of an axial point load applied to a wall, the magnitude that is entered to represent the point load should consider this distribution effect. The top of the wall may also need to be checked by appended calculations for the localized effects of the full magnitude of the concentrated load.

### **Axial Load Eccentricity**

This is the eccentricity of the axial load with respect to the centerline of the uppermost stem section. Positive values of eccentricity move the load toward the toe, causing bending moments that are additive to those caused by the lateral soil pressure over the heel. Negative eccentricities are not accepted.

### **Vertical Adjacent Footing Load**

This entry gives you the option of placing a footing (line or square) adjacent and parallel to the back face of the wall, and have its effect on the wall included in both the vertical and horizontal forces on the wall and footing. Refer to the General Reference Diagram for locations where input measurements should be taken.

For "Line (Strip) Load" the entry is the total load per ft. parallel to the wall (not psf). If the adjacent footing is specified as "Square Footing" (not line load), the load entered should be the adjacent footing load divided by its dimension parallel to the wall, giving a pounds per lineal foot value, as for a continuous (line) footing.

A Boussinesq analysis is used to calculate the vertical and lateral pressures acting on the stem and footing. The module uses equation (11-20a) in Bowles' Foundation Analysis and Design, 5th Edition, McGraw-Hill, pages 630. When the Boussinesq analysis is used, the module may require additional computing time, depending upon the speed of your computer (hundreds of internal calculations are done after each entry). To avoid this delay (which occurs any time any entry is changed) we suggest you use a vertical load of zero until your data entry is nearly finalized. Then enter the actual footing load and modify your final values.

For adjacent truck or highway loading, it may be preferable to use a heel surcharge (uniform) of 250 psf (or more), instead of treating it as an adjacent footing.

It is generally not necessary to use this feature if the adjacent footing load is farther from the stem than the retained height, less the depth of the adjacent footing below the retained height, since at this distance it will not have significant effect on the wall.

### **Wall to Footing Centerline Distance**

This is the horizontal distance from the center of the adjacent footing to the back face of the stem (measured at the top of retaining wall footing). The nearest edge of the footing should be at least a foot away from the wall face – otherwise it is suggested to use an equivalent heel surcharge instead.

Note: If the horizontal distance from the center of the adjacent footing to the back face of the stem is greater than the vertical distance from the top of the retaining wall

footing to the bottom of the adjacent footing, then the effect on the retaining wall will be insignificant.

**Footing Width**

Width of the adjacent footing measured perpendicular to the wall. This is necessary to create a one-foot long by Width wide area over which the load is applied.

**Height of Base Above (+) or Below (-) Retained Height**

Use this entry to locate the bottom of the adjacent footing with respect to the Retained Height. Entering a negative number places the footing below the Retained Height. A positive entry would typically only be used when the soil is sloped and the adjacent footing resides uphill. To insert a negative number, first type the number, then press the "-" (minus) sign.

Note: If the Adjacent Footing is another retaining wall at a higher elevation, the Boussinesq analysis may be used for the vertical load applied to the soil from the wall, however the design must also consider the lateral (sliding) loads from that adjacent wall. This load could be applied as Added Lateral Load, however this is at the discretion of the designer and is not within the scope of the module. Caution is urged for this condition. See discussion in the companion book: Basics of Retaining Wall Design. For questionable soil or site conditions a global stability analysis is advised.

**Eccentricity**

This entry is provided in case the soil pressure under the adjacent footing is not uniform. Enter the eccentricity of the resultant force under the adjacent footing from the centerline of the adjacent footing. Positive eccentricity shifts the load toward the toe, resulting in greater pressure at the side of the adjacent footing closest to the stem of the retaining wall. The module will use the vertical load and eccentricity and create a trapezoidal pressure distribution under the adjacent footing for use with the Boussinesq analysis of vertical and lateral pressures.

**Footing Type**

This drop-down list box allows you to enter either an isolated footing using the "Square Footing" selection, or a continuous footing using the "Line Load" selection.

**Poisson's Ratio**

Since the resulting pressures are sensitive to Poisson's Ratio, there is an entry allowing you to select a ratio from 0.30 to 0.55. This value should be provided by the geotechnical engineer. A value of 0.50 is often assumed.

**Lateral Load on Stem**

This input allows you to specify an additional uniformly distributed lateral load applied to the stem.

This is for an impact point load, such as due to an impact of a car or similar force. Enter the load as a one-foot high increment, separating the "Height to Bottom" and "Height to Top" by one-half foot (or meter).

Note: **This load is not factored.** To apply a load factor (such as for an impact load), increase the applied load proportionately (e.g. an impact load of 1000 lbs requiring a load factor of 2.0 would be entered as 2,000 lbs). You may need to do several designs to check load factor combinations.

Keep in mind that when considering a concentrated lateral load, it may be possible to reduce the magnitude to account for the fact that the load distributes horizontally at levels below the point of application.

### **Height to Top**

This dimension defines the upper extent of the added lateral load measured from the top of the footing. Do not enter a dimension that exceeds "retained height" plus "Wall height above retained soil".

### **Height to Bottom**

This dimension defines the lower extent (or bottom) of the added lateral load measured from the top of the footing.

## **STEM DESIGN TAB**

General Loads **Stem** Footing Options

Stem Section

2nd Base of Section @ 3.50 ft above footing

Bottom Base of Section @ 0.00 ft above footing

For the "Stem Section" selected above, Material is :

Masonry **Concrete** Fence

Concrete Stem Values

Thickness 8.000 in

fc 3,000.0 psi

Fy 60,000 psi

Wall Weight 100.00 psf

Stem Concrete Weight 150.00 pcf

Rebar Size # 7

Rebar Spacing 12.00 in

Rebar Position Edge

Rebar Depth 'd' 5.563 in

Specify

Reduce lap splice by stress ratio

Reduce hook embed by stress ratio

Stem Section Stress Ratio =  $f_a / F_a + f_b / F_b = 0.268$  OK

Moment

Mu 3,602.93 ft-lb

Mn \* Phi 13,425.75 ft-lb

Rebar Lap & Embedment Lengths...

Lap Splice if Above 37.57 in

Lap Splice if Below 37.57 in

Please verify that lap lengths are available in stem sections

Shear

Total Force 1,441.17 lbs

Vu 21.59 psi

Vn \* Phi 82.16 psi

### Material

Use the buttons to select Masonry, Concrete, or Fence. Fence is only allowed on top of the wall, higher than the Retained Height, and is considered weightless.

### Thickness

Use the drop-down list box to input the wall thickness. If masonry is chosen, you will be given standard masonry thickness (e.g. 6", 8", 12"). If concrete is chosen, you can increment in one-inch steps. If Fence is chosen, this entry is unavailable since the fence is assumed to be weightless.

### Wall Weight

This displayed value is based upon the wall data entered earlier. For concrete stems, the unit weight of concrete can be specified on the Stem tab. For masonry stems, 140 pcf grout is assumed, and the unit weight of the completed stem is a function of the specified thickness, CMU Type, and the status of the Solid Grouting checkbox, all of which are located on the Stem tab. A multiplier is also available on the Options tab to modify the tabular weights for masonry walls.

The industry standard masonry unit weight values used by this module may be modified by clicking **Databases > Concrete Masonry Unit Data** from the main menu and then clicking the **[Change]** button.

### Design Method

When a masonry stem section is chosen, this allows a choice of ASD or LRFD methods. When the latter is selected the input notations change (e.g. fs to fy) and all calculations are based upon LRFD.

### Rebar Size

Make your selection from the pull-down menu for bar sizes #3 to #10. "Soft Metric" sizes will be displayed in parentheses alongside.

### Rebar Position

Chose between Center or Edge. If Center is chosen, the rebar d distance will be 1/2 the actual wall thickness. If Edge is chosen it will be located at the heel side of the stem.

For masonry design, the module contains a table of the appropriate "d" values to use for various block sizes and center/edge locations, as shown in the table below.

### Rebar Position Depth for Masonry, Default Values.

Nominal Thickness	Rebar Depth (in)	
	Center	Edge
6"	2.75"	2.75"
8"	3.75"	5.25"
10"	4.75"	7.25"
12"	5.75"	9.0"
14"	6.75"	11.0"
16"	7.75"	13.0"

For concrete, the edge rebar depth is always stem thickness less 1.5" for #5 and smaller bars (or 2" for #6 or larger), less one-half the bar diameter.

**Specify Position Box**

Click this box to change the default "d" value.

**F<sub>s</sub>**

Enter the allowable steel stress, based on working stress design, which should be used for design of the masonry stem section. The spin button changes this value in increments, and is not visible when a concrete wall has been specified.

**Short Term Increase**

This factor is applied to masonry ASD design and allowable soil bearing as permitted by IBC 2009, section 1806.1, and ACI 530-08, section 2.1.2.3. This is applicable only when wind and/or seismic is applied.

**Solid Grout**

This applies to masonry only. If this box is checked, the weight of the wall will be based upon industry standard solid-grout weight for either lightweight, medium weight, or normal weight block regardless of the specified spacing of reinforcing. If this box is not checked, the module will calculate the weight based on the assumption that only cells containing reinforcing are grouted.

This also affects equivalent solid thickness for stem shear calculations, and area for axial stress calculations (combined with moment for masonry stems).

**Modular "n", Ratio**

This is the multiplier used to calculate the modulus of elasticity of masonry. The ACI 530-05 and ACI 530-08 both specify  $E_m = 900 \cdot f'_m$  which is the default value. The multiplier can be modified on the Options tab.

**Equivalent Solid Thickness**

If partially grouted (not solid grout), this value is generated from an internal database that is accessible by clicking **Database > Concrete Masonry Unit Data**.

**Stem Design Heights**

**IMPORTANT!** The term "Stem Design Height" used in this module is the height above the top of the footing (i.e. above the base of the stem). It is the height above the bottom of the stem where you want the module to compute moments and shears.

You can divide the stem into up to five sections (increments of height). Each section represents either a different material (concrete, masonry, or fence), a change in thickness, or a change in reinforcing size or spacing.

For most walls, only two or three changes in stem sections are used. For example, it would be logical to create a change of section at the top of the dowels projecting into the stem from the footing and perhaps another change in section further up the wall where a more economical design is desired.

**Bottom**

You must start the stem design here, at the base (height above footing = 0.00), where the stem moment and shear are maximum. As you manipulate the bar sizes, spacing, and position (you first, of course, will have selected a wall material and trial thickness)



---

until the Summary box shows you an acceptable stress ratio (the higher and closer to 1.0, the more efficient).

To check the wall at a higher Design Height, such as at least the LAP REQ'D IF ABOVE distance, where reinforcing or thickness can be reduced, click the **[Insert Stem]** button and enter the next higher section. Advance the spin button to the desired height above the top of the footing or enter it by typing. This will move (and dim) the Bottom Section and you can now design this new section.

Continue this way, clicking **[Insert Stem]** button after each stem section design is completed, up to a maximum of five heights. A new Design Height should only be entered when you want to change the material, thickness, or reinforcing, and should never be less than about two foot intervals.

General	Loads	Stem	Footing	Options
<b>Stem Section</b>				
2nd	Base of Section @	3.50	ft	above footing
Bottom	Base of Section @	0.00	ft	above footing
For the "Stem Section" selected above, Material is :				
Masonry	Concrete			
<b>Concrete Stem Values</b>				
Thickness	12.000	in	Rebar Size	# 7
f <sub>c</sub>	3,000.0	psi	Rebar Spacing	12.00
F <sub>y</sub>	60,000	psi	Rebar Position	Edge
Wall Weight	150.00	psf	Rebar Depth 'd'	9.563 in
Stem Concrete Weight	150.00	pcf	<input type="checkbox"/> Specify	
			Reduce lap splice by stress ratio	<input type="checkbox"/>
			Reduce hook embed by stress ratio	<input type="checkbox"/>
Stem Section Stress Ratio = $f_a / F_a + f_b / F_b =$ <b>0.469</b> OK				
<b>Moment</b>		<b>Shear</b>		
M <sub>u</sub>	11,358.58	ft-lb	Total Force	3,074.50 lbs
M <sub>n</sub> * Phi	24,225.75	ft-lb	V <sub>u</sub>	26.79 psi
<b>Rebar Lap &amp; Embedment Lengths...</b>		V <sub>n</sub> * Phi		
Lap Splice if Above	37.57	in	82.16 psi	
Hook Embed into Footing	12.42	in		
Please verify that lap lengths are available in stem sections				

## FOOTING TAB

General		Loads		Stem		Footing		Options	
<b>Footing Size</b>									
Toe Width	2.000	ft	$f_c$	3,500	psi				
Heel Width	5.500	ft	$F_y$	60,000	psi				
Total Width	7.50		ft	Footing Density	150.0	pcf			
Thickness	20.00	in	Min As Ratio	0.0018					
<input type="checkbox"/> Center Stem on Footing									
<b>Shear Key Size</b>									
Key Depth	0.00	in	<input type="checkbox"/> Align front of key w/ front of stem						
Key Width	12.00	in							
Key Location	2.00	ft	from front of toe						
<b>Sliding Resistance</b>									
Sliding Resistance Method	Friction+Passive								
Soil over toe to neglect	12.00	in	Ftg/Soil Friction Ratio	0.500					
% FRICTION Usable for Sliding Resistance				100.0	%				
% PASSIVE Usable for Sliding Resistance				100.0	%				
Lateral Force at Base of Footing				2,569.2	lbs				
less Passive Pressure Force				-	1,008.3	lbs			
less Friction Force				-	4,435.0	lbs			
Added Resisting Force Required				0.0		lbs			
Add'l Force Req'd for 1.5 F.O.S.				0.0		lbs			
<b>Reinforcing</b>									
Rebar Cover.....	In Heel	2.00	in	In Toe	3.00	in			
Toe Reinf. options...	Not req'd, $M_u < S * Fr$				Use : #	7			
					@	16.00	in	max	
Heel Reinf. options...	#4@ 6.50 in, #5@ 10.00 in, #6@ 14.00 in, #7@				Use : #	6			
					@	16.00	in	max	
Key Reinf...	Not req'd, $M_u < S * Fr$				Use : #	Non			
					@	0.00	in	max	
Rebar @ Stem Base : #7 @ 12.00in									

### Toe Width

This is the width of the Toe of the footing, and is measured from the front edge of the footing to the front face of the stem. Can be set to 0.00 for a property line condition. All overturning and resisting moments are taken about the bottom-front edge of the toe.

### Heel Width

Distance from front face of stem to back of heel projection. If a dimension is entered that is less than the stem width at the base, the module will automatically reset the heel dimension to at least the stem width. For a property line at the rear face of the stem, this dimension would be the stem width.

**Total Width**

The calculated width of the footing, Toe Width + Heel Width.

**Thickness**

Total footing thickness, NOT including the key depth (if used). For bending and shear design of the footing, the rebar depth "d" is taken as Footing Depth - Rebar Cover - 1/2" (to account for the rebar radius). If footing thickness is inadequate for shear capacity a red warning indicator will appear.

The footing thickness must be sufficient to allow for rebar development (for hooked dowels) plus rebar cover (adjacent to the soil). If you enter a dimension less than required for stem bar development, a red message will appear at the top of the screen. If the thickness is inadequate, increase the footing thickness, or change the stem dowels, until this message disappears.

**f'c**

Enter concrete compressive stress for footing.

**Fy**

Allowable rebar yield stress to be used for design of footing bending reinforcement.

**Footing Density**

This option is necessary since, if there is any buoyancy effect, it will reduce the effective weight of the footing concrete.

**Min "As" Ratio**

Enter the absolute minimum steel percentage to be used to calculate rebar spacing requirements (commonly 0.0018 Ag for Fy=60,000 psi, but code applicability for footings is arguable). If the % steel required by stress analysis is less than 200/Fy, the minimum of (200/Fy or 1.333 \* bending percentage required) is calculated and compared with the Minimum As% entered here, and the greater of the two is used to calculate rebar spacing requirements.

**Key Depth**

Depth of the key below the bottom of footing. The bottom of the key is used as the lower horizontal plane for determining the size of the passive pressure block from the soil in front of the footing. Adjust this depth so the sliding safety factor is acceptable (typically a value of 1.5 is used).

**Key Width**

Width of the key, measured along the same direction as the footing width. This is usually 12"-14", but generally not less than one-half the key depth so flexural stress in the key is usually minimal.

**Key Location**

Enter the distance from the front edge of the toe to the beginning of the key. Do not enter a distance greater than the footing width minus key width.

**Sliding Resistance Method**

Enter whether sliding resistance will be by friction and passive pressure or by cohesion and passive pressure.

**Soil over toe to neglect**

Since the soil over the toe of the footing may be loose and uncompacted, it may have little or no passive resistance. This entry gives you the option of neglecting any or all of the Height of Soil Over Toe that you entered in the Criteria tab. You can neglect the soil over toe plus the footing thickness, if desired.

**Ftg/Soil Friction Ratio**

Enter the friction factor here. It is generally provided by the geotechnical engineer and usually varies from 0.25 to 0.45.

**% FRICTION Usable for Sliding Resistance**

This may be a stated restriction in the geotechnical report. Enter a value from zero to 100%.

**% PASSIVE Usable for Sliding Resistance**

This may be a stated restriction in the geotechnical report. Enter a value from zero to 100%

**Lateral Forces at Base of Footing**

This is the total lateral force against the stem and footing which causes the wall to slide and which must be resisted. It is the total active pressure on the heel side less the active pressure on the toe side.

**less Passive Pressure Force**

This uses the allowable passive pressure in pcf times the available depth (footing thickness plus soil above toe minus height to neglect) and multiplied by the percent usable that you indicated, to compute the total passive resistance. Weight due to toe surcharge, if applicable, will also be added. If a key is used, the available passive pressure depth will be to the bottom of the key.

**less Friction Force**

This is the total vertical reaction multiplied by the friction factor and multiplied by the percent usable that you indicated.

**Added resisting force required**

If this is 0.0 lbs., the forces balance, but there may be no safety factor. Watch the Sliding Factor of Safety for an adequate value (usually 1.5). Consider adding a key or revising the footing dimensions if required.

**Additional force required for a 1.5 Factor of Safety**

This is the additional resisting force that would be required in order to achieve a 1.5 safety factor. If this value indicates zero, then the sliding factor of safety is already greater than or equal to 1.5.

### Rebar Cover in Heel & Toe

These input fields allow you to specify the clear cover that will be used at the heel and at the toe. When specifying these values, keep in mind that the toe rebar is placed closest to the bottom of the footing, and the heel rebar is placed closest to the top of the footing. When calculating the "d" dimension for bending and shear strength calculations, this module will consider the footing thickness and then deduct the specified clear cover and an additional 1/2" to account for the radius of the rebar.

### Toe Reinforcing Options

This list gives you choices for reinforcing sizes and spacing for the bottom toe bars. Typically the toe bars are extensions of the stem dowels, which are bent out toward the toe. Therefore, it may be most efficient to simply verify that the bar size and spacing used for the stem dowels is within the range of the selections offered for toe reinforcing options.

NOTE: If "No reinf' req'd" message appears, it means the flexural capacity of the footing (modulus of rupture times the section modulus, with 2" deducted from the thickness for crack allowance per code) is adequate to resist the applied moment. However, the designer in some cases may consider it prudent to add reinforcing regardless of the theoretical flexural capacity. For plain concrete per ACI 22.5.1,  $F_r = \phi(5)(f'_c)^{1/2}$ , where  $\phi = 0.55$ .

### Heel Reinforcing Options

This list gives you choices for acceptable sizes and spacing of top heel bars. It is desirable to select a spacing that is modular with the stem dowel bars for ease of construction. Note: The module does not calculate the heel bar development length inward from the back face of the stem (where the moment is maximum).

NOTE: If "No reinf' req'd" message appears, it means the flexural capacity of the footing (modulus of rupture times the section modulus, with 2" deducted from the thickness for crack allowance per code) is adequate to resist the applied moment. However, the designer in some cases may consider it prudent to add reinforcing regardless of the theoretical flexural capacity.

ALSO NOTE: The heel design moment may be influenced by the setting used for the item labeled "Neglect Upward Pressure at Heel for Ftg M & V" on the Options tab. See the section on the Options tab for additional information.

### Key Reinforcing Options

If flexural tension is insufficient to resist bending in key, a message will appear indicating reinforcing required. You can vary the width of the key until the message disappears. If reinforcing is required options will be shown on the Footing tab.

## OPTIONS TAB

The screenshot shows the 'Options' tab of a software interface. It is divided into three sections:

- Miscellaneous Settings:**
  - Toe Active Pressure Used for:  (dropdown menu)
  - Slab is present to resist all sliding forces:
  - Neglect Upward Pressure at Heel for Ftg M & V:
  - Use 2010 CBC Section 1807.2.1:
  - Use vertical component of active lateral soil pressure for:
    - Soil Bearing Pressure:
    - Sliding Resistance:
    - Overturning Resistance:
- Miscellaneous Masonry Values:**
  - Factor applied to masonry  $f_m$  to calc of  $E_m$ :
  - Multiplier applied to CMU weight from tables:
- Load Factors:**
  - Dead Load:  (spinner)
  - Live Load:  (spinner)
  - Earth, H:  (spinner)
  - Wind, W:  (spinner)
  - Seismic, E:  (spinner)

### Toe Active Pressure Used

This drop-down list box provides the option to specify whether the module should or should not apply the toe side horizontal active pressure to reduce the overturning moment and sliding force to be resisted. Typically this is NEVER used. It was added to assist in cases where the footing was buried very deeply in soil.

### Slab is Present to Resist all Sliding Forces

Check this box when a slab is in front of the wall to resist lateral sliding. When this box is checked, sliding is not a design issue – passive and friction resistance are ignored -- but the lateral sliding force is displayed for checking the resistance offered by the slab.

The slab is assumed to be at the top of the footing – not higher, so selecting this checkbox will not reduce the design shear or moment in the stem.

### Neglect Upward Pressure at Heel for Ftg M & V

When the user DESELECTS the option to “Neglect Upward Pressure at Heel for Footing Moment and Shear”:

- The program is considering the upward pressure at heel.

- The upward pressure tends to reduce the moment caused by the weight of the soil and the self-weight of the heel itself.
- The program is reporting the actual net moment found to exist in the heel.

When the user SELECTS the option to “Neglect Upward Pressure at Heel for Footing Moment and Shear”:

- The program is NOT considering the upward pressure at heel.
- The program determines the heel moment caused by the weight of the soil and the self-weight of the heel itself.
- The program then applies the following logic:
  - The calculated heel moment is conservative when the upward pressure at heel is neglected.
  - The calculated heel moment would act in the same direction as the toe moment.
  - The sum of the heel moment and the toe moment can't be any greater than the stem design moment, which is delivering the moment to that joint in the first place.
  - So the program conservatively assumes that the heel design moment is the calculated heel moment but not to exceed the stem design moment.

### Use 2010 CBC Section 1807.2.1

Section 1807.2.1 of 2010 CBC and IBC 2009 requires the designer to consider in the sliding analysis the effects of the active pressure extending all the way to the bottom of a keyway when one is used. Selecting this option will ensure that the analysis properly considers the full extent of the active pressure on a keyway.

### Choices for Use of Vertical Component of Active Pressure

The vertical component of the lateral pressure is applied at a vertical plane at the back of the heel. You can choose whether or not to use this force to resist overturning, to resist sliding, and to reduce soil bearing pressure.

If you choose the option to use this force to resist overturning, then for a level backfill, the module will back-solve the EFP method to find the equivalent internal friction angle, and then apply this vertical component equal to  $\tan\beta$ . If either the Rankine or Coulomb

method had been chosen, this vertical component would be tangent of  .

If you choose the option to use this force to resist sliding, then the sliding calculation will incorporate the additional frictional force that can be generated as a result of the additional vertical force.

If you choose the option named "Soil Bearing Pressure", then the the effect of this vertical component at the back of the heel will be considered in the calculation of the soil bearing pressures.



**Factor Applied to Masonry  $f'_m$  for Calculation of  $E_m$** 

The modulus of elasticity for masonry is 900 times  $f'_m$  per ACI 530-05. This field allows you to enter a multiplier of other than 900 if necessary.

**Multiplier Applied to CMU Weight from Tables**

This entry allows you to increase or decrease the internal default values of CMU weights, as displayed on the Stem tab.

**Load Factors**

For each type of load (DL, LL, etc) the default factor will be displayed. You can change them and set new defaults, but remember to review them for a new design since they may have been changed.

**RESULTS TAB**

The screenshot displays a software interface with a menu bar at the top containing 'Results', 'Sketch', and 'Loading'. Below the menu bar is a toolbar with icons for 'Summary', 'RSM', 'OTM', 'Sliding', and 'Stem'. The main content area is divided into three sections: 'Stability Ratios', 'Soil Loading Results', and 'Footing Results'. The 'Stability Ratios' section shows OTM Ratio as 3.638:1.00 and Sliding Ratio as 2.119:1.00. The 'Soil Loading Results' section includes a table for service loads with columns for 'Actual' and 'Allowable', showing soil pressures at toe and heel, total bearing load, and resultant eccentricity. The 'Footing Results' section lists ACI factored pressures, design moments, and one-way footing shears.

Stability Ratios	
OTM Ratio	3.638 : 1.00
Sliding Ratio	2.119 : 1.00

Soil Loading Results		(Service loads)	
	Actual	Allowable	
Soil Pressure @ Toe	1,678.8 psf	3,000.0 psf	
Soil Pressure @ Heel	686.6 psf		
Total Bearing Load	8,870.0 lbs		
...resultant ecc	6.29 in		
Eccentricity within middle third			

Footing Results	
ACI Factored Pressure @ Toe	1,952.1 psf
ACI Factored Pressure @ Heel	798.3 psf
Mu:Design @ Toe	2,835.0 ft-lb
Mu:Design @ Heel	11,358.6 ft-lb
Stem Base Moment Governs HEEL Moment	
One-Way Footing Shears...	
Shear @ Toe (vu)	4.508 psi
Shear @ Heel (vu)	37.543 psi
Allow. Footing Shear (phi*vn)	88.741 psi

Design Notes . . . *(visible when needed)*

### Stability Ratios

These are displayed for both overturning and sliding.

### Soil Pressure @ Toe and Heel

This is the resulting unfactored soil pressure for both the toe and heel. If the eccentricity is outside the middle third, the heel pressure will show 0.00. (Note: when the resultant is outside the middle-third, the module calculates the toe pressure assuming no tension at heel).

### Allowable Soil Pressure

This is for your reference as input on the Criteria tab.

**Total Bearing Load**

This is the sum of all vertical forces.

**Resultant Eccentricity**

Distance from center of footing to resultant soil pressure.

**Eccentricity Within/Outside Middle Third**

The resultant is outside the middle third of the footing width if the eccentricity is greater than one-sixth the footing width. (If outside the middle third, the module computes the toe soil pressure assuming no tension at heel.)

**ACI Factored Soil Pressure @ Toe and Heel**

Load factors are applied to all dead and live loads to determine total vertical load for soil pressure used in calculating footing moments and shears. This load is then applied at the same eccentricity calculated for service load soil pressures to yield the actual factored soil pressures for footing design using ultimate strength design principles. Note that since only factored vertical loads are applied at the non-factored resultant eccentricity, a true 1.6 load factor applied to lateral earth pressure is not used for footing design. If resultant vertical load eccentricity were to be calculated using factored loads, the distance would not truly represent a correct state of stress in the soil. ACI load factors are intended to give conservative results for stress. Calculation of a factored load eccentricity would give soil pressure diagrams that would not always represent the actual soil pressure distribution under the footing, and yield unreasonable results. Factored lateral earth pressure, however, is always used for concrete stem design.

**Mu Design @ Toe/Heel**

These are the factored (by 1.2) moments at face of stem for toe and heel moments. Since neither can be greater than the stem base moment (factored if concrete stem), the latter may govern. These moments will be reduced if you choose to neglect the upward soil pressure on the Options tab.

A message will indicate which controls.

**Shear @ Toe and Heel**

The actual shear is calculated from the one-way action in the footing at a distance "d" (footing thickness - rebar cover) from the toe side of the bottom stem section, and at the face of the stem on the heel side. If "d" is greater than the projecting toe or heel length, then the one-way shear is zero.

**Allowable Footing Shear**

The allowable unit shear equals  $(0.75 * 2 * f'c^{1/2})$ .

**RSM - RESISTING MOMENTS TAB**

Results Sketch Loading Print Sketch & Loading separately.

Summary RSM OTM Sliding Stem

Resisting Moments	Force	Distance	Moment
Soil Over Heel	5,445.0 lbs	5.25 ft	28,586.3 ft-lb
Sloped Soil Over Heel	0.0		
Surcharge Over Heel	0.0		
Adjacent Footing Load	0.0		
Axial Dead Load on Stem	0.0		
Axial Live Load on Stem **	0.0		
Soil Over Toe	0.0	1.00	
Surcharge Over Toe	0.0		
Stem Weight(s)	1,275.0	2.40	3,062.5
Earth @ Stem Transitions	275.0	2.83	779.2
Footing Weight	1,875.0	3.75	7,031.3
Key Weight	0.0	2.50	
Vert. Component *	0.0	7.50	
<b>Total Vertical Loads</b>	<b>8,870.0 lbs</b>		
		<b>Resisting Moment</b>	<b>39,459.2 ft-lb</b>

\*\* Axial live load NOT included in total displayed, or used for overturning resistance, but is included for soil pressure calculations.

**Safety Ratio : Resisting/Overturning = 3.638 : 1.00**

\* EFP method used. To calculate vertical component, angle of internal friction is back-solved using EFP and Rankine equation. = 24.80 deg

These values are used for soil pressure calculations

Force = 8,870.0 lbs      Moment = 39,459.2 ft-lb

Design Notes . . . *(visible when needed)*

This screen presents in tabular form each component contributing to resisting moment, giving weights and lever arms from the front edge of the toe to the centroid of the weight.

For calculating the vertical component, if checked on the OPTIONS screen, and if the EFP method was chosen, the module will back-solve using the Rankine formula to obtain an equivalent internal friction angle.

The force and moment displayed at the bottom accounts for deduction of effect of vertical component, if box on Options tab has been checked.

### OTM - OVERTURNING MOMENTS TAB

The screenshot displays the 'OTM - OVERTURNING MOMENTS TAB' interface. At the top, there are tabs for 'Results', 'Sketch', and 'Loading', along with a 'Print Sketch & Loading separately.' option. Below these are sub-tabs for 'Summary', 'RSM', 'OTM', 'Sliding', and 'Stem'. The 'OTM' sub-tab is active, showing a table titled 'Overturning Moments'.

	Force	Distance	Moment
Heel Active Pressure	2,569.2 lbs	4.22 ft	10,847.7 ft-lb
Surcharge over Heel	0.0		
Toe Active Pressure	0.0		
Adjacent Footing	0.0		
Surcharge Over Toe	0.0		
Load @ Stem Above Soil	0.0		
Added Lateral Load	0.0		
<b>Totals =</b>	<b>2,569.2 lbs</b>	<b>Overturning Moment</b>	<b>10,847.7 ft-lb</b>

Below the table, a box displays the **Safety Ratio : Resisting/Overturning = 3.638 : 1.00**. At the bottom, there is a section for **Design Notes . . .** with the note *(visible when needed)*.

This screen presents in tabular form each component acting horizontally to overturn the wall/footing system. The centroid of each force is multiplied by its distance up from the bottom of the footing. The Heel Active Pressure includes the effect of surcharges and water table, if applicable, and its Distance is to the centroid of the total lateral force.

The total overturning moment is displayed, along with the Resisting/Overturning ratio. The overturning moment is reduced by the toe side active pressure, if this option is selected on the Options tab.

## SLIDING TAB

The screenshot shows the 'Sliding' tab selected in a software interface. The top navigation bar includes 'Results', 'Sketch', and 'Loading'. Below it, a secondary bar shows 'Summary', 'RSM', 'OTM', 'Sliding', and 'Stem'. The main content area is titled 'Sliding Results' and contains a table of force calculations. A summary box at the bottom shows a safety ratio of 2.119 : 1.00. A 'Design Notes' section is visible at the bottom right, with the text '(visible when needed)'.

Sliding Results	
Lateral Force at Base of Footing	2,569.2 lbs
less Passive Pressure Force	- 1,008.3 lbs
less Friction Force	- 4,435.0 lbs
Added Resisting Force Required	0.0 lbs
Add'l Force Req'd for 1.5 F.O.S.	0.0 lbs

Safety Ratio : Sliding = 2.119 : 1.00

Design Notes . . . *(visible when needed)*

## STEM TAB


The screenshot displays the 'STEM TAB' software interface. At the top, there is a menu bar with options: 'Results' (with a checkmark icon), 'Sketch' (with a landscape icon), and 'Loading' (with a double-headed arrow icon). To the right of the menu bar, the text 'Print Sketch & Loading separately.' is visible, along with a pencil icon. Below the menu bar is a secondary toolbar with icons for 'Summary' (list icon), 'RSM' (curved arrow icon), 'OTM' (curved arrow icon), 'Sliding' (upward arrow icon), and 'Stem' (vertical bar icon). The main content area is titled 'Summary of Stem Construction' and contains two paragraphs of text:

Top Stem goes from 3.5ft to top of wall, using 8 in thick Concrete w/ # 7 at 12 in o/c at d=5.25 in

Bottom Stem goes from 0 to 3.5 ft above top of footing, using 12 in thick Concrete w/ # 7 at 12 in o/c at d=9.5625 in


At the bottom of the interface, there is a section labeled 'Design Notes . . .' with the text '(visible when needed)' to its right. The design notes area is currently empty.

## SKETCH TAB



## LOADING TAB





## 10.7 Foundations

Please select a subtopic.

## 10.7.1 General Footing

[Need more? Ask Us a Question](#)

This module provides analysis of a rectangular footing with applied axial load, overburden, moment and shear loads. Click here for a video: General Footing

The module allows you to move the axial load application position off-center of the footing, and provides automatic calculation of allowable soil bearing pressure increases based on footing dimensions and/or depth below surface.

The module checks service load soil pressure, overturning stability, sliding stability, flexure at each of the four pedestal faces, 1-way shear at 'd' from each of the four pedestal faces, and punching shear along a perimeter located 'd/2' from the pedestal faces.

The screenshot shows the 'General Footing' software interface. The top menu bar includes 'General', 'Soil Allowables', 'Footing Size & Reinforcing', 'Applied Loads', and 'Load Combinations'. The 'Description' field contains 'Sample Footing Design'. The 'Material Properties' section includes input fields for  $f_c$  (3.0 ksi),  $f_y$  (60.0 ksi),  $E_c$  (3,122.0 ksi),  $\Psi$  (145.0 pcf), and  $\phi$  values for Flexure (0.90) and Shear (0.750). The 'Analysis/Design Settings...' section has checkboxes for 'Biaxial Analysis' (Yes), 'Soil bearing pressure', 'Sliding, overturning, & uplift', and 'Ignore Checks for Sliding'. It also includes input fields for 'Min Steel Ratio' (0.00180), 'MIN. Overturning Safety Factor' (1.0), and 'MIN. Sliding Safety Factor' (1.0). The bottom section shows a 'Results' table with columns for 'Min. Ratio', 'Item', 'Applied', 'Capacity', and 'Governing Load Combination'. A 'Design OK' button is visible in the bottom right.

Min. Ratio	Item	Applied	Capacity	Governing Load Combination
0.5405	Soil Bearing	2.162 ksf	4.0 ksf	0.0 deg CCW
n/a	Overturning - X-X	0.0 k-ft	0.0 k-ft	No Overturning
7.301	Overturning - Z-Z	54.0 k-ft	394.240 k-ft	D
49.568	Sliding - X-X	1.0 k	49.568 k	D
n/a	Sliding - Z-Z	0.0 k	0.0 k	No Sliding
n/a	Uplift	0.0 k	0.0 k	No Uplift
0.2796	Z Flexure (+X)	13.531 k-ft	48.397 k-ft	+1.40D
0.1479	Z Flexure (-X)	7.156 k-ft	48.397 k-ft	+1.40D
0.2781	X Flexure (+Z)	13.461 k-ft	48.397 k-ft	+1.40D
0.1479	X Flexure (-Z)	7.156 k-ft	48.397 k-ft	+1.40D
0.1798	1-way Shear (+X)	14.776 psi	82.158 psi	+1.40D
0.08674	1-way Shear (-X)	7.126 psi	82.158 psi	+1.40D
0.2457	1-way Shear (+Z)	20.189 psi	82.158 psi	+1.40D
0.1735	1-way Shear (-Z)	14.251 psi	82.158 psi	+1.40D
0.1738	2-way Punching	28.554 psi	164.317 psi	+1.40D

### General

**$f'_c$**   
28-day compressive strength of the concrete.

**$f_y$**   
Yield point stress of reinforcing.

**$E_c$**

Modulus of elasticity of concrete.

### **Concrete Density**

The density of the concrete is used to calculate the self-weight of the pedestal and footing when that option is selected.

### **Phi Values**

Enter the capacity reduction values to be applied to  $V_n$  and  $M_n$ .

### **Biaxial Analysis**

Select Yes or No to indicate if a biaxial analysis is to be performed. If a biaxial analysis is performed, the solution will consider moments applied simultaneously about the two orthogonal axes of the footing. If a biaxial analysis is NOT performed, the solution will consider moments applied about the two orthogonal axes to be acting non-concurrently.

### **Amount of Edge Length for M & V (Only displayed when biaxial analysis is selected)**

When calculating shear and moment for footings where the maximum soil pressure values occur at the corners, this value specifies the fraction (as a decimal) of the footing dimension from the edge to use when calculating moments and shears due to variable soil pressure in that region. A smaller value for this variable will produce a more conservative design, because it will focus on a narrower strip which is experiencing the highest soil bearing pressure.

### **Click to Calculate (Button is only visible when biaxial analysis is selected)**

Due to the iterative nature of the calculations that are required for a biaxial analysis, it would be undesirable to rerun the entire analysis and design every time an input parameter changes. So for reasons of efficiency, the program automatically goes into manual recalculation mode when biaxial analysis is selected. Click this button any time you wish to recalculate with the current input parameters.

### **Consider footing weight when determining soil bearing pressure**

Select this option to have the module calculate the self-weight of the footing and apply it as a downward load when determining soil bearing pressures. The self-weight will be multiplied by the dead load factor in each of the Soil Bearing Pressure load combinations.

***Note: This option should generally be selected. Deselecting this option can lead to incorrect soil bearing pressure calculations in footings with moment. If the goal is to try to compare soil bearing pressures to net allowable pressures, then it would be advisable to use the option on the Soil Allowables tab to "Increase Bearing by Footing Weight".***

### **Consider footing weight when determining sliding, overturning and uplift**

Select this option to have the module calculate the self-weight of the footing and apply it as a downward load when determining sliding, overturning and uplift factors of safety. The self-weight will be multiplied by the dead load factor in each of the Stability load combinations.

### Ignore Checks for Sliding

Select this option if sliding is not a design consideration for any particular reason.

### Min Steel Ratio - Temperature/Shrinkage

Enter the minimum ratio for temperature/shrinkage steel, calculated using the full footing thickness. This will trigger a warning message if the section is under-reinforced.

Note: This check is performed assuming that only one mat of the defined rebar will be provided. If the design has net uplift, such that a top mat is warranted, or if a top mat will be provided anyway, then be aware that the program will still only consider the contribution of one mat toward meeting the Temperature & Shrinkage requirement. In this case, it may be more convenient to set the T&S ratio to a value that represents one-half of the total, knowing that the two mats will be sufficient to provide the full amount required.

### Minimum overturning safety factor

Enter the minimum allowable ratio of resisting moment to overturning moment. If the actual ratio is less than the specified minimum ratio, it will trigger a message that overturning stability is not satisfied.

### Minimum sliding safety factor

Enter the minimum allowable ratio of resisting force to sliding force. If the actual ratio is less than the specified minimum ratio, it will trigger a message that sliding stability is not satisfied.

### Consider ACI 10.5.1 & 10.5.3 as minimum reinforcing

Select this checkbox if you wish to have the module consider ACI 318 Sections 10.5.1 and 10.5.3 in the determination of minimum reinforcing.

The screenshot shows the 'General Footing' software interface. The 'Material Properties' section includes input fields for:
 

- $f_c$  : Concrete 28 day strength: 3.0 ksi
- $f_y$  : Rebar Yield: 60.0 ksi
- $E_c$  : Concrete Elastic Modulus: 3,122.0 ksi
- $\psi$  : Concrete Density: 145.0 pcf
- $\phi$  : Phi Values: Flexure : 0.90, Shear : 0.750

 The 'Analysis/Design Settings...' section includes:
 

- Biaxial Analysis: Yes (selected)
- Percentage of Edge Length for M & V: 0.250
- Consider footing weight when determining:
  - Soil bearing pressure
  - Sliding, overturning, & uplift
- Ignore Checks for Sliding
- Min Steel Ratio : Temp Reinf (based on thick) (ratio = Steel Area / Concrete Area): 0.00180
- MIN. Overturning Safety Factor: 1.0
- MIN. Sliding Safety Factor: 1.0
- Consider ACI 10.5.1 & 10.5.3 as min. reinforcing

## Soil Allowable Values

### Allowable Soil Bearing

Enter the allowable soil bearing pressure that the soil can resist. This is a service load resistance and will be compared to calculated service load soil pressures (loads not factored as in strength design).

#### **Increase bearing by footing weight**

Click [**Yes**] to tell the module to calculate the weight of one square foot (plan view) of footing weight and add it to the allowable soil bearing value. This has the effect of not penalizing the soil for the self weight of the footing, and is useful for situations where the geotechnical engineering report provides allowable net bearing pressures.

#### **Soil passive sliding resistance**

Enter the value of passive soil pressure resistance to sliding. This value will be used to determine a component of sliding resistance that is generated by the passive pressure of the soil. The sliding resistance due to passive pressure is then added to the sliding resistance due to friction to determine the total resistance to sliding for each load combination.

#### **Coefficient of Soil/Concrete Friction**

Enter the coefficient of friction between soil and footing to use in sliding resistance calculations.

#### **Soil Bearing Increase**

This section allows you to specify some dimensions that, when exceeded, will automatically increase the allowable soil bearing pressure.

**Footing base depth below soil surface:** The distance from the bottom of the footing to the top of the soil. This value is used to determine allowable soil bearing pressure increases and soil passive sliding resistance, but it is not used in any other calculations in this module.

**Increases based on footing depth:** Provides a method to automatically apply increases to the basic allowable soil bearing pressure based on footing depth below some reference depth. Collects the following parameters:

**Allowable pressure increase per foot:** Specifies the amount that the basic allowable soil bearing pressure can be increased for each foot of depth below some reference depth.

**When base of footing is below:** Specifies the required depth in order to start realizing incremental increases in the allowable soil bearing pressure on the basis of footing depth.

**Example:** Assume the following: Basic Allowable Soil Bearing Pressure = 3 ksf. Footing base is 6'-0" below soil surface. The Geotechnical report specifies that a 0.15 ksf increase in bearing pressure is allowed for each foot of depth when the base is deeper than 4' below top of soil. Since you've indicated that the footing is 6' below the soil surface, the module will automatically calculate the adjusted allowable soil bearing pressure to be  $3 \text{ ksf} + (6' - 4') * 0.15 \text{ ksf} = 3.30 \text{ ksf}$ .

**Increases based on footing plan dimension:** Provides a method to automatically apply increases to the basic allowable soil bearing pressure based on footing dimensions greater than some reference dimension. Collects the following parameters:

**Allowable pressure increase per foot:** Specifies the amount that the basic allowable soil bearing pressure can be increased for each foot of length or width greater than some reference dimension.

**When maximum length or width is greater than:** Specifies the required dimension in order to start realizing incremental increases in the allowable soil bearing pressure on the basis of footing dimension.

**Example:** Assume the following: Basic Allowable Soil Bearing Pressure = 3 ksf. Footing measures 12'-0" x 6'-0". The Geotechnical report specifies that a 0.15 ksf increase in soil bearing pressure is allowed for each foot when the largest plan dimension of the footing is greater than 4'. The module will automatically calculate the adjusted allowable soil bearing pressure to be  $3 \text{ ksf} + (12' - 4') * 0.15 \text{ ksf} = 4.2 \text{ ksf}$ .

Note: Increases based on footing depth and plan dimensions are cumulative.

The screenshot shows the 'General Footing' software interface with the following parameters:

Section	Parameter	Value	Units
Soil Design Values	Allowable Soil Bearing	4.0	ksf
	Increase Bearing By Footing Weight	No	
	Soil Passive Sliding Resistance	250.0	pcf
	Coefficient of Soil/Concrete Friction	0.30	
Soil Bearing Increase	Footing base depth below soil surface	6.0	ft
	Increases based on footing Depth . . .		
	Allowable pressure increase per foot when base of footing is below	3.0	ft
	Increases based on footing plan dimension . . .		
	Allowable pressure increase per foot when maximum length or width is greater than		ft
	Maximum Allowed Bearing Pressure (zero is no limit)	10.0	ksf
Adjusted Allowable Soil Bearing		4.0	ksf

*(Allowable Soil Bearing adjusted for footing weight and depth & width increases as specified by user.)*

## Footing Dimensions

This tab is where you enter the footing and pedestal dimensions.


**Width, Length & Thickness:** defines the overall dimensions of the footing

**Load Location:** defines the offset from the center of the footing where the axial load is applied. If a biaxial analysis is NOT being used, then only one direction can be used.

**Pedestal dimensions:** If a concrete pedestal bears on the footing, its dimensions can be specified here. The px and pz dimensions are used to define the locations on all four sides where one-way shear, two-way shear and bending moment are calculated. If you enter a nonzero height, then you can choose to have the weight of that prism

calculated and added as dead load. Any applied overburden loads will be omitted from the area defined as the pedestal dimension along the xx and yy axis, regardless of the specified height of the prism.


Note: If no pedestal is defined, then the center of the footing will be treated as the face of the pedestal when determining the critical locations to check shear and flexure.



**Consider Pedestal Weight When Determining:** This option allows the user to specify whether or not the self-weight of the pedestal is to be considered when determining the soil bearing pressure, and separately, whether or not the self-weight of the pedestal is to be considered when performing the checks for sliding, overturning, and uplift.

## Footing Reinforcing

This tab allows you to specify the reinforcing in each direction of the footing.




## Applied VERTICAL Loads

This tab allows you to specify the axial load applied to the pedestal location and an overburden load applied to the entire plan dimension of the footing (except the area designated as the pedestal).




Enter loads with a positive sign for downward direction.

Note! This module will not allow a net uplift on the footing. If the result of the factored axial loads (dead, live, wind, etc) produces a negative load sign, the module will not recalculate and will notify you of which load combination resulted in net uplift.




### Applied BENDING Loads

This tab allows you to enter applied moments.




### Applied SHEAR Loads

This tab allows you to enter applied shear forces. These loads are applied at the location of the pedestal. If the pedestal is specified to have a height, the shear will be applied at that height and will create a moment on the footing equal to Shear Load \* (Footing Thickness + Pedestal Height).



### Load Combinations - Service

This is the typical load combination tab used throughout **Structural Engineering Library**. The Service Combinations tab is used to calculate soil pressures to be compared to the allowable soil bearing pressure. The "Soil Increase" is a factor that can be specified individually for each load combination and is applied to the allowable soil bearing pressure.



### Load Combinations - Factored

This is the typical load combination tab used throughout **Structural Engineering Library** for strength design. These load combinations are used to calculate moments and shears in the footing for use in determining stresses and required reinforcing.

Note: The General Footing module is applying the factored loads to the footing and determining a different eccentricity than was determined using the service loads for the soil bearing pressure check.

**General Footing**

General | Soil Allowables | Footing Size & Reinforcing | Applied Loads | **D+L+? Load Combinations** | \*\*\* Click To Calculate \*\*\*

Service Combinations | **Factored Combinations** | **IBC 2009** | Change Load Combination Set

Load Combinations for BENDING & SHEAR

Run	D	Lr	L	S	W	E	H
+1.40D	1.40						
+1.20D+0.50Lr+1.60L+1.60H	1.20	0.50	1.60				1.60
+1.20D+1.60L+0.50S+1.60H	1.20		1.60	0.50			1.60
+1.20D+1.60Lr+0.50L	1.20	1.60	0.50				
+1.20D+1.60Lr+0.80W	1.20	1.60			0.80		
+1.20D+0.50L+1.60S	1.20		0.50	1.60			
+1.20D+1.60S+0.80W	1.20			1.60	0.80		
+1.20D+0.50Lr+0.50L+1.60W	1.20	0.50	0.50		1.60		
+1.20D+0.50L+0.50S+1.60W	1.20		0.50	0.50	1.60		
+1.20D+0.50L+0.20S+E	1.20		0.50	0.20		1.0	
+0.90D+1.60W+1.60H	0.90				1.60		1.60
+0.90D+E+1.60H	0.90					1.0	1.60

L ≤ 100, f1=0.5  
L > 100, f1=1.0

Use add'l factors per ASCE 12.4.2.3

Auto Reverse Wind  
Auto Reverse Seismic

### Results Tab

This tab provides a summary of all calculated values. The stress ratios, applied & allowable values and load combination for those governing values are reported.

Results | Soil Pressures | Overturning & Sliding Stability | Footing Bending | Footing Shear | **Design OK**

Min. Ratio	Item	Applied	Capacity	Governing Load Combination
0.4674	Soil Bearing	2.220 ksf	4.750 ksf	+D+0.750L+0.750S+0.750W+H
3.676	Overturning - X-X	17.050 k-ft	62.669 k-ft	0.6D+L+S+W/2
3.942	Overturning - Z-Z	18.250 k-ft	71.934 k-ft	0.6D+L+S+W/2
7.219	Sliding - X-X	3.10 k	22.378 k	0.6D+L+S+W/2
8.489	Sliding - Z-Z	3.10 k	26.315 k	0.6D+L+S+W/2
n/a	Uplift	0.0 k	0.0 k	No Uplift
0.07305	Z Flexure (+X)	2.559 k-ft	35.036 k-ft	+1.20D+0.50Lr+0.50L+1.60W
0.06108	Z Flexure (-X)	2.140 k-ft	35.036 k-ft	+1.40D
0.1287	X Flexure (+Z)	3.256 k-ft	25.306 k-ft	+1.20D+0.50L+0.50S+1.60W
0.07954	X Flexure (-Z)	2.013 k-ft	25.306 k-ft	+1.40D
0.02350	1-way Shear (+X)	1.931 psi	82.158 psi	+1.40D
0.1567	1-way Shear (-X)	12.874 psi	82.158 psi	+1.40D
0.09540	1-way Shear (+Z)	7.838 psi	82.158 psi	+1.20D+0.50Lr+0.50L+1.60W
0.05474	1-way Shear (-Z)	4.498 psi	82.158 psi	+1.40D
0.1063	2-way Punching	15.956 psi	150.15 psi	+1.40D

### Soil Pressures Tab

This tab summarizes the calculated service load soil bearing pressure for moments & shears applied about the specified axis, for each load combination.

Results | **Soil Pressures** | Overturning & Sliding Stability | Footing Bending | Footing Shear

Soil Pressure Results (using service loads) .....

Rotation Axis	Bearing Load	Allowable Bearing	Resultant Eccentricity		Soil Pressures				Maximum	ctual / Allowabl Ratio
			Prll to X-X	Prll to Z-Z	Top, +Z	Bottom, -Z	Right, +X	Left, -X		
-X-X										
+D	37.613	4.750	n/a	1.755	1.261	0.8886	n/a	n/a	1.261	0.2655
+D+L+H	38.613	4.750	n/a	3.419	1.475	0.7311	n/a	n/a	1.475	0.3105
+D+Lr+H	38.613	4.750	n/a	3.419	1.475	0.7311	n/a	n/a	1.475	0.3105
+D+S+H	38.613	4.750	n/a	3.419	1.475	0.7311	n/a	n/a	1.475	0.3105
+D+0.750Lr+0	39.113	4.750	n/a	4.219	1.583	0.6524	n/a	n/a	1.583	0.3333
+D+0.750L+0	39.113	4.750	n/a	4.219	1.583	0.6524	n/a	n/a	1.583	0.3333
+D+W+H	38.613	4.750	n/a	3.419	1.475	0.7311	n/a	n/a	1.475	0.3105
+D+0.750Lr+0	39.863	4.750	n/a	5.381	1.744	0.5342	n/a	n/a	1.744	0.3672
+D+0.750L+0	39.863	4.750	n/a	5.381	1.744	0.5342	n/a	n/a	1.744	0.3672
+D+0.750Lr+0	39.113	4.750	n/a	4.219	1.583	0.6524	n/a	n/a	1.583	0.3333
+D+0.750L+0	39.113	4.750	n/a	4.219	1.583	0.6524	n/a	n/a	1.583	0.3333
+D+0.60D+H+H	23.568	4.750	n/a	4.481	0.9710	0.3757	n/a	n/a	0.9710	0.2044
-Z-Z										
+D	37.613	4.750	9.771	n/a	n/a	n/a	1.815	0.3346	1.815	0.3821
+D+L+H	38.613	4.750	11.466	n/a	n/a	n/a	1.995	0.2117	1.995	0.4201

### Overturning Stability Tab

This tab provides the calculations for overturning and resisting moment stability of the footing about each axis and for each load combination. Please note that the load combinations used here are internally generated and are NOT from the Service Load Combinations you have entered for the purpose of evaluating soil bearing pressures.

Note that the program is set up to look for overturning and resisting forces individually. For example, take the situation where the footing is subjected to equal and opposite shears at a given elevation. Common sense dictates that these forces cancel each other, and the footing experiences no net applied overturning moment from them. But the program treats one of the two equal and opposite forces as an *overturning* force, and the other as a *resisting* force. So for these two forces, there IS a net overturning moment reported, but the resisting moment ALSO considers the effect of the opposing load, so the accounting used to determine the overturning ratio is proper.

Rotation Axis	Moment		Overturning Safety Ratio
	Overturning	Resisting	
Load Combination			
-D	5.50 k-ft	94.031 k-ft	17.097
-D+L+Lr	16.50 k-ft	99.031 k-ft	6.002
-D+L+S	16.50 k-ft	99.031 k-ft	6.002
-0.6D+L+W	14.30 k-ft	61.419 k-ft	4.295
-0.6D+L+S+W/2	17.050 k-ft	62.669 k-ft	3.676
-0.6D+L+W+S/2	17.050 k-ft	62.669 k-ft	3.676
-0.6D+W	8.80 k-ft	58.919 k-ft	6.695
Z-Z			
-D	7.50 k-ft	108.52 k-ft	14.469
-D+L+Lr	18.50 k-ft	113.98 k-ft	6.161
-D+L+S	18.50 k-ft	113.98 k-ft	6.161
-0.6D+L+W	15.50 k-ft	70.570 k-ft	4.553
-0.6D+L+S+W/2	18.250 k-ft	71.934 k-ft	3.942
-0.6D+L+W+S/2	18.250 k-ft	71.934 k-ft	3.942
-0.6D+W	10.0 k-ft	67.840 k-ft	6.784

### Sliding Stability Tab

This tab provides the calculations for applied and resisting sliding stability of the footing in each axis direction and for each load combination. Please note the load combinations used here are internally generated and are NOT from the Service Load Combinations you have entered for the purpose of evaluating soil bearing pressures.

Force Direction	Load Combination	Forces		Sliding Safety Ratio
		Sliding	Resisting	
X-X				
-D		1.0 k	28.650 k	28.650
-D+L+Lr		3.0 k	29.650 k	9.883
-D+L+S		3.0 k	29.650 k	9.883
-0.6D+L+W		2.60 k	22.128 k	8.511
-0.6D+L+S+W/2		3.10 k	22.378 k	7.219
-0.6D+L+W+S/2		3.10 k	22.378 k	7.219
-0.6D+W		1.60 k	21.628 k	13.517
Z-Z				
-D		1.0 k	32.588 k	32.588
-D+L+Lr		3.0 k	33.588 k	11.196
-D+L+S		3.0 k	33.588 k	11.196
-0.6D+L+W		2.60 k	26.065 k	10.025
-0.6D+L+S+W/2		3.10 k	26.315 k	8.489
-0.6D+L+W+S/2		3.10 k	26.315 k	8.489
-0.6D+W		1.60 k	25.565 k	15.978

### Footing Bending Tab

This tab provides a summary of the calculated factored load moment at all four edges of the pedestal perimeter for each load combination. It indicates whether the named load combination produces tension on the top surface of the footing or the bottom.

Note: In cases where tension occurs on the top of the footing, the flexural check will be based on the assumption that the defined rebar mat is provided on the top surface of the footing. The user must review the results and determine if any load combinations actually require a top mat of reinforcing, or if the footing could be reinforced with a bottom mat only.

Results | Soil Pressures | Overturning & Sliding Stability | **Footing Bending** | Footing Shear | Design OK

Footing Bending Results (using factored loads) .....

As Required Parallel to X-X Axis for Z-Z Axis Bending 3.187 in<sup>2</sup>

As Required Parallel to Z-Z Axis for X-X Axis Bending 3.187 in<sup>2</sup>

Bending Axis	Mu : Applied (k-ft/ft)	Which Side ?	Tension @ Btm or Top	d : Depth to Bar CL	Ru Req'd	ACI 10.5	Temp	Min As (in <sup>2</sup> ) Applied Mu	Governing As	Steel Bar A Min Req'd
X-X										
-D Only	13.165	+Z	Bottom	15.000	65.011		0.389	0.198	Min Temp %	0.389
-D Only	13.165	-Z	Bottom	15.000	65.011		0.389	0.198	Min Temp %	0.389
+1.20D+0.50Lr+1.60L+1.60H	15.239	+Z	Bottom	15.000	75.255		0.389	0.229	Min Temp %	0.389
+1.20D+0.50Lr+1.60L+1.60H	15.239	-Z	Bottom	15.000	75.255		0.389	0.229	Min Temp %	0.389
+1.20D+1.60Lr+0.50S+1.60H	11.284	+Z	Bottom	15.000	55.724		0.389	0.169	Min Temp %	0.389
+1.20D+1.60Lr+0.50S+1.60H	11.284	-Z	Bottom	15.000	55.724		0.389	0.169	Min Temp %	0.389
+1.20D+1.60Lr+0.50L	23.940	+Z	Bottom	15.000	118.223		0.389	0.363	Min Temp %	0.389
+1.20D+1.60Lr+0.50L	23.940	-Z	Bottom	15.000	118.223		0.389	0.363	Min Temp %	0.389
+1.20D+1.60Lr+0.80W	21.690	+Z	Bottom	15.000	107.112		0.389	0.328	Min Temp %	0.389
+1.20D+1.60Lr+0.80W	21.690	-Z	Bottom	15.000	107.112		0.389	0.328	Min Temp %	0.389
+1.20D+1.60Lr-0.80W	26.190	+Z	Bottom	15.000	129.334		0.389	0.398	Min for Bending	0.398
+1.20D+1.60Lr-0.80W	26.190	-Z	Bottom	15.000	129.334		0.389	0.398	Min for Bending	0.398

### Footing Shear Tab

This tab provides a summary of the calculated factored load shear at all four edges of the pedestal perimeter for each load combination. Two-way or punching shear is also calculated.


Results | Soil Pressures | Overturning & Sliding Stability | Footing Bending | **Footing Shear**

Footing Shear Results (using factored loads) .....

Footing Thickness : 18.0 in (modify thickness here to change design)

Load Combination	One-Way Shear (psi)					Two Way Shear (psi)				
	Vu @ -X	Vu @ +X	Vu @ +Z	Vu @ -Z	Max.	Allow Vc	Vc/Vn Ratio	Vu	Allow Vc	
+1.40D	12.874	1.931	6.537	4.498	12.874	82.2	0.157	15.956	150.150	
+1.20D+0.50Lr+1.60L+1.60H	11.678	1.752	7.408	2.602	11.678	82.2	0.142	14.474	150.150	
+1.20D+1.60Lr+0.50S+1.60H	11.678	1.752	7.408	2.602	11.678	82.2	0.142	14.474	150.150	
+1.20D+1.60Lr+0.50L	11.678	1.752	7.408	2.602	11.678	82.2	0.142	14.474	150.150	
+1.20D+1.60Lr+0.80W	11.770	1.766	7.666	2.423	11.770	82.2	0.143	14.588	150.150	
+1.20D+0.50Lr+1.60S	11.678	1.752	7.408	2.602	11.678	82.2	0.142	14.474	150.150	
+1.20D+1.60S+0.80W	11.770	1.766	7.666	2.423	11.770	82.2	0.143	14.588	150.150	
+1.20D+0.50Lr+0.50L+1.60W	11.831	1.775	7.838	2.303	11.831	82.2	0.144	14.664	150.150	
+1.20D+0.50Lr+0.50S+1.60W	11.831	1.775	7.838	2.303	11.831	82.2	0.144	14.664	150.150	
+1.20D+0.50Lr+0.20S+E	11.249	1.687	6.205	3.437	11.249	82.2	0.137	13.942	150.150	
+0.90D+1.60W+1.60H	8.766	1.315	5.578	1.936	8.766	82.2	0.107	10.865	150.150	

### Sketch Tab





## 10.7.2 Combined Footing

[Need more? Ask Us a Question](#)

This module provides analysis of a rectangular footing with two applied axial, moment and shear loads. Overburden loads can also be specified, and will apply to the surface area of the footing (except the areas covered by the two piers). The module allows you to position the application of the pier loads as necessary, and provides automatic calculation of allowable soil bearing pressure increases based on footing dimensions and/or depth below surface.

The module checks service load soil pressure, overturning stability, sliding stability, uplift stability, flexure left and right of each pedestal, 1-way shear at 'd' from each of the pedestals, and punching shear along a perimeter located 'd/2' from the pedestal faces. The module does not evaluate the footing for flexure about the Length axis.

The screenshot shows the 'Combined Footing' software interface. It includes a menu bar with 'Cancel', 'New', 'Save Only', and 'Save & Exit'. The main window is divided into several sections:

- Description:** A text box containing 'Sample Combined Footing'.
- Material Properties:** A table of input values:
 

f <sub>c</sub> : Concrete 28 day strength	4.0	ksi
f <sub>y</sub> : Rebar Yield	60	ksi
E <sub>c</sub> : Concrete Elastic Modulus	3122	ksi
Concrete Density	150.0	pcf
φ : Phi Values		
Flexure :	0.9	
Shear :	0.750	
- Analysis/Design Settings...:** A series of checkboxes and input fields:
  - Include footing weight as dead load: Yes
  - Include pedestal weight as dead load: Yes
  - Min Allow % Temp Reinf (based on thick): 0.0018
  - Min. Overturning Safety Factor: 1.0
  - Min. Sliding Safety Factor: 1.0
  - Consider ACI 10.5.1 & 10.5.3 as min. reinforcing
- Calculations:** A table showing the results of various checks:
 

Ratio	Item	Applied	Capacity	Governing Load Combination
0.2922	Soil Bearing	0.9643 ksf	3.30 ksf	+D+Lr+H
6.024	Overturning	21.530 k-ft	129.696 k-ft	0.6D+W
9.673	Sliding	-1.722 k	16.657 k	0.6D+0.7E
12.481	Uplift	1.570 k	19.595 k	0.6D+W
0.04375	1-way Shear - Col #1	4.150 psi	94.868 psi	D Only
0.07810	1-way Shear - Col #2	7.410 psi	94.868 psi	+1.20D+1.60Lr+0.50L+0.80W
0.01055	2-way Punching - Col #1	2.001 psi	189.737 psi	+1.20D+1.60Lr+0.50L+0.80W
0.01822	2-way Punching - Col #2	3.457 psi	189.737 psi	+1.20D+1.60Lr+0.50L+0.80W
No Bending	Flexure - Left of Col #1 - Top	0.0 k-ft	0.0 k-ft	N/A
0.002077	Flexure - Left of Col #1 - Bottom	0.5291 k-ft	254.750 k-ft	D Only
0.06779	Flexure - Between Cols - Top	-17.069 k-ft	251.780 k-ft	+1.20D+1.60Lr+0.50L
0.004061	Flexure - Between Cols - Bottom	1.035 k-ft	254.750 k-ft	+0.90D+E+1.60H
0.005722	Flexure - Right of Col #2 - Top	-1.441 k-ft	251.780 k-ft	+0.90D+1.60W+1.60H
0.01080	Flexure - Right of Col #2 - Bottom	2.750 k-ft	254.750 k-ft	+1.20D+1.60Lr+0.50L

### General

**f<sub>c</sub>**  
28-day compressive strength of the concrete.

**f<sub>y</sub>**  
Yield point stress of reinforcing.

**E<sub>c</sub>**

Modulus of elasticity of concrete.

### Concrete Density

The density of the concrete is used to calculate the self weight of the pedestals and footing when those options are selected.

### Phi Values

Enter the capacity reduction values to be applied to  $V_n$  and  $M_n$ .

### Include footing weight as dead load

Click [Yes] to have the module calculate the weight of the footing and apply it as a downward load. The footing self weight will be multiplied by the dead load factor in each load combination.

### Include pedestal weight as dead load

Click [Yes] to have the module calculate the weight of the pedestals and apply it as downward loads. The pedestal self weight will be multiplied by the dead load factor in each load combination.

### Min Steel Ratio - Temperature/Shrinkage

Enter the minimum ratio for temperature/shrinkage steel, calculated using the footing thickness. This will trigger a warning message if the section is under-reinforced.

### Minimum Overturning Safety Factor

Enter the minimum allowable ratio of resisting moment to overturning moment. If the actual ratio is less than the specified minimum ratio, it will trigger a message that overturning stability is not satisfied.

### Minimum Sliding Safety Factor

Enter the minimum allowable ratio of resisting force to sliding force. If the actual ratio is less than the specified minimum ratio, it will trigger a message that sliding stability is not satisfied.

The screenshot displays the 'Combined Footing' software interface. The window title is 'Combined Footing'. The menu bar includes 'Cancel', 'New', 'Save Only', and 'Save & Exit'. The ribbon contains 'General', 'Soil Allowables', 'Footing Size & Reinforcing', 'Applied Loads', and 'D+L? Load Combinations'. The 'General' tab is active, showing a 'Description' field with 'Sample Combined Footing'. The 'Material Properties' section includes:
 

- $f_c$  : Concrete 28 day strength: 4.0 ksi
- $f_y$  : Rebar Yield: 60 ksi
- $E_c$  : Concrete Elastic Modulus: 3122 ksi
- Concrete Density: 150.0 pcf
- $\phi$  : Phi Values: Flexure: 0.9, Shear: 0.750

 The 'Analysis/Design Settings...' section includes:
 

- Include footing weight as dead load: Yes
- Include pedestal weight as dead load: Yes
- Min Allow % Temp Reinf (based on thick): 0.0018
- Min. Overturning Safety Factor: 1.0
- Min. Sliding Safety Factor: 1.0
- Consider ACI 10.5.1 & 10.5.3 as min. reinforcing

## Soil Allowables

### Allowable Soil Bearing



Enter the allowable soil bearing pressure that the soil can resist. This is a service load resistance and will be compared to calculated service load soil pressures (loads not factored as in strength design).

### **Increase Bearing by Footing Weight**

Click [**Yes**] to tell the module to calculate the weight of one square foot (plan view) of footing and add it to the allowable soil bearing value. This has the effect of not penalizing the soil for the self weight of the footing, and is useful for situations where the geotechnical engineering report provides allowable net bearing pressures.

### **Soil Passive Sliding Resistance**

Enter the value of passive soil pressure resistance to sliding. This value will be used to determine a component of sliding resistance that is generated by the passive pressure of the soil. The sliding resistance due to passive pressure is then added to the sliding resistance due to friction to determine the total resistance to sliding for each load combination.

### **Coefficient of Soil/Concrete Friction**

Enter the coefficient of friction between soil and footing to use in sliding resistance calculations.

### **Soil Bearing Increase**

This section allows you to specify some dimensions that, when exceeded, will automatically increase the allowable soil bearing pressure.

**Footing base depth below soil surface:** The distance from the bottom of the footing to the top of the soil. This value is used to determine allowable soil bearing pressure increases and soil passive sliding resistance, but it is not used in any other calculations in this module.

**Increases based on footing depth:** Provides a method to automatically apply increases to the basic allowable soil bearing pressure based on footing depth below some reference depth. Collects the following parameters:

**Allowable pressure increase per foot:** Specifies the amount that the basic allowable soil bearing pressure can be increased for each foot of depth below some reference depth.

**When base of footing is below:** Specifies the required depth in order to start realizing incremental increases in the allowable soil bearing pressure on the basis of footing depth.

**Example:** Assume the following: Basic Allowable Soil Bearing Pressure = 3 ksf. Footing base is 6'-0" below soil surface. The Geotechnical report specifies that a 0.15 ksf increase in bearing pressure is allowed for each foot of depth when the base is deeper than 4' below top of soil. Since you've indicated that the footing is 6' below the soil surface, the module will automatically calculate the adjusted allowable soil bearing pressure to be  $3 \text{ ksf} + (6' - 4') * 0.15 \text{ ksf} = 3.30 \text{ ksf}$ .

**Increases based on footing plan dimension:** Provides a method to automatically apply increases to the basic allowable soil bearing pressure based on footing dimensions greater than some reference dimension. Collects the following parameters:

**Allowable pressure increase per foot:** Specifies the amount that the basic allowable soil bearing pressure can be increased for each foot of width or length greater than some reference dimension.

**When maximum length or width is greater than:** Specifies the required dimension in order to start realizing incremental increases in the allowable soil bearing pressure on the basis of footing dimension.

**Example:** Assume the following: Basic Allowable Soil Bearing Pressure = 3 ksf. Footing measures 12'-0" x 6'-0". The Geotechnical report specifies that a 0.15 ksf increase in soil bearing pressure is allowed for each foot when the largest plan dimension of the footing is greater than 4'. The module will automatically calculate the adjusted allowable soil bearing pressure to be  $3 \text{ ksf} + (12' - 4') * 0.15 \text{ ksf} = 4.2 \text{ ksf}$ .

Note: Increases based on footing depth and plan dimensions are cumulative.

## Footing Size & Reinforcing

### Dimensions tab


**Projection on Left, Distance Between Columns, Projection on Right:** Define the dimensions of the footing in the Length direction.

**Footing Width:** Define the dimension of the Width direction.

**Footing Thickness:** Define the total thickness of the footing.

**Pedestal dimensions:** If concrete pedestals bear on the footing, their dimensions can be specified here. Pedestals are assumed to be square, and they are assumed to be centered on the Width dimension of the footing.


Note: Any applied overburden loads will be omitted from the area occupied by the pedestals.



### Reinforcing tab


Reinforcing parallel to the Length dimension can be defined separately for the left and right projections of the footing and for the area between the columns. Input fields are provided to define top bars and bottom bars separately.

Note: Bars are assumed to be fully developed at the locations where they are required. It is the engineer's responsibility to validate that assumption. The program is not taking rebar development length into consideration.



### Applied Loads

The Applied Loads tab provides sub-tabs for Column #1 (the column on the left), Column #2 (the column on the right), and Overburden. The two column load tabs offer input fields for vertical loads, moment about the Width axis, and shear in the Length direction. The Overburden tab provides input fields for a uniform vertical pressure that will be applied to the entire surface area of the footing with the exception of the areas occupied by the pedestals.



## Load Combinations

The Load Combinations tab is used to specify the load combinations to be used in the design. The Service Combinations tab controls the load combinations that are used to perform the serviceability checks for Soil Bearing, Overturning, Sliding, and Uplift. The Factored Combinations tab controls the load combinations that are used to perform the strength checks for Flexure, One-Way Shear, and Two-Way Punching Shear.

These tabs allow the user to select from load combination sets that are supplied with the program or to select from custom load combination sets that have been created and saved on the user's machine. It is also possible to unlock the selected load combination set and make edits to the factors directly in this view. The user has control over which combinations are run and which are ignored. A Soil Increase factor can be applied on a load combination by load combination basis, as permitted by the geotechnical engineering report.

Finally, this tab allows the user to specify whether the program should consider the algebraic sign of the specified load factors on wind loads and seismic loads to be reversible or not. This can be a convenient way to ensure that these loads are investigated as acting in both positive and negative directions, if that is the design intent. Note, however, that if selected, the algebraic sign reversal will be applied to ALL wind loads and/or ALL seismic loads including horizontally AND vertically applied loads.

**Service Combinations** Factored Combinations **IBC 2009** Change Load Combination Set

Load Combination for SOIL PRESSURE	Run	Soil Increase	D	Lr	L	S	W	E	H
D Only	<input checked="" type="checkbox"/>	1	1.0						
+D+L+H	<input checked="" type="checkbox"/>	1	1.0		1.0				1.0
+D+Lr+H	<input checked="" type="checkbox"/>	1	1.0	1.0					1.0
+D+S+H	<input checked="" type="checkbox"/>	1	1.0			1.0			1.0
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1	1.0	0.750	0.750				1.0
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1	1.0		0.750	0.750			1.0
+D+W+H	<input checked="" type="checkbox"/>	1	1.0				1.0		1.0
+D+0.70E+H	<input checked="" type="checkbox"/>	1	1.0					0.70	1.0
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1	1.0	0.750	0.750		0.750		1.0
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1	1.0		0.750	0.750	0.750		1.0
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1	1.0	0.750	0.750			0.5250	1.0
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1	1.0		0.750	0.75		0.525	1.0
+0.60D+W+H	<input checked="" type="checkbox"/>	1	0.60	0		0	1.0		1.0
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	1	0.60					0.70	1.0

Use add'l factors per ASCE 12.4.2.3

Auto Reverse Wind

Auto Reverse Seismic

## Calculations

### Results tab

This tab summarizes the controlling values (highest utilization ratio) for each design consideration, from all of the load combinations that have been run. For the controlling load combination, it presents the Applied load, the Capacity or available resisting load, the ratio of the Applied to the Capacity, and the governing load combination that produces this controlling ratio.

Ratio	Item	Applied	Capacity	Governing Load Combination
0.1879	Soil Bearing	0.6108 ksf	3.250 ksf	+D+Lr+H
20.141	Overturning	40.370 k-ft	813.07 k-ft	0.6D+W
13.321	Sliding	-1.722 k	22.939 k	0.6D+0.7E
26.108	Uplift	1.570 k	40.990 k	0.6D+W
0.03803	1-way Shear - Col #1	4.089 psi	107.52 psi	+1.40D
0.02483	1-way Shear - Col #2	2.670 psi	107.52 psi	+1.20D+0.50Lr+0.50L+1.60W
0.01786	2-way Punching - Col #1	3.840 psi	215.03 psi	+1.20D+1.60Lr+0.50L+0.80W
0.02027	2-way Punching - Col #2	4.360 psi	215.03 psi	+1.20D+1.60Lr+0.50L+0.80W
No Bending	Flexure - Left of Col #1 - Top	0.0 k-ft	0.0 k-ft	N/A
0.002305	Flexure - Left of Col #1 - Bottom	1.053 k-ft	456.68 k-ft	+1.40D
0.09365	Flexure - Between Cols - Top	-42.268 k-ft	451.35 k-ft	+1.20D+1.60Lr+0.50L
0.005147	Flexure - Between Cols - Bottom	2.350 k-ft	456.68 k-ft	+1.20D+1.60Lr+0.50L+0.80W
0.005969	Flexure - Right of Col #2 - Top	-2.694 k-ft	451.35 k-ft	+0.90D+1.60W+1.60H
0.01026	Flexure - Right of Col #2 - Bottom	4.685 k-ft	456.68 k-ft	+1.20D+1.60Lr+0.50L

### Soil Pressures tab

For each service load combination, this tab presents the total vertical load, the resultant eccentricity, the soil pressures on the left and the right ends of the footing, the allowable soil pressure, and the ratio of the actual to the allowable soil pressure.

Rotation Axis	Bearing Load	Resultant Eccentricity	Soil Pressures		Allowable Soil Pressure	Stress Ratio
Load Combination			Left, -X	Right, +X		Actual / Allow
+D	96.190	-0.050	0.463	0.453	3.250	0.142
+D+Lr+H	116.000	-0.495	0.611	0.494	3.250	0.188
+D+0.750Lr+0.750L+H	111.048	-0.399	0.574	0.484	3.250	0.177
+D+W+H	96.190	-0.387	0.496	0.420	3.250	0.153
+D+0.70E+H	96.190	-0.333	0.491	0.426	3.250	0.151
+D+0.750Lr+0.750L+0.750W+H	111.048	-0.618	0.599	0.459	3.250	0.184
+D+0.750L+0.750S+0.750W+H	96.190	-0.302	0.488	0.428	3.250	0.150
+D+0.750Lr+0.750L+0.5250E+H	111.048	-0.582	0.595	0.463	3.250	0.183
+D+0.750L+0.750S+0.5250E+H	96.190	-0.262	0.484	0.432	3.250	0.149
+0.60D+W+H	57.714	-0.611	0.311	0.239	3.250	0.096
+0.60D+0.70E+H	57.714	-0.521	0.305	0.244	3.250	0.094

### Overturning & Sliding Stability tab

For each service load combination, this tab presents the overturning moment, the resisting moment and the ratio of the resisting to overturning moment about the left and right edges of the footing. It also reports the sliding force, the resisting force, and the ratio of the resisting to sliding force.

Note that the program is set up to look for overturning and resisting forces individually. For example, take the situation where the footing is subjected to equal and opposite shears at a given elevation. Common sense dictates that these forces cancel each other, and the footing experiences no net applied overturning moment from them. But

the program treats one of the two equal and opposite forces as an overturning force, and the other as a resisting force. So for these two forces, there IS a net overturning moment reported, but the resisting moment ALSO considers the effect of the opposing load, so the accounting used to determine the overturning ratio is proper.

Overturning Results (using service loads) .....

Load Combination	Moments about Left Edge (k-ft)			Moments about Right Edge (k-ft)		
	M-Overturn	M-Resisting	Resis/OTM Ratio	Overturning	Resisting	Resis/OTM Ratio
D	0.15	1,342.04	999.000	0.15	1,351.58	999.000
D+Lr	5.37	1,571.95	292.728	5.37	1,686.79	314.114
0.6D+W	40.37	813.07	20.141	7.94	851.23	107.208
0.6D+0.7E	33.43	811.35	24.269	6.22	844.29	135.847

Sliding Results (using service loads) .....

Load Combination	Forces		Sliding Safety Ratio
	Sliding	Resisting	
D	0.00	34.48	999.000
D+Lr	0.00	40.43	999.000
0.6D+W	-1.39	22.94	16.503
0.6D+0.7E	-1.72	22.94	13.321

### Footing Bending tab

This tab reports the results of the flexural design on a load combination by load combination basis, at small increments along the length of the footing.

Footing Bending Results (using factored loads) .....

Load Combination	Mu: Applied (ft-k)	Dist From Left Side	Tension @ Btm or Top	d: Depth to Bar CL	Ru Req'd	ACI 10.5	Min As (in <sup>2</sup> ) Based on ...		Steel Bar Area		Pt Ca
							Temp	Applied Mu	As Controlled By:	As Req'd	
D Only											
+1.20D+0.50Lr+1.60Lr	0.001	0.047	Bottom	21.875	0.001	2.333	0.000	Min Temp %	2.333		
+1.20D+0.50Lr	0.006	0.093	Bottom	21.875	0.003	2.333	0.000	Min Temp %	2.333		
+1.20D+0.50Lr	0.013	0.140	Bottom	21.875	0.007	2.333	0.000	Min Temp %	2.333		
+1.20D+0.50Lr	0.022	0.187	Bottom	21.875	0.012	2.333	0.000	Min Temp %	2.333		
+1.20D+0.50Lr	0.035	0.233	Bottom	21.875	0.018	2.333	0.000	Min Temp %	2.333		
+1.20D+0.50Lr	0.050	0.280	Bottom	21.875	0.026	2.333	0.001	Min Temp %	2.333		
+1.20D+0.50Lr	0.068	0.327	Bottom	21.875	0.035	2.333	0.001	Min Temp %	2.333		
+1.20D+0.50Lr	0.089	0.373	Bottom	21.875	0.046	2.333	0.001	Min Temp %	2.333		
+1.20D+0.50Lr	0.113	0.420	Bottom	21.875	0.058	2.333	0.001	Min Temp %	2.333		
+1.20D+0.50Lr	0.139	0.467	Bottom	21.875	0.072	2.333	0.001	Min Temp %	2.333		
+1.20D+0.50Lr	0.168	0.513	Bottom	21.875	0.087	2.333	0.002	Min Temp %	2.333		

### Footing Shear tab


This tab reports the results of the one-way and two-way shear design on a load combination by load combination basis.

Footing Shear Results (using factored loads) .....

Load Combination	PhiVn (psi)	Vu - One-Way Shear				Two Way Shear (psi)				
		Col #1 (k)	vu (psi)	Col #2 (k)	vu (psi)	PhiVn (psi)	Col #1 (k)	vu (psi)	Col #2 (k)	vu (psi)
+1.40D	107.517	8.050	4.089	0.198	0.101	215.035	4.801	1.251	4.686	1.221
+1.20D+0.50Lr+1.60Lr	107.517	4.354	2.212	1.377	0.700	215.035	1.455	0.379	2.007	0.523
+1.20D+1.80Lr+0.50L	107.517	4.034	2.049	4.034	2.049	215.035	13.710	3.571	15.258	3.974
+1.20D+1.80Lr+0.50L+0.50S	107.517	4.443	2.257	4.443	2.257	215.035	14.743	3.840	16.737	4.360
+1.20D+0.50Lr+1.60S+0.50L	107.517	6.757	3.432	2.508	1.274	215.035	3.082	0.803	2.538	0.661
+1.20D+0.50Lr+0.50S+1.60Lr	107.517	4.068	2.066	5.256	2.670	215.035	3.521	0.917	4.965	1.293
+1.20D+0.50Lr+0.50S+1.60Lr+0.20S+E	107.517	6.613	3.359	4.876	2.477	215.035	2.050	0.534	1.058	0.276
+1.20D+0.50Lr+0.20S+E	107.517	6.817	3.463	3.557	1.806	215.035	2.700	0.703	1.932	0.503
+0.90D+1.60W+1.60H	107.517	4.888	2.483	4.842	2.459	215.035	1.021	0.266	0.054	0.014
+0.90D+E+1.60H	107.517	5.092	2.587	3.522	1.789	215.035	1.671	0.435	0.928	0.242

**Sketch tab**

This tab provides a plan view and a longitudinal section view of the footing with rebar callouts and overall dimensions.



## 10.7.3 Wall Footing

### [Need more? Ask Us a Question](#)

This module provides analysis of a unit strip of a continuous wall footing with applied axial, moment and shear loads. Overburden loads can also be specified, and will apply to the surface area of the footing (except the area covered by the wall). The module also provides automatic calculation of allowable soil bearing pressure increases based on footing width and/or depth below surface.

The module checks service load soil pressure, overturning stability, sliding stability, uplift stability, footing flexure and one-way footing shear.

The screenshot shows the 'Wall Footing' software interface. The 'General' tab is active, displaying material properties and analysis/design settings. The 'Results' tab is also visible, showing a table of calculations.

**Material Properties:**

- $f_c$  : Concrete 28 day strength: 3.0 ksi
- $f_y$  : Rebar Yield: 60.0 ksi
- $E_c$  : Concrete Elastic Modulus: 3,122.0 ksi
- $\nu$  : Concrete Density: 145.0 pcf
- $\phi$  : Phi Values: Flexure: 0.90, Shear: 0.750

**Analysis/Design Settings:**

- Include footing weight as dead load: Yes
- Min Steel Ratio : Temp Reinf (based on thick): 0.00180
- MIN. Overturning Safety Factor: 1.50
- MIN. Sliding Safety Factor: 1.50
- Consider ACI 10.5.1 & 10.5.3 as min. reinforcing

**Results Table:**

Factor of Safety	Item	Applied	Capacity	Governing Load Combination
2.207	Overturning - Z-Z	0.6840 k-ft	1.509 k-ft	+0.60D+0.60W
3.354	Sliding - X-X	0.1080 k	0.3623 k	+0.60D+0.60W
n/a	Uplift	0.0 k	0.0 k	No Uplift
Utilization Ratio	Item	Applied	Capacity	Governing Load Combination
0.9292	Soil Bearing	2.788 ksf	3.0 ksf	+D+0.750L+0.750S+0.450W
0.06705	Z Flexure (+X)	0.7666 k-ft	11.434 k-ft	+1.20D+0.50L+1.60S
0.000978	Z Flexure (-X)	0.01118 k-ft	11.434 k-ft	+0.90D
0.005593	1-way Shear (+X)	0.4595 psi	82.158 psi	+1.20D+0.50L+1.60S
0.005593	1-way Shear (-X)	0.4595 psi	82.158 psi	+1.20D+0.50L+1.60S

### General

This tab collects material property values, strength reduction factors, and other settings that influence the design.

$f'_c$

28-day compressive strength of the concrete.

$f_y$

Yield point stress of reinforcing.

$E_c$

Modulus of elasticity of concrete.



### Concrete Density

The density of the concrete is used to calculate the self weight of the footing when the option is selected.

### Phi Values

Enter the capacity reduction values to be applied to  $V_n$  and  $M_n$ .

### Include footing weight as dead load

Click [Yes] to have the module calculate the weight of the footing and apply it as a downward load. The footing self weight will be multiplied by the dead load factor in each load combination.

### Min Steel Ratio - Temperature/Shrinkage Reinf.

Enter the minimum ratio for temperature/shrinkage steel, calculated using the footing thickness. This will trigger a warning message if the section is under-reinforced.

### Minimum Overturning Safety Factor

Enter the minimum allowable ratio of resisting moment to overturning moment. If the actual ratio is less than the specified minimum ratio, it will trigger a message that overturning stability is not satisfied.

### Minimum Sliding Safety Factor

Enter the minimum allowable ratio of resisting force to sliding force. If the actual ratio is less than the specified minimum ratio, it will trigger a message that sliding stability is not satisfied.

The screenshot shows the 'Wall Footing' software interface. The 'General' tab is active, displaying 'Sample Wall Footing Calc' in the description field. The 'Material Properties' section includes input fields for concrete strength ( $f_c$ : 3.0 ksi), rebar yield ( $f_y$ : 60.0 ksi), concrete elastic modulus ( $E_c$ : 3,122.0 ksi), and concrete density ( $\psi$ : 145.0 pcf). It also includes 'Phi Values' for Flexure (0.90) and Shear (0.750). The 'Analysis/Design Settings...' section has a 'Yes' button selected for 'Include footing weight as dead load'. Other settings include 'Min Steel Ratio : Temp Reinf (based on thick)' at 0.00180, 'MIN. Overturning Safety Factor' at 1.50, and 'MIN. Sliding Safety Factor' at 1.50. A checkbox for 'Consider ACI 10.5.1 & 10.5.3 as min. reinforcing' is checked. A warning message at the top right reads: 'NOTE! 12" Long footing strip width used. Enter Values Accordingly'.

## Soil Allowables

### Allowable Soil Bearing Pressure

Enter the allowable soil bearing pressure. This is a service load resistance and will be compared to calculated service load soil pressures (loads not factored as in strength design).

### Increase Bearing by Footing Weight

Click [Yes] to tell the module to calculate the weight of one square foot (plan view) of footing and add it to the allowable soil bearing value. This has the effect of not

penalizing the soil for the self weight of the footing, and is useful for situations where the geotechnical engineering report provides allowable net bearing pressures.

### **Soil Passive Sliding Resistance**

Enter the value of passive soil pressure resistance to sliding. This value will be used to determine a component of sliding resistance that is generated by the passive pressure of the soil. The sliding resistance due to passive pressure is then added to the sliding resistance due to friction to determine the total resistance to sliding for each load combination.

### **Coefficient of Soil/Concrete Friction**

Enter the coefficient of friction between soil and footing to use in sliding resistance calculations.

### **Soil Bearing Increase**

This section allows you to specify some dimensions that, when exceeded, will automatically increase the allowable soil bearing pressure.

**Footing base depth below soil surface:** The distance from the bottom of the footing to the top of the soil. This value is used to determine allowable soil bearing pressure increases and soil passive sliding resistance, but it is NOT used in any other calculations in this module.

**Increases based on footing depth:** Provides a method to automatically apply increases to the basic allowable soil bearing pressure based on footing depth below some reference depth. Collects the following parameters:

**Allowable pressure increase per foot:** Specifies the amount that the basic allowable soil bearing pressure can be increased for each foot of depth below some reference depth.

**When base of footing is below:** Specifies the required depth in order to start realizing incremental increases in the allowable soil bearing pressure on the basis of footing depth.

**Example:** Assume the following: Basic Allowable Soil Bearing Pressure = 3 ksf. Footing base is 6'-0" below soil surface. The Geotechnical report specifies that a 0.15 ksf increase in bearing pressure is allowed for each foot of depth when the base is deeper than 4' below top of soil. Since you've indicated that the footing is 6' below the soil surface, the module will automatically calculate the adjusted allowable soil bearing pressure to be  $3 \text{ ksf} + (6' - 4') * 0.15 \text{ ksf} = 3.30 \text{ ksf}$ .

**Increases based on footing width:** Provides a method to automatically apply increases to the basic allowable soil bearing pressure based on footing width greater than some reference dimension. Collects the following parameters:

**Allowable pressure increase per foot:** Specifies the amount that the basic allowable soil bearing pressure can be increased for each foot of width greater than some reference dimension.

**When maximum length or width is greater than:** Specifies the required dimension in order to start realizing incremental increases in the allowable soil bearing pressure on the basis of footing width.

**Example:** Assume the following: Basic Allowable Soil Bearing Pressure = 3 ksf. Footing measures 6'-0" wide. The Geotechnical report specifies that a 0.15 ksf increase in soil bearing pressure is allowed for each foot when the width of the footing is greater than 4'-0". The module will automatically calculate the adjusted allowable soil bearing pressure to be  $3 \text{ ksf} + (6' - 4') * 0.15 \text{ ksf} = 3.3 \text{ ksf}$ .

Note: Increases based on footing depth and width are cumulative.

The screenshot shows the 'Wall Footing' software interface. The 'Soil Allowables' tab is active, displaying the following parameters:

- Soil Design Values:**
  - Allowable Soil Bearing Pressure: 3.0 ksf
  - Increase Bearing By Footing Weight: Yes (selected), No
  - Soil Passive Sliding Resistance: 250.0 pcf (Uses entry for "Footing base depth below soil surface" for force)
  - Coefficient of Soil/Concrete Friction: 0.30
- Soil Bearing Increase:**
  - Footing base depth below soil surface: [ ] ft
  - Increases based on footing Depth . . . .:
    - Allow. Pressure Increase per foot: [ ] ksf
    - when base footing is below: [ ] ft
  - Increases based on footing Width . . . .:
    - Increase per foot of width: [ ] ksf
    - when width is greater than: [ ] ft
  - Maximum Allowed Bearing Pressure (zero is no limit): 10.0 ksf
  - Adjusted Allowable Soil Bearing: 3.0 ksf (Allowable Soil Bearing adjusted for footing weight and depth & width increases as specified by user.)

A warning message at the top right of the interface reads: "NOTE! 12" Long footing strip width used. Enter Values Accordingly".

## Footing Size & Reinforcing

### Dimensions tab

**Footing Width:** Define the width of the footing.

**Wall Width:** Define the width of the supported wall.

**Wall center offset from footing centerline:** Define the dimension between the centerline of the wall and the centerline of the footing. Positive offsets shift the wall toward the right edge of the footing.

**Footing Thickness:** Define the thickness of the footing.

**Auto Calculate Footing Size & Thickness:** Provides an automated routine to increase footing dimensions until soil pressures are satisfied and one-way shear is acceptable.

Note: Any applied overburden loads will be omitted from the area occupied by the wall.

### Reinforcing tab

**Reinforcing Bar Size:** Indicate the rebar size to consider for the bars that run parallel to the footing width.

**Rebar Spacing:** Provides an option to either specify an explicit value for the rebar spacing, or to specify the number of bars in a 12-inch length.

**Rebar Center to Concrete Edge @ Bottom:** Specify the clear cover plus 1/2 the diameter of the rebar.

### Applied Loads

#### Vertical Loads tab

Provides input fields for vertical loads and overburden pressures. Vertical loads are specified in units of kips per foot, and they are considered to act at the center of the width of the wall. Overburden loads are specified in units of kips per square foot, and they are considered to act on the top surface area of the footing, excluding the area occupied by the wall.

**Wall Footing**

General | Soil Allowables | Footing & Reinforcing | **Applied Loads** | Load Combinations

NOTE! 12" Long footing strip width used. Enter Values Accordingly

Vertical Loads Moments & Shears Enter unfactored loads Note: Wall Location is specified on "Footing Size" tab.

Vertical Loads	P-y *	OB-y *
D : Dead Load	1.20 k	0.30 ksf
Lr : Roof Live	0.60 k	ksf
L : Live	0.80 k	ksf
S : Snow	1.0 k	ksf
W : Wind	k	ksf
E : Seismic*	k	ksf
H : Earth	k	ksf

\* "p" = Gravity load, "+" sign is downward.  
 "OB" = Overburden load, "+" sign is downward, uniform load over footing but not in "wall" area.

### Moments & Shears tab

Provides input fields for moments and shears. Moments are specified in units of foot kips per foot. Shears are specified in units of kips per foot, and they are considered to act at the height specified in the field named **Shear application above top of footing**. Shears will produce a moment equal to the shear force times the distance from the bottom of the footing to the location of application of the shear force.

**Wall Footing**

General | Soil Allowables | Footing & Reinforcing | **Applied Loads** | Load Combinations

NOTE! 12" Long footing strip width used. Enter Values Accordingly

Vertical Loads Moments & Shears Enter unfactored loads Note: Wall Location is specified on "Footing Size" tab.

Moments	M-zz	V-x
D : Dead Load	0.60 k-ft	k
Lr : Roof Live	0.30 k-ft	k
L : Live	0.40 k-ft	k
S : Snow	0.50 k-ft	k
W : Wind	k-ft	0.180 k
E : Seismic*	k-ft	k
H : Earth	k-ft	k

Shear application above top of footing = 24.0 in


### Load Combinations

The Load Combinations tab is used to specify the load combinations to be used in the design. The LRFD Load Combinations tab controls the combinations that are used for reinforced concrete design checks. The Soil Pressure Combinations tab controls the combinations that are used for evaluating soil bearing pressure. A Soil Increase factor can be applied on a load combination by load combination basis, as permitted by the geotechnical engineering report. The Stability Combinations tab controls the load combinations that are used to perform the serviceability checks for Overturning, Sliding, and Uplift.

These tabs allow the user to select from load combination sets that are supplied with the program or to select from custom load combination sets that have been created and saved on the user's machine. It is also possible to unlock the selected load combination set and make edits to the factors directly in this view.

The user has control over which combinations are run and which are ignored. Finally, these tabs allow the user to specify whether the program should consider the algebraic


sign of the specified load factors on wind loads and seismic loads to be reversible or not. This can be a convenient way to ensure that these loads are investigated as acting in both positive and negative directions, if that is the design intent. Note, however, that if selected, the algebraic sign reversal will be applied to ALL wind loads and/or ALL seismic loads including horizontally AND vertically applied loads.



## Calculations

### Results tab

This tab summarizes the controlling values (highest utilization ratio) for each design consideration, from all of the load combinations that have been run. For the controlling load combination, it presents the Applied load, the Capacity or available resisting load, the ratio of the Applied to the Capacity, and the governing load combination that produces this controlling ratio.



### Soil Pressures tab

For each service load combination, this tab presents the total vertical load, the resultant eccentricity, the soil pressures on the left and the right ends of the footing, the allowable soil pressure, and the ratio of the actual to the allowable soil pressure.

Calculations	Results / Soil Pressures / Overturning & Sliding Stability / Footing Bending / Footing Shear							
	Soil Pressure Results (using service loads) .....							
	Load Combination	Bearing Load	Allowable Bearing	Resultant Eccentricity Along X-X	Soil Pressures		Maximum	Actual / Allowable Ratio
				Left, -X	Right, +X			
D Only	2.013 k	3.0 ksf	3.578 in	0.2367 ksf	1.373 ksf	1.373 ksf	0.4578	
+D+L	2.813 k	3.0 ksf	4.267 in	0.1776 ksf	2.072 ksf	2.072 ksf	0.6907	
+D+Lr	2.813 k	3.0 ksf	4.134 in	0.1925 ksf	1.897 ksf	1.897 ksf	0.6325	
+D+S	3.013 k	3.0 ksf	4.382 in	0.1631 ksf	2.247 ksf	2.247 ksf	0.7490	
+D+0.750L+0.750L	3.063 k	3.0 ksf	4.408 in	0.1594 ksf	2.291 ksf	2.291 ksf	0.7635	
+D+0.750L+0.750S	3.363 k	3.0 ksf	4.550 in	0.1373 ksf	2.553 ksf	2.553 ksf	0.8509	
+D+0.60W	2.013 k	3.0 ksf	5.510 in	0.0 ksf	1.685 ksf	1.685 ksf	0.5615	
+D+0.750L+0.750L+0.450W	3.063 k	3.0 ksf	5.360 in	0.0 ksf	2.524 ksf	2.524 ksf	0.8413	
+D+0.750L+0.750S+0.450W	3.363 k	3.0 ksf	5.417 in	0.0 ksf	2.788 ksf	2.788 ksf	0.9292	
+0.60D+0.60W	1.208 k	3.0 ksf	6.798 in	0.0 ksf	1.168 ksf	1.168 ksf	0.3894	
+0.60D	1.208 k	3.0 ksf	3.578 in	0.1420 ksf	0.8240 ksf	0.8240 ksf	0.2747	

### Overturning & Sliding Stability tab

For each service load combination, this tab presents the overturning moment, the resisting moment and the ratio of the resisting to overturning moment about the left and right edges of the footing.

Calculations	Results / Soil Pressures / Overturning & Sliding Stability / Footing Bending / Footing Shear				Minimum Stability Ratio : 2.207 : 1
	Overturning Results (using service loads)		Sliding Results (using service loads)		
	Load Combination	Moment	Overturning Safety Ratio		
	Overturning	Resisting			
D Only	0.60 k-ft	2.516 k-ft	4.193		
+D+L	1.0 k-ft	3.516 k-ft	3.516		
+D+Lr	0.90 k-ft	3.266 k-ft	3.628		
+D+S	1.10 k-ft	3.766 k-ft	3.423		
+D+0.750L+0.750L	1.125 k-ft	3.828 k-ft	3.403		
+D+0.750L+0.750S	1.275 k-ft	4.203 k-ft	3.297		
+D+0.60W	0.9240 k-ft	2.516 k-ft	2.723		
+D+0.750L+0.750L+0.450W	1.368 k-ft	3.828 k-ft	2.798		
+D+0.750L+0.750S+0.450W	1.518 k-ft	4.203 k-ft	2.769		
+0.60D+0.60W	0.6840 k-ft	1.509 k-ft	2.207		
+0.60D	0.360 k-ft	1.509 k-ft	4.193		

It also reports the sliding force, the resisting force, and the ratio of the resisting to sliding force.

Calculations	Results / Soil Pressures / Overturning & Sliding Stability / Footing Bending / Footing Shear				Minimum Stability Ratio : 0.0 : 1
	Overturning Results (using service loads)		Sliding Results (using service loads)		
	Load Combination	Forces	Sliding Safety Ratio		
	Sliding	Resisting			
D Only	0.0 k	0.6038 k	No Sliding		
+D+L	0.0 k	0.8438 k	No Sliding		
+D+Lr	0.0 k	0.7838 k	No Sliding		
+D+S	0.0 k	0.9038 k	No Sliding		
+D+0.750L+0.750L	0.0 k	0.9188 k	No Sliding		
+D+0.750L+0.750S	0.0 k	1.009 k	No Sliding		
+D+0.60W	0.1080 k	0.6038 k	5.590		
+D+0.750L+0.750L+0.450W	0.0810 k	0.9188 k	11.343		
+D+0.750L+0.750S+0.450W	0.0810 k	1.009 k	12.454		
+0.60D+0.60W	0.1080 k	0.3623 k	3.354		
+0.60D	0.0 k	0.3623 k	No Sliding		

### Footing Bending tab

This tab reports the results of the flexural design on a load combination by load combination basis.

Results Soil Pressures Overturning & Sliding Stability Footing Bending Footing Shear

Footing Bending Results (using factored loads) .....

Load Combination	Mu : Applied	Which Side?	Tension @ Btm or Top	d : Depth to Bar CL	Ru		Min As (in <sup>2</sup> ) Based on ...			Steel Bar Area	
					Req'd	ACI 9.6	Temp	Applied Mu	Governing As	As Req'd	Supplied
+1.40D	0.017	-X	Bottom	8.500	0.268	0.001	0.259	0.000	Min Temp %	0.259	0.31C
+1.40D	0.380	+X	Bottom	8.500	5.845	0.013	0.259	0.010	Min Temp %	0.259	0.31C
+1.20D+0.50Lr+1.60L	0.022	-X	Bottom	8.500	0.339	0.001	0.259	0.001	Min Temp %	0.259	0.31C
+1.20D+0.50Lr+1.60L	0.674	+X	Bottom	8.500	10.365	0.024	0.259	0.018	Min Temp %	0.259	0.31C
+1.20D+1.60Lr+0.50S	0.023	-X	Bottom	8.500	0.352	0.001	0.259	0.001	Min Temp %	0.259	0.31C
+1.20D+1.60Lr+0.50S	0.718	+X	Bottom	8.500	11.043	0.025	0.259	0.019	Min Temp %	0.259	0.31C
+1.20D+1.60Lr+0.50L	0.021	-X	Bottom	8.500	0.323	0.001	0.259	0.001	Min Temp %	0.259	0.31C
+1.20D+1.60Lr+0.50L	0.626	+X	Bottom	8.500	9.620	0.022	0.259	0.016	Min Temp %	0.259	0.31C
+1.20D+1.60Lr+0.50W	0.038	-X	Bottom	8.500	0.592	0.001	0.259	0.001	Min Temp %	0.259	0.31C
+1.20D+1.60Lr+0.50W	0.596	+X	Bottom	8.500	9.165	0.021	0.259	0.016	Min Temp %	0.259	0.31C
+1.20D+0.50Lr+1.60S	0.024	-X	Bottom	8.500	0.368	0.001	0.259	0.001	Min Temp %	0.259	0.31C
+1.20D+0.50Lr+1.60S	0.767	+X	Bottom	8.500	11.789	0.027	0.259	0.020	Min Temp %	0.259	0.31C
+1.20D+1.60S+0.50W	0.034	-X	Bottom	8.500	0.530	0.001	0.259	0.001	Min Temp %	0.259	0.31C
+1.20D+1.60S+0.50W	0.738	+X	Bottom	8.500	11.342	0.026	0.259	0.019	Min Temp %	0.259	0.31C

### Footing Shear tab

This tab reports the results of the shear design on a load combination by load combination basis.


Results Soil Pressures Overturning & Sliding Stability Footing Bending Footing Shear

Footing Shear Results (using factored loads) .....

Load Combination	One-Way Shear (psi)				
	Vu @ -X	Vu @ +X	Max	Allow Vc	Vc/Vn Ratio
+1.40D	0.231	0.231	0.231	82.158	0.003
+1.20D+0.50Lr+1.60L	0.405	0.405	0.405	82.158	0.005
+1.20D+1.60Lr+0.50S	0.431	0.431	0.431	82.158	0.005
+1.20D+1.60Lr+0.50L	0.376	0.376	0.376	82.158	0.005
+1.20D+1.60Lr+0.50W	0.324	0.324	0.324	82.158	0.004
+1.20D+0.50Lr+1.60S	0.460	0.460	0.460	82.158	0.006
+1.20D+1.60S+0.50W	0.407	0.407	0.407	82.158	0.005
+1.20D+0.50Lr+0.50Lr+W	0.290	0.290	0.290	82.158	0.004
+1.20D+0.50Lr+0.50S+W	0.316	0.316	0.316	82.158	0.004
+1.20D+0.50Lr+0.70S	0.342	0.342	0.342	82.158	0.004
+0.90D+W	0.149	0.149	0.149	82.158	0.002
+0.90D	0.149	0.149	0.149	82.158	0.002

### 3D tab


This tab presents the 3D rendering of the footing:



### 2D tab

This tab presents plan and section views of the footing:





## 10.7.4 Pile Group

### [Need more? Ask Us a Question](#)

This module considers a concentrated load applied to a rigid pile cap and distributes it to a group of piles. Force distribution is performed assuming a rigid pile cap and that all piles have equal vertical load resistance.

Distribution of loads to each pile due to the effect of load eccentricity is determined using a skew bending analysis. This considers simultaneous action about both X and Y axes.

The module is also an efficient method for determining loads on a pile group in the as-driven arrangement.

**Pile Group Analysis**

General | **D+L+?** Load Combinations

Description: -None-

Number of Piles: 4

Pile Locations...	X Location	Y Location
1	0.0 ft	0.0 ft
2	12.0 ft	0.0 ft
3	12.0 ft	12.0 ft
4	0.0 ft	12.0 ft

Total Applied Load . . .	Load #1	Load #2	Load #3	Unit
D : Dead Load	1.0	0.0	0.0	k
Lr : Roof Live Load	2.0	0.0	0.0	k
Lf : Live Load	3.0	0.0	0.0	k
S : Snow Load	4.0	0.0	0.0	k
W : Wind Load	0.0	0.0	0.0	k
E : Seismic Load	0.0	0.0	0.0	k
H : Earth Load	0.0	0.0	0.0	k
X Distance from Datum	6.0	0.0	0.0	ft
Y Distance from Datum	6.0	0.0	0.0	ft


Load Combination to Use: **ASD** | LRFD

---

**Results** | Detailed Results

C.G. Distance from Datum		Maximum Pile Forces...				
X	6.00 ft	Pile ID	Max. Factored Force (kip)		Min. Factored Force (kip)	
Y	6.00 ft		Load Combination	Value	Load Combination	Value
Load Distance from C.G. of Piles		Pile 1	+D+0.750L+0.750S+H	1.563	+D	0.250
X	0.000 ft	Pile 2	+D+0.750L+0.750S+H	1.563	+D	0.250
Y	0.000 ft	Pile 3	+D+0.750L+0.750S+H	1.563	+D	0.250
Moments...		Pile 4	+D+0.750L+0.750S+H	1.563	+D	0.250
X-X Axis	0.00 k-ft					
Y-Y Axis	0.00 k-ft					
Moments of Inertia						
Y-Y Axis	144.00 ft <sup>4</sup>					
X-X Axis	144.00 ft <sup>4</sup>					
X-Y Axis	0.00 ft <sup>4</sup>					
XY <sup>2</sup>	0.00 ft <sup>8</sup>					

### General Tab



**NOTE! Establish an X & Y Coordinate system prior to entering pile and load locations. Module requires a 2-dimensional pile group to be defined. It will not report results for a collinear group, i.e. a single line of piles.**

### Total Applied Axial Load

Enter the total vertical load to be distributed to the piles in the pile group using the coordinate system you have defined.

Note: Only vertical loads are allowed; no lateral shears.

### X & Y Distance to Load

Enter the distance from the X & Y datum (0,0) to the location of the applied vertical load.

### Number of Piles

This entry defines the number of piles in the group. As you change the number of piles, the number of data entry locations will match the specified number of piles.

### Pile Locations: distance from Datum to the pile


Enter the distance from the X & Y datum (0,0) to the center of each pile location.

### Load Combination to use

This selection will switch the load combinations shown on the Load Combinations tab between Service and Factored design combinations.


## Load Combination Tab

This tab allows you to specify the load combinations to be considered.



## Results Tab

This tab summarizes the overall calculated values for the pile group and lists the maximum factored load for each pile and the load combination that produced the maximum load.




## Detailed Results Tab

This tab gives the detailed calculations for each pile for each load combination. It indicates the Direct force as well as the component of axial load that is due to the net moment applied to the entire group. This latter effect will be observed for any pile that is located at a distance from the center of gravity of the pile group.

Load Combination	Pile Location (ft)		Component Forces per Pile (kip)			Max. Force (kip)
	Pile ID	X Dist.	Y Dist.	Direct	X-X Moment	
+D	Pile 1			0.250		0.250
	Pile 2	12.000		0.250		0.250
	Pile 3	12.000	12.000	0.250		0.250
	Pile 4		12.000	0.250		0.250
+D+L+H	Pile 1			1.000		1.000
	Pile 2	12.000		1.000		1.000
	Pile 3	12.000	12.000	1.000		1.000
	Pile 4		12.000	1.000		1.000
+D+L+H	Pile 1			0.750		0.750
	Pile 2	12.000		0.750		0.750
	Pile 3	12.000	12.000	0.750		0.750
	Pile 4		12.000	0.750		0.750

Sketch Tab



Design Basis: [Pile Group Analysis](#)

## 10.7.5 Pole Footing Embedded in Soil

[Need more? Ask Us a Question](#)

This module determines actual soil pressures and required depths for pole footings primarily supporting lateral loads. Such footings are commonly called "flagpole footings".

Click here for a video:

Pole Footing Embedded in Soil

Since applied top moment generates lateral soil pressures that usually govern the design, these footings typically have a depth/width ratio of 2:1 and greater.

Cases with and without lateral restraint at the ground surface are allowed. Evaluation of actual and allowable pressures is in accordance with the IBC Section entitled "Embedded posts and poles".

ENERCALC Build 12.20.1.30 : examples.ec6 : Sample Pole Footing Calc

File Settings Databases Tools License Help

Licensed ENERCALC User: KW-06000215

### Pole Footing Embedded in Soil

Print Cancel New Save Save & Show PM

General Applied Loads Load Combinations

**Description**  
Sample Pole Footing Calc

Allowable Pressure Limit :  
Limit only by "Max. Passive" Use limit of 12 ft (per IBC)

Pole Footing Shape: Square Circular

Pole Footing Diameter: 30.0 in

Restrict at ground surface exists

Operation Mode . . .  
Calculate Min. Depth Find Lateral Pressure for Given Depth


Allowable Lateral Passive Pressure: 400.0 psf/ft  
Maximum Lateral Pressure Limit: 4,000.0 psf  
*Enter "0" for no limit.*

**Results**

Calculations	Load Combination	Forces @ Ground Surface		Required Depth - (ft)	Pressure at 1/3 Depth		Vertical Applied - (psf)
		Loads - (k)	Moment - (k-ft)		Actual - (psf)	Allow - (psf)	
<b>Controlling Values</b>							
+D+0.60W							
Lateral Load	8.40 k	0.00	0.00	0.125	0.0	0.0	2.0
Moment	67.20 k-ft	8.40	67.20	10.500	1,386.3	1,389.1	2.0
	<b>NO Ground Surface Restraint</b>	6.30	50.40	9.375	1,234.3	1,236.1	2.0
	+0.60D+0.60W	8.40	67.20	10.500	1,386.3	1,389.1	1.2
	+0.60D	0.00	0.00	0.125	0.0	0.0	1.2
	<b>Minimum Required Depth :</b>						
	<b>10.50 ft</b>						
	<b>Pressures at 1/3 Depth</b>						
	Actual	1,386.32 psf					
	Allowable	1,389.11 psf					
	<b>Footing Base Area</b>	4.909 ft <sup>2</sup>					
	<b>Maximum Axial Soil Pressure</b>	0.4074 ksf					

IBC 2006, ASCE 7-05, CBC 2007, AISC 360-05, NDS 2005, ACI 318-05, ACI 530-05 | Build: 12.20.1.30

### General Data Tab



### Pole Footing Shape

Use this section to specify whether the pole is round or rectangular (assumed square).

### Footing Width/Diameter

Enter the width or diameter of the pole footing. Width is measured perpendicular to force direction. If the pole is specified as rectangular, the module will multiply the value entered for footing width 1.41 to determine an equivalent width dimension for calculations.

### Restraint at Ground Surface

Specify whether the footing is free at the ground surface or restrained and cannot translate. A restrained footing indicates that a concrete slab or other rigid element prevents translation of the pole footing at the ground surface, but does not prevent rotation. When specifying a restrained footing, you must assure yourself that the final force required to provide the restraint can actually be developed by the restraining construction.

When ground surface restraint is present, the lateral pressure value at the bottom of the pole will govern the design.

### Operation Mode

This setting provides an option to select from two different modes of operation as follows:

*Calculate Minimum Depth:* In this mode, the module will iterate to determine the minimum embedment depth required to make the actual lateral soil pressure lower than the allowable soil pressure.

*Find Lateral Pressure for Given Depth:* In this mode, the module will calculate the lateral earth pressures caused by the specified pole size, embedment depth and applied loads. When this option is selected, a Pole Footing Embedment Depth input field will appear as shown below:

Operation Mode . . .

Calculate Min. Depth      Find Lateral Pressure for Given Depth

Pole Footing Embedment Depth      4.0 ft

### Allowable Pressure Limit

Two options are provided as indicated below:

Allowable Pressure Limit :

Limit only by "Max. Passive"      Use limit of 12 ft (per IBC)

**Limit only by "Max. Passive"**: Solves for a design that allows the passive pressure to approach the value specified in the Allowable Lateral Passive Pressure field below (limited to the value specified in the Maximum Lateral Pressure Limit field).

Example: Assume allowable lateral passive pressure is 200 psf/ft with an upper limit of 3000 psf.

When the **Limit only by "Max. Passive"** option is selected, the solution will progress as follows:

- The program will start with a shallow assumed depth and calculate the 1/3 embedment depth.
- Then it will calculate an allowable lateral passive pressure for that 1/3 embedment depth.
- Next, the program will compare this calculated allowable lateral passive pressure value to the specified upper limit on the allowable passive pressure and select the smaller of the two.
- The IBC formula is then used to determine the actual pressure for the assumed embedment depth.
- If the actual pressure is higher than the allowable pressure, the program increments the length and repeats the above process.
- For illustration, assume that the iterations have progressed to the point where the embedment depth is now 42 feet.
- The program will calculate the 1/3 embedment depth as  $(42 \text{ feet} / 3) = 14 \text{ feet}$ .
- Then it will calculate an allowable lateral passive pressure of  $(200 \text{ psf/ft} * 14 \text{ ft}) = 2800 \text{ psf}$ .
- Next, the program will compare this calculated allowable lateral passive pressure value to the specified upper limit on the allowable passive pressure and determine



that 2800 psf < 3000 psf, therefore it will use 2800 psf as the Allowable Lateral Passive Pressure.

- When the program finds an embedment depth for which the actual pressure is lower than the allowable pressure, it rounds the embedment depth up slightly and reports that value.

**Use limit of 12 ft (per IBC):** Solves for a design that achieves a passive pressure that does not exceed the Allowable Lateral Passive Pressure, where the Allowable Lateral Passive Pressure is calculated based on 1/3 of the embedment depth but not to exceed 12 feet (and limited to the value specified in the Maximum Lateral Pressure Limit field).

Example: Assume allowable lateral passive pressure is 200 psf/ft with an upper limit of 3000 psf.

When the **Use limit of 12 ft (per IBC)** option is selected, the solution will progress as follows:

- The program will start with a shallow assumed depth and calculate the 1/3 embedment depth.
- Next, it will compare the 1/3 embedment depth to 12 feet and base the allowable lateral passive pressure calculation on the smaller of the two.
- Next, the program will compare this calculated allowable lateral passive pressure value to the specified upper limit on the allowable passive pressure and select the smaller of the two.
- The IBC formula is then used to determine the actual pressure for the assumed embedment depth.
- If the actual pressure is higher than the allowable pressure, the program increments the length and repeats the above process.
- For illustration, assume that the iterations have progressed to the point where the embedment depth is now 42 feet.
- The program will calculate the 1/3 embedment depth as  $(42 \text{ feet} / 3) = 14 \text{ feet}$ .
- Next, it will compare the 1/3 embedment depth to 12 feet and determine that 14 feet > 12 feet, therefore it will base the allowable lateral passive pressure calculation on 12 feet.
- Then it will calculate an allowable lateral passive pressure of  $(200 \text{ psf/ft} * 12 \text{ ft}) = 2400 \text{ psf}$ .
- Next, the program will compare this calculated allowable lateral passive pressure value to the specified upper limit on the allowable passive pressure and determine that 2400 psf < 3000 psf, therefore it will use 2400 psf as the Allowable Lateral Passive Pressure.
- When the program finds an embedment depth for which the actual pressure is lower than the allowable pressure, it rounds the embedment depth up slightly and reports that value.

### **Allowable Lateral Passive Pressure**

The allowable lateral passive pressure that the soil can withstand. This value is entered as pounds per square foot per foot of embedment depth.

### Maximum Lateral Pressure Limit

This value is used to specify an upper limit on the Allowable Lateral Passive Pressure, so that it does not increase in an uncontrolled manner as the embedment depth increases. This value is entered as pounds per square foot.

### Applied Loads Tab

This module allows many types of loads to be applied to a pole footing embedded in soil.

#### Lateral Concentrated Loads

Module allows one concentrated load with various load types to be applied at a specified distance above the surface of the soil.

#### Lateral Distributed Loads

You can apply a uniform lateral load to the pole by specifying the magnitude of the load and the starting and ending locations.

#### Applied Moments


You can apply a concentrated moment. No "height" entry is required, because it is purely a rotational force.

#### Vertical Load

You can also apply a vertical load so that the module can calculate the vertical bearing load on the footing for each load combination.

### Load Combinations Tab

Use this tab to specify the load combinations you want the module to analyze.



### Results Tab

The results tab provides a summary of the calculations.

The table reports the resulting forces, moments and required depth for each load combination.


The Controlling Values area provides information for the most severe load combination.

Load Combination	Forces @ Ground Surface		Required Depth - (ft)	Pressure at 1/3 Depth		Vertical Applied
	Loads - (k)	Moment - (k-ft)		Actual - (psf)	Allow - (psf)	
D Only	0.00	0.00	0.000	1.0	533.3	2.0
+D+0.60W	8.40	67.20	0.000	6,251.0	533.3	2.0
+D+0.450W	6.30	50.40	0.000	4,689.0	533.3	2.0
+0.60D+0.60W	8.40	67.20	0.000	6,251.0	533.3	1.2
+0.60D	0.00	0.00	0.000	1.0	533.3	1.2


  

Controlling Values	
+D+0.60W	Lateral Load 8.40 k
	Moment 67.20 k-ft
NO Ground Surface Restraint	
Pressures at 1/3 Depth	
Actual	Exceeded! 6,251.0 psf
Allowable	533.33 psf
Footing Base Area 4.909 ft <sup>2</sup>	
Maximum Axial	
Soil Pressure	0.4074 ksf

### 3D Tab



## 2D Tab



## 10.7.6 Beam on Elastic Foundation

See [Beam on Elastic Foundation](#)<sup>294</sup> in the Beams section.

## 10.8 2D Frame Analysis

[Need more? Ask Us a Question](#)

This module provides force & deflection analysis, steel member stress analysis and wood stress analysis for two dimensional frames. Click here for the first in a series of videos:


2-D Frame Analysis Intro

The frame you create can be general in nature...the module is not limited to trusses or frames with rigid connections. You have the ability to specify the connection between all members in terms of axial, shear and bending restraints or releases.

Here are the highlights of this module:

- Use the Frame Wizard to automatically create common trusses and frames.
- Generic joint & member method of specifying the geometry of the frame.
- Completely flexible way to specify how the X, Y & Z degrees of freedom for joints are connected to the earth and how the members are connected to the joints (three degrees of freedom are available at each end of each member).
- Apply forces and moments directly to joints. You can also specify joint start temperatures.
- All loads can have dead, live, roof live, snow, wind, seismic and earth types.
- Apply concentrated and distributed loads to beams. These loads can be Global or local in direction and can be applied as forces, moments or temperature changes.
- Members are easily linked to section properties. For stress analysis you can set unbraced length, slenderness factors,  $C_b$  &  $C_m$  for members.
- Loads and members can be deactivated for quick modeling of alternatives.
- Complete AISC and NDS section databases are available.
- Specify material properties used by sections.
- Specify an extensive set of load combinations.
- Complete graphics of frame with deflected shapes.
- Complete stress & deflection diagrams of members individually.
- Extensive reporting capability and control.
- Module uses beam elements and a very fast matrix solver. With each change of the input data, the frame can be completely recalculated in an instant. (For convenience with large models or when running many load combinations, this module has been enhanced with the ability to turn the Automatic Recalculation feature off, and to trigger manual recalculations only when desired.)

Note: This module is intended to be a simple alternative to complex frame programs. The intent is to provide a simple and fast tool to perform simple indeterminate analysis & member design. No P-Delta effects, exotic elements, or non-linear analysis will ever be added to this module.



### Program Limitations

Maximum Number of Allowed:

J  
o  
i  
n  
t  
s  
=  
3  
0  
0  
J  
o  
i  
n  
t  
L  
o  
a  
d  
s

=  
6  
0  
0  
B  
e  
a  
m  
s  
=  
6  
0  
0  
B  
e  
a  
m  
P  
o  
i  
n  
t  
L  
o  
a  
d  
s  
=  
6  
0  
0  
B  
e  
a  
m  
D  
i  
s  
t  
r  
i  
b  
u  
t  
e  
d  
L  
o  
a



d  
s  
=  
  
6  
0  
0  
S  
e  
c  
t  
i  
o  
n  
s  
=  
  
1  
0  
0  
M  
a  
t  
e  
r  
i  
a  
l  
s  
=  
  
5  
0  
L  
o  
a  
d  
C  
o  
m  
b  
i  
n  
a  
t  
i  
o  
n  
s

=

1

0

0








## 10.8.1 Frame Wizard




### Overview

The **Frame Wizard** can create complete 2D Frame models for many typical framing configurations and truss layouts with just a few simple inputs.

The Frame Wizard is also especially helpful when you are just beginning to use this module and want to learn about how to specify joint end restraints and member end releases.

### Types of Models the Frame Wizard Can Generate


Pratt Truss	
Warren Truss	
Vierendeel Truss	
Howe Truss	
Inverted Warren Truss	
Single Bay 3-Member Frame	
Continuous Member	

Multi-Bay One Story Frame	
Multi-Story Single Bay Frame	
Multi-Story Frame	


Please send additional requests to [support@enercalc.com](mailto:support@enercalc.com).

### Example: Using the Frame Wizard to create a Pratt Truss

Creating a truss with the Frame Wizard is extremely simple. Just start by selecting **[Pratt]** and clicking **[Next]**.



The screen you see below will be displayed.



Simply enter the overall length and height of the truss and the number of panels the truss will have. The sample image shown has 6 panels.

The next entries allow you to easily specify a member size for the three main members that are typically the same on a truss like this (Verticals, Horizontals, and Diagonals).

The button to the right of each data entry area provides access to the built-in section database in **Structural Engineering Library**.


If you **DO** specify a database section, all of the associated section properties will be brought into the frame model for you.

If you **DO NOT** specify a database section, then the members will be assigned a name of "Vertical", "Diagonal" or "Chord" as a section group. Then all you need to do is enter property values for those three sections.

To finish just click [**Finish**]. The model will be instantly created.

### Example: Using the Frame Wizard to create a Continuous Beam

The Frame Wizard is an extremely efficient way to model a continuous beam. Just start by selecting [**Continuous Member**] and then click [**Next**].



The screen you see below will be displayed:

Frame Wizard

**Set Frame Generation Data**

Number of Spans

Member Section

Support Spacing

Equal Spacing  Specify Spacing

Span #1	<input type="text" value="0.000"/>	Span #5	<input type="text" value="0.000"/>	Span #9	<input type="text" value="0.000"/>
Span #2	<input type="text" value="0.000"/>	Span #6	<input type="text" value="0.000"/>	Span #10	<input type="text" value="0.000"/>
Span #3	<input type="text" value="0.000"/>	Span #7	<input type="text" value="0.000"/>	Span #11	<input type="text" value="0.000"/>
Span #4	<input type="text" value="0.000"/>	Span #8	<input type="text" value="0.000"/>	Span #12	<input type="text" value="0.000"/>

Continuous Member

« Previous  Finish  Cancel

Note: This wizard allows just one beam to be entered BUT you can easily change that beam specification for each span after the model is built.

Enter the Number of Spans first.

The next entry allows you to easily specify a member section name. The button to the right of each data entry area provides access to the built-in section database in **Structural Engineering Library**.

If you **DO** specify a database section, all of the associated section properties will be brought into the continuous beam model for you.

If you **DO NOT** specify a database section then the members will be assigned a name of "Beam" as a section group. Then all you need to do is enter property values for that section.

For specification of span lengths you can either use **[Equal Spacing]**:

Support Spacing

Equal Spacing  Specify Spacing

Typical Span

-or- **[Specify Spacing]** which allows you to enter the span lengths for each span.

Then just click **[Finish]**, and the model will be instantly created.

## 10.8.2 Joints & Joint Loads

[Need more? Ask Us a Question](#)

**Joints** are the points in space where members are interconnected. Members can ONLY connect to another member or the boundary by first connecting to a joint.

IMPORTANT: See **JOINT RESTRAINTS** below.

### Joints & Loads Tab

This tab contains two sub-tabs that allow you to specify joints and loads applied to the joints.

Note: The data entered into this module is linked by a database system. The effects of this linking can be seen in the screen capture seen below. Notice that the table in the upper half of the view lists available joints for which Joint Data can be viewed. As a result of the data linking, selecting Joint #1 in the upper table automatically causes the lower table to display a list of members connected to Joint #1.

**2-D Frame Analysis**

General | **Joints & Loads** | Members & Loads | Sections & Materials | Load Combs | Results | Sketch | Diagrams | Reports

JOINT DATA | Joint Loads & Results

Label X Y Restraints <- Sort + Add Joint - Delete Joint Generate

Joint Label	Location (ft)		Boundary Restraints			Temperature (deg F)
	X Loc	Y Loc	X	Y	Z	
1	0.00	0.00	Fixed	Fixed	Fixed	0.00
2	5.00	0.00	Free	Free	Fixed	0.00
3	10.00	0.00	Free	Free	Fixed	0.00
4	15.00	0.00	Free	Free	Fixed	0.00
5	20.00	0.00	Free	Free	Fixed	0.00
6	25.00	0.00	Free	Free	Fixed	0.00
7	30.00	0.00	Free	Free	Fixed	0.00
8	35.00	0.00	Free	Free	Fixed	0.00
9	40.00	0.00	Free	Fixed	Fixed	0.00
10	5.00	5.00	Free	Free	Fixed	0.00
11	10.00	5.00	Free	Free	Fixed	0.00
12	15.00	5.00	Free	Free	Fixed	0.00
13	20.00	5.00	Free	Free	Fixed	0.00
14	25.00	5.00	Free	Free	Fixed	0.00
15	30.00	5.00	Free	Free	Fixed	0.00
16	35.00	5.00	Free	Free	Fixed	0.00

Members Connected to Joint

Members attached to Joint : 1

Member Label	Section Label	Endpoint Joints		"I" End Releases			"J" End Releases		
		"I" End	"J" End	X	Y	Z	X	Y	Z
1-10	Angle	1	10	Fixed	Fixed	Pinne	Fixed	Fixed	Pinne
1-2	Chord	1	2	Fixed	Fixed	Pinne	Fixed	Fixed	Pinne

All joints are stable.

### Automatic Joint Generation



You can use the **[Generate]** button to have joints automatically generated. The joint generation popup is self explanatory....just select from the mode of generation, specify a label increment, the number of joints to generate, and the x and y distance increments to use. The "Grid Irregular X & Y" can generate some very complex joint layouts.

Another powerful tool is the Also Generate Members option, which will generate members to interconnect between the joints for the generation grid or arc/circle you have specified.

Joint Generation

Starting Joint Label : 1      X = 0.000      Y = 0.000

Joint Label Increment = 1

Generation Method

Specify # Joints      Last X      Last Y      Last X & Y

Y Distance Increment = 0.000

X Distance Increment = 0.000

Number to Generate = 1

Select Generate Mode . . .

Linear

Arc/Circle

Grid: Regular X & Y Increments

Grid: Irregular X, Regular Y

Grid: Regular X, Irregular Y

Grid: Irregular X, & Y

Also Generate Members

Cancel      Generate

## JOINT RESTRAINTS

These interconnections are extremely important, and when set incorrectly, they lead to the majority of the instabilities and other unexpected results when using this 2-D Frame Analysis module. The connections between members and the connections to "ground" have a significant effect on structural behavior, and as such, they warrant a thorough discussion and complete understanding. Always keep in mind the following concepts related to joint boundary restraints and the end releases of the member(s) connecting to the joint:

- Joints have Degrees of Freedom (DOF) associated with them.
- In the 2-D Frame Analysis program, each joint has two translational and one rotational DOF.
- An individual DOF may be restrained or released.
- DOF can be defined as Boundary Restraints or as Member End Releases.
- When the degrees of freedom are defined as Boundary Restraints, they are defined with respect to the global coordinate axis system.
- When the degrees of freedom are defined as Member End Releases, they are defined with respect to the member local coordinate axis system.

The term Degrees of Freedom refers to the capability of a joint to move in the X and Y direction and to rotate about the Z axis.

An X Restraint prevents a joint from moving in the Global X direction.

A Y Restraint prevents a joint from moving in the Global Y direction.

A Z Restraint prevents a joint from rotating about the Global Z axis.


Please see the diagram below for a brief primer on joint restraints and member releases.

The **dark black** items define the joint restraints. **Joint restraints attach the joint to the boundary.** The boundary is an infinitely stiff support and is most commonly called earth. When a joint is restrained against translation in the X and Y directions and against rotation about the Z axis, it is held firmly in place. Any forces or moments applied to it will result in a reaction which is the boundary applying a force to the joint to keep it from moving in a particular direction.

**THE MOST IMPORTANT PIECE OF INFORMATION:** Each joint must be prevented from moving in/rotating about each of its three degrees of freedom, either by a joint restraint or by a positive connection to member. If a joint can translate or rotate in an unrestrained manner, then it is unstable.

**NEXT MOST IMPORTANT PIECE OF INFORMATION:** When a joint restraint is specified, then any connected members that are not released in that particular direction will not deflect in that direction. If a joint has an "X" restraint and a member framing into that joint does not have an "X" release, then the member is actually rigidly connected to the boundary through the joint.


**ALSO IMPORTANT:** When you are modeling a frame, nearly all joints will be free from the boundary. This means that those joints will need to have their X, Y & Z degrees of freedom restrained by a connection to one or more members. Because members can only attach to each other through a joint, this is usually handled by virtue of the member having all three degrees of freedom "fixed" at its ends. **BUT FOR TRUSS CONNECTIONS, THIS CAN CAUSE PROBLEMS WITH THE "Z" rotational degree of freedom.** For truss models (where moments are not applied to nodes), it may be easier to achieve stability for all joints by declaring all joints as "fixed" against rotation about the Z-axis, and then "pinning" both ends of all members to prevent the transfer of moment from one member to another.



### 10.8.2.1 Joint Data

#### Joint Data Tab

This tab is where you add and edit the joints that define the member interconnections for the frame.



**Joint Label**

The label for a joint can be up to 25 characters long. They are CASE INSENSITIVE meaning the module internally converts all joint names to all lower case for internal usage.


**Location**

This is the X and Y location of the joint in a Cartesian coordinate system.

**Boundary Restraints**

These specify how the joint is connected to the boundary. The boundary is an infinitely rigid item and is typically earth. See the [Joints & Joint Loads](#) topic for more information.

When you click on these items (or use [Tab] to move between them) the entry turns into a drop-down list box with the available selections.




**Temperature**

This specifies the base temperature for the joint. It is only used when you are defining temperature loads for the members.


### [+Add Joint]

Prompts you for the label to assign to the newly added joint. Joint labels can be up to 25 characters long.



### [- Delete Joint]

Deletes the highlighted joint after your confirmation. Keep in mind that members depend upon joints for connectivity. So if there are any members connected to a joint, the members will be deleted if the joint is deleted. Any joint loads that were assigned to a joint will also be deleted if the joint is deleted.



### Generate

See bottom of this section.

### Joint Sketch/Full Frame Sketch

The Joint Sketch displays a graphic representation of the individual joint that is currently selected in the list of joints. The Full Frame Sketch displays a graphic representation of the entire model with the currently selected joint highlighted for easy recognition.

### Editing Joint Information

Click on any data item when the joint list first appears, and the list will switch into an editing mode. See the image below where we have clicked on the "X Loc" for joint 1.

JOINT DATA		Joint Loads & Results						
Label	X	Y	Restraints	<- Sort			+ Add Joint	- Delete
Joint Label	Location (ft)		Boundary Restraints			Temperature (deg F)		
	X Loc	Y Loc	X	Y	Z			
1	0.000	0.00	Fixed	Fixed	Fixed	0.00		
2	0.00	12.00	Free	Free	Free	0.00		
3	12.00	12.00	Free	Free	Free	0.00		
4	12.00	0.00	Fixed	Fixed	Fixed	0.00		

You can type in a numeric value or use the "spin" buttons to change the value by a fixed decimal amount.

To finish the entry either press [Tab], [Enter] or click on another data item in the list.

**When your entry is completed the entire frame will be recalculated if the Auto Calculate option is selected.**

### Automatic Joint Generation

You can use the [Generate] button to initiate the automatic generation of joints. Just select from the mode of generation, and you can specify the label and the x and y distance increments to use. The "Grid Irregular X & Y" can generate some very complex joint layouts.

Another powerful tool is the Also Generate Members option, which will generate members to interconnect the joints for the generation grid or arc/circle you have specified.

Joint Generation

Starting Joint Label : 1      X = 0.000      Y = 0.000

Joint Label Increment = 1

Generation Method

Specify # Joints      Last X      Last Y      Last X & Y

Y Distance Increment = 0.000

X Distance Increment = 0.000

Number to Generate = 1

Select Generate Mode . . .

Linear

Arc/Circle

Grid: Regular X & Y Increments

Grid: Irregular X, Regular Y

Grid: Regular X, Irregular Y

Grid: Irregular X, & Y

Also Generate Members

Cancel      Generate

### 10.8.2.2 Joint Loads & Results

#### Joint Loads & Results Tab

This tab provides the input locations for all loads applied to the joints in the frame EXCEPT member self weights.

This tab is divided into three sections:

**Select Joint:** list is where you select the joint for which you wish to modify loads. This selection controls what is visible in the other two lists.

**Applied Loads for Joint:** is where you build and edit the loads applied to that joint

**Calculated Results for Joint:** displays the calculated displacements and reactions for the joint selected in the Select Joint list.

The only list that can be edited is the Applied Loads for Joint list.

**2-D Frame Analysis** | ? | [Cancel] | [New] | [Save & Exit]

General | **JOINTS & LOADS** | Members & Loads | Sections & Materials | Load Combs | Results | Sketch | Diagrams | Reports

JOINT DATA | **Joint Loads & Results**

Select Joint . . .

Label	# Lds
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	1
14	
15	
16	

Applied Loads for Joint : 13 Note: "+" Global Y loads act in "-Y" direction. + Add Load - Delete Load

Active	Direction	Global Load Magnitude (k) or (k-ft)						
		Dead	Roof Live	Live	Snow	Wind	Seismic	Earth
Yes	Global Y	1.000						

Calculated Results for Joint : 13

Load Combination	Displacements			Reactions		
	X (in)	Y (in)	Z (radians)	X (k)	Y (k)	Z (k-ft)
+0.60D+0.70E+H	0.0012	-0.0357				
+0.60D+W+H	0.0012	-0.0357				
+0.90D+1.60W+1.60H	0.0012	-0.0374				
+0.90D+E+1.60H	0.0012	-0.0374				
+1.20D+0.50L+0.20S+E	0.0013	-0.0390				
+1.20D+0.50L+0.50S+1.60W	0.0013	-0.0390				
+1.20D+0.50L+1.60S	0.0013	-0.0390				
+1.20D+0.50Lr+0.50L+1.60W	0.0013	-0.0390				
+1.20D+0.50Lr+1.60L+1.60H	0.0013	-0.0390				
+1.20D+1.60L+0.50S+1.60H	0.0013	-0.0390				
+1.20D+1.60Lr+0.50L	0.0013	-0.0390				
+1.20D+1.60Lr+0.80W	0.0013	-0.0390				
+1.20D+1.60S+0.80W	0.0013	-0.0390				

## Adding & Deleting Loads

To add a joint load just click the **[Add Load]** button and a new load entry line will be added at the bottom of the list for the currently selected joint.

To delete a load just click on the load line you wish to delete and click the **[Delete Load]** button.

## Editing Joint Load Information

Click on any data item in the joint load list, and it will switch into an editing mode. See the image below where we have clicked on the Dead load column in the first line in the list of loads associated with joint 1.

JOINT DATA | **Joint Loads & Results**

Select Joint . . .

Label	# Lds
1	2
2	
3	
4	

Applied Loads for Joint : 1 + Add Load

Active	Direction	Global Load Magnitude (k) or (k-ft)						
		Dead	Roof Live	Live	Snow	Wind	Seism	
Yes	Global Y	12.000	3.000			0.198		
Yes	Global X					1.200		

You can type in a numeric value or use the "spin" buttons to change the value by a fixed decimal amount.



---

To finish the entry either press [Tab], [Enter] or click on another data item in the list.

**When your entry is completed the entire frame will be recalculated if the Auto Calculate option is selected.**

**Note:** If a load is applied in the same direction that a Joint Restraint is specified, that load will immediately be "absorbed" by the joint restraint, so it will not have any effect on the frame.

### 10.8.3 Members & Member Loads

[Need more? Ask Us a Question](#)

"Member" is the generic term that describes the beams, columns, struts, braces, diagonals, hangers, and other structural entities that make up the frame. This module uses a general stiffness matrix approach to solve for forces and deflections. Members are modeled by one-dimensional (length-only) entities that offer resistance to axial loads, bending moment about an axis perpendicular to the plane of the frame, and shear forces acting in the plane of the frame.

#### Members & Loads Tab

Member Label	Active	Minor	Section Name	Joints		I End Conditions			J End Conditions			Length (ft)	Unbraced Length (ft)	
				I End	J End	X	Y	Z	X	Y	Z		Lu - Z	Lu - XY
1-2	Yes	No	Chord	1	2	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
2-3	Yes	No	Chord	2	3	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
3-4	Yes	No	Chord	3	4	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
4-5	Yes	No	Chord	4	5	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
5-6	Yes	No	Chord	5	6	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
6-7	Yes	No	Chord	6	7	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
8-9	Yes	No	Chord	8	9	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
9-10	Yes	No	Chord	9	10	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
10-11	Yes	No	Chord	10	11	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
11-12	Yes	No	Chord	11	12	Fixed	Fixed	Pinne	Fixed	Fixed	Free	10.00	-1.000	-1.000
1-8	Yes	No	Diagonal	1	8	Fixed	Fixed	Pinne	Fixed	Fixed	Free	18.03	-1.000	-1.000
7-12	Yes	No	Diagonal	7	12	Fixed	Fixed	Pinne	Fixed	Fixed	Free	18.03	-1.000	-1.000
3-8	Yes	No	Diagonal	3	8	Fixed	Fixed	Pinne	Fixed	Fixed	Free	18.03	-1.000	-1.000
4-9	Yes	No	Diagonal	4	9	Fixed	Fixed	Pinne	Fixed	Fixed	Free	18.03	-1.000	-1.000
4-11	Yes	No	Diagonal	4	11	Fixed	Fixed	Pinne	Fixed	Fixed	Free	18.03	-1.000	-1.000
5-12	Yes	No	Diagonal	5	12	Fixed	Fixed	Pinne	Fixed	Fixed	Free	18.03	-1.000	-1.000

#### Member End Releases

These interconnections lead to the greatest potential for instabilities and other unexpected effects from the use of the 2-D module. The connections between members and the connections to "ground" have a significant effect on structural behavior, and as such, they warrant a thorough discussion and complete understanding. Always keep in mind the following concepts related to joint boundary restraints and the end releases of the member(s) connecting to the joint:

- Joints have Degrees of Freedom (DOF) associated with them.
- In the 2-D Frame Analysis program, each joint has two translational and one rotational DOF.

- An individual DOF may be restrained or released.
- DOF can be defined as Boundary Restraints or as Member End Releases.
- When the degrees of freedom are defined as Boundary Restraints, they are defined with respect to the global coordinate axis system.
- When the degrees of freedom are defined as Member End Releases, they are defined with respect to the member local coordinate axis system.

The term Degrees of Freedom refers to the capability of a joint to move in the X and Y direction and to rotate about the Z axis.

An X Restraint prevents a joint from moving in the Global X direction.

A Y Restraint prevents a joint from moving in the Global Y direction.

A Z Restraint prevents a joint from rotating about the Global Z axis.


Please see the diagram below for a brief primer on joint restraints and member releases.

The **dark black** items define the joint restraints. **Joint restraints attach the joint to the boundary.** The boundary is an infinitely stiff support and is most commonly called earth. When a joint is restrained against translation in the X and Y directions and against rotation about the Z axis, it is held firmly in place. Any forces or moments applied to it will result in a reaction which is the boundary applying a force to the joint to keep it from moving in a particular direction.

***THE MOST IMPORTANT PIECE OF INFORMATION:*** Each joint must be prevented from moving in/rotating about each of its three degrees of freedom, either by a joint restraint or by a positive connection to member. If a joint can translate or rotate in an unrestrained manner, then it is unstable.

***NEXT MOST IMPORTANT PIECE OF INFORMATION:*** When a joint restraint is specified, then any connected members that are not released in that particular direction will not deflect in that direction. If a joint has an "X" restraint and a member framing into that joint does not have an "X" release, then the member is actually rigidly connected to the boundary through the joint.

***ALSO IMPORTANT:*** When you are modeling a frame, nearly all joints will be free from the boundary. This means that those joints will need to have their X, Y & Z degrees of freedom restrained by a connection to one or more members. Because members can only attach to each other through a joint, this is usually handled by virtue of the member having all three degrees of freedom "fixed" at its ends. **BUT FOR TRUSS CONNECTIONS, THIS CAN CAUSE PROBLEMS WITH THE "Z" rotational degree of freedom.** For truss models (where moments are not applied to nodes), it may be easier to achieve stability for all joints by declaring all joints as "fixed" against rotation about the Z-axis, and then "pinning" both ends of all members to prevent the transfer of moment from one member to another.



### 10.8.3.1 Member Data

#### Member Data Tab

Members always span between two joints. The Member End Conditions tell the module how each of the three degrees of freedom at each end of the member are attached to the joint. To connect two members rigidly together you must specify the two connecting ends as "fixed" conditions for all three degrees of freedom. That locks each beam end to the joint.

For each member you can specify the section to use for its properties, and values to be used when stress analysis is performed (unbraced length, slenderness factor, Cm and Cb).

You can also set the member to be inactive to test force distributions and stresses for alternate framing conditions.

#### Editing Member Information

Click on any data item when the member list first appears, and the list will switch into an editing mode. See the image below where we have clicked on the "X" degree of freedom for the I: end of member 1-2.

Member Label	Active	Minor	Section Name	Joints		I End Conditions			J End Conditions			Length (ft)	Unbraced Length (ft)			Slenderness		Cm
				I End	J End	X	Y	Z	X	Y	Z		Lu - Z	Lu - XY	K - Z	K - XY		
1-2	Yes	No	W8X24	1	2	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	8.00	8.000	-1.000	1.00	1.00	1.00	
2-3	Yes	No	W18X35	2	3	Free	Fixed	Fixed	Fixed	Fixed	Fixed	20.00	-1.000	-1.000	1.00	1.00	1.00	
3-4	Yes	No	W8X24	3	4	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	8.00	-1.000	-1.000	1.00	1.00	1.00	

You can type in a numeric value or use the "spin" buttons to change the value by a fixed decimal amount.

To finish the entry, either press **[Tab]**, **[Enter]** or click on another data item in the list.


Note: Each column in the Member Data table can have its own type of editing mode. The Active column turns into a checkbox for yes/no selections. The Section Name column turns into a button so you can select or add a section from the Section list. See descriptions for each item below.

### Adding & Deleting Members

To add a member click the **[Add Member]** button. You will be prompted for three pieces of information:

- 1) A label for the member.
- 2) The member's "I" joint number.
- 3) The member's "J" joint number.

In the screen capture below you will notice a button to the right of the joint label entries.



Just click in the "I" or "J" joint entry and click the **[Lookup Joints]** button. This will display a window where you can scroll through the list of created joints and select one. Simply click on one of the listed joints and then click **[Select]**.

The screenshot shows the 'MEMBER DATA' window with the following table:

Member	Yes	No	Section	I	J	Fixed
13-14	Yes	No	Chord	13	14	Fixed
14-15	Yes	No	Chord	14	15	Fixed
15-16	Yes	No	Chord	15	16	Fixed
2-10	Yes	No	Vertical	2	10	Fixed
2-3	Yes	No	Chord	2	3	Fixed
3-10	Yes	No	Diagonal	3	10	Fixed
3-11	Yes	No	Vertical	3	11	Fixed
3-4	Yes	No	Chord	3	4	Fixed
4-11	Yes	No	Diagonal	4	11	Fixed
4-12	Yes	No	Vertical	4	12	Fixed
4-5	Yes	No	Chord	4	5	Fixed

The 'Select the "I" Joint' dialog box shows the following table:

Joint Label	Location		End Restraints		
	X	Y	X	Y	Z
1	0.000	0.000	Fixed	Fixed	Fixed
10	5.000	5.000	Free	Free	Fixed
11	10.000	5.000	Free	Free	Fixed
12	15.000	5.000	Free	Free	Fixed
13	20.000	5.000	Free	Free	Fixed
14	25.000	5.000	Free	Free	Fixed
15	30.000	5.000	Free	Free	Fixed
16	35.000	5.000	Free	Free	Fixed
2	5.000	0.000	Free	Free	Fixed
3	10.000	0.000	Free	Free	Fixed
4	15.000	0.000	Free	Free	Fixed

To delete a member, select the member and click [**Delete Member**]. After you approve the deletion, that member and all loads applied to that member will be deleted.

## Generating Members

You can use the [**Generate**] button to initiate the automatic generation of members. This is a simple process that automates member creation by generating members between existing nodes in the specified order.

Note: This tool will generate new members, but it will not generate new nodes.

Member Generation

Starting Member: 1-2      I Joint: 1      J Joint: 2

Member Label Increment =

I Joint Label Increment =

J Joint Label Increment =

Number of Members to Generate =

Section Label =

Cancel      Go

## Detailed Item Descriptions (see 2 screen captures below)

### Member Label

This label can be any combination of letters and numbers. It is common to use numbers for joints and letters for members, but a very convenient member labeling convention is to use the I and J joint numbers separated by a dash. So the member between joint 5 and 12 would be labeled "5-12".

The member label can ONLY be specified when Adding the member. After that point, the name can't be changed unless the member is deleted and added again.

### Active

This item is a yes/no selection. When you click on it or [**Tab**] to it, the entry changes to a checkbox. When the box is checked, the member will be considered active, meaning that it will contribute stiffness to the model. When the box is not checked, the member will be considered inactive, meaning that it will be ignored in the analysis and will not contribute stiffness to the model.

MEMBER DATA		Member Loads		Member Force	
Member Label	Section Label	I Joint	J Joint	Length <- Sort	
Member Label	Active	Minor	Section	Joints	
	?	?	Name	I End	J End
1-2	Yes	No	Chord	1	2
2-3	Yes	No	Chord	2	3
3-4	Yes	No	Chord	3	4
4-5	Yes	No	Chord	4	5

### Weak Orientation


This item allows the member to be rotated so that its strong axis is **in** the plane of the truss or frame. By default, the member is assumed to be oriented so that its strong axis is **perpendicular to** the plane of the truss or frame.

MEMBER DATA		Member Loads		
Member Label	Section Label	I Joint	J Joint	Length
Member Label	Active	Weak	Section	
	?	Orient?	Name	
1-2	Yes	No	BotChord	
1-8	Yes	No	TopChord	
10-11	Yes	No	TopChord	
11-12	Yes	No	TopChord	
2-3	Yes	No	BotChord	
2-8	Yes	No	Webs	
3-4	Yes	No	BotChord	


### Section Name

This establishes what section is to be used for that member. When you click on it or [Tab] to it, the entry changes to a button labeled Lookup.





When you click the [Lookup] button, a selection window appears as shown below:




On this window you can scroll through the sections you have already added to the section list.

Note that the sections are listed with both Section labels and Group labels. A Group label is used when you want to have more than one member have the same section properties. In the screen capture above, notice that there are groups named "Chord", "Diagonal", and "Vertical", all of which have the same section assigned to them. This offers two convenient benefits:

- First, it provides a handy way to manage multiple sets of members, some of which may have the same section.
- Second, by assigning a group name to the appropriate members in the model, it is possible to change the AISC or NDS section assigned to all members of that group by simply assigning a new section to the group, rather than having to assign the new section to many individual members.


The **[+Add Section]** button provides access to the built-in section property databases. It displays the screen below, which allows you to either type in a typical section name or click a button and display the database to select the desired section from the database.



The 'Add Section' dialog box features three tabs: 'Steel' (selected), 'Wood', and 'Undefined'. Below the tabs is a 'Section Label' text input field. To the right of this field is a button with a blue 'I' icon and the text 'Steel Lookup'. At the bottom of the dialog are two buttons: 'Cancel' with a red 'X' icon and 'OK' with a green checkmark icon.

### Joints


These two columns let you specify and change the i and j end joints of a member. When you click on these columns, the entry will change to a [Lookup] button as shown below:



The 'MEMBER DATA' window shows a table with columns for Member Label, Section Label, I Joint, J Joint, and Length. The I Joint and J Joint columns contain 'Lookup' buttons. The table lists four members with their respective properties.


Member Label	Active	Minor	Section Name	I End	J End
1-2	Yes	No	Chord	Lookup	2
1-8	Yes	No	Diagonal	1	8
10-11	Yes	No	Chord	10	11
11-12	Yes	No	Chord	11	12

Clicking that button displays a window where you can scroll through the joint list and click to identify the desired joint.



### I & J End Conditions

These six columns allow you to specify how the ends of the member are attached to the joints. When you click on or [Tab] to one of these columns, the entry will change to a drop-down list box offering appropriate fixity options:



In order to most efficiently describe the I & J End Conditions, it helps to introduce the concept of the member local axis system. Each member can be thought of as having its own x, y, and z coordinate axes that are mutually perpendicular and follow the right-hand rule. The orientation of the member local axes can be determined as follows:


1. The local x axis is always parallel to a vector from the "I" node to the "J" node. (This axis is parallel to the longitudinal axis of the member.)
2. The local z axis is always parallel to the Global Z axis and points out of the plane of the screen.
3. The local y axis can be found by taking the vector cross product of local z cross local x. (Envision using the right hand to rotate the local z axis into the local x axis, and the right thumb will automatically indicate the positive direction of the local y axis.)

Note: It is important to understand that I & J End Conditions are defined with respect to the member local axes, not the Global axis system.

A "Fixed" status for a particular end of a member, for a particular degree of freedom (X, Y or Z) means that end of the member is locked to the joint for that degree of freedom. A "Free" or "Pinned" status means that end of the member is disconnected from the joint for that degree of freedom. Here are some examples:

X, Y, Z Setting	How it will work
Fixed, Fixed, Fixed	The member is locked to the joint. If this joint was completely restrained to the boundary, then this end of the member would have an X and Y force reaction and a Z moment reaction.
Fixed, Fixed, Pinned	The member is locked to the joint in its local X and Y directions, meaning that this end of the member cannot translate with respect to the joint, however, this end of the member is free to rotate independently of the joint about the member's local Z axis (which is always parallel to the Global Z axis).
Fixed, Free, Fixed	<p>The member is locked to the joint with respect to translation in the local X axis direction. It is disconnected from the joint with respect to translation in the local Y axis direction. It is locked to the joint with respect to rotation about the member's local Z axis.</p> <p>If this member is oriented horizontally, then this combination of end conditions could be thought of as a vertical roller. When a member is in the horizontal orientation, its member local axes are parallel to the corresponding Global axes. Therefore, the fixed condition in the local X axis direction means that this end of this horizontal member cannot move left or right in the Global X direction. The free condition in the local Y direction means that this end of this horizontal member is free to move up and down in the Global Y direction. Finally, the fixed condition about the local Z axis means that this end of the member is fixed against rotation about the local Z axis, which is parallel to the Global Z axis.</p>

Along the bottom of the list is a set of buttons that allows you to quickly set the Z-axis rotation end conditions. Clicking one of these buttons will set the end releases for both ends of the member that is currently selected in the list.



**NOTE!** A truss connection is unique. You must look at the joint where the truss members intersect. If they are all free to rotate, you will set the "X" and "Y" conditions of all member ends at that joint to "Fixed". And for all "Z" conditions you will set them to "Pinned" so they can rotate freely. For that joint you will set its "X" and "Y" restraint to "Free" (assuming it is not a support location) and set its "Z" restraint to "Fixed", so that the joint will be stable.

### Length

This value is automatically calculated for you from the distance between the I and J joints.

### Unbraced Length

Enter the unbraced compression edge length that should be used for allowable stress analysis of this member. Entering a "-1" means to use the full length of the member. Any other number (0.00 or greater) is used as the unbraced length. Note that the unbraced length can be assigned a value that is greater than the node-to-node length of a member.

Lu-y is used as the unbraced compression edge length for flexural design. It is also used in  $K_y * Lu_y$  to define the unbraced length for column buckling about the y axis of the member.

Lu-z is used in  $K_z * Lu_z$  to define the unbraced length for column buckling about the z axis of the member.

### Slenderness

This entry is a simple multiplier to be applied to the Unbraced Length you have entered.


### Cm

You can specify these values for use in allowable stress calculations.

2-D Frame Analysis																		
MEMBER DATA																		
Member Label	Section Label	I Joint	J Joint	Length	Sort													
Member Label	Active	Minor	Section Name	Joints		I End Conditions			J End Conditions			Length (ft)	Unbraced Length (ft)			Slenderness		Cm
				I End	J End	x	y	z	x	y	z		Lu - z	Lu - y	K - z	K - y		
A	Yes	No	My Section	1	2	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	7.07	-1.000	-1.000	1.00	1.00	1.00	
B	Yes	No	My Section	2	3	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	7.07	-1.000	-1.000	1.00	1.00	1.00	
C	Yes	No	My Section	3	4	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	11.18	-1.000	-1.000	1.00	1.00	1.00	
D	Yes	No	My Section	4	5	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	11.18	-1.000	-1.000	1.00	1.00	1.00	
E	Yes	No	My Section	5	6	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	7.07	-1.000	-1.000	1.00	1.00	1.00	
F	Yes	No	Chris	6	7	Fixed	Fixed	Fixed	Fixed	Fixed	Fixed	7.07	-1.000	-1.000	1.00	1.00	1.00	

## Default Member Orientation

Based on the concept of the member local axis system introduced above, it is now meaningful to describe the default orientation of the various sections that can be assigned to a member in a 2-D Frame Analysis model. Of most interest is the default orientation of steel sections. When a steel section is assigned to a member, it will be assumed to be oriented as shown in the following diagram, which references the member local Z axis, the axis that is perpendicular to the plane of the model by default:



### 10.8.3.2 Member Loads

#### Member Loads Tab

This tab provides the input locations for all loads applied to the frame EXCEPT joint loads and member self weights. This module can automatically generate member self weight loads using Member Self Wt item in the load combination lists.


This tab contains three lists and one graphic area.

**Select Member:** lists all members in the model. This is where you click to select a member for which to add/delete/modify loads. This selection controls what is visible on the other two lists and in the graphic image at the bottom. The column labeled # Lds indicates the number and type of loads that have been applied to each member. "P" represents a point load, and "D" is for distributed loads. "1-P, 2-D" means that the member has one point load and two distributed loads applied to it.

**Point Loads for Member X:** shows the point loads that are applied to the selected member.

**Distributed Loads for Member X:** shows the distributed loads that are applied to the selected member.

At the bottom is a sketch showing the member and applied loads for reference.




When you click on any item in the two load entry lists, that location in the list will change into a data entry item. The columns in the list have their own specific entry types that will be described below.

### Point Loads Entry List

Point Loads for Member : 6-7			Units : (k) or (k-ft)							
Active	Direction	Location (ft)	Global Load Magnitudes							
			Dead	Roof Live	Live	Snow	Wind	Seismic	Earth	

#### Active

This is a Yes/No checkbox that allows you to turn the load on and off. This is useful when you want to quickly see the effect of removing the load without actually having to delete the load and then potentially have to redefine the load at a later time.



#### Direction

This specifies the direction of application of the load. Here is a description of each direction:

**Global X:** This point load acts in a direction parallel to the Global X Axis. Entering a positive value will apply the load to the right (in the positive X direction).

**Global Y:** This point load acts in a direction parallel to the Global Y Axis. The algebraic sign on the magnitude will affect the direction of application based on the Applied Global Y Load Sign Convention setting on the General tab as follows:

When the Applied Global Y Load Sign Convention is set to "Global +Y Loads act towards +Y (Upward)", then loads applied in the Global Y direction with a positive algebraic sign act upward, and loads applied in the Global Y direction with a negative algebraic sign act downward.

When the Applied Global Y Load Sign Convention is set to "Global +Y Loads act towards -Y (Downward)", then loads applied in the Global Y direction with a positive algebraic sign act downward, and loads applied in the Global Y direction with a negative algebraic sign act upward.

In order to most efficiently describe the direction of application of the "Local" load types, it helps to refer to the member local axis system. Each member can be thought of as having its own x, y, and z coordinate axes that are mutually perpendicular and follow the right-hand rule. The orientation of the member local axes can be determined as follows:

1. The local x axis is always parallel to a vector from the "I" node to the "J" node. (This axis is parallel to the longitudinal axis of the member.)
2. The local z axis is always parallel to the Global Z axis.
3. The local y axis can be found by taking the vector cross product of local z cross local x. (Envision using the right hand to rotate the local z axis into the local x axis, and the right thumb will automatically indicate the positive direction of the local y axis.)

**Local x:** This point load acts parallel to the member's local x axis. If this load is specified with a positive magnitude, the load will act in the positive direction of the local x axis. If this load is specified with a negative magnitude, the load will act in the negative direction of the local x axis.


**Local y:** This point load acts parallel to the member's local y axis. If this load is specified with a positive magnitude, the load will act in the positive direction of the local y axis. If this load is specified with a negative magnitude, the load will act in the negative direction of the local y axis.

It should now be obvious that it is VERY important to have a thorough understanding of member orientation when using "Local" load types.



**Moment:** This specifies that the load is a concentrated moment. Positive moments follow the right-hand rule and apply a counter-clockwise rotational force to the member (when viewing the model from the positive Z direction).

**Temperature:** This is used to specify temperatures at particular locations along the length of a member. The module then uses these spot temperatures, in conjunction with the joint temperatures specified in the Joint Data list, to establish temperature gradients along the member(s). The module will calculate the effects of the specified temperature gradient from the end joint to the location along the member at which the temperature was specified. If you apply more temperature loads, the gradients are developed between each adjacent point of temperature load.



**Location**

This specifies the distance from the "I" joint where the point load is located.

**Load Type & Magnitude**

You can enter seven different types of loads on the frame and combine them using the factors on the Load Combinations tab.

**Distributed Load Entry List**

Distributed Loads for Member : 6-7																	
Units : (k/ft)																	
Active	Dir	Location		Dead Load		Roof Live		Live		Snow		Wind		Seismic		Earth	
		(ft)	(ft)	Start	End	Start	End	Start	End	Start	End	Start	End	Start	End		
?																	
Yes	Global Y	0.00	0.00	1.000	1.000	1.000	1.000	1.000	1.000	0.000							

Note: "+" Global Y loads act in "-Y" direction.

**Active**

This is a Yes/No checkbox that allows you to turn the load on and off. This is useful when you want to quickly see the effect of removing the load.

## Direction

This specifies the direction of application of the load.

Distributed Loads for Member : 1-2

Active	Dir	Location		Roof L
		(ft)	(ft)	Start
?				
Yes	Global Y	0.00	4.00	
	Global X			
	Global Y			
	Proj X			
	Proj Y			
	Local x			
	Local y			
	Temp			

Here is a description of the different directions:

**Global X:** This load acts in a direction parallel to the Global X Axis and is distributed along the full length of the member. If the member is sloped, the load will be applied for the full length of the member. So if a member has a 10-foot rise and a 10-foot run, the length of the load will equal 14.14 feet. Entering a positive value will apply the load to the right (in the positive X direction).

**Global Y:** This load acts in a direction parallel to the Global Y Axis and is distributed along the full length of the member. If the member is sloped, the load will be applied for the full length of the member. So if a member has a 10-foot rise and a 10-foot run, the length of the load will equal 14.14 feet. The algebraic sign on the magnitude will affect the direction of application based on the Applied Global Y Load Sign Convention setting on the General tab as follows:

When the Applied Global Y Load Sign Convention is set to "Global +Y Loads act towards +Y (Upward)", then loads applied in the Global Y direction with a positive algebraic sign act upward, and loads applied in the Global Y direction with a negative algebraic sign act downward.

When the Applied Global Y Load Sign Convention is set to "Global +Y Loads act towards -Y (Downward)", then loads applied in the Global Y direction with a positive algebraic sign act downward, and loads applied in the Global Y direction with a negative algebraic sign act upward.

**Projected X:** This load acts in a direction parallel to the Global X Axis, but it is applied only to the length of the member projected onto the Global Y Axis. So if a member has a 10-foot rise and a 20-foot run, the length of the load will equal 10.00 feet (the rise of the member).

**Projected Y:** This load acts in a direction parallel to the Global Y Axis, but it is applied only to the length of the member projected onto the Global X axis. So if a member has

a 10-foot rise and a 20-foot run, the length of the load will equal 20.00 feet (the run of the member).

In order to most efficiently describe the direction of application of the "Local" load types, it helps to refer to the member local axis system. Each member can be thought of as having its own x, y, and z coordinate axes that are mutually perpendicular and follow the right-hand rule. The orientation of the member local axes can be determined as follows:

1. The local x axis is always parallel to a vector from the "I" node to the "J" node. (This axis is parallel to the longitudinal axis of the member.)
2. The local z axis is always parallel to the Global Z axis.
3. The local y axis can be found by taking the vector cross product of local z cross local x. (Envision using the right hand to rotate the local z axis into the local x axis, and the right thumb will automatically indicate the positive direction of the local y axis.)

**Local x:** This distributed load acts parallel to the member's local x axis. If this load is specified with a positive magnitude, the load will act in the positive direction of the local x axis. If this load is specified with a negative magnitude, the load will act in the negative direction of the local x axis.

**Local y:** This distributed load acts parallel to the member's local y axis. If this load is specified with a positive magnitude, the load will act in the positive direction of the local y axis. If this load is specified with a negative magnitude, the load will act in the negative direction of the local y axis.

It should now be obvious that it is VERY important to have a thorough understanding of member orientation when using "Local" load types.

**Temperature:** This is used to specify temperatures at particular locations along the length of a member. The module then uses these spot temperatures, in conjunction with the joint temperatures specified in the Joint Data list, to establish temperature gradients along the member(s). The module will calculate the effects of the specified temperature gradient from the end joint to the location along the member at which the temperature was specified. If you apply more temperature loads, the gradients are developed between each adjacent point of temperature load.

### Location - Start, End

This specifies the distance from the "I" joint to the beginning and end of the load. Leaving BOTH values as zero (0.0) will cause the load to be applied to the full length of the member.

### Load Type & Magnitude

You can enter seven different types of loads on the frame and combine them using the values on the Load Combinations tab.

### 10.8.3.3 Member Forces

This tab allows you to review the final calculated forces for a member.

To review member forces, first click the member of interest in the Select Member list. Next, click on a load combination in the Select Load Comb. list. The member end forces will be displayed for the chosen load combination, and a table of member forces at increments along the length of the member will be shown.

This tab provides a more simplified view of member forces than the large tables displayed on the Results tab.

**2-D Frame Analysis**

General | Joints & Loads | **Members & Loads** | Sections & Materials | Load Combs | Results | Sketch | Diagrams | Reports

MEMBER DATA | Member Loads | **Member Forces**

Select Member... | Select Load Comb... | Calculated Forces @ End of Member : **14-15** | +0.60D+0.70E+H

Member	Load Combination	Forces at Location			
		Location on Member (ft)	Axial (k)	Shear (k)	Moment (k-ft)
14-15	+0.60D+0.70E+H	<b>I End Forces</b>			
		Axial	14.217 k		
		Shear	0.419 k		
		Moment	0.000 k-ft		
		<b>J End Forces</b>			
		Axial	-14.217 k		
		Shear	0.419 k		
		Moment	0.000 k-ft		
		0.000	14.217	0.419	0.000
		0.102	14.217	0.401	-0.042
0.204	14.217	0.384	-0.082		
0.306	14.217	0.367	-0.120		
0.408	14.217	0.350	-0.157		
0.510	14.217	0.333	-0.192		
0.612	14.217	0.316	-0.225		
0.714	14.217	0.299	-0.256		
0.816	14.217	0.282	-0.286		
0.918	14.217	0.265	-0.314		
1.020	14.217	0.248	-0.340		
1.122	14.217	0.231	-0.364		
1.224	14.217	0.214	-0.387		
1.327	14.217	0.196	-0.408		

## 10.8.4 Sections & Materials

### [Need more? Ask Us a Question](#)

The two tabs under Sections & Materials provide the ability to define the section properties and material properties for the members used in the frame.

Section Label	Material	Area	Ixx	Section (in <sup>2</sup> , inches, in <sup>4</sup> )				
Label	Name			Area	Depth	Width	Ixx	Iyy
Default	Group	Default		1.000	0.000	0.000	1.00	1.000
HSS6x6x5/16	My Section	Steel		6.430	6.000	6.000	34.30	34.300

Depth	=	6.000 in	Ixx	=	34.30 in <sup>4</sup>	J	=	55.400 in <sup>4</sup>
			Sxx	=	11.40 in <sup>3</sup>			
Width	=	6.000 in	Rxx	=	2.310 in			
Wall Thick	=	0.291 in	Iyy	=	34.300 in <sup>4</sup>			
Area	=	6.430 in <sup>2</sup>	Syy	=	11.400 in <sup>3</sup>	Ycg	=	3.000 in
Weight	=	23.286 plf	Ryy	=	2.310 in			
			Zx	=	13.600 in <sup>3</sup>			

### 10.8.4.1 Section Data

The SECTION DATA tab allows you to specify sections to be used for the frame.

#### Section Label vs. Group Label

These two ways of labeling a section are very helpful and should be understood.

The Section Label is the actual name of the section, whether it is an AISC section name like W14x22 or a wood section like 4x10. The Section Label always represents something that can be retrieved from the internal databases.

It can also be the name of a section that you create by entering a name and some properties.


The Group Label lets you associate a section name with a label that is meaningful to you and that can be used on multiple members. This makes it so you can easily revise the

section that is assigned to a set of members without the need to change the section name individually for all the members where it is used.

For example, say that members 1,3,5,7,9,11,13,15 and 17 will all use the same section. You don't know which AISC section will be selected, but you DO know it will be the same section. You can assign a preliminary section name of HSS 3x3x1/4 and a group label of "diagonal\_1". If the frame analysis shows that the HSS section fails, you can simply change it to a different section (with new properties). Because that section is linked to those members with the group label, it simplifies the section assignment and modification for the entire group.


### Adding and Deleting Sections

When you click the **[Add Section]** button, the following window appears:



To select a section from the built-in AISC or NDS databases, just click the appropriate tab and either type in the section name or click the **[Lookup]** button.

If you want to add your own section name and type in the properties, click the Undefined tab, type in the desired section name, and click **[OK]**.



**[Delete Section]** will delete the section you've highlighted in the list. Any members using that section will be changed to reference the Default section.

## Editing the List Columns

### Section label


When you click on the entries in this column the entry position will change to a button labeled **[Lookup]**. This button provides access to the built-in section databases.

### Group Label

When you click on the entries in this column the entry position changes to a text editing box.

### Material

When you click on the entries in this column the entry position changes to a **[Lookup]** button. This button provides access to a list of the material properties that you have already defined on the Materials tab.



Material Label	Youngs	Density	Yield	Thermal Coeff.
Default	1.00	0.00	1.00	0.00
Steel	29,000.00	0.49	50.00	0.00

✓ Select

✗ Cancel


### Section property values

These entry columns change to numeric entries when selected to allow entry of the values.

#### 10.8.4.2 Material Data

This screen provides the ability to define the material values used by the sections you define.

Clicking **[Add General Material]** displays the following input box for you to enter the material name:



To add a new material, enter the name of the material and then click **[OK]**. The new material will appear in the Materials list on the Material Data tab.

Clicking **[Add Wood Material]** displays the Wood Reference Design Values database where you can select a wood species and grade combination:

Wood Reference Design Values

NDS 2005 Supplement Reference Design Values

Size Classes to Show

2" -> 4" Thick, 2" & Wider | 5" x 5" & Larger | Glulam Table 5A - Beams | Manufactured

Beams & Stringers | Posts & Timbers | User Defined

Show Favorites Only | Toggle Favorite ON-OFF | Expand/Contract Trees

Wood Species	Size/Group	Fb (psi)	Fv	Fc (psi)	Ft	E - Modu				
Common Name	Classification	Tension	Compr.	psi	Perp.	Prl	psi	E Bend	E Min Bend	E Ber
Baldcypress	5"x5" & Lrgr									
Select structural	5"x5" & Lrgr	1,150	1,150	200	615	1,050	750	1,300	470	
No. 1	5"x5" & Lrgr	1,000	1,000	200	615	925	675	1,300	470	
No. 2	5"x5" & Lrgr	625	625	175	615	600	425	1,000	370	
Mixed Southern Pine	5"x5" & Lrgr									
Select structural SR	5"x5" & Lrgr	1,500	1,500	165	375	900	1,000	1,300	470	
No. 1	5"x5" & Lrgr	1,350	1,350	165	375	800	900	1,300	470	
No. 2	5"x5" & Lrgr	850	850	165	375	525	550	1,000	370	
Redwood	5"x5" & Lrgr									
Clear Structural	5"x5" & Lrgr	1,850	1,850	145	650	1,650	1,250	1,300	470	
Select structural	5"x5" & Lrgr	1,400	1,400	145	650	1,200	950	1,300	470	
Select structural OG	5"x5" & Lrgr	1,100	1,100	145	420	900	750	1,000	370	
No. 1	5"x5" & Lrgr	1,200	1,200	145	650	1,050	800	1,300	470	
No. 1 OG	5"x5" & Lrgr	950	950	145	420	800	650	1,000	370	
No. 2	5"x5" & Lrgr	1,000	1,000	145	650	900	525	1,100	400	
No. 2 OG	5"x5" & Lrgr	750	750	145	420	650	400	900	330	
Southern Pine	5"x5" & Lrgr									
Dense select structural	5"x5" & Lrgr	1,750	1,750	165	440	1,100	1,200	1,600	580	
Select structural SR	5"x5" & Lrgr	1,500	1,500	165	375	950	1,000	1,500	550	

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\NDS\_2005.TPS

To select a wood material to use in the current calculation, click on the desired material in the Wood Reference Design Values database and then click **[Select]**. The new wood material will appear in the Materials list on the Material Data tab as shown below:



The screenshot shows the '2-D Frame Analysis' software interface. The 'SECTION DATA' tab is active, and the 'Material Data' sub-tab is selected. The 'Materials . . .' table is displayed with the following data:

Material Label	Density	Therm Coeff.	Elastic Modulus	Steel Yield	Spec	Wood Specific Values (psi)				
	( kcf )	(in per degree)	( ksi )	( ksi )		Fb-Tens	Fb-Comp	Fc-Prll	Ft-Prll	Fv-Perp
Default	0.000	0.0005000	29,000.0	46.00		0	0	0	0	0
Steel	0.490	0.0006500	29,000.0	50.00		0	0	0	0	0
Douglas Fir-South, No.2	0.030	0.0000000	1,200.0	0.00	Fir-South, No.2	850	850	1,350	1,200	180
Aspen, Select structural	0.025	0.0000000	1,100.0	0.00	elect structural	875	875	725	1,100	120

Clicking on the Elastic Modulus, Density, Yield Stress and Thermal Coefficient entry items will change them into numeric entry boxes where you can type in a value and press **[Tab]** or click off of the value to complete the data entry.

### Elastic Modulus

The elastic modulus defines how the members will react to forces by defining the relationship between stress and strain.

### Density

The density entry is used only when the module calculates and applies member self weights using the **Member Self Weight** entry column on the Load Combination tab.

### Yield Stress

The use of this column and additional allowable stress information will be enhanced as the module matures. For steel members this property is used to perform the AISC member allowable stress evaluation. When wood stress evaluation is added, the module will store other pertinent values from the built-in database.

### Thermal Coefficient

This defines the rate of thermal expansion per degree of temperature change. This value is only used when temperature loads are defined for a member.

### Wood-Specific Values

The Wood-Specific Values are only populated when the selected material comes from the Wood Reference Design Values database.

## 10.8.5 Load Combinations

This data table controls how all of the loads are applied to the frame and also enables you to have member self weight loads automatically considered in specified directions.

The current list of load combinations comes from ASCE 7-05. It represents most of the commonly used load combinations suggested for both Allowable Stress Design and Strength Design. This table will be enhanced to provide more controlled specification of load combinations including templates for serviceability checks.

### Auto-Minimize Combinations to Run

This checkbox instructs the module to eliminate load combinations that have a duplicate set of factored loads or specific combinations that include wind, seismic, earth, and snow load types when none of those load types is present in the model.

The purpose is simply to suppress duplicate result sets.

### Add

This button adds a load combination line to the list. You can then edit the factors.

### Delete

This button deletes the currently selected load combination from the list.



### (Load a new load combination set)

This button allow you to retrieve load combination sets from the built-in load combination database and place them in the list. Clicking it will display a popup menu listing the load combination sets currently included in the database.

Run	Group	Factors Applied to each Load Type for this Combination								Member Self Wt.	
LC	Mult	Dead	Roof Live	Live	Snow	Wind	Seismic	Earth	Global X	Global Y	
2009 IBC ASCE 7-05	Yes	1.000								-1.000	
2006 IBC ASCE 7-05	Yes	1.000								-1.000	
My Custom Combos	Yes	1.000		1.000				1.000		-1.000	
NBC 2005	Yes	1.000	1.000	1.000				1.000		-1.000	
Office Standard Load Combos	Yes	1.000			1.000			1.000		-1.000	
+D+0.75Lr+0.750S+0.750W+H+MbrWt(0,-1)	Yes	1.000		0.750	0.750			1.000		-1.000	
+D+0.60D+W+H+MbrWt(0,-1)	Yes	1.000			0.750	0.750		1.000		-1.000	
+D+0.75Lr+0.750S+0.750W+H+MbrWt(0,-1)	Yes	1.000		0.750	0.750		0.700	1.000		-1.000	
+D+0.750Lr+0.750S+0.750W+H+MbrWt(0,-1)	Yes	1.000		0.750	0.750	0.750	0.750	1.000		-1.000	
+D+0.750Lr+0.750S+0.5250E+H+MbrWt(0,-1)	Yes	1.000		0.750	0.750		0.525	1.000		-1.000	
+D+0.750Lr+0.750S+0.5250E+H+MbrWt(0,-1)	Yes	1.000		0.750	0.750	0.750	0.525	1.000		-1.000	
+0.60D+W+H+MbrWt(0,-1)	Yes	1.000	0.600				1.000	1.000		-1.000	
+0.60D+0.70E+H+MbrWt(0,-1)	Yes	1.000	0.600				0.700	1.000		-1.000	

## Description of Items in List

### Load Combination Name

This is the name of the load combination. It consists of abbreviations for each included load type along with the associated numeric values that represent the respective load


factors. You cannot edit this name. It is constructed automatically based on the entries you make in the following columns.

Note in the following image how the Load Combination Name is constructed from the specified values:


Load Combination Name	Run	Group	Factors Applied to each Load Type for this Combination							Member Self Wt.	
	LC	Mult	Dead	Roof Live	Live	Snow	Wind	Seismic	Earth	Global X	Global Y
0.75(+D)+MbrWt(0,-1)	No	0.750	1.000								-1.000
+D+L+H+MbrWt(0,-1)	No	1.000	1.000		1.000				1.000		-1.000
+D+Lr+H+MbrWt(0,-1)	No	1.000	1.000	1.000					1.000		-1.000
+D+S+H+MbrWt(0,-1)	No	1.000	1.000			1.000			1.000		-1.000

### Run LC

Clicking on this entry changes it to a checkbox, which controls whether that load combination is used or ignored.



This button allows you to change the Run setting for all the load combinations at once using several options.



### Group Multiplier

This value acts as a multiplier on the entire load combination.

Lets say your values describe a combination of  $1.0D + 0.7L + 0.3E$  and you want to reduce that entire combined loading by 50%. You would enter a value of 0.5 for the Group Multiplier. The resulting load combination would be  $0.50 * (1.0D + 0.7L + 0.3E)$ .

### Individual Load Factors

Enter the numeric value to be applied to each type of load.

### Member Self Weight

When either of these two values is non-zero, the module will calculate the weight of each member (as cross sectional area \* density \* length) and consider that weight during the analysis.

A "-1" value for "Global Y" will apply the member self weight downward (in the -Y direction). A value of "1" for "Global X" will have the member self weight applied to the right (the +X direction).

<span>General</span>   <span>Joins &amp; Loads</span>   <span>Members &amp; Loads</span>   <span>Sections &amp; Materials</span>   <b>Load Combs</b>   <span>Results</span>   <span>Sketch</span>   <span>Diagrams</span>   <span>Reports</span>											
<span>▲</span> <span>+ Add</span> <span>- Delete</span> <span>Run</span> <span>Quick Selection : ▼</span> <span>▼</span>											
Load Combination Name	Run LC	Group Mult	Factors Applied to each Load Type for this Combination							Member Self Wt.	
			Dead	Roof Live	Live	Snow	Wind	Seismic	Earth	Global X	Global Y
+D+MbrWt(0,-1)	Yes	1.000	1.000								-1.000
+D+L+H+MbrWt(0,-1)	Yes	1.000	1.000			1.000				1.000	-1.000
+D+Lr+H+MbrWt(0,-1)	Yes	1.000	1.000	1.000							-1.000
+D+S+H+MbrWt(0,-1)	Yes	1.000	1.000				1.000				-1.000
+D+0.750Lr+0.750L+H+MbrWt(0,-1)	Yes	1.000	1.000	0.750	0.750						-1.000
+D+0.750L+0.750S+H+MbrWt(0,-1)	Yes	1.000	1.000		0.750		0.750				-1.000
+D+W+H+MbrWt(0,-1)	Yes	1.000	1.000					1.000			-1.000
+D+0.70E+H+MbrWt(0,-1)	Yes	1.000	1.000						0.700		-1.000
+D+0.750Lr+0.750L+0.750W+H+MbrWt(0,-1)	Yes	1.000	1.000	0.750	0.750			0.750			-1.000
+D+0.750L+0.750S+0.750W+H+MbrWt(0,-1)	Yes	1.000	1.000		0.750	0.750	0.750	0.750			-1.000
+D+0.750Lr+0.750L+0.5250E+H+MbrWt(0,-1)	Yes	1.000	1.000	0.750	0.750				0.525		-1.000
+D+0.750L+0.750S+0.5250E+H+MbrWt(0,-1)	Yes	1.000	1.000		0.750	0.750	0.750		0.525		-1.000
+0.60D+W+H+MbrWt(0,-1)	Yes	1.000	0.600					1.000			-1.000
+0.60D+0.70E+H+MbrWt(0,-1)	Yes	1.000	0.600						0.700		-1.000
+1.40D+MbrWt(0,-1)	Yes	1.000	1.400								-1.000
+1.20D+0.50Lr+1.60L+1.60H+MbrWt(0,-1)	Yes	1.000	1.200	0.500	1.600						-1.000
+1.20D+1.60L+0.50S+1.60H+MbrWt(0,-1)	Yes	1.000	1.200		1.600	0.500					-1.000
+1.20D+1.60Lr+0.50L+MbrWt(0,-1)	Yes	1.000	1.200	1.600	0.500						-1.000
+1.20D+1.60Lr+0.80W+MbrWt(0,-1)	Yes	1.000	1.200	1.600				0.800			-1.000
+1.20D+0.50L+1.60S+MbrWt(0,-1)	Yes	1.000	1.200		0.500	1.600					-1.000
+1.20D+1.60S+0.80W+MbrWt(0,-1)	Yes	1.000	1.200			1.600	0.800				-1.000
+1.20D+0.50Lr+0.50L+1.60W+MbrWt(0,-1)	Yes	1.000	1.200	0.500	0.500	1.600	1.600				-1.000
+1.20D+0.50L+0.50S+1.60W+MbrWt(0,-1)	Yes	1.000	1.200		0.500	0.500	1.600				-1.000
+1.20D+0.50L+0.20S+E+MbrWt(0,-1)	Yes	1.000	1.200		0.500	0.200		1.000			-1.000
+0.90D+1.60W+1.60H+MbrWt(0,-1)	Yes	1.000	0.900					1.600		1.600	-1.000
+0.90D+E+1.60H+MbrWt(0,-1)	Yes	1.000	0.900						1.000	1.600	-1.000

**Note** - Load factors can be entered as positive or negative values. Entering a factor as a negative value will reverse the direction of application of the loads you have specified as "Joint" and "Member" loads.

For "Member Self Weight" factors the sign indicates the direction of application, i.e. a negative value for "Global Y" will generate member self weight loads acting in the -Y direction.

### 10.8.6 Wood Design

The 2D Frame module now incorporates wood stress checking according based on ASD or LRFD methods according to NDS methods.

#### Adjustment Factors for Sawn Lumber

The module only collects  $C_D$  or Lambda from the user.

The module assumes a value of 1.0 for  $C_M$ ,  $C_t$ ,  $C_{fu}$ ,  $C_i$ ,  $C_r$  and  $C_T$ .

The module calculates values for  $C_L$ ,  $C_F$ , and  $C_P$ .

The bearing area factor  $C_b$  never comes into play in the functions performed within this module.

#### Adjustment Factors for Glued Laminated Timber

The module only collects  $C_D$  or Lambda from the user.

The module assumes a value of 1.0 for  $C_M$ ,  $C_t$ ,  $C_{fu}$ ,  $C_c$ ,  $C_l$ , and  $C_{vr}$ .

The module calculates values for  $C_L$ ,  $C_V$ , and  $C_P$ .

The bearing area factor  $C_b$  never comes into play in the functions performed within this module.



Extreme Values		Joint Displacements & Reactions		Member End Forces		Member Details		Use [-] box to expand results tree	
Joint Disp. & Reactions		Member Forces							
This table lists extreme magnitude values for each JOINT. For each joint, top line has values and second line has the LOAD COMBINATION for that value.									
Joint Label		Extreme Joint Displacements & Reactions							
		X Disp. (in)	Y Disp. (in)	Z Rot. (rad)	X React (kip)	Y React (kip)	Z React (k-ft)		
1	Max	0.0000	-0.0000	-0.0000	-0.000	24.472	89.964		
	Min	0.0000	-0.0000	-0.0000	-0.000	13.394	51.698		
2	Max	0.0202	-0.2003	0.0000			-2.941		
	Min	0.0194	-0.2092	0.0000			-6.861		
3	Max	0.0404	-0.0000	0.0000		5.299	-23.094		
	Min	0.0387	-0.0000	0.0000		5.177	-23.223		
4	Max	0.0202	-0.1995	0.0000			-0.000		
	Min	0.0194	-0.2083	0.0000			-0.000		

### Member Forces

This table summarizes the extreme forces that occur anywhere along the length of each member. (The detailed forces ALONG the length of the member are given in another list within this Results section.)

For each member there is a four-line result display. The first line shows the member label and the maximum member force values that occur anywhere along the length of the member. The second line indicates the load combinations that create the maximum values. The third line indicates the minimum (most negative) member force values that occur anywhere along the length of the member. The fourth line indicates the load combinations that create the minimum values.

Extreme Values		Joint Displacements & Reactions		Member End Forces		Member Details		Use [-] box to expand results tree	
Joint Disp. & Reactions		Member Forces							
This table lists extreme values for each MEMBER. For each joint, top line has values and second line has the LOAD COMBINATION for that value.									
Member		Extreme Member Forces							
Label		Axial (k)	Location (ft)	Moment (k-ft)	Location (ft)	Shear (k)	Location (ft)		
1-2	Max	-13.1889	0.0000	78.2869	0.0000	20.4351	0.0000		
		+0.60D+W+H+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)			
	Min	-13.7723	0.0000	-10.1802	17.3469	-1.5639	50.0000		
		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)			
1-4	Max	14.2966	0.0000	11.6774	0.0000	1.2577	0.0000		
		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)			
	Min	13.2213	50.9902	-5.1303	27.0560	-1.1437	50.9902		
		+0.60D+W+H+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+0.60D+W+H+Mb+W(0,-1)			
2-3	Max	-13.1889	0.0000	11.5458	50.0000	1.1401	0.0000		
		+0.60D+W+H+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+0.60D+W+H+Mb+W(0,-1)			
	Min	-13.7723	0.0000	-5.0365	23.4694	-1.2615	50.0000		
		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)			
2-4	Max	-2.4630	0.0000	0.0000	0.0000	0.0000	0.0000		
		+0.60D+W+H+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)			
	Min	-3.1811	10.0000	-0.0000	10.0000	0.0000	0.0000		
		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+0.60D+W+H+Mb+W(0,-1)			
3-4	Max	14.2966	0.0000	5.1303	27.0560	1.1437	50.9902		
		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+0.60D+W+H+Mb+W(0,-1)			
	Min	13.2213	50.9902	-11.6774	0.0000	-1.2577	0.0000		
		+0.60D+W+H+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)		+1.40D+Mb+W(0,-1)			

## Stress Checks

The Stress Checks tab is only displayed when the Member Stress Check Status item on the General tab has been set to ASD or LRFD stress checks.

For each member this list shows the following information:

- member label
- section or group label
- material
- governing load combination that results in the maximum Axial plus Bending stress ratio
- maximum stress ratio for the Axial plus Bending check
- pass/fail status for the Axial plus Bending check
- location along the member length where the critical Axial plus Bending result was found to occur
- governing load combination that results in the maximum Shear stress ratio
- maximum stress ratio for the Shear check
- pass/fail status for the Shear check
- location along the member length where the critical Shear result was found to occur.

The image below shows the results for the steel members used in this frame:



**2-D Frame Analysis**

General | Joints & Loads | Members & Loads | Sections & Materials | Load Combs | **Results** | Sketch | Diagrams | Reports

Extreme Values | Joint Displacements & Reactions | Member End Forces | Member Details | Member Check Results | Use [+] box to expand results tree

Joint Disp. & Reactions | Member Forces | **Stress Checks** | Steel stress checks are performed using AISC 360-05

This table lists the maximum stress analysis results for each MEMBER.

Member Data			Max. Axial+Bending Stress Ratios				Max Shear Ratios			
Label	Section	Material	Load Combination	Ratio	Status	Dist. (ft)	Load Combination	Ratio	Status	Dist. (ft)
1-10	Angle	Steel	+D+MbrWt(0,-1)	0.1070	PASS	0.000	+D+MbrWt(0,-1)	0.0011	PASS	0.000
1-2	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
10-11	Chord	Steel	+D+MbrWt(0,-1)	0.0123	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
11-12	Chord	Steel	+D+MbrWt(0,-1)	0.0158	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
12-13	Chord	Steel	+D+MbrWt(0,-1)	0.0173	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
13-14	Chord	Steel	+D+MbrWt(0,-1)	0.0173	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
14-15	Chord	Steel	+D+MbrWt(0,-1)	0.0158	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
15-16	Chord	Steel	+D+MbrWt(0,-1)	0.0123	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
2-10	Vertical	Steel	+D+MbrWt(0,-1)	0.0154	PASS	5.000		0.0000	PASS	0.000
2-3	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
3-10	Diagonal	Steel	+D+MbrWt(0,-1)	0.0461	PASS	7.071	+0.60D+W+H+MbrWt(0,-1)	0.0010	PASS	7.071
3-11	Vertical	Steel	+D+MbrWt(0,-1)	0.0905	PASS	0.000		0.0000	PASS	0.000
3-4	Chord	Steel	+D+MbrWt(0,-1)	0.0078	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
4-11	Diagonal	Steel	+D+MbrWt(0,-1)	0.0296	PASS	7.071	+0.60D+W+H+MbrWt(0,-1)	0.0010	PASS	7.071
4-12	Vertical	Steel	+D+MbrWt(0,-1)	0.0509	PASS	0.000		0.0000	PASS	0.000
4-5	Chord	Steel	+D+MbrWt(0,-1)	0.0101	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
5-12	Diagonal	Steel	+D+MbrWt(0,-1)	0.0131	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS	0.000
5-13	Vertical	Steel	+D+MbrWt(0,-1)	0.0404	PASS	0.000		0.0000	PASS	0.000
5-14	Diagonal	Steel	+D+MbrWt(0,-1)	0.0130	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS	0.000
5-6	Chord	Steel	+D+MbrWt(0,-1)	0.0101	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
6-14	Vertical	Steel	+D+MbrWt(0,-1)	0.0508	PASS	0.000		0.0000	PASS	0.000
6-15	Diagonal	Steel	+D+MbrWt(0,-1)	0.0295	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS	7.071
6-7	Chord	Steel	+D+MbrWt(0,-1)	0.0079	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
7-15	Vertical	Steel	+D+MbrWt(0,-1)	0.0904	PASS	0.000		0.0000	PASS	0.000
7-16	Diagonal	Steel	+D+MbrWt(0,-1)	0.0461	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS	0.000
7-8	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
8-16	Vertical	Steel	+0.60D+W+H+MbrWt(0,-1)	0.0154	PASS	5.000		0.0000	PASS	0.000
8-9	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000
9-16	Diagonal	Steel	+D+MbrWt(0,-1)	0.0648	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS	0.000

### 10.8.7.2 Joint Displacements & Reactions

This list summarizes the joint displacements resulting from each load combination.

**Joint displacements are reported with respect to the global coordinate system.**

Clicking on the **[+]** icon to the left of each combination will expand the sub-list to show the detailed values.

Extreme Values						
Joint Displacements & Reactions						
Use [+] box to expand results tree						
Load Combination	Displacements			Reactions		
	Joint Label	X (in)	Y (in)	Z (radians)	X (k)	Y (k)
+D+MbrWt(0,-1)						
+D+Lr+H+MbrWt(0,-1)						
-1	0.0000	-0.0000	-0.0000	-0.000	18.933	70.831
-2	0.0198	-0.2047	0.0000			-4.901
-3	0.0396	-0.0000	0.0000		5.238	-23.159
-4	0.0198	-0.2039	0.0000			-0.000
+D+Lr+H+MbrWt(0,-1)						
+D+S+H+MbrWt(0,-1)						
+D+0.750Lr+0.750L+H+MbrW						
+D+0.750L+0.750S+H+MbrWt						
+D+W+H+MbrWt(0,-1)						
+D+0.70E+H+MbrWt(0,-1)						
+D+0.750Lr+0.750L+0.750W						
+D+0.750L+0.750S+0.750W+						
+D+0.750Lr+0.750L+0.5250						
+D+0.750L+0.750S+0.5250E						
+0.60D+W+H+MbrWt(0,-1)						
+0.60D+0.70E+H+MbrWt(0,-						
+1.40D+MbrWt(0,-1)						
+1.20D+0.50Lr+1.60L+1.60						
+1.20D+1.60L+0.50S+1.60H						
+1.20D+1.60Lr+0.50L+MbrW						
+1.20D+1.60Lr+0.80W+MbrW						
+1.20D+0.50L+1.60S+MbrWt						
+1.20D+1.60S+0.80W+MbrWt						
+1.20D+0.50Lr+0.50L+1.60						
+1.20D+0.50L+0.50S+1.60W						
+1.20D+0.50L+0.20S+E+Mbr						
+0.90D+1.60W+1.60H+MbrWt						
+0.90D+E+1.60H+MbrWt(0,-						

### 10.8.7.3 Member End Forces

This list summarizes the member end forces resulting from each load combination.

Clicking on the [+] icon to the left of each combination will expand the sub-list to show the detailed values.

General   Joints & Loads   Members & Loads   Sections & Materials   Load Combs   Results   Sketch   Diagrams   Reports						
Extreme Values   Joint Displacements & Reactions   Member End Forces   Member Details   Member Check Results   Use [+] box to expand results tree						
Load Combination Member Label	I End Joints			J End Values		
	Axial (k)	Shear (k)	Moment (k-ft)	Axial (k)	Shear (k)	Moment (k-ft)
+D+MbrWt(0,-1)						
+D+L+H+MbrWt(0,-1)						
+D+Lr+H+MbrWt(0,-1)						
+D+S+H+MbrWt(0,-1)						
-1-2	-13.481	14.956	59.185	13.481	1.443	-13.380
-1-4	13.999	1.256	11.646	-13.519	1.143	-8.741
-2-3	-13.481	1.139	8.478	13.481	1.260	-11.513
-2-4	-2.582	0.000	0.000	3.062	-0.000	0.000
-3-4	13.999	-1.256	-11.646	-13.519	-1.143	8.741
+D+0.750Lr+0.750L+H+MbrW						
+D+0.750L+0.750S+H+MbrWt						
+D+W+H+MbrWt(0,-1)						
+D+0.70E+H+MbrWt(0,-1)						
+D+0.750Lr+0.750L+0.750W						
+D+0.750L+0.750S+0.750W+						
+D+0.750Lr+0.750L+0.5250						
+D+0.750L+0.750S+0.5250E						
+0.60D+W+H+MbrWt(0,-1)						
+0.60D+0.70E+H+MbrWt(0,-						
+1.40D+MbrWt(0,-1)						
+1.20D+0.50Lr+1.60L+1.60						
+1.20D+1.60L+0.50S+1.60H						
+1.20D+1.60Lr+0.50L+MbrW						
+1.20D+1.60Lr+0.80W+MbrW						
+1.20D+0.50L+1.60S+MbrWt						
+1.20D+1.60S+0.80W+MbrWt						
+1.20D+0.50Lr+0.50L+1.60						
+1.20D+0.50L+0.50S+1.60W						
+1.20D+0.50L+0.20S+E+Mbr						
+0.90D+1.60W+1.60H+MbrWt						
+0.90D+E+1.60H+MbrWt(0,-						

### 10.8.7.4 Member Details

This list gives a very detailed presentation of the member forces and member deflections at small increments along the member length.

**Note that the Member Deflections provided in this list are reported relative to the straight-line chord drawn between the *deflected* position of the two end nodes of the member. In other words, these Member Deflections will ALWAYS report a value of zero at both ends of all members.**

The list is a tree with two sub-levels:

- The main level allows a choice of the load combination.
- The next level down offers the choice of which member to observe.

Click on the [+] icons to expand the list to show more details. Click on the [-] icon will compress the level.

Load Combination		Values at Span Locations			Deflection (in)
Member Label	Axial (k)	Shear (k)	Moment (k-ft)	Relative to member ends	
+D+MbrWt(0,-1)					
+D+L+H+MbrWt(0,-1)					
+D+Lr+H+MbrWt(0,-1)					
1-2					
0.000 ft	-13.481	14.956	59.185		
1.020 ft	-13.481	13.886	44.470	0.00443	
2.041 ft	-13.481	12.817	30.846	-0.00861	
3.061 ft	-13.481	11.747	18.313	-0.03435	
4.082 ft	-13.481	10.760	6.868	-0.06837	
5.102 ft	-13.481	0.711	-3.066	-0.10665	
6.122 ft	-13.481	0.662	-3.766	-0.14556	
7.143 ft	-13.481	0.613	-4.417	-0.18332	
8.163 ft	-13.481	0.564	-5.017	-0.21970	
9.184 ft	-13.481	0.515	-5.567	-0.25450	
10.204 ft	-13.481	0.466	-6.068	-0.28750	
11.224 ft	-13.481	0.417	-6.519	-0.31855	
12.245 ft	-13.481	0.368	-6.919	-0.34747	
13.265 ft	-13.481	0.319	-7.270	-0.37413	
14.286 ft	-13.481	0.270	-7.570	-0.39840	
15.306 ft	-13.481	0.221	-7.821	-0.42016	
16.327 ft	-13.481	0.172	-8.022	-0.43933	
17.347 ft	-13.481	0.123	-8.173	-0.45583	
18.367 ft	-13.481	0.074	-8.273	-0.46959	
19.388 ft	-13.481	0.025	-8.324	-0.48059	
20.408 ft	-13.481	-0.024	-8.325	-0.48879	
21.429 ft	-13.481	-0.073	-8.276	-0.49417	
22.449 ft	-13.481	-0.121	-8.177	-0.49677	
23.469 ft	-13.481	-0.170	-8.028	-0.49658	
24.490 ft	-13.481	-0.219	-7.829	-0.49367	
25.510 ft	-13.481	-0.268	-7.580	-0.48808	
26.531 ft	-13.481	-0.317	-7.282	-0.47989	
27.551 ft	-13.481	-0.366	-6.933	-0.46920	
28.571 ft	-13.481	-0.415	-6.534	-0.45611	
29.592 ft	-13.481	-0.464	-6.085	-0.44075	
30.612 ft	-13.481	-0.513	-5.587	-0.42326	

### 10.8.7.5 Member Check Results

The Member Check Results tab is only shown when the Member Stress Check Status item on the General tab has been set to ASD or LRFD stress checks.

#### Stress Check Results

For each member this list shows the following information:

- member label
- section or group label
- material
- governing load combination that results in the maximum stress ratios
- maximum stress ratio for the Axial plus Bending check
- pass/fail status for the Axial plus Bending check
- location along the member length where the critical Axial plus Bending result was found to occur
- maximum stress ratio for the Shear check
- pass/fail status for the Shear check
- location along the member length where the critical Shear result was found to occur.

The image below shows the results for the steel members used in this frame:

**2-D Frame Analysis**

General | Joints & Loads | Members & Loads | Sections & Materials | Load Combs | Results | Sketch | Diagrams | Reports

Extreme Values | Joint Displacements & Reactions | Member End Forces | Member Details | **Member Check Results** | Use [+] box to expand results tree

**Stress Check Results** | Steel Details

Label	Member Data		Max. Axial-Bending Stress Ratios			Max Shear Ratios			
	Section	Material	Load Combination	Stress Ratio	Status	Dist. (ft)	Load Combination	Stress Ratio	Status
1-10	Angle	Steel	+D+MbrWt(0,-1)	0.1070	PASS	0.000	+D+MbrWt(0,-1)	0.0011	PASS
1-2	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
10-11	Chord	Steel	+D+MbrWt(0,-1)	0.0123	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
11-12	Chord	Steel	+D+MbrWt(0,-1)	0.0158	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
12-13	Chord	Steel	+D+MbrWt(0,-1)	0.0173	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
13-14	Chord	Steel	+D+MbrWt(0,-1)	0.0173	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
14-15	Chord	Steel	+D+MbrWt(0,-1)	0.0158	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
15-16	Chord	Steel	+D+MbrWt(0,-1)	0.0123	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
2-10	Vertical	Steel	+D+MbrWt(0,-1)	0.0154	PASS	5.000		0.0000	PASS
2-3	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
3-10	Diagonal	Steel	+D+MbrWt(0,-1)	0.0461	PASS	7.071	+0.60D+W+H+MbrWt(0,-1)	0.0010	PASS
3-11	Vertical	Steel	+D+MbrWt(0,-1)	0.0905	PASS	0.000		0.0000	PASS
3-4	Chord	Steel	+D+MbrWt(0,-1)	0.0078	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
4-11	Diagonal	Steel	+D+MbrWt(0,-1)	0.0296	PASS	7.071	+0.60D+W+H+MbrWt(0,-1)	0.0010	PASS
4-12	Vertical	Steel	+D+MbrWt(0,-1)	0.0509	PASS	0.000		0.0000	PASS
4-5	Chord	Steel	+D+MbrWt(0,-1)	0.0101	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
5-12	Diagonal	Steel	+D+MbrWt(0,-1)	0.0131	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS
5-13	Vertical	Steel	+D+MbrWt(0,-1)	0.0404	PASS	0.000		0.0000	PASS
5-14	Diagonal	Steel	+D+MbrWt(0,-1)	0.0130	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS
5-6	Chord	Steel	+D+MbrWt(0,-1)	0.0101	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
6-14	Vertical	Steel	+D+MbrWt(0,-1)	0.0508	PASS	0.000		0.0000	PASS
6-15	Diagonal	Steel	+D+MbrWt(0,-1)	0.0295	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS
6-7	Chord	Steel	+D+MbrWt(0,-1)	0.0079	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
7-15	Vertical	Steel	+D+MbrWt(0,-1)	0.0904	PASS	0.000		0.0000	PASS
7-16	Diagonal	Steel	+D+MbrWt(0,-1)	0.0461	PASS	7.071	+D+MbrWt(0,-1)	0.0010	PASS
7-8	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
8-16	Vertical	Steel	+0.60D+W+H+MbrWt(0,-1)	0.0154	PASS	5.000		0.0000	PASS
8-9	Chord	Steel	+D+MbrWt(0,-1)	0.0044	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS
9-16	Diagonal	Steel	+D+MbrWt(0,-1)	0.0648	PASS	0.000	+D+MbrWt(0,-1)	0.0010	PASS

### Steel Details

This list pertains only to the stress checks for steel members, and it provides detailed information about the stress checks at small increments along the length of each member.

Member Label	Location ft	Governing Stress Ratio		Axial (kips)			Moments (k-ft)		Shears (kips)	
		Ratio	Equation	Pu	Pn-C/Omega	Pn-T/Omega	Mu	Mn / Omega	Vu	Vn / Omega
1-10										
1-2										
10-11										
11-12										
+D+Mbr/Wt(C)		0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054		583.83	0.42	407.07
+D+Mbr/Wt(C)	0.102	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.04	583.83	0.40	407.07
+D+Mbr/Wt(C)	0.204	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.08	583.83	0.38	407.07
+D+Mbr/Wt(C)	0.306	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.12	583.83	0.37	407.07
+D+Mbr/Wt(C)	0.408	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.16	583.83	0.35	407.07
+D+Mbr/Wt(C)	0.510	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.19	583.83	0.33	407.07
+D+Mbr/Wt(C)	0.612	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.22	583.83	0.32	407.07
+D+Mbr/Wt(C)	0.714	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.26	583.83	0.30	407.07
+D+Mbr/Wt(C)	0.816	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.29	583.83	0.28	407.07
+D+Mbr/Wt(C)	0.918	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.31	583.83	0.26	407.07
+D+Mbr/Wt(C)	1.020	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.34	583.83	0.25	407.07
+D+Mbr/Wt(C)	1.122	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.36	583.83	0.23	407.07
+D+Mbr/Wt(C)	1.224	0.001	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.39	583.83	0.21	407.07
+D+Mbr/Wt(C)	1.327	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.41	583.83	0.20	407.07
+D+Mbr/Wt(C)	1.429	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.43	583.83	0.18	407.07
+D+Mbr/Wt(C)	1.531	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.44	583.83	0.16	407.07
+D+Mbr/Wt(C)	1.633	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.46	583.83	0.15	407.07
+D+Mbr/Wt(C)	1.735	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.47	583.83	0.13	407.07
+D+Mbr/Wt(C)	1.837	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.49	583.83	0.11	407.07
+D+Mbr/Wt(C)	1.939	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.50	583.83	0.09	407.07
+D+Mbr/Wt(C)	2.041	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.51	583.83	0.08	407.07
+D+Mbr/Wt(C)	2.143	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.51	583.83	0.06	407.07
+D+Mbr/Wt(C)	2.245	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.52	583.83	0.04	407.07
+D+Mbr/Wt(C)	2.347	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.52	583.83	0.03	407.07
+D+Mbr/Wt(C)	2.449	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.52	583.83	0.01	407.07
+D+Mbr/Wt(C)	2.551	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.52	583.83	-0.01	407.07
+D+Mbr/Wt(C)	2.653	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.52	583.83	-0.03	407.07
+D+Mbr/Wt(C)	2.755	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.52	583.83	-0.04	407.07
+D+Mbr/Wt(C)	2.857	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.51	583.83	-0.06	407.07
+D+Mbr/Wt(C)	2.959	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.51	583.83	-0.08	407.07
+D+Mbr/Wt(C)	3.061	0.000	Vu / (Vn/Omega)	14.812	-937.902	1,473.054	-0.50	583.83	-0.09	407.07

### 10.8.7.6 Sign Convention

#### Coordinate Axis Convention

The right-hand rule states that if you take the vector cross product of X cross Y, the result is in the Z direction. This is what is used to establish the positive Z direction if you know the positive X and Y directions. It applies to the Global Coordinate Axis system and the member local coordinate axis system in the 2-D Frame Analysis module, in the 2-D Frame Analysis module.

The Global Coordinate Axis system is oriented such that X points to the right, Y points upward, and Z is perpendicular to the screen in the 2-D Frame Analysis module.

The member local coordinate axis system is established as follows. A vector from the I node to the J node establishes the member local x axis. The vector cross product of local x cross Global Y produces the member local z direction. This works for all member orientations except for vertically oriented members, because it is not possible to take the vector cross product of two parallel vectors. So in those cases the module adopts the convention that the member local z axis will be parallel to the Global Z axis. These are just mathematical rules that establish that member local z will be perpendicular to the screen (unless you have specified that the member is working in weak axis bending). The local z axis is perpendicular to the web of a wide flange section. It typically represents the “strong” axis of a member. Finally, we need to establish the orientation of the local y axis. Vector cross product rules for a right-hand coordinate system also state that local z cross local x produces local y. So this pins down the orientation of the local y axis. The local y axis of a wide flange member lies in the plane of the web and is mutually perpendicular to the local x

and local z axes. For a horizontally oriented beam member, the local y axis points straight up, parallel to the Global Y axis.

## Result Sign Convention

Now for the sign conventions of the various results that are available.

## Joint Displacements

Joint Displacements are reported with respect to the Global Coordinate Axis system. A positive displacement indicates a displacement in the direction of the positive corresponding axis. A positive rotation indicates a positive rotation about the Global Z axis. (Using the thumb of the right hand, point the thumb in the direction of the positive Global Z axis, and the natural curl of the right fingers will indicate the direction of a positive rotation.)

## Reactions

Reactions are also reported with respect to the Global Coordinate Axis system. A positive force reaction indicates a force in the direction of the positive corresponding axis. A positive moment reaction indicates a positive moment about the Global Z axis. (Using the thumb of the right hand, point the thumb in the direction of the positive Global Z axis, and the natural curl of the right fingers will indicate the direction of a positive moment.)

## Member End Forces

Member End Forces are reported with respect to the member local coordinate axis system. A positive value of axial load at the I end of the member means that the force acts in the member local x direction, so it is pushing into the starting end of the member, so it represents a compressive force. Likewise, a negative value of axial load at the J end of the member means that the force acts in the member local -x direction, so it is pushing into the ending end of the member, so again this represents a compressive force.

Shears are also reported with respect to the member local coordinate axis system. A positive value of shear at the I end of the member means that the force acts in the member local y direction. Likewise, a negative value of shear at the J end of the member means that the force acts in the member local -y direction.

A positive value of moment at either end of the member means that the moment acts in the member local z direction. (Using the thumb of the right hand, point the thumb in the direction of the positive Global Z axis, and the natural curl of the right fingers will indicate the direction of a positive moment.)

## Member Forces at Sections

The physical sense of the member forces at sections can best be established by relating to the physical sense of the member end forces at the starting end of the member as described above.

### **Deflections (Relative to member ends)**

The deflections relative to member ends are measured parallel to the member local y axis and are referenced from the straight-line chord connecting the undeflected end node locations. Positive values represent deflections in the positive local y axis direction from that straight-line chord.



### 10.8.8 Frame Sketch

This tab provides a graphical display of the frame. You can use various check boxes, displacement magnification and load combination selection items to control the display.

You can quickly display a sketch of the frame when in another tab by hovering the cursor over the double rectangle icon in the upper right corner of the window. See small image below:



**2-D Frame Analysis**

General | Joints & Loads | Members & Loads | Sections & Materials | Load Combs | Results | **Sketch** | Diagrams | Reports

1-10 2-10 3-10 3-11 4-11 4-12 5-12 5-13 5-14 6-14 6-15 7-15 7-16 8-16 9-16

1-2 2-3 3-4 4-5 5-6 6-7 7-8 8-9

10-11 11-12 12-13 13-14 14-15 15-16

D(1)

Display Selections

<input checked="" type="checkbox"/> Show Undeformed	<input checked="" type="checkbox"/> Joints	<input checked="" type="checkbox"/> Members	<input checked="" type="checkbox"/> Show Loads	<input checked="" type="checkbox"/> Show Values	Load Combination.. +D+MbrWt(0,-1)
<input type="checkbox"/> Show Deformed	<input type="checkbox"/> Labels	<input checked="" type="checkbox"/> Labels	<input checked="" type="checkbox"/> Joint	<input type="checkbox"/> Member Point	
Magnification : 161.1	<input checked="" type="checkbox"/> Restraints	<input type="checkbox"/> Sections <input checked="" type="checkbox"/> Restraint	<input checked="" type="checkbox"/> Member Distributed		

## 10.8.9 Member Diagrams

This tab allows you to display axial load, moment, shear and deflection diagrams for each individual member in the frame.


You have two selection areas to use...

### Select Load Combination

This box lists all of the load combinations that are being run. Click on any of the available load combinations in the list to view diagrams based on that load combination.

### Select Member to Chart

This box lists all of the members in the frame. Click on any of the members in the list to view diagrams for that member.




### Tabs All, A, V, M, D

These tabs let you explore the force details for the selected member and load combination in different ways.

When the All tab is selected, the extreme values of axial load, moment, shear, and deflection are presented for the currently selected member.

The other tabs provide detailed list of the values for the currently selected which are used to create the respective diagrams.



Location	Shear
0.000	5.291
0.204	5.075
0.408	4.859
0.612	4.643
0.816	4.427
1.020	4.211
1.224	3.995
1.429	3.779
1.633	3.563
1.837	3.347
2.041	3.131
2.245	2.915
2.449	2.699
2.653	2.484
2.857	2.268
3.061	2.052
3.265	1.836
3.469	1.620
3.673	1.404
3.878	1.188
4.082	0.972
4.286	0.756
4.490	0.540
4.694	0.324

## 10.8.10 Reports

This tab lets you select what data to print from the frame analysis.

The screenshot shows the 'Reports' tab in a software interface. The title bar includes tabs for 'General', 'Joints & Loads', 'Members & Loads', 'Sections & Materials', 'Load Combs', 'Results', 'Sketch', 'Diagrams', and 'Reports'. Below the title bar is a link: 'Select Frame Data Areas To Print...'. The main area is divided into two sections: 'Input Data....' and 'Output Data...'.  
**Input Data....**  
 Joint Data  
 Joint Loads  
 Member Data  
 Member Point Loads  
 Member Distributed Loads  
 Member Stress Check Data  
 Material Data  
 Section Property Data  
 Load Combinations  
**Output Data....**  
 Joint Reactions & Displacements  
 Member End Forces  
 Member Envelope Results  
 Member Stress Check Results  
 Print Sketch of Frame  
Buttons on the right side of the 'Input Data....' section:  
Set All Areas to Print  
Set Input to Print  
Set Output to Print  
Clear all print selections

Under Output Data you have the choice of compressing the output to an Envelope Only status. If Envelope Only is not checked the full details will be printed which can result in many pages of output. It is advisable to look at a print preview to see what it generates.

Using Envelope Only will examine each table and print only the extreme values for each load combination.

### 10.8.11 Printout

Here is a sample printout for the current frame:



Joseph P. Engineer  
**GREAT ENGINEERING UNLIMITED**  
 1234 Main Street, 1st Floor  
 Anytown, USA 99221  
 jpe@GreatEngineering.com  
 Phone : (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:  
 Project Notes:


Job #

Printed: 18 APR 2018, 11:33AM

**2-D Frame Analysis**

File: C:\ENR\NA\_TBCH\EX\_FILE\Example2  
 ENERCALC, INC. Ver: 4.1.8  
 License Owner: licensed enercalc user

Lic # : MW05000216



Joins...

Joint Label	Joint Coordinates		X Restaint	Y Restaint	Z Restaint	Joint Temp deg F
	X ft	Y ft				
1	0.0	0.0	Fixed	Fixed	Fixed	0
2	20.667	0.0			Fixed	0
3	41.333	0.0			Fixed	0
4	62.0	0.0			Fixed	0
5	82.667	0.0			Fixed	0
6	103.33	0.0			Fixed	0
7	124.0	0.0		Fixed	Fixed	0
8	20.667	35.0			Fixed	0
9	41.333	35.0			Fixed	0
10	62.0	35.0			Fixed	0
11	82.667	35.0			Fixed	0
12	103.33	35.0			Fixed	0

Members...

Member Label	Property Label	End point Joins		Member Length ft	I End Releases			J End Releases		
		I Joint	J Joint		X	Y	Z	X	Y	Z
1-2	Chord	1	2	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
1-8	Diagonal	1	8	40.646	Fixed	Fixed	Free	Fixed	Fixed	Free
10-11	Chord	10	11	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
11-12	Chord	11	12	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
2-3	Chord	2	3	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
2-8	Vertical	2	8	35.000	Fixed	Fixed	Free	Fixed	Fixed	Free
3-4	Chord	3	4	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
3-8	Diagonal	3	8	40.646	Fixed	Fixed	Free	Fixed	Fixed	Free
3-9	Vertical	3	9	35.000	Fixed	Fixed	Free	Fixed	Fixed	Free
4-10	Vertical	4	10	35.000	Fixed	Fixed	Free	Fixed	Fixed	Free
4-11	Diagonal	4	11	40.646	Fixed	Fixed	Free	Fixed	Fixed	Free
4-5	Chord	4	5	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
4-9	Diagonal	4	9	40.646	Fixed	Fixed	Free	Fixed	Fixed	Free



Joseph P. Engineer  
 GREAT ENGINEERING UNLIMITED  
 1234 Main Street, 1st Floor  
 Anytown, USA, 99221  
 jpe@GreatEngineering.com  
 Phone : (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:

Job #

Project Notes:

File: E:\APP\218\113344

**2-D Frame Analysis**

Lic # : KW05000216

File: C:\EQUW\_TECH\EX\_FILES\example01  
 ENERCALC, INC. 2013-2014 Ver: 5.1.0  
 License Owner: licensed\_enercalc\_user

**Members...**

Member Label	Property Label	End point Joints		Member Length ft	I End Release			J End Release		
		I Joint	J Joint		X	Y	Z	X	Y	Z
5-11	Vertical	5	11	35.000	Fixed	Fixed	Free	Fixed	Fixed	Free
5-12	Diagonal	5	12	40.646	Fixed	Fixed	Free	Fixed	Fixed	Free
5-6	Chord	5	6	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
6-12	Vertical	6	12	35.000	Fixed	Fixed	Free	Fixed	Fixed	Free
6-7	Chord	6	7	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
7-12	Diagonal	7	12	40.646	Fixed	Fixed	Free	Fixed	Fixed	Free
8-9	Chord	8	9	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free
9-10	Chord	9	10	20.667	Fixed	Fixed	Free	Fixed	Fixed	Free

**Materials...**

Member Label	Young's Modulus ksi	Density pcf	Thermal Expansion in/Meg	Yield Strength ksi
Default	1.00	0.000	0.000000	1.00
Steel	29,000.00	0.490	0.000650	50.00
wood	1.00	65.000	1.000000	1.50

**Section Sections...**

Prop Label	Group Tag	Material	Area in <sup>2</sup>	Depth in	Width in	b <sub>x</sub> in	b <sub>y</sub> in
Default	Group	Default	1.0 in <sup>2</sup>	0.0 in	0.0 in	1.0 in	1.0 in
url4d45	Chord	Steel	42.70 in <sup>2</sup>	14.80 in	15.50 in	1,710.0 in <sup>4</sup>	677.0 in <sup>4</sup>
url4d45	Diagonal	Steel	42.70 in <sup>2</sup>	14.80 in	15.50 in	1,710.0 in <sup>4</sup>	677.0 in <sup>4</sup>
url4d45	Vertical	Steel	42.70 in <sup>2</sup>	14.80 in	15.50 in	1,710.0 in <sup>4</sup>	677.0 in <sup>4</sup>
5-23		Wood	18.750 in <sup>2</sup>	2.50 in	7.50 in	9.766 in <sup>4</sup>	87.891 in <sup>4</sup>

**Joint Loads...**

Joint Label	Load Direction	Load Magnitude						
		Dead	Roof Live	Live	Snow	Seismic	Wind	Earth
1	Global Y	1.0						k
2	Global Y	2.0						k
3	Global Y	3.0						k
4	Global Y	4.0						k
5	Global Y	5.0						k
6	Global Y	6.0						k
7	Global Y	7.0						k
8	Global Y	8.0						k
9	Global Y	9.0						k

**Member Point Loads...**

Member Label	Load Direction	Distance from "I" Joint ft	Load Magnitude						
			Dead	Roof Live	Live	Snow	Seismic	Wind	Earth
8-9	Global Y	5 ft	1.0						k

**Member Distributed Loads...**

Member Label	Load Direction	Load Extents Start End ft	Load Magnitude						
			Dead	Roof Live	Live	Snow	Seismic	Wind	Earth
8-9	Global Y	0.0 20.667	Start Mag: 1.0						k/ft
			End Mag: 1.0						k/ft

**Load Combinations...**

Load Combination Description	Group Multiplier	Gravity Load Factors		Load Combination Factors						
		X	Y	Dead	Roof Live	Live	Snow	Seismic	Wind	Earth
+D	1.0	1.0	1.0	1.0						
+D+L+H	1.0	1.0	1.0	1.0		1.0				1.0
+D+Lr+H	1.0	1.0	1.0	1.0	1.0					1.0
+D+S+H	1.0	1.0	1.0	1.0				1.0		1.0
0.3(+D+2.0Lr+3.0L+4.0S+6.0W+6.0E+7.0H)	0.30	-1.0	-1.0	1.0	2.0	3.0	4.0	6.0	5.0	7.0
+D+0.750L+0.750Lr+H	1.0	1.0	1.0	0.750	0.750					1.0
+D+0.750L+0.750S+H	1.0	1.0	1.0	1.0		0.750	0.750			1.0



Joseph P. Engineer  
 GREAT ENGINEERING UNLIMITED  
 1234 Main Street, 1st Floor  
 Anytown, USA 99221  
 jpe@GreatEngineering.com  
 Phone : (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:

Job #

Project Notes:

Date: 18 APR 2018, 11:30AM

2-D Frame Analysis

Lic # : KW05000216

File: C:\ECHO\TECH\FILES\Completed  
 ENERCALC, INC. 2013-2018 Ver: 1.13  
 License Owner: licensed\_enercalc\_user

Load Combinations...

Load Combination Description	Group Multiplier	Gravity Load Factors		Load Combination Factors								
		X	Y	Dead	Roof Live	Live	Snow	Seismic	Wind	Earth		
+D+0H	1.0	1.0	1.0	1.0								1.0
+D+0.70E+H	1.0	1.0	1.0	1.0					0.70			1.0
+D+0.750L+0.750L+0.7500W+H	1.0	1.0	1.0	1.0	0.750	0.750				0.750		1.0
+D+0.750L+0.750S+0.7500W+H	1.0	1.0	1.0	1.0		0.750	0.750	0.750			0.750	1.0
+D+0.750L+0.750L+0.5250E+H	1.0	1.0	1.0	1.0	0.750	0.750			0.5250			1.0
+D+0.750L+0.750S+0.5250E+H	1.0	1.0	1.0	1.0		0.750	0.750	0.750	0.5250			1.0
+0.60D+0W+H	1.0	1.0	1.0	0.60							1.0	1.0
+0.60D+0.70E+H	1.0	1.0	1.0	0.60					0.70			1.0
+1.40D	1.0	1.0	1.0	1.40								
+1.20D+0.50L+1.60L+1.60H	1.0	1.0	1.0	1.20	0.50	1.60						1.60
+1.20D+1.60L+0.50S+1.60H	1.0	1.0	1.0	1.20		1.60	0.50					1.60
+1.20D+1.60L+0.50L	1.0	1.0	1.0	1.20	1.60	0.50						
+1.20D+1.60L+0.80W	1.0	1.0	1.0	1.20	1.60					0.80		
+1.20D+0.50L+1.60S	1.0	1.0	1.0	1.20		0.50	1.60					1.60
+1.20D+1.60S+0.80W	1.0	1.0	1.0	1.20			1.60			0.80		
+1.20D+0.50L+0.50L+1.60W	1.0	1.0	1.0	1.20	0.50	0.50						1.60
+1.20D+0.50L+0.50S+1.60W	1.0	1.0	1.0	1.20		0.50	0.50					1.60
+1.20D+0.50L+0.20S+E	1.0	1.0	1.0	1.20		0.50	0.20		1.0			
+0.90D+1.60W+1.60H	1.0	1.0	1.0	0.90						1.60		1.60
+0.90D+E+1.60H	1.0	1.0	1.0	0.90					1.0			1.60
+D+L+L+S+W+E+H	1.0	1.0	-1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Joint Displacements & Reactions for Load Combination :

Joint Label	LoadCombination	Joint Displacements			Joint Reactions		
		X in	Y in	Z Radians	X k	Y k	Z k-ft
1	+D	0.0	0.000	0.0	0.000	-7.152	0.0
2	+D	-0.000437	0.008754	0.0	0.0	0.0	0.0
3	+D	-0.000875	0.01756	0.0	0.0	0.0	0.0
4	+D	-0.002411	0.030	0.0	0.0	0.0	0.0
5	+D	-0.005928	0.02812	0.0	0.0	0.0	0.0
6	+D	-0.008248	0.01780	0.0	0.0	0.0	0.0
7	+D	-0.01057	0.000	0.0	0.0	-17.072	0.0
8	+D	-0.009461	0.007551	0.0	0.0	0.0	0.0
9	+D	-0.007925	0.01885	0.0	0.0	0.0	0.0
10	+D	-0.004630	0.03188	0.0	0.0	0.0	0.0
11	+D	-0.001334	0.03036	0.0	0.0	0.0	0.0
12	+D	0.002182	0.01795	0.0	0.0	0.0	0.0
1	+D+L+H	0.0	0.000	0.0	0.000	-7.152	0.0
2	+D+L+H	-0.000437	0.008754	0.0	0.0	0.0	0.0
3	+D+L+H	-0.000875	0.01756	0.0	0.0	0.0	0.0
4	+D+L+H	-0.002411	0.030	0.0	0.0	0.0	0.0
5	+D+L+H	-0.005928	0.02812	0.0	0.0	0.0	0.0
6	+D+L+H	-0.008248	0.01780	0.0	0.0	0.0	0.0
7	+D+L+H	-0.01057	0.000	0.0	0.0	-17.072	0.0
8	+D+L+H	-0.009461	0.007551	0.0	0.0	0.0	0.0
9	+D+L+H	-0.007925	0.01885	0.0	0.0	0.0	0.0
10	+D+L+H	-0.004630	0.03188	0.0	0.0	0.0	0.0
11	+D+L+H	-0.001334	0.03036	0.0	0.0	0.0	0.0
12	+D+L+H	0.002182	0.01795	0.0	0.0	0.0	0.0
1	+D+L+H	0.0	0.000	0.0	0.000	-7.152	0.0
2	+D+L+H	-0.000437	0.008754	0.0	0.0	0.0	0.0
3	+D+L+H	-0.000875	0.01756	0.0	0.0	0.0	0.0
4	+D+L+H	-0.002411	0.030	0.0	0.0	0.0	0.0
5	+D+L+H	-0.005928	0.02812	0.0	0.0	0.0	0.0
6	+D+L+H	-0.008248	0.01780	0.0	0.0	0.0	0.0
7	+D+L+H	-0.01057	0.000	0.0	0.0	-17.072	0.0
8	+D+L+H	-0.009461	0.007551	0.0	0.0	0.0	0.0
9	+D+L+H	-0.007925	0.01885	0.0	0.0	0.0	0.0
10	+D+L+H	-0.004630	0.03188	0.0	0.0	0.0	0.0
11	+D+L+H	-0.001334	0.03036	0.0	0.0	0.0	0.0
12	+D+L+H	0.002182	0.01795	0.0	0.0	0.0	0.0
1	+1.40D	0.0	0.000	0.0	0.0	8.165	0.0



Joseph P. Engineer  
 GREAT ENGINEERING UNLIMITED  
 1234 Main Street, 1st Floor  
 Anytown, USA 99221  
 jpe@GreatEngineering.com  
 Phone : (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:

Job #

Project Notes:

Date: 18 APR 2018, 11:20AM

2-D Frame Analysis

File: C:\ENR\14\_TECHEC\FILES\Completed  
 ENERCALC, INC. 803-222-1122 Ver: 1.13  
 License Owner: licensed\_enercalc\_user

Lic #: MW05000216

Joint Displacements & Reactions for Load Combination :

Joint Label	Load Combination	Joint Displacements			Joint Reactions		
		X in	Y in	Z Radians	X k	Y k	Z k-ft
2	+1.40D	0.001327	-0.005306	0.0	0.0	0.0	0.0
3	+1.40D	0.002654	-0.003453	0.0	0.0	0.0	0.0
4	+1.40D	0.003648	0.007761	0.0	0.0	0.0	0.0
5	+1.40D	0.001869	0.01133	0.0	0.0	0.0	0.0
6	+1.40D	0.000560	0.007353	0.0	0.0	0.0	0.0
7	+1.40D	-0.000749	0.0000	0.0	0.0	-5.722	0.0
8	+1.40D	0.000469	-0.006237	0.0	0.0	0.0	0.0
9	+1.40D	-0.000525	-0.003957	0.0	0.0	0.0	0.0
10	+1.40D	0.000542	0.009642	0.0	0.0	0.0	0.0
11	+1.40D	0.001608	0.01217	0.0	0.0	0.0	0.0
12	+1.40D	0.003386	0.008321	0.0	0.0	0.0	0.0

Member End Forces for Load Combination :

Member Label	Load Combination	Joint "I" End Forces			Joint "J" End Forces		
		Axial k	Shear k	Moment k-ft	Axial k	Shear k	Moment k-ft
1-2	+D	2.184	-1.501	0.0	-2.184	-1.501	0.0
1-8	+D	-6.837	-1.501	0.0	1.752	-1.501	0.0
10-11	+D	-16.453	-1.501	0.0	16.453	-1.501	0.0
11-12	+D	-17.560	-1.501	0.0	17.560	-1.501	0.0
2-3	+D	2.184	-1.501	0.0	-2.184	-1.501	0.0
2-8	+D	1.003	0.0	0.0	-6.088	0.0	0.0
3-4	+D	7.671	-1.501	0.0	-7.671	-1.501	0.0
3-8	+D	8.250	1.501	0.0	-13.336	1.501	0.0
3-9	+D	-6.338	0.0	0.0	1.253	0.0	0.0
4-10	+D	-8.088	0.0	0.0	3.003	0.0	0.0
4-11	+D	-4.720	-1.501	0.0	-0.3650	-1.501	0.0
4-5	+D	17.560	-1.501	0.0	-17.560	-1.501	0.0
4-9	+D	14.729	1.501	0.0	-19.814	1.501	0.0
5-11	+D	-9.166	0.0	0.0	4.081	0.0	0.0
5-12	+D	9.212	-1.501	0.0	-14.297	-1.501	0.0
5-6	+D	11.584	-1.501	0.0	-11.584	-1.501	0.0
6-12	+D	-2.997	0.0	0.0	-2.088	0.0	0.0
6-7	+D	11.584	-1.501	0.0	-11.584	-1.501	0.0
7-12	+D	-25.325	1.501	0.0	20.239	1.501	0.0
8-9	+D	-7.671	9.590	0.0	7.671	9.074	0.0
9-10	+D	-16.453	-1.501	0.0	16.453	-1.501	0.0
1-2	+D+L+H	2.184	-1.501	0.0	-2.184	-1.501	0.0
1-8	+D+L+H	-6.837	-1.501	0.0	1.752	-1.501	0.0
10-11	+D+L+H	-16.453	-1.501	0.0	16.453	-1.501	0.0
11-12	+D+L+H	-17.560	-1.501	0.0	17.560	-1.501	0.0
2-3	+D+L+H	2.184	-1.501	0.0	-2.184	-1.501	0.0
2-8	+D+L+H	1.003	0.0	0.0	-6.088	0.0	0.0
3-4	+D+L+H	7.671	-1.501	0.0	-7.671	-1.501	0.0
3-8	+D+L+H	8.250	1.501	0.0	-13.336	1.501	0.0
3-9	+D+L+H	-6.338	0.0	0.0	1.253	0.0	0.0
4-10	+D+L+H	-8.088	0.0	0.0	3.003	0.0	0.0
4-11	+D+L+H	-4.720	-1.501	0.0	-0.3650	-1.501	0.0
4-5	+D+L+H	17.560	-1.501	0.0	-17.560	-1.501	0.0
4-9	+D+L+H	14.729	1.501	0.0	-19.814	1.501	0.0
5-11	+D+L+H	-9.166	0.0	0.0	4.081	0.0	0.0
5-12	+D+L+H	9.212	-1.501	0.0	-14.297	-1.501	0.0
5-6	+D+L+H	11.584	-1.501	0.0	-11.584	-1.501	0.0
6-12	+D+L+H	-2.997	0.0	0.0	-2.088	0.0	0.0
6-7	+D+L+H	11.584	-1.501	0.0	-11.584	-1.501	0.0
7-12	+D+L+H	-25.325	1.501	0.0	20.239	1.501	0.0
8-9	+D+L+H	-7.671	9.590	0.0	7.671	9.074	0.0
9-10	+D+L+H	-16.453	-1.501	0.0	16.453	-1.501	0.0
1-2	+D+L+H	2.184	-1.501	0.0	-2.184	-1.501	0.0
1-8	+D+L+H	-6.837	-1.501	0.0	1.752	-1.501	0.0
10-11	+D+L+H	-16.453	-1.501	0.0	16.453	-1.501	0.0
11-12	+D+L+H	-17.560	-1.501	0.0	17.560	-1.501	0.0





Joseph P. Engineer  
 GREAT ENGINEERING UNLIMITED  
 1234 Main Street, 1st Floor  
 Anytown, USA 99221  
 je@GreatEngineering.com  
 Phone : (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:

Job #

Project Notes:

**2-D Frame Analysis**

Lic # : MW05000216

File: E:\APP\318\_11234\...  
 R:\C:\EN\44\_TECH\EX\_FILES\example...  
 ENERCALC, INC. 2013-2014 Ver: 1.1a  
 License Owner: licensed\_enercalc\_user

**Member End Forces for Load Combination :**

Member Label	Load Combination	Joint "I" End Forces			Joint "J" End Forces		
		Axial k	Shear k	Moment k-ft	Axial k	Shear k	Moment k-ft
2-3	+D+L+H	2.184	-1.501	0.0	-2.184	-1.501	0.0
2-8	+D+L+H	1.003	0.0	0.0	-6.088	0.0	0.0
3-4	+D+L+H	7.671	-1.501	0.0	-7.671	-1.501	0.0
3-8	+D+L+H	8.250	1.501	0.0	-13.336	1.501	0.0
3-9	+D+L+H	-6.338	0.0	0.0	1.253	0.0	0.0
4-10	+D+L+H	-8.088	0.0	0.0	3.003	0.0	0.0
4-11	+D+L+H	-4.720	-1.501	0.0	-0.3650	-1.501	0.0
4-5	+D+L+H	17.560	-1.501	0.0	-17.560	-1.501	0.0
4-9	+D+L+H	14.729	1.501	0.0	-19.814	1.501	0.0
5-11	+D+L+H	-9.166	0.0	0.0	4.081	0.0	0.0
5-12	+D+L+H	9.212	-1.501	0.0	-14.297	-1.501	0.0
5-6	+D+L+H	11.584	-1.501	0.0	-11.584	-1.501	0.0
6-12	+D+L+H	-2.997	0.0	0.0	-2.088	0.0	0.0
6-7	+D+L+H	11.584	-1.501	0.0	-11.584	-1.501	0.0
7-12	+D+L+H	-25.325	1.501	0.0	20.239	1.501	0.0
8-9	+D+L+H	-7.671	9.590	0.0	7.671	9.074	0.0
9-10	+D+L+H	-16.453	-1.501	0.0	16.453	-1.501	0.0
1-2	+1.40D	-6.625	-1.501	0.0	6.625	-1.501	0.0
1-8	+1.40D	10.486	-1.501	0.0	-15.572	-1.501	0.0
10-11	+1.40D	-5.323	-1.501	0.0	5.323	-1.501	0.0
11-12	+1.40D	-8.881	-1.501	0.0	8.881	-1.501	0.0
2-3	+1.40D	-6.625	-1.501	0.0	6.625	-1.501	0.0
2-8	+1.40D	0.2028	0.0	0.0	-5.288	0.0	0.0
3-4	+1.40D	-4.964	-1.501	0.0	4.964	-1.501	0.0
3-8	+1.40D	0.7243	1.501	0.0	-5.810	1.501	0.0
3-9	+1.40D	-1.057	0.0	0.0	-4.028	0.0	0.0
4-10	+1.40D	-8.088	0.0	0.0	3.003	0.0	0.0
4-11	+1.40D	-9.539	-1.501	0.0	4.454	-1.501	0.0
4-5	+1.40D	8.881	-1.501	0.0	-8.881	-1.501	0.0
4-9	+1.40D	17.689	1.501	0.0	-22.775	1.501	0.0
5-11	+1.40D	-5.017	0.0	0.0	-0.06889	0.0	0.0
5-12	+1.40D	2.070	-1.501	0.0	-7.156	-1.501	0.0
5-6	+1.40D	6.535	-1.501	0.0	-6.535	-1.501	0.0
6-12	+1.40D	-5.397	0.0	0.0	0.3117	0.0	0.0
6-7	+1.40D	6.535	-1.501	0.0	-6.535	-1.501	0.0
7-12	+1.40D	-15.396	1.501	0.0	10.311	1.501	0.0
8-9	+1.40D	4.964	14.027	0.0	-4.964	13.304	0.0
9-10	+1.40D	-5.323	-1.501	0.0	5.323	-1.501	0.0

**Maximum Member Forces**

Only Load Combinations giving maximum values are listed

Member Label	Axial	Distance from "I" Joint	Moment	Distance from "I" Joint	Shear	Distance from "I" Joint
1-2	-6.625 k	0.0 ft +1.40D	7.754 k-ft	0.8435 ft +D	-1.501 k	0.0 ft +D
1-8	15.572 k	3.387 ft +1.40D	15.250 k-ft	1.728 ft +1.40D	-1.501 k	0.0 ft +1.40D
10-11	-16.453 k	0.0 ft +D	7.754 k-ft	0.8435 ft +D	-1.501 k	0.0 ft +D
11-12	-17.560 k	0.0 ft +D	7.754 k-ft	0.8435 ft +D	-1.501 k	0.0 ft +D
2-3	-6.625 k	0.0 ft +1.40D	7.754 k-ft	0.8435 ft +D	-1.501 k	0.0 ft +D
2-8	6.088 k	2.317 ft +D	0.0 k-ft	0.0 ft	0.0 k	0.0 ft
3-4	7.671 k	0.0 ft +D	7.754 k-ft	0.8435 ft +D	-1.501 k	0.0 ft +D
3-8	13.336 k	3.387 ft +D	-15.250 k-ft	1.728 ft +1.40D	1.501 k	0.0 ft +1.40D
3-9	-6.338 k	0.0 ft +D	0.0 k-ft	0.0 ft	0.0 k	0.0 ft



Joseph P. Engineer  
 GREAT ENGINEERING UNLIMITED  
 1234 Main Street, 1st Floor  
 Anytown, USA 99221  
 je@GreatEngineering.com  
 Phone : (800) 111-2222

Title :  
 Dsgnr:  
 Project Desc.:  
 Project Notes:

Job #

### 2-D Frame Analysis

Lic # : MW05000216

File: # APP 218, 112344  
 File: C:\EQW\TECH\EQ\_FILES\example2  
 ENERCALC, INC. 2013-2014 Ver: 5.1.0  
 License Owner: licensed\_enercalc\_user

Maximum Member Forces						
Only Load Combination giving maximum values are listed						
Member Label	Axial	Distance from "I" Joint	Moment	Distance from "I" Joint	Shear	Distance from "I" Joint
4-10	-8.088 k	0.0 英尺 +1.400	0.0 k-英尺	0.0 英尺	0.0 k	0.0 英尺
4-11	-9.539 k	0.0 英尺 +1.400	15.250 k-英尺	1.728 英尺 +1.400	1.501 k	3.387 英尺 +0
4-5	17.560 k	0.0 英尺 +0	7.754 k-英尺	0.8435 英尺 +0	-1.501 k	0.0 英尺 +0
4-9	22.775 k	3.387 英尺 +1.400	-15.250 k-英尺	1.728 英尺 +1.400	-1.501 k	3.387 英尺 +0
5-11	-9.166 k	0.0 英尺 +0	0.0 k-英尺	0.0 英尺	0.0 k	0.0 英尺
5-12	14.297 k	3.387 英尺 +0	15.250 k-英尺	1.728 英尺 +0	-1.501 k	0.0 英尺 +0
5-6	11.584 k	0.0 英尺 +0	7.754 k-英尺	0.8435 英尺 +0	-1.501 k	0.0 英尺 +0
6-12	-5.397 k	0.0 英尺 +1.400	0.0 k-英尺	0.0 英尺	0.0 k	0.0 英尺
6-7	11.584 k	0.0 英尺 +0	7.754 k-英尺	0.8435 英尺 +0	-1.501 k	0.0 英尺 +0
7-12	-25.325 k	0.0 英尺 +0	-15.250 k-英尺	1.728 英尺 +0	1.501 k	0.0 英尺 +0
8-9	-7.671 k	0.0 英尺 +0	-70.531 k-英尺	0.8435 英尺 +1.400	14.027 k	0.0 英尺 +1.400
9-10	-16.453 k	0.0 英尺 +0	7.754 k-英尺	0.8435 英尺 +0	-1.501 k	0.0 英尺 +0

## 10.9 Miscellaneous Calculation Modules

## 10.9.1 Torsional Analysis of Rigid Diaphragm

[Need more? Ask Us a Question](#)

This module provides horizontal force distribution analysis for a rigid diaphragm laterally supported by up to 160 resisting elements (walls, columns or generic resisting elements).

Click here for a video:

Torsional Analysis of Rigid Diaphragm

The lateral shear force is applied to the rigid diaphragm, and that force is distributed to all elements after the rotational stiffness analysis has been completed.

All lateral forces are distributed to each element on the basis of relative rigidities and resisting element locations. Lateral shear forces, direct torsional forces, and accidental eccentricity torsional forces are considered after determining the location of the center of rigidity.

The module provides analysis for one level only. For structures where elements are symmetrically placed on many levels, a calculation may be performed for each level and results added to determine shears and overturning moments for each element. When determining center of mass (where the lateral force is applied) on successively lower levels when elements are NOT all aligned vertically, a new center of mass position should be calculated based upon element forces acting from the diaphragm from the level above and combined with the force at that level.

A very unique capability of this module is to have the applied lateral load applied at angular increments for a full 360 degree rotation. The prior version of this module in our Version 5.8 software only applied the lateral load at 90 degree increments. Because seismic or wind loads can occur at any angle, we provide the ability for the user to define the angles at which the lateral load is applied to the rigid diaphragm for distribution to the resisting elements.

When the lateral force is rotated around the specified number of angular increments, the user has two options for specifying the magnitude of the force to consider at each angular orientation. One option is to specify the magnitude of the applied lateral force and an optional orthogonal force magnitude that will be considered to act concurrently. When this option is selected, the program uses the same magnitude for the resultant lateral force at all angular increments, and that magnitude is calculated as the SRSS of the applied lateral force and the orthogonal force. The second option is to specify the magnitude of the applied lateral force when the force points in the X direction and the magnitude of the applied lateral force when the force points in the Y direction. When this option is selected, the program considers the lateral force to vary in an elliptical manner as the angular orientation of the force changes. When the force is considered to act at the zero-degree orientation, the magnitude will be exactly equal to the specified lateral force in the X direction. As the angular orientation changes, the lateral force will vary in that elliptical manner. When the force is considered to act at the 90-degree orientation, the lateral force will be exactly equal to the specified force in the Y direction, and so on.

Another unique feature is the handling of the accidental eccentricity. The code specifies that an accidental eccentricity must be considered, as it will have an effect on the total torsional moment applied to the diaphragm. The minimum eccentricity is typically specified as 5% of the building dimension measured perpendicular to the direction of load application. To thoroughly address the eccentricity requirements, this module creates an ellipse measuring 5% (or the specified value) of the building dimension on each axis, around which the lateral load is applied.

*Technical note: Prior to build 6.15.7.24, this module neglected the shear due to the torsional component of load if it was of the opposite algebraic sign to the direct shear component, because considering that component would reduce the total shear on the particular element being considered. However, build 6.15.7.24 introduced a user option to change this behavior. It appears in the form of a checkbox labeled "Neglect torsional shear component when it reduces total shear in element". If this option is selected, the program will operate in the way that it used to prior to build 6.15.7.24. If this option is Deselected, the program will **always** consider the shears due to torsion (inherent and accidental), even if they are of opposite algebraic sign to the direct shears and therefore tend to reduce the total shears in an element.*

So to recap.....the applied lateral load is applied at the angular increments you specify for a full 360 degrees, and this is performed for the number of angular locations you specify around the minimum eccentricity ellipse. This means if you use 15 degree angular increments for load direction and 15 degree increments for accidental eccentricity, then the lateral load is actually applied  $(360/15+1) * (360/15+1) = 625$  times in various locations and directions. This can provide a very accurate calculation of applied torsions and direct shears to all resisting elements connected to a rigid diaphragm.

**Torsional Analysis of Rigid Diaphragm**

General | Resisting Elements

Description: Building Diaphragm

Measurements

Location of Shear Application :  
 Distance from "X" datum point . . . . . 10.0 ft  
 Distance from "Y" datum point . . . . . ft

Accidental Torsion :  
 Ecc. as % of Maximum Dimension . . . . . 5.0 %

Maximum Dimensions :  
 Along "X" Axis . . . . . 200.0 ft  
 Along "Y" Axis . . . . . 100.0 ft

Additional Eccentricity +/- from :  
 "X" Coord. of Load Application : 10.0 ft  
 "Y" Coord. of Load Application : 5.0 ft

Loading

Specify Primary & Orthogonal Force  
 Applied Lateral Force X Direction . . . 100.000 k  
 Applied Lateral Force Y Direction . . . 200.000 k

Specify Noncurrent X & Y Forces  
 Note: These loads are resolved into X & Y components when applied to the system of elements at angular increments.

Load Angular Increment  
 Smaller = more load applications  
 1 deg | 15 deg | 30 deg | 45 deg | 90 deg | 0 & 180  
 90 & 270 | Specify : | Only One :

Accidental Eccentricity Angular Increment 1.0 degrees

Summary Maximums | Force Summary in Detail | Stiffness Values | Datum to Center of Rigidity : (X, Y) = 0.000, 11.136 ft

Forces Summary for each Resisting Element

Resisting Item Label	Load Angle	Max. Shear Along MAJOR Axis (k)			Shear Force	Max. Shear Along MINOR Axis (k)		
		X Ecc	Y Ecc	Y Ecc		X Ecc	Y Ecc	Y Ecc
A	340	-18.29	-8.34	58.681	90	0.00	-11.14	5.195
B	205	-18.83	-13.48	49.323	90	0.00	-11.14	3.711
C	273	0.00	-11.31	95.682	4	-12.76	-15.94	1.518
D	87	-20.00	-11.22	113.580	4	-12.76	-15.94	1.518

## Basic Usage

- The most important step for successful use of this module is to properly enter the X and Y location of the center of rigidity of each resisting element and its angle in degrees counterclockwise from a normal Cartesian "0" degree orientation.
- For each resisting element, its center of rigidity will be at the centroid of the element.
- Default angular orientation of elements is as follows:
  - Walls: When rotation is zero, length (local y) is parallel to Global X (points right on the screen), and local x points downward on the screen.
  - Bending Members: When rotation is zero, local y is parallel to Global X (points right on the screen), and local x points downward on the screen.
  - Generic Resisting Elements: When rotation is zero, local y is parallel to Global X (points right on the screen), and local x points downward on the screen.
- When rotation angles are applied to resisting elements, the angle increases positively in a counterclockwise direction. Enter all angles as positive.
- Lateral shears are typically the force at the diaphragm level due to wind or seismic forces at that level. Location of Shear Application specifies the X-Y coordinates of the center of the load ellipse where the lateral shears act. If lateral forces must be added to the diaphragm from the level above or below, you must combine all forces to calculate an adjusted mass application point. Maximum Dimensions are used to

calculate the minimum additional eccentricity that will be added to and subtracted from the inherent eccentricity to calculate governing forces for each resisting element.

- When defining walls as resisting elements, the thickness, length, and height are required for each wall providing lateral support to the diaphragm. These values are used with the elastic modulus to establish the relative stiffness of each wall. For other resisting elements you can enter the section information or just enter the resisting element deflection under the same load for all elements.
- The Elastic Modulus does not have to be an exact value if all of the elements are of identical construction. In this situation, it may be simpler to just use a value of 1.
- X & Y Distances for each resisting element define the location of the center of stiffness of each element in plan view. This location will be used when combining all stiffnesses and calculating the overall center of rigidity for all elements acting as a system.
- Enter the fixity condition that best describes the element's top and bottom restraint against rotation about the longitudinal and transverse axes. Fix-Pin would be appropriate for an inverted pendulum condition (where walls or columns cantilever up from a fixed base condition, but are free to rotate at their tops). Fix-Pin would also be appropriate for a moment frame structure with pinned column bases (a structure that behaves like a table). Fix-Fix would be appropriate for conditions where both the tops and the bottoms of the columns and/or walls are fixed against rotation about their longitudinal and transverse axes. This setting results in double curvature in the vertical lateral force resisting elements.

### Unique Features

This module uses a numerical approach to determine center of rigidity location and to distribute lateral forces to each resisting element. Because resisting elements may be located at any angle, a rigorous stiffness analysis is performed, calculating each element's stiffness about both axes and combining the stiffnesses of all the elements to determine a center of rigidity location.

### Coordinate System

Please note that a strict X-Y coordinate system should be used to ensure that the analysis is properly carried out. When setting up a model, remember that Global X increases to the right and Global Y increases up the screen.

### General Input Tab

## Loading

### Specify Primary & Orthogonal Force

#### Applied Lateral Force

This is the main force applied to the rigid diaphragm. The location of application is defined by the load ellipse, the center of which is specified in the input item labeled Location of Shear Application.

#### Additional Orthogonal Force

This is an optional force that is applied at a 90-degree angle to the main force. Some codes specify that this force must be applied concurrently with the main force.

#### Maximum Load Used for Analysis

This is the resultant force applied to the diaphragm, calculated as  $\sqrt{\text{Main}^2 + \text{Orthogonal}^2}$ .

### Specify Nonconcurrent X & Y Forces

#### Applied Lateral Force X Direction

This is the magnitude of the lateral force applied to the rigid diaphragm when the load is oriented at exactly zero or 180 degrees.

#### Applied Lateral Force Y Direction

This is the magnitude of the lateral force applied to the rigid diaphragm when the load is oriented at exactly 90 or 270 degrees.

When the load orientation is anywhere between the cardinal directions, the magnitude of the applied lateral force is determined by assuming that the lateral force follows a smoothly varying elliptical function.

The location of application is defined by the load ellipse, the center of which is specified in the input item labeled Location of Shear Application.



### Load Angular Increment

This module allows the force to be applied to the rigid diaphragm in almost all angular directions.

According to the entry for angular increment, the module will apply the load to the diaphragm at multiple angular increments. For example, if you select "15 deg", the module will apply the lateral load at 0, 15, 30 degrees, etc. When the Load Angular Increment is set to smaller values, it will result in slightly longer calculation times, but it will also allow the module to "zero in" more accurately on the actual maximum shear forces in all of the resisting elements.

Note that there is also an option named "Specify". This allows you to specify an angular increment for the direction of load.

### Accidental Eccentricity Angular Increment

Most building codes require the consideration of an "accidental eccentricity". This is a prescribed additional amount of moment arm that must be compounded with the inherent eccentricity that already exists in the system; i.e. the distance between the center of rigidity and the center of mass for seismic loads or the distance between the center of rigidity and the center of exposure for wind loads. This additional eccentricity accounts for the variability of the exact location of the center of rigidity in normal as-built conditions.

Normally an "X direction" and a "Y direction" accidental eccentricity would be determined as a function (typically 5%) of the overall building dimension perpendicular to each direction. Then, the X directed force would be applied at two locations:

- center of mass PLUS "Y direction" eccentricity, and
- center of mass MINUS "Y direction" eccentricity.

And the Y directed force would be applied at two locations:

- center of mass PLUS "X direction" eccentricity, and
- center of mass MINUS "X direction" eccentricity.

However, in this module the "X direction" and "Y direction" eccentricities are used to specify the dimensions of an ellipse that encircles the center of mass. This ellipse creates a continuous path that smoothly incorporates the "X direction" and "Y direction" eccentricities. In this way, it defines all possible locations where the load should be applied to account for all possible accidental eccentricity locations.

The entry for Accidental Eccentricity Angular Increment specifies the angular increment that will be used to subdivide the ellipse into a number of locations where the force will be applied to the diaphragm.

### Summary of Angular Increment & Accidental Eccentricity Angular Increment

The module applies the lateral load at the "Load Angular Increments" at each location of "Accidental Eccentricity Angular Increment" to generate an extensive set of results from which the maximum force values for each resisting element may be inspected.

For example, setting both "Load Angular Increment" and "Accidental Eccentricity Angular Increment" to 15 degrees tells the module to run  $(360/15 + 1) * (360/15 + 1) = 625$  separate analyses of force distributions to the resisting elements.

### Location of Shear Application

This specifies the X and Y location of the center of mass. The Accidental Eccentricity ellipse will be circumscribed around this location.

### Accidental Torsion Values

Accidental torsion is defined as a percentage of overall constructed diaphragm dimension in each of two orthogonal directions. Therefore enter the necessary eccentricity percentage and both maximum diaphragm dimensions here.

### When Stiffness deflections are 0.00, assume completely flexible

Note the option named "When Stiffness deflections are 0.00, assume completely flexible". This option can be used if your intent is to specify that an element is completely flexible in the weak direction. In this situation, you would need to specify an infinite deflection in that direction. So as a convenience, the system has been configured such that when this option is selected, it will interpret a deflection value of 0.00 as meaning that the element is completely flexible in that direction (i.e. has no ability to resist an applied force in that direction).

## Resisting Elements Tab

**Torsional Analysis of Rigid Diaphragm**

Resisting Element Type :  Use a Wall  Use a Bending Member  Use Generic Resisting Element

Resisting Element List . . . *CLICK ON LINE to edit values*

Label	Wall Dimensions			Fixity		Resisting Element C.G.		Angle deg	Top Deflection Per Kip	
	Height	Length	Thick.	Major	Minor	X (ft)	Y (ft)		Major Axis	Minor Axis
A	10.00	14.00	12.00	Fix-Fix	Fix-Fix	0.00	50.00	0.0	2.0894E-004	6.1310E-003
B	10.00	10.00	12.00	Fix-Fix	Fix-Fix	0.00	-50.00	0.0	3.3333E-004	8.5833E-003
C	10.00	10.00	12.00	Fix-Fix	Fix-Fix	-50.00	0.00	90.0	3.3333E-004	8.5833E-003
D	10.00	10.00	12.00	Fix-Fix	Fix-Fix	50.00	0.00	90.0	3.3333E-004	8.5833E-003

Wall Data

Label:

X - C.G.:  ft

Y - C.G.:  ft

Wall Stiffness & Rotation :

Wall Rotation:  deg 0 90  
(Ctrl+ClickWise, 0 -> 179 deg)

Height:  ft

Major Axis Length:  ft

Minor Axis Thickness:  in

Length Axis: Wall End Fixity:  Fix-Fix  Fix-Pin

Thickness Axis: Wall End Fixity:  Fix-Fix  Fix-Pin

E-bend:  Mpsi

E-shear:  Mpsi

Set Ev = 0.4 Eb

Calculate Top Deflection per Kip :

$$\frac{P.H^3}{12EI_b} + \frac{1.2.P.H}{AE_v} : \frac{P.H^3}{12EI_b} + \frac{1.2.P.H}{AE_v}$$


Major Defl. = .0894E-004in      Minor Defl. = .1310E-003in

### Resisting Element Type

This module allows you to use three types of resisting elements. In past versions of this module, only walls were allowed. But many users wanted to enter information for braced frames or cantilevered columns for open buildings. So we've expanded this module to allow more general types of lateral resisting elements.


**WALL:** Click the [**Use a Wall**] button to define a wall as a resisting element. The wall must be rectangular in plan and must have a non-zero height. The selections for "Fix" and "Pin" will alter the equation used to calculate deflection in BOTH directions of the wall (unless the option is selected to "Consider all minor axis wall stiffnesses to be negligible"). Using the entered height, length, thickness, and modulus of

elasticity for bending and shear, the module will calculate the bending and shear stiffness of the wall and report the deflection for a unit 1 kip applied load.




Note: The option to "Consider all minor axis wall stiffnesses to be negligible" allows walls to be modeled with a weak spring stiffness resisting flexure about the weak axis. It will tend to minimize the stiffness of walls about that axis, so they will not pick up much loading in the weak direction.

**BENDING MEMBER:** Click the [Use a Bending Member] button to define a bending member (such as a column) as a resisting element. This will be a linear member whose stiffness is specified simply by its X and Y axis moments of inertia. You must also provide a value for the modulus of elasticity of the Bending Member for bending. Finally, you must make a fixity selection, which dictates the equation used to calculate deflection in BOTH directions of the member (unless the option is selected to "Force all MINOR AXIS Stiffnesses to ZERO"). Using these settings, the module will calculate the bending stiffness of the member and report the deflection for a unit 1 kip applied load.



**GENERIC ELEMENT:** Click the [Use Generic Resisting Element] button to specify a generic resisting element whose lateral deflection is known for an applied 1 kip load. This selection is intended for complex resisting elements like braced or moment frames, where another analysis module has determined the unit deflection.



**Add & Delete Buttons**

Use the [Add] and [Delete] buttons to add a new resisting element or delete the one currently highlighted in the list.

**Element Data**

This area allows you to specify a label and location of the center of resistance for a resisting element.

**Resisting Element List**

This is the list that you create to define the resisting element locations that give lateral force resistance to the rigid diaphragm.

This table serves to give a summary of the deflections, location and major axis angle for each element. When you click to highlight a line in the table, the information for that resisting element is brought into the variables on the input area.

**Summary Maximum Tab**

Please note that a STRICT X-Y coordinate system should be used to ensure that the analysis is properly carried out. When setting up an X-Y coordinate axis, please follow the standard Cartesian model with the diaphragm.

Recall that the module calculates the forces to each resisting element by rotating the force about its point of application. That point of application is in increments around an accidental eccentricity ellipse.

This Summary Maximums tab provides the maximum forces for each resisting element along the major and minor axis of the element.

Resisting Item	Load Angle	Max. Shear Along MAJOR Axis (k)			Max. Shear Along MINOR Axis (k)			
		X Ecc	Y Ecc	Shear Force	X Ecc	Y Ecc	Shear Force	
A	340	-18.29	-8.34	58.681	90	0.00	-11.14	5.195
B	205	-18.83	-13.48	49.323	90	0.00	-11.14	3.711
C	273	0.00	-11.31	95.682	4	-12.76	-15.94	1.518
D	87	-20.00	-11.22	113.580	4	-12.76	-15.94	1.518

### Force Envelope Detail Tab


This tab provides the main table that shows all of the force calculations for each resisting element. It is tree structured, so clicking the [+] sign to the left of each item name will expand the result set for that item.

In the image below we see that the data for the wall labeled "D" is expanded. Below "Label : D" we see many lines labeled "0 deg". These are the results for the load applied at an orientation of 0 degrees. On each "0 deg" line, observe that the "X Ecc" and "Y Ecc" values are changing. These values are the locations of the applied load as it moves its way around the accidental eccentricity ellipse. The note at the top of the table indicates that the analysis is based on 15-degree "Eccentricity Location" increments. This implies that there will be (360 degrees/15 degrees) = 24 lines of data based on the "0 deg" force orientation. Then, if we scrolled down through the table, we would see that the load application angle has also been set to change in 15-degree increments as well.

Resisting Item	Load Angle	Load Eccentricity (ft)		Total Force to Wall	Major Axis Shear (k)			Minor Axis Shear (k)		
		X Ecc.	Y Ecc.		Direct V	Tors. V	Max. V	Direct V	Tors. V	Max. V
[-] Label: A										
[-] Label: B										
[-] Label: C										
[+] Label: D	0 deg		-11.136	1.453	0.000	4.991	4.991	1.453	0.043	1.496
	0 deg		-11.049	1.453	0.000	4.952	4.952	1.453	0.043	1.496
	0 deg		-10.962	1.453	0.000	4.913	4.913	1.453	0.042	1.495
	0 deg	-0.014	-10.874	1.453	0.000	4.873	4.873	1.453	0.042	1.495
	0 deg	-0.024	-10.787	1.453	0.000	4.834	4.834	1.453	0.042	1.495
	0 deg	-0.038	-10.700	1.453	0.000	4.795	4.795	1.453	0.041	1.494
	0 deg	-0.055	-10.613	1.453	0.000	4.756	4.756	1.453	0.041	1.494
	0 deg	-0.075	-10.527	1.453	0.000	4.718	4.718	1.453	0.041	1.494
	0 deg	-0.097	-10.440	1.453	0.000	4.679	4.679	1.453	0.040	1.493
	0 deg	-0.123	-10.354	1.453	0.000	4.640	4.640	1.453	0.040	1.493

Note that direct shear is always considered as a positive value, and the algebraic sign on the torsional shear component will be **positive** if its effect is **additive** to the effects of the direct shear, or **negative** if its effects are **subtractive** from the direct shear. The algebraic sign on the torsional shear component does NOT indicate its direction with respect to the overall Cartesian coordinate system.

### Sketch Tab



### Analysis Procedure

Please see the following description for the procedure used to calculate the system stiffness matrix and resolve the forces for each resisting element.

76.2.0 THEORY

Consider the displacements of the single wall assembly shown in Figure 1. The magnitude of the displacements are assumed to be very small. The assembly rotates through an angle  $\Delta_\theta$  about the origin of coordinates Y and Z, and translates  $\Delta_y$  and  $\Delta_z$ . The diaphragm is assumed to be very rigid compared to the walls. When the diaphragm rotates without translation, displacements occur which generate the following forces:

$$F_y = -K_{yy}\Delta_y + K_{yz}\Delta_z \quad (5)$$

$$F_z = -K_{zy}\Delta_y + K_{zz}\Delta_z \quad (6)$$

$$M_x = J\Delta_\theta \quad (7)$$

$$M_p = -zF_y + yF_z + J\Delta_\theta \quad (8)$$

in which the stiffness coefficient  $K_{yz}$  is the force in the Y direction due to a unit displacement in the Z direction. The rotational stiffness J is the moment about the X axis due to a unit rotation of the element about the X axis. All values are plotted using the right hand cartesian coordinate axis system; thus a negative sign indicates a displacement in the negative direction or a clockwise moment.  $F_x$ ,  $M_y$  and  $M_z$  are zero for this type of system.

It can be shown that for the displacement in Figure 1,  $\Delta_y = z\Delta_\theta$  and  $\Delta_z = y\Delta_\theta$ ; thus, Equations 5 and 6 can be revised as follows: Also note that  $K_{zy} = K_{yz}$

$$F_y = -zK_{yy}\Delta_\theta + yK_{yz}\Delta_\theta \quad (9)$$

$$F_z = -zK_{yz}\Delta_\theta + yK_{zz}\Delta_\theta \quad (10)$$

Equation 8 now becomes:

$$M_p = \left[ z^2K_{yy} + y^2K_{zz} - 2yzK_{yz} + J \right] \Delta_\theta \quad (11)$$

When the diaphragm translates without rotation, see Figure 2, displacements occur which generate the following forces.

$$F_y = K_{yy}\Delta_y + K_{yz}\Delta_z \quad (12)$$

$$F_z = K_{yz}\Delta_y + K_{zz}\Delta_z \quad (13)$$

The element forces acting on the diaphragm may now be written in matrix notation.

$$\begin{Bmatrix} F_y \\ F_z \\ M_p \end{Bmatrix} = \begin{bmatrix} K_{yy} & K_{yz} & (yK_{yz} - zK_{yy}) \\ K_{yz} & K_{zz} & (yK_{zz} - zK_{yz}) \\ 0 & 0 & (z^2K_{yy} + y^2K_{zz} - 2yzK_{yz} + J) \end{bmatrix} \begin{Bmatrix} \Delta_y \\ \Delta_z \\ \Delta_\theta \end{Bmatrix} \quad (14)$$

If the applied loads on the diaphragm are  $P_y$  and  $P_z$  in the Y and Z directions, and a torsional moment  $T_p$ , is also applied to the diaphragm in the positive, counter-clockwise direction,

$$P_y = \sum F_y \quad (15)$$

$$P_z = \sum F_z \quad (16)$$

$$T_p = \sum M_p \quad (17)$$

Substituting the values from Equation 14 into Equation 15, 16 and 17,

$$P_y = \Delta_y \sum K_{yy} + \Delta_z \sum K_{yz} + \Delta_\theta (\sum yK_{yz} - \sum zK_{yy}) \quad (18)$$

$$P_z = \Delta_y \sum K_{yz} + \Delta_z \sum K_{zz} + \Delta_\theta (\sum yK_{zz} - \sum zK_{yz}) \quad (19)$$

$$T_p = \Delta_\theta (\sum z^2K_{yy} + \sum y^2K_{zz} - 2\sum yzK_{yz} + \sum J) \quad (20)$$

Select a coordinate axis system such that;

$$\sum y K_{yz} - \sum z K_{yy} = 0 \quad (21)$$

$$\sum y K_{zz} - \sum z K_{yz} = 0 \quad (22)$$

Then,

$$P_y = \Delta_y \sum K_{yy} + \Delta_z \sum K_{yz} \quad (23)$$

$$P_z = \Delta_y \sum K_{yz} + \Delta_z \sum K_{zz} \quad (24)$$

$$T_p = \Delta_\theta J_p \quad (25)$$

$$\text{where } J_p = \sum z^2 K_{yy} + \sum y^2 K_{zz} - 2 \sum yz K_{yz} + \sum J \quad (26)$$

The solution for  $F_y$ ,  $F_z$  and  $M_x$  forces and torsional moment acting on a wall, is then found as follows:

1. Compute values for  $K_{yy}$ ,  $K_{zz}$ ,  $K_{yz}$ . See Example 1.
2. Locate coordinate axis system as defined in Equations 21 and 22.
3. Compute displacements  $\Delta_y$ ,  $\Delta_z$ , and  $\Delta_\theta$  from Equations 23, 24 and 25.
4. Solve for forces from Equations 14 and 7.

The solution for the origin of coordinate axis as defined in Equation 21 and 22, can be accomplished if any set of trial axes are taken  $y_1$  and  $z_1$  with distances  $\bar{y}$  and  $\bar{z}$  to the desired origin. From Figure 3,

$$y = y_1 - \bar{y} \quad (27)$$

$$z = z_1 - \bar{z} \quad (28)$$



substituting Equation 27 and 28 into Equation 21 and 22

$$\bar{z} \sum (y_1 - \bar{y}) K_{yz} - \sum (z_1 - \bar{z}) K_{yy} = 0 \quad (29)$$

$$\bar{z} \sum (y_1 - \bar{y}) K_{zz} - \sum (z_1 - \bar{z}) K_{yz} = 0 \quad (30)$$

Then,

$$\bar{z} \sum K_{yy} - \bar{y} \sum K_{yz} = \sum z_1 K_{yy} - \sum y_1 K_{yz} \quad (31)$$

$$\bar{z} \sum K_{yz} - \bar{y} \sum K_{zz} = \sum z_1 K_{yz} - \sum y_1 K_{zz} \quad (32)$$

Now must solve two simultaneous equations (Equation 31 and 32) for  $\bar{y}$  and  $\bar{z}$ .

If  $K_{yz} = 0$ , the problem is greatly simplified.

$$\sum y K_{zz} = 0$$

$$\sum z K_{yy} = 0$$

$$\Delta_y = P_y \div \sum K_{yy}$$

$$\Delta_z = P_z \div \sum K_{zz}$$

$$\Delta_\theta = T_p \div J_p$$

$$F_y = \Delta_y K_{yy} - \Delta_\theta (z K_{yy})$$

$$= \frac{P_y K_{yy}}{\sum K_{yy}} - \frac{T_p (z K_{yy})}{J_p}$$

$$F_z = \Delta_z K_{zz} + \Delta_\theta (y K_{zz})$$

$$= \frac{P_z K_{zz}}{\sum K_{zz}} + \frac{T_p (y K_{zz})}{J_p}$$

$$M_a = J \Delta_\theta$$

$$= \frac{T_p J}{J_p}$$

The stiffness coefficients  $K_{yy}$ ,  $K_{zz}$  and  $K_{yz}$  may be found by inverting the flexibility matrix of the lateral load resisting wall system. See Example Problem 1.

## 10.9.2 Point Load on Slab

[Need more? Ask Us a Question](#)

This module calculates the capacity of an unreinforced concrete slab to support isolated concentrated loads. Typical use is for legs of storage racks not supported by a building structure, and is not within the scope of the ACI code.

The design method is based on the recent research of Shentu, Jiang and Hsu. For further information see (1) "Load carrying capacity for concrete slabs on grade" in the ASCE Journal of Structural Engineering January 1997; (2) Acceptable Design & Analysis methods for use of slabs-on-grade foundations, City of Los Angeles LAMC91.1806 and (3) Seismic considerations for steel storage racks, FEMA 460 September 2005.

The work of Shentu and colleagues has shown that load carrying capacity, verified with test results, can be very closely predicted using the formulas given below.

Rather than historical elastic methods, the method used here is elasto-plastic which is more applicable to ultimate capacity determination.

Allowable load capacity is given by this equation:

$$P_n = 1.72 [(k_s R_1 / E_c) 10,000 + 3.60] * f_t' * d^2$$

Where

$k_s$  is the modulus of subgrade reaction of the soil, pci

$R_1$  is  $\sqrt{\text{Plate Width} * \text{Plate Length}} / 2$ , inches

$E_c$  is the concrete elastic modulus, psi

$f_t'$  is the tensile strength of the concrete =  $7.5 \sqrt{f'c}$ , psi

$d$  is the slab thickness, inches

The above equation assumes that the load acting on the slab is unique and no other nearby loads are affecting the calculation.

To assist in the evaluation of slabs-on-grade, this module also provides a calculation of the distance that the closest load may be without affecting the calculated slab capacity. The calculation given below is based on research of Packard, Pickett & Ray and more recently by Spears and Panarese. It is also discussed in ACI 360R-92(4).

In this module the distance is calculated as  $1.5 * \text{"Radius of Relative Stiffness"}$  given by the following equation:

$$b = [ E_c d^3 / (12 * (1-u^2) * k_s) ]^{0.25}$$

Where

- b is the radius of relative stiffness
- $E_c$  is the concrete elastic modulus, psi
- d is the slab thickness, inches
- u is Poisson's ratio which is set to 0.15 in this module
- $k_s$  is the modulus of subgrade reaction of the soil, pci

Additionally this module allows the user to enter a Factor of Safety that is used when the module reports the adequacy of each applied load.

### Tabular Entry Screen

This module is designed to allow the user to create a table of loads applied to a particular concrete slab and supporting soil with one set of material properties.

You can then use the **[Add]**, **[Edit]** and **[Delete]** buttons to add a set of applied loads and base plate dimensions. From this data all load combinations are used to determine the maximum axial force. For the plate dimension you specify, the maximum load capacity for the point load application is calculated and compared with your required factor of safety.

The option for ASD or LRFD analysis only changes the load combination set used. Because this is a non-ACI design process, you need to enter a Factor of Safety to determine the final design status. Research material suggests a F.S. of 3.0.

## Load Combinations

**Point Load on Slab**

General **D-L? Load Combinations**

Service Combinations **2009 IBC & ASCE 7-05** Change Load Combination

Load Combination for SOIL PRESSURE

	Run	D	Lr	L	S	W	E
+D	<input checked="" type="checkbox"/>	1					
+D+L+H	<input checked="" type="checkbox"/>	1		1			
+D+Lr+H	<input checked="" type="checkbox"/>	1	1				
+D+S+H	<input checked="" type="checkbox"/>	1			1		
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>	1	0.75	0.75			
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>	1		0.75	0.75		
+D+W+H	<input checked="" type="checkbox"/>	1				1	
+D+0.70E+H	<input checked="" type="checkbox"/>	1					0.7
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>	1	0.75	0.75		0.75	
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>	1		0.75	0.75	0.75	
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>	1	0.75	0.75			0.525
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>	1		0.75	0.75		0.525
+0.60D+W+H	<input checked="" type="checkbox"/>	0.6				1	
+0.60D+0.70E+H	<input checked="" type="checkbox"/>	0.6					0.7

### 10.9.3 General Section Property Calculator

[Need more? Ask Us a Question](#)


#### Overview

This module determines section properties for built-up sections with rectangles, hollow circles, solid circles, standard AISC steel sections and general multi-sided solid shapes.

Click here for a video: General Section Property Calculator

AISC sections can be recalled from the database files and can be included in the built-up section. All sections from the 13th Edition AISC Steel Construction Manual are available, and can be reoriented as necessary.

The calculated section property values include: area, moments of inertia, center of gravity location, extreme fiber distances, section moduli, and radius of gyration.



#### Basic Usage

- Before starting data entry, be sure you have set up an X-Y coordinate system to consistently reference all component locations.

- For each rectangular shape, enter the height, width, and center of area measured from the datum.
- Hollow circular sections are entered by specifying the outside radius and thickness. Solid circular sections are entered by specifying the outside radius and setting the thickness to zero.
- For AISC sections, you can use the Xcg and Ycg input fields to locate the section's centroid position with respect to the datum. The module knows the centroid location of AISC members with respect to their own extreme fiber locations. However, you need to enter the location of the member's centroid in relation to the other members in the built-up section. Be careful, as this can be tricky when entering channels, angles, and tee sections that are rotated.
- A unique feature allows the user to specify that AISC sections can be rotated in 90-degree increments, and steel angle sections can also be mirrored about their Y axis.


### Assumptions & Limitations

The module operates on a simple calculation procedure:

- Calculate the moment of inertia of each shape,
- Calculate the neutral axis of the group of shapes, and
- Calculate the moment of inertia of the group using  $I + A \cdot D^2$  equations.

More complex analysis such as polar moment of inertia, plastic moduli, and buckling constants are beyond the scope of the module at this time but continuing development will add these items in future updates.

### Rolled Section / Table tab



This tab enables you to specify up to 10 sections from the AISC 13th Edition database to use in a built-up member.

The square buttons across the top of the tab are used to represent the component sections that comprise your built-up shape. When a section has been specified for a

particular button, a small green upward facing triangle will be shown under the corresponding button. Click on any button to add a section or view and modify the section that has already been assigned to that button.

Note: It is important to understand that the numbered buttons on the various tabs DO NOT represent different built-up shapes. Instead, each instance of this module only creates ONE built-up shape, and the overall built-up shape consists of a composite of ALL sections that currently exist on ANY buttons in the Rolled Section / Table tab, the Rectangular & Circular tab, and the General Shapes tab.

To insert an AISC section you can:

- Type in the section name and press [**Tab**]. The module will search the database and retrieve the information.
- Use the [**Browse Steel Sections**] button to display the steel database where you can navigate and select the desired section.

### **Rotation Angle: Counter-Clockwise**

If you need to rotate a section, click one of the four angular rotation buttons.

### **Rotate Section 180 degrees about its own y-y Axis**

This checkbox option will only be displayed for single-angle sections. It offers the ability to mirror a single-angle section if needed.

### **Xcg & Ycg**

Enter the location of the section's centroidal axis measured from the datum (the origin of your assumed X-Y Cartesian coordinate system).

### **Section Properties**

These values will be filled in after you make your choice from the AISC database. HOWEVER you can alter these values yourself. Of particular importance for unsymmetrical sections is entering the correct "Xbar" and "Ybar" location. This is the distance from the lower-left edge of the section, measured upwards and to the right, to the centroidal axis position of the section.

### **Steel Section Database**

Click the [**Browse Steel Sections**] button to display the AISC database window:

Steel Section Database

Steel Database

AISC 360-05

User Defined

Section Type to Display . . .

W C WT HSS-P HSS-Square L - Equal LL - Equal

HP MC MT P HSS-Rectangular L - Unequal LL - Long Leg Vert

S ST TS - Rectangular LL - Short Leg Vert

M TS - Square

Displaying Data For 31 "C" Shapes

Sort Order  Show Favorites Only

Toggle Favorite ON-OFF

Order	Area	Depth	Web Thick	Width	Fl. Thick	Sx	Sy	Ix	Iy	Rx	Ry	J
Section Name	Wt.	Area	Depth	Web Thick	FL Width	FL Thick	K Dist	T Dist	Eo	Ixx	S	
	lbs	in^2	in	in	in	in	in	in	in	in^4	in	
C8X13.7	13.700	4.040	8.000	0.303	2.340	0.390	0.938	6.124	0.604	36.100	1	
C8X11.5	11.500	3.370	8.000	0.220	2.260	0.390	0.938	6.124	0.697	32.500	1	
C9X20	20.000	5.870	9.000	0.448	2.650	0.413	1.000	7.000	0.515	60.900	1	
C9X15	15.000	4.410	9.000	0.285	2.490	0.413	1.000	7.000	0.681	51.000	1	
C9X13.4	13.400	3.940	9.000	0.233	2.430	0.413	1.000	7.000	0.742	47.800	1	
C10X20	20.000	5.870	10.000	0.379	2.740	0.436	1.000	8.000	0.636	78.900	1	
C10X15.3	15.300	4.480	10.000	0.240	2.600	0.436	1.000	8.000	0.796	67.300	1	
C10X30	30.000	8.810	10.000	0.673	3.030	0.436	1.000	8.000	0.368	103.000	2	
C10X25	25.000	7.340	10.000	0.526	2.890	0.436	1.000	8.000	0.494	91.100	1	
C12X30	30.000	8.810	12.000	0.510	3.170	0.501	1.130	9.740	0.618	162.000	2	
C12X25	25.000	7.340	12.000	0.387	3.050	0.501	1.130	9.740	0.746	144.000	2	
C12X20.7	20.700	6.080	12.000	0.282	2.940	0.501	1.130	9.740	0.870	129.000	2	
C15X50	50.000	14.700	15.000	0.716	3.720	0.650	1.440	12.120	0.583	404.000	5	
C15X40	40.000	11.800	15.000	0.520	3.520	0.650	1.440	12.120	0.767	348.000	4	
C15X33.9	33.900	10.000	15.000	0.400	3.400	0.650	1.440	12.120	0.896	315.000	4	

Depth Range :  Class Range :

Using Database Filename : C:\Users\Public\Documents\ENERCALC Common Data Files\EC6\_STL\_C.TPS

Select

Cancel

View All Properties

Standard AISC shapes can not be edited. Please contact us if you feel data should be changed.

Check availability at [www.aisc.org](http://www.aisc.org)

## Rectangular & Circular tab

General Section Property Calculator

Description | Rolled Section / Table | Rectangular & Circular | General Shapes

Rectangular & Round Sections - Click Numbered Box To Select Shape

1 2 3 4 5 6 7 8 9 10

Section Type : Not Used Rectangular Circular

Height  in Width  in

X cg  in Y cg  in

Rotation Counter-Clockwise  deg

0 90 180 270

Set Color

This tab allows you to specify simple rectangular and circular shapes.

The square buttons across the top of the tab are used to represent the component sections that comprise your built-up shape. When a section has been specified for a particular button, a small green upward facing triangle will be shown under the corresponding button. Click on any button to add a section or view and modify the section that has already been assigned to that button.

### Not Used / Rectangular / Circular

Select the shape you wish to use for this item.




### Rectangular Data Entry

When a rectangular shape is chosen the data entry consists of height and width.

### Circular Data Entry


When a circular shape is selected the data entry consists of Outside Radius and Wall Thickness (not inside radius). To model a solid circular section, enter the appropriate Outside Radius and set the Wall Thickness to zero.



### Xcg & Ycg

Enter the location of the section's centroidal axis measured from the datum (the origin of your assumed X-Y Cartesian coordinate system).

### General Shapes tab



This tab allows you to select from a number of common polygonal shapes. With each selection the reference drawing and data entry prompts will change.

The square buttons across the top of the tab are used to represent the component sections that comprise your built-up shape. When a section has been specified for a particular button, a small green upward facing triangle will be shown under the corresponding button. Click on any button to add a section or view and modify the section that has already been assigned to that button.

### Xcg & Ycg

Enter the location of the section's centroidal axis measured from the datum (the origin of your assumed X-Y Cartesian coordinate system).

### Rotation Angle: Counter-Clockwise

For these shapes you can rotate the section in one-degree increments. Positive angles represent counter-clockwise rotation.

## Results Tab

Calculated Properties & Dimensions														
Total Area	=	29.670 in <sup>2</sup>					Calculated C.G. distance from (0,0)							
Ixx	=	1,578.42 in <sup>4</sup>					Sxx : - Y	=	265.46 in <sup>3</sup>					
Iyy	=	242.0 in <sup>4</sup>					Sxx : +Y	=	99.559 in <sup>3</sup>					
rx	=	7.294 in					Syy : - X	=	40.333 in <sup>3</sup>					
ry	=	2.856 in					Syy : +X	=	40.333 in <sup>3</sup>					
						Extreme edge distances from calculated C.G.								
						+ X	=	6.0 in						
						- X	=	-6.0 in						
						+ Y	=	15.854 in						
						- Y	=	-5.946 in						
Detailed Properties for each Element . . .														
ItemName	C. G. Dist. from Lower-Left		Angle CCW	Area	Inertia		Section Modulus		Radius Gyration		Max. Dist. from C.G.			
	Xcg	Ycg			Ixx	Iyy	Sxx	Syy	Rxx	Ryy	Xmax	Xmin	Ymax	Ymin
W18X40 : 1	0.000	0.000	0	11.800	612.000	19.100	68.380	6.346	7.202	1.272	3.010	-3.010	8.950	-5.000
C10X20 : 2	0.000	-9.650	90	5.870	2.800	78.900	4.620	15.780	3.666	0.691	5.000	-5.000	0.606	13.400
Rect : 1	0.000	-12.350	0	12.000	1.000	144.000	2.000	24.000	0.289	3.464	6.000	-6.000	0.500	10.000

### Detailed Properties Table

This table summarizes each of the component items you have added to the section. It reports their individual locations, properties and maximum distance from CG for each of the four edges.

Note: This table scrolls to the right. Just use the scroll bar along the bottom of the table.

### Total Area

The total area of all defined shapes, including the area of any AISC sections which have been included in the built-up shape.

### Inertia: Ixx & Iyy

The overall moment of inertia of the composite section is determined by applying the following equation to all the defined shapes:

$$I_{xx} = I_{ox} + (A * d_y^2) \text{ and } I_{yy} = I_{oy} + (A * d_x^2)$$

where  $d$  = Distance from the shape's C.G. to the overall C.G. of the composite section, measured in the direction indicated by the subscript.

### Section Modulus: $S_{xx}$ and $S_{yy}$

These values are the calculated section moduli of the composite section. The values are determined by dividing  $I_{xx}$  or  $I_{yy}$  by the extreme fiber distances above, below, right, and left of the center of gravity of the section.


### Radius of Gyration

The radius of gyration of the composite section is determined using the typical equation:  $r_{xx} = (I_{xx}/A)^{1/2}$  and  $r_{yy} = (I_{yy}/A)^{1/2}$ .

### Max Distance from CG

For each of the sections in the built-up shape, these columns report the distance from the extreme fibers of that section to the C.G. of the composite section.

## Sketch



## 10.9.4 Rebar Development Table

### [Need more? Ask Us a Question](#)

This module calculates development and splice lengths for deformed steel rebar in concrete. Since typical development lengths are readily available in tables, this module is primarily for developing tables of development lengths when unusual conditions affect the lengths.

The module uses ACI 318-05 sections 12.1, 12.2, 12.3 and 12.5 for straight tension & compression development and hooked tension development.

Two major categories of development calculation are available; straight development and hooked development. The module calculates the basic tension development length for straight and hooked cases, and compression development for straight cases only.

**Rebar Development Table**

Description: Sample Rebar Development Calculations

Bar # 1 | Bar # 2 | Bar # 3 | Bar # 5 | Bar # 6 | Bar # 7 | Bar # 8 | Bar # 9 | Bar # 10 | Bar # 11 | Bar # 12 | Bar # 13 | Bar # 14 | Bar # 15

Print This Information

This Bar: Dowel from footing into typical frostwall

**Bar Details**

Bar Size: # 4 Code Edition: ACI 318-05 ACI 318-91

Fc: 3.0 ksi

Fy: 60.0 ksi

**Straight Development**

Reinf. Location Factor  $\psi_t$ : 1.3

Coating Factor  $\psi_e$ : 1

Lightweight Factor  $\lambda$ : 1

As req'd / As actual: 1.000

Bars are Confined per 12.3.3(b):

Sufficient Clearance per 12.2.2, 12.2.3:

**Tension Development..**

Final after adjustments: 22.785 in

**Compression Development...**

Final after adjustments: 10.954 in

**Hooked Development**

Adequate Cover  $\psi_t$ :

Epoxy Coating  $\psi_e$ :

Lightweight Concrete  $\lambda$ :

Basic Before Adjustments: 10.954 in

Final after adjustments: 7.668 in

**Splice Lengths**

Rebar Area: 0.200 in

Class A Splice: 22.79 in

Class B Splice: 29.62 in

Compression Splice: 15.00 in

### Item Descriptions

#### Print This Information

Check this box if you want the development calculation on the current tab to appear on the printout.

#### This Bar

Enter a description for the current development calc.

**Bar Details**

Enter the basic stress info for this bar. You can also select to perform the calculation according to ACI 318-91.

**Straight Development**

This section performs tension & compression bar development according to ACI section 12.2 and 12.3. Please refer to the ACI code for the proper definitions of these entries.

**Hooked Development**

This section performs tension hooked rebar development according to ACI section 12.5. Please refer to the ACI code for the proper definitions of these entries.

## 10.9.5 Steel Bolt Group Analysis

[Need more? Ask Us a Question](#)

This module applies the Elastic Method to determine the force distribution from loads applied to a group of up to 16 bolts.

The required input data includes vertical and horizontal load magnitudes and their location with respect to a datum point, along with the coordinates of up to sixteen bolts.

Using these force and bolt coordinates, the module calculates direct shears and torsional shears on each bolt due to its relative location within the group.

Note:

- At least two bolts should be specified.
- All bolts are assumed to be of the same deformation characteristics when loads are distributed.
- Vertical and Horizontal forces are divided by the number of fasteners to give direct shears.

Steel Bolt Group Analysis

General Loads D+L? Load Combinations

Description  
Sample Steel Bolt Group Analysis

Total Number of Bolts 4.0

Bolt Coordinates....

	X in	Y in
# 1	2.0	2.0
# 2	2.0	12.0
# 3	12.0	2.0
# 4	12.0	12.0

Load Combination to Use ASD LRFD

Results Detailed Bolt Results

Load Eccentricity from C.B.G  
Y Distance -3.000 in  
X Distance -3.000 in  
Moment 157.50 k-in


Center of Bolt Group (CBG)  
Y Distance 7.000 in  
X Distance 7.000 in

Maximum Bolt Forces

Bolt ID	Load Combination	Bolt Dist from CBG		Direct Force (k)		Torsional Shear (k)		Total Bolt Shear (k)
		X	Y	X	Y	X	Y	
1	+D+0.750L+0.750S+H	-5.000	-5.000	0.000	-13.125	3.938	-3.938	17.511
2	+D+0.750L+0.750S+H	-5.000	5.000	0.000	-13.125	-3.938	-3.938	17.511
3	+D+0.750L+0.750S+H	5.000	-5.000	0.000	-13.125	3.938	3.938	9.996
4	+D+0.750L+0.750S+H	5.000	5.000	0.000	-13.125	-3.938	3.938	9.996


### General Tab

Specify the locations up to 16 bolts. Use the Total Number of Bolts entry to indicate bolt quantity. The correct number of data entry locations will be displayed.




### Loads Tab

Enter the magnitude of the applied loads, the angle of load application measured CCW from Cartesian zero degrees and the location of the point of load application relative to the Datum point. The module now accepts applied moments as well.



### Load Combinations Tab


Based upon the selection of ASD or LRFD factoring, the appropriate load combinations will be displayed on the load combinations tab.



### Results Tab


On the left side of this tab are the calculated Center of Bolt Group location, calculated moment applied to the group from the load combination that creates the extreme moment and the eccentricity of the load application from the Center of Bolt Group.

In the table on the right are presented the calculated of force for each bolt due to direct and torsional shears for each axis (after the applied load is reduced to X & Y components).




### Detailed Bolt Results

This tab provides the detailed calculations for all load combinations and all bolts.





### Sketch



## 10.9.6 Steel Base Plate

[Need more? Ask Us a Question](#)

This module designs steel column base plates according to the 13th Edition AISC Steel Construction Manual and the AISC Design Guide 1, Second Edition. Click here for a video:

Steel Base Plate

This module handles base plate design for the following conditions:

- where the resultant eccentricity is zero,
- where the resultant eccentricity is within the middle third for full bearing pressure,
- where the resultant eccentricity is outside the middle third resulting in a triangular pressure distribution on part of the base plate, and
- extreme eccentricity conditions where anchor bolts are required.


This module does not handle conditions where NET UPLIFT is present. When the summation of factored axial loads in a load combination is negative, then uplift controls and the module will not calculate. Under these conditions, a red error message will be displayed at the bottom of the window to notify you of this condition.

The screenshot displays the 'Steel Base Plate' software interface. The main window has a title bar with standard Windows controls and a menu bar with options like 'Cancel', 'New', 'Save Only', and 'Save & Exit'. Below the menu bar are several tabs: 'General & Materials', 'Column & Plate', 'Applied Loads', 'Anchor Bolts', and 'D+L+? Load Combinations'. The 'General & Materials' tab is active, showing a 'Description' field with 'Sample Steel Base Plate'. To the right, there are input fields for 'AISC 360-05 Method' (set to ASD), 'Plate Material' (Steel Base Plate Fy = 36.0 ksi,  $\Omega$  steel = 1.67), 'Concrete Support Material' (Concrete Support f<sub>c</sub> = 3.0 ksi), and 'Nominal Bearing Pp/A1 per J.8' (2.550 ksi). A checkbox for 'Use AISC 360-05 Section 1.8 for "Fp" Calculation?' is checked. At the bottom of this tab, it says 'Calculations per AISC Design Guide 1, 2nd Ed., 2006 by Fisher & Klobner'.


Below the main window is a 'Results' window. It has a 'Load Combination (select to view)' dropdown and an 'Overall Results' section. The 'Overall Results' section is expanded to show 'Plate Design Summary'. The summary includes:
 

- Design Method: Allowable Strength Design
- Governing Load Combination: +D+0.750Lr+0.750L+H
- Governing Load Case Type: Axial Load Only
- Design Plate Size: 1'-0" x 1'-0" x 1"
- Pa: Axial Load: 2.500 k
- Ma: Moment: 0.000 k-ft
- Mu: Max. Moment: 0.166 k-in
- fb: Max. Bending Stress: 0.665 ksi
- Fb: Allowable: Fy / Omega: 21.557 ksi
- Bending Stress Ratio: 0.031
- Result: Bending Stress OK
- fu: Max. Plate Bearing Stress: 0.017 ksi
- Fp: Allowable: min(0.85\*f<sub>c</sub>\*sqrt(A2/A1), 1.7\*f<sub>c</sub>)/Omega: 1.020 ksi
- Plate Bearing Stress Ratio: 0.017
- Result: Bearing Stress OK
- Tension in each Bolt: 0.000
- Allowable Bolt Tension: 0.000
- Bolt Tension Stress Ratio: 0.000
- Result: Tension Stress OK

General & Materials Tab



The right side of this tab will look slightly different for LRFD:



**For Axial Load Cases Only....**

This selection controls the upward pressure used to design the plate. A brief description of each choice is provided below the buttons for each selection.

**Full Bearing:** Bearing is assumed uniform under plate. If plate area is larger than needed, the larger "m" and "n" cantilevered dimensions could result in a thicker plate than would be required if the pressure was calculated by the other option.

**Bearing Area = P / Fp:** Base plate is considered flexible with bearing concentrated close to column. Maximum Fp is used to calculate "design" minimum plate size. Determining the bearing pressure by this method might result in thicker plates if bending stress is high between webs or within pipe or tube walls.

**Steel Design Method**

Select between ASD or LRFD design methods.

**Steel Base Plate Fy**

Specify the yield strength of the base plate material.

**ASD: Omega**

Enter the capacity reduction factor, Omega, to be used in ASD per AISC 360.

**LRFD: Phi**

Enter the capacity reduction factor, Phi, to be used in LRFD per AISC 360.

**Concrete Support f'c**


28-day compressive strength of concrete used to support the base plate.

**ASD: Omega per AISC J.8**

AISC 360 Section J.8 specifies Omega as 2.5. This entry allows the value to be modified.

**LRFD: Phi per AISC J.8**

AISC 360 Section J.8 specifies Phi as 0.6. This entry allows the value to be modified.

**Column & Plate Tab****Steel Section Name & Database Button**

Type the AISC section name in the entry and press **[Tab]**. The module will look up the section in the Steel database and, if found, will retrieve the values. The name must be typed just as it appears in the 13th Edition AISC Steel Construction Manual.




Or click the **[Section Database]** button to display the built-in steel database and select a section.

**[Edit Values] Button**

Clicking this button will allow you to enter the steel properties.


### Plate Information

Enter the length, width and thickness of the base plate. Use the  buttons to quickly change the values...the results are instantly recalculated.

### Concrete Support

Enter the support dimensions that will be used to calculate the allowable bearing pressure increase,  $A1 * \sqrt{A2/A1}$ .

### Applied Loads Tab



### Py - Axial Load

This column of entries specifies the axial load applied to the base plate. Note that positive values represent downward loads.

### Vz - Shear


This column of entries specifies the shear applied parallel to the plate and to be resisted by the anchor bolts.

### Mx - Moment

This column of entries specifies the moment that the column applies to the plate.

### Anchor Bolts Tab

Items on this tab specify the strength and location of the anchor bolts that will resist shear and tension.



### Description

Description of the bolt for your reference. Not used by module.

### Tension Capacity

Net tension capacity of bolt after all capacity factors are applied.

### Shear Capacity

Net shear capacity of bolt after all capacity factors are applied.

### Edge Distance

Distance from edge of plate to center of bolt closest to edge.

### Number of Bolts in a Row

The "Row" referred to is a row of bolts at the plate edge that will take any tension force.

### Number of Bolt Rows

Number of rows of bolts.

### Row Spacing

Spacing of rows when more than one row is used.

## Load Combinations Tab

This tab displays the load combinations used for either the ASD or LRFD selections.

The screen capture below shows a sample of the load combinations factors:

Load Combination	Run	ASIF?	D	Lr	L	S	W	E	H
+D	<input checked="" type="checkbox"/>		1.0	0					
+D+L+H	<input checked="" type="checkbox"/>		1.0		1.0				1.0
+D+Lr+H	<input checked="" type="checkbox"/>		1.0	1.0					1.0
+D+S+H	<input checked="" type="checkbox"/>		1.0			1.0			1.0
+D+0.750Lr+0.750L+H	<input checked="" type="checkbox"/>		1.0	0.750	0.750				1.0
+D+0.750L+0.750S+H	<input checked="" type="checkbox"/>		1.0		0.750	0.750			1.0
+D+W+H	<input checked="" type="checkbox"/>		1.0				1.0		1.0
+D+0.70E+H	<input checked="" type="checkbox"/>		1.0					0.70	1.0
+D+0.750Lr+0.750L+0.750W+H	<input checked="" type="checkbox"/>		1.0	0.750	0.750		0.750		1.0
+D+0.750L+0.750S+0.750W+H	<input checked="" type="checkbox"/>		1.0		0.750	0.750	0.750		1.0
+D+0.750Lr+0.750L+0.5250E+H	<input checked="" type="checkbox"/>		1.0	0.750	0.750			0.5250	1.0
+D+0.750L+0.750S+0.5250E+H	<input checked="" type="checkbox"/>		1.0		0.750	0.750		0.5250	1.0
+0.60D+W+H	<input checked="" type="checkbox"/>		0.60				1.0		1.0
+0.60D+0.70E+H	<input checked="" type="checkbox"/>		0.60					0.70	1.0

### Results Tab - Overall

The **Results** tab contains a list of load combinations on the left and a summary of all the calculated values for each load combination on the right. Click one of the load combinations in the list to view results specifically for that load combination.

The very first item in the list will always say **Overall Results**. The module will examine the results for all of the load combinations and determine which gives the extreme condition of stress and presents it the **Overall Results** item. This is the governing case for the base plate.

Note that Maximum Bending Stress is calculated using the *plastic* section modulus, in keeping with AISC Design Guide 1, Second Edition.

Load Combination	Overall Results
+1.40D	
+1.20D+0.50Lr+1.60L+1.60H	
+1.20D+1.60L+0.50S+1.60H	
+1.20D+1.60Lr+0.50L	
+1.20D+1.60Lr+0.80W	
+1.20D+0.50L+1.60S	
+1.20D+1.60S+0.80W	
+1.20D+0.50Lr+0.50L+1.60W	
+1.20D+0.50L+0.50S+1.60W	
+1.20D+0.50L+0.20S+E	

Plate Design Summary			
Design Method . . . . . Load Resistance Factor Design			
Governing Load Combination . . . +1.20D+0.50Lr+1.60L+1.60H			
Governing Load Case Type . . . Axial Load Only			
Design Plate Size . . . . . 1'-0" x 1'-0" x 1"			
Pu : Axial	3.300 k		
Mu : Moment	0.000 k-ft		
Mu : Max. Moment	0.219 k-in	Bending Stress Ratio	0.027
fb : Max. Bending Stress	0.878 ksi		
Fb : Allowable : Fy * Phi	32.400 ksi	<input checked="" type="checkbox"/> Bending Stress OK	
fu : Max. Plate Bearing Stress	0.023 ksi	Plate Bearing Stress Ratio	0.015
Fp : Allowable : min( 0.85*Fc*sqrt(A2/A1), 1.7* Fc)*Phi	1.530 ksi	<input checked="" type="checkbox"/> Bearing Stress OK	
Tension in each Bolt	0.000	Bolt Tension Stress Ratio	0.000
Allowable Bolt Tension	0.000	<input checked="" type="checkbox"/> Tension Stress OK	

### Results Tab - Axial Load Only

When a load combination results in only an axial load being applied, the summary of information below is displayed. See the AISC Design Guide #1 starting on page 4 for a description of the values present here.

Results		W4x13, Axial Load Only, +1.40D	
<b>Overall Results</b>			
+1.40D			
+1.20D+0.50Lr+1.60L+1.60H			
+1.20D+1.60L+0.50S+1.60H			
+1.20D+1.60Lr+0.50L			
+1.20D+1.60Lr+0.80W			
+1.20D+0.50L+1.60S			
+1.20D+1.60S+0.80W			
+1.20D+0.50Lr+0.50L+1.60W			
+1.20D+0.50L+0.50S+1.60W			
+1.20D+0.50L+0.20S+E			
<b>Loading</b>			
Pu : Axial .....	1.400 k		
Design Plate Height	12.000 in		
Design Plate Width	12.000 in		
<i>Will be different from entry if partial bearing used.</i>			
A1 : Plate Area	144.000 in <sup>2</sup>		
A2 : Support Area	144.000 in <sup>2</sup>		
sqrt(A2/A1)	0.000		
<b>Distance for Moment Calculation</b>			
"m"	4.024 in		
"n"	4.376 in		
X	0.006 in <sup>2</sup>		
Lambda	0.080		
n'	1.027 in		
n' * Lambda	0.082 in		
l = max(m, n')	4.376 in		
<b>Bearing Stresses</b>			
Fp : Allowable	1.530 ksi		
fu : Max. Bearing Pressure	0.010 ksi		
<b>Stress Ratio .....</b>	<b>0.006</b>		
<b>Plate Bending Stresses</b>			
Mmax = Fu * L <sup>2</sup> / 2	0.093 k-in (1" strip)		
fb : Actual	0.372 ksi		
Fb : Allowable	32.400 ksi		
<b>Stress Ratio .....</b>	<b>0.011</b>		

### Results Tab - Small Eccentricity

When a load combination results in an axial load and very small moment being applied, the summary of information below is displayed. This condition is caused when the moment causes the resultant eccentricity of the axial load to be within the middle 1/3rd of the base plate. See the AISC Design Guide #1 starting on page 19 for a description of the values present here.

Results		W4x13, Axial + Moment, Eccentricity <= L/6, +1.40D	
<b>Overall Results</b>			
+1.40D			
+1.20D+0.50Lr+1.60L+1.60H			
+1.20D+1.60L+0.50S+1.60H			
+1.20D+1.60Lr+0.50L			
+1.20D+1.60Lr+0.80W			
+1.20D+0.50L+1.60S			
+1.20D+1.60S+0.80W			
+1.20D+0.50Lr+0.50L+1.60W			
+1.20D+0.50L+0.50S+1.60W			
+1.20D+0.50L+0.20S+E			
<b>Loading</b>			
Pu : Axial .....	1.400 k		
Mu : Moment .....	0.140 k-ft		
Eccentricity	1.200 in		
A1 : Plate Area	144.000 in <sup>2</sup>		
A2 : Support Area	144.000 in <sup>2</sup>		
sqrt(A2/A1)	1.000		
<b>Distance for Moment Calculation</b>			
"m"	4.024 in		
"n"	4.376 in		
<b>Bearing Stresses</b>			
Fp : Allowable	1.530 ksi		
fu : Max. Bearing Pressure	0.016 ksi		
<b>Stress Ratio .....</b>	<b>0.010</b>		
<b>Plate Bending Stresses</b>			
Mmax1 = Fu * m <sup>2</sup> / 2	0.115 k-in (1" strip)		
Mmax2 = Fu * n <sup>2</sup> / 2	0.051 k-in (1" strip)		
Mmax	0.115 k-in (1" strip)		
fb : Actual	0.462 ksi		
Fb : Allowable	32.400 ksi		
<b>Stress Ratio .....</b>	<b>0.014</b>		

### Results Tab - Large Eccentricity

When a load combination results in an axial load and large moment being applied, the summary of information below is seen. This condition is caused when the moment causes the resultant eccentricity of the axial load to be outside the middle 1/3rd of the base plate. See the AISC Design Guide #1 starting on page 21 for a description of the values present here.



Results

Load Combination (select to view) W4x13, Axial + Moment, L/2 < Eccentricity, Tension on Bolts, +1.20D+1.60Lr+0.50L

Overall Results		Loading		Calculate plate moment from bolt tension . . .	
+1.40D		Pu : Axial . . . . .	3.300 k	Tension per Bolt	0.059 k
+1.20D+0.50Lr+1.60L+1.60H		Mu : Moment . . . . .	1.720 k-ft	Tension : Allowable	0.000 k
+1.20D+1.60L+0.50S+1.60H		Eccentricity	6.255 in	<b>Stress Ratio</b> . . . . .	0.000
<b>+1.20D+1.60Lr+0.50L</b>		A1 : Plate Area	144.000 in <sup>2</sup>	Dist. from Bolt to Col. Edge	2.774 in
+1.20D+1.60Lr+0.80W		A2 : Support Area	144.000 in <sup>2</sup>	Effective Bolt Width for Bending	11.096 in
+1.20D+0.50L+1.60S		sqrt(A2/A1)	0.000	Plate Moment from Bolt Tension	0.029 k-in
+1.20D+1.60S+0.80W		<b>Calculate plate moment from bearing</b>			
+1.20D+0.50Lr+0.50L+1.60W		"m"	4.024 in	Fp : Allowable	1.530 ksi
+1.20D+0.50L+0.50S+1.60W		"A" : Bearing Length	0.372 in	fu : Max. Bearing Pressure (set equal to Fp)	<b>Stress Ratio</b>
+1.20D+0.50L+0.20S+E		Mpl : Plate Moment	0.093 k-in		1.000
		<b>Plate Bending Stresses</b>			
				Mmax	1.111 k-in (1" strip)
				fb : Actual	4.443 ksi
				Fb : Allowable	32.400 ksi
				<b>Stress Ratio</b> . . . . .	0.137

### Sketch Tab

Sketch Tab

Calculations

Sketch

Column = W4x13

1'-0"

1'-0"

1'-0"

1'-0"

Z

X

Z

X


## 10.10 External Items

**Structural Engineering Library** allows you to add non-ENERCALC items into a Project File, such as:

- MS Excel Spreadsheets
- MS Word Documents
- Adobe Acrobat PDF Files
- Scanned Images

The ability to include these types of items allows you to use the ENERCALC Project File as a central point of document preparation and storage for structural project calculations.

These external items can be interspersed within the ENERCALC calculations. Here is an image of the Project Manager showing a Division that has been created specifically to contain the external items we are about to add:




### 10.10.1 EXCEL Spreadsheet

[Need more? Ask Us a Question](#)


Click here for a video: Inserting an EXCEL Spreadsheet

**Adding a Microsoft Excel spreadsheet to the project requires that you already have Excel loaded on your computer.**


To add an Excel spreadsheet to your Project, click on the Division where you would like to insert the spreadsheet, click the **[Add]** button, and then click **[MS Excel Spreadsheet]**:




The screen will appear like this, ready for you to load the spreadsheet of your choice:



- (1) Use the [**Open/Retrieve**] button to load the desired Excel spreadsheet.
- (2) Use the [**Print Document**] button to print this item using the Excel printing functionality.
- (3) Use the [**Clear Document**] button to remove the currently loaded Excel spreadsheet from the Project File.
- (4) Use the [**SaveAs**] button to save the currently loaded Excel spreadsheet to a new filename.
- (5) The Storage Method buttons are used to specify how the Excel spreadsheet will be stored for use within ENERCALC.
  - [**Embed**] saves a *copy* of the item in the Project File. (Easiest for portability, results in larger Project File size, changes to original item will **not** be visible.)
  - [**Link**] saves a *link* to the item in Project File. (Changes to original item **will** be visible, keeps Project File size small, not easily portable.)
- (6) This area is used to define the name of the Excel spreadsheet when it is stored externally from the Project File.
- (7) Enter a description of this item as needed. It will be displayed in the Descriptions column of the Project Manager for reference.
- (8) This is the area where the Excel spreadsheet is loaded, as shown below:



The last step is to click the **[Save & Exit]** button. The display will return to the Project Manager, and you will see an indication that the selected spreadsheet has been attached as shown in the image below:



### 10.10.2 WORD Document


[Need more? Ask Us a Question](#)

Click here for a video:


Inserting a WORD Document

**Adding a Microsoft Word document to the Project requires that you already have Word loaded on your computer.**

To add a Word document to your Project, click on the Division where you would like to insert the document, click the **[Add]** button, and then click **[MS Word Document]**:




The screen will appear like this, ready for you to load the document of your choice:




- (1) Use the **[Open/Retrieve]** button to load the desired Word document.
- (2) Use the **[Print Document]** button to print this item using the Word printing functionality.
- (3) Use the **[Clear Document]** button to delete the currently loaded Word document from the Project File.
- (4) Use the **[SaveAs]** button to save the currently loaded Word document to a new filename.
- (5) The Storage Method buttons are used to specify how the Word document will be stored for use within ENERCALC.
  - **[Embed]** saves a *copy* of the item in the Project File. (Easiest for portability, results in larger Project File size, changes to original item will **not** be visible.)
  - **[Link]** saves a *link* to the item in Project File. (Changes to original item **will** be visible, keeps Project File size small, not easily portable.)
- (6) This area is used to define the name of the Word document when it is stored externally from the Project File.
- (7) Enter a description of this item as needed. It will be displayed in the Descriptions column of the Project Manager for reference.



(8) This is the area where the Word document is loaded, as shown below:



The last step is to click the [Save & Exit] button. The display will return to the Project Manager, and you will see an indication that the selected document has been attached as shown in the image below:



### 10.10.3 Adobe Acrobat PDF


[Need more? Ask Us a Question](#)

Click here for a video:


Inserting an Adobe Acrobat PDF

Note: When using Adobe Reader X, it is necessary to disable Protected Mode if PDFs are to be used as External Items in Structural Engineering Library. To disable Protected Mode in Adobe Reader X, go to Edit > Preferences > General > Application Startup, and disable the option named “Enable Protected Mode at startup”.


To add an Adobe Acrobat PDF file to your Project, click on the Division where you would like to insert the document, click the **[Add]** button, and then click **[Acrobat PDF]**:




The screen will appear like this, ready for you to load the PDF file of your choice:



- (1) Use the **[Open/Retrieve]** button to load the desired PDF file.
- (2) Use the **[Print Document]** button to print this item using the PDF printing functionality.
- (3) Use the **[Clear Document]** button to delete the currently loaded PDF file from the Project File.
- (4) The Storage Method buttons are used to specify how the PDF file will be stored for use within ENERCALC.
  - **[Embed]** saves a copy of the item in the Project File. (Easiest for portability, results in larger Project File size, changes to original item will **not** be visible.)
  - **[Link]** saves a link to the item in Project File. (Changes to original item **will** be visible, keeps Project File size small, not easily portable.)
- (5) This area is used to define the name of the PDF file when it is stored externally from the Project File.
- (6) Enter a description of this item as needed. It will be displayed in the Descriptions column of the Project Manager for reference.
- (7) This is the area where the PDF file is loaded, as shown below:




The last step is to click the [**Save & Exit**] button. The display will return to the Project Manager, and you will see an indication that the selected PDF file has been attached as shown in the image below:




### 10.10.4 Scanned Document

[Need more? Ask Us a Question](#)

Structural Engineering Library now offers you the ability to use your scanner to create items and insert them into your Project File. To scan an item and add it to your Project File, click on the Division where you would like to insert the scanned item, click the **[Add]** button, and then click **[Scan a Document]**:



When the module is loaded you will see the screen below:



Here is a description of the various controls in this module:

**Scan Page:** Using all the settings on the "Scanner Setup" page, perform a high resolution scan.


**Delete & Rescan:** Delete the currently visible scan and rescan the image at a different resolution.

**Print this Scan:** Print the currently visible image to a printer.


**Save scanned image:** Save the current scan to a file.

**Scanner Setup:** Access the scanner setup screen (see image below)





### Options:



**Reset Scanner:** Send signals to the scanner to reset itself to its default state.

**Preview/Crop/Scan:** Perform a fast, low resolution "preview" scan and display it for your use in defining the final region that will be used for the high resolution scan.

**Delete Page:** Remove the current scan from this viewer.

**Image Manipulation buttons:** Allow you to change the way you view the scans in this document.



To create a scanned item, place the item on the scanner and click the [**Scan Page**] button. If desired, enter text in the Description field. Then, click the [**Save & Exit**] button. The display will return to the Project Manager, and you will see an indication that the scanned item has been attached as shown in the image below:

