

Non-Internet Installation Notes

ENERCALC, INC
Structural Engineering Library Version 6.0

We designed the **Structural Engineering Library** around the universal availability of an Internet Connection. If your computer does not have the ability to connect to the Internet then there will be some additional steps you need to take to install, activate, and maintain your software.

We regret that this will cause you some inconvenience. To best serve the largest percentage of our users our policy is to assume the user has an Internet Connection (and our surveys reveal that over 94% of you do).

To Install the Software

- (1) Download the single installation program file from a computer with Internet Access. We will provide you with the link.
- (2) When you are offered the selection to **[Run]** or **[Save]** you must choose **[Save]** and select a location to store the installation program file. We suggest that you use a “memory stick” as a removable drive so that you can easily move the file to the computer where you wish to install the **Structural Engineering Library**.

Alternately you can transfer the file and “burn” a CD.


Please note that our installation program is digitally signed so that you can be assured it does not contain any virus code.

- (3) Take your memory stick or CD to the installation computer and execute the installation program file ECSEL6_SETUP.EXE. Please see the [installation instructions](#) here :

www.enercalc.com/pdf/ENERCALC_V6_InstallationGuide.pdf

To Activate the Software after installation . . .



- 1) Locate your *Product Control Code* (PCC). The encrypted PCC contains information about your software license. This was supplied to you in your delivery email.
- 2) Start **Structural Engineering Library** by selecting it from the Start -> Programs -> ENERCALC SEL V6 -> Structural Library Version 6
- 3) When the “Licensing Information” screen is shown select “Click Here to start your product activation process”
- 4) On the next screen enter your PCC and press the **[Check & Save Control Code]** button.
If the code was entered incorrectly it will be erased and you can try again.
- 5) After the PCC code is entered your screen will change with “**Software is Ready for Activation**” shown in green near the top of the screen.



Non-Internet Installation Notes - Page 1

6) Press the [Manual Activation] button and you will be asked to confirm your choice.

7) The software will then display some instructions on how to proceed. See the screen capture below and do as instructed:



8) When you receive your "Unlocking Key" just paste it into the **Unlocking Key** entry location provided and press [Activate].

NOTE! If you wish to DEACTIVATE AND REMOVE your license from this computer you must go through a special "removal" process. See "**Manual License Deactivation**" at www.enercalc.com/users.html.

Software Updates

We regularly release updates to the software. Most users will get these automatically with the built-in "Web Update" capability. You will need to check for a newer version and download the installation manual (transferring the installation file to your computer as described earlier).

The latest version is shown on this web page: www.enercalc.com/users.html

If you cannot update over the Internet please go to www.enercalc.com/users.html and select "Latest SEL Updates". HOWEVER this link will be removed after August 2008.